# SIEMENS





# کتابچه راهنما درایو ۷۲۰ زیمنس

**OPERATING INSTRUCTIONS** 

# **SINAMICS**

# **SINAMICS V20**

Low voltage converters

www.siemens.com/drives

# **SIEMENS**

	Fundamental safety instructions	1
SINAMICS	Introduction	2
	Mechanical installation	3
SINAMICS V20 Converter	<b>Electrical installation</b>	4
Operating Instructions	Commissioning via the built-in BOP	5
operating instructions	Commissioning via the SINAMICS V20 Smart Access	6
	Communicating with the PLC	7
	Parameter list	8
	Faults and alarms	9
	Technical specifications	Α
	Options and spare parts	В
	General license conditions	С

Preface

\_

### Legal information

#### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

#### **A**DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.

#### WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

#### 

indicates that minor personal injury can result if proper precautions are not taken.

#### NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

#### **Qualified Personnel**

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

#### **Proper use of Siemens products**

Note the following:

#### **M**WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

#### Trademarks

All names identified by <sup>®</sup> are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

#### **Disclaimer of Liability**

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Preface

#### Purpose of this manual

This manual provides you with information about the proper installation, commissioning, operation, and maintenance of SINAMICS V20 converters.

#### SINAMICS V20 user documentation components

Document	Content	Available languages
Operating Instructions	(this manual)	English
		Chinese (Simplified)
		French
		German
		Italian
		Korean
		Portuguese
		Spanish
Compact Operating Instructions	Describes how you install, operate, and	English
	perform basic commissioning of the SINAMICS V20 converter	Chinese (Simplified)
		German
Product Information	Describes how you install and operate the following options or spare parts:	English
		Chinese (Simplified)
	Dynamic Braking Modules	
	External Basic Operator Panels (BOPs)	
	BOP Interface Modules	
	Migration mounting kit	
	Shield Connection Kits	
	I/O Extension Module	
	SINAMICS V20 Smart Access	
	Replacement Fans	
	Describes how you install and operate the following option:	English
	Protective Devices	

#### **Product maintenance**

The components are subject to continuous further development within the scope of product maintenance (improvements to robustness, discontinuations of components, etc.).

These further developments are "spare parts-compatible" and do not change the article number.

In the scope of such spare parts-compatible further developments, connector positions are sometimes changed slightly. This does not cause any problems with proper use of the components. Please take this fact into consideration in special installation situations (e.g. allow sufficient clearance for the cable length).

#### Use of third-party products

This document contains recommendations relating to third-party products. Siemens accepts the fundamental suitability of these third-party products.

You can use equivalent products from other manufacturers.

Siemens does not accept any warranty for the properties of third-party products.

#### **Technical support**

Country	Hotline
China	+86 400 810 4288
France	+33 0821 801 122
Germany	+49 (0) 911 958 1231
Italy	+39 (02) 24362000
Brazil	+55 11 3833 4040
India	+91 22 2760 0150
Korea	+82 2 3450 7114
Turkey	+90 (216) 4440747
United States of America	+1 423 262 5710
Poland	+48 22 870 8200
Further service contact information: (https://support.industry.siemens.co	

#### **Recycling and disposal**



For environmentally-friendly recycling and disposal of your old device, please contact a company certified for the disposal of waste electrical and electronic equipment, and dispose of the old device as prescribed in the respective country of use.

#### Compliance with the General Data Protection Regulation

Siemens respects the principles of data protection, in particular the data minimization rules (privacy by design).

For this product, this means:

The product does not process neither store any person-related data, only technical function data (e.g. time stamps). If the user links these data with other data (e.g. shift plans) or if he stores person-related data on the same data medium (e.g. hard disk), thus personalizing these data, he has to ensure compliance with the applicable data protection stipulations.

# Table of contents

	Preface		3
1	Fundament	al safety instructions	. 11
	1.1	General safety instructions	. 11
	1.2	Equipment damage due to electric fields or electrostatic discharge	. 17
	1.3	Warranty and liability for application examples	. 17
	1.4	Security information	. 17
	1.5	Residual risks of power drive systems	. 18
2	Introductio	n	. 21
	2.1	Converter variants	. 21
	2.2	Converter rating plate	. 24
3	Mechanical	installation	. 27
	3.1	Mounting orientation and clearance	. 27
	3.2	Mounting in a control cabinet	. 28
	3.3	Mounting a SINAMICS V20 Flat Plate variant	. 32
	3.4	Push-through mounting (frame sizes B E)	. 34
	3.5	DIN rail mounting (frame sizes AA, AB, AC, A, and B)	. 37
4	Electrical in	stallation	. 41
	4.1	Typical system connections	. 41
	4.2	Terminal description	. 45
	4.3	Using several single-phase converters in machines and plants	. 52
	4.4	EMC-compliant installation	. 52
	4.5	EMC-compliant cabinet design	. 55
	4.6	Forming DC link capacitors	. 56
5	Commissio	ning via the built-in BOP	. 57
	5.1 5.1.1 5.1.2 5.1.3 5.1.4 5.1.5 5.1.6	The built-in Basic Operator Panel (BOP) Introduction to the built-in BOP Converter menu structure Viewing converter status Editing parameters Screen displays LED states	. 57 . 59 . 61 . 62 . 64
	5.2	Checking before power-on	
	5.3	Setting the 50/60 Hz selection menu	. 67

5.4	Starting the motor for test run	68
5.5 5.5.1 5.5.1.1 5.5.1.2 5.5.1.3 5.5.1.4 5.5.1.5 5.5.2	Quick commissioning Quick commissioning through the setup menu Structure of the setup menu Setting motor data Setting connection macros Setting application macros Setting common parameters. Quick commissioning through the parameter menu	68 68 69 71 82 84
5.6	Function commissioning	90
5.6.1	Overview of converter functions	
5.6.2	Commissioning basic functions	
5.6.2.1	Selecting the stop mode	
5.6.2.2	Running the converter in JOG mode	
5.6.2.3	Setting the voltage boost	
5.6.2.4	Setting the PID controller	
5.6.2.5	Setting the braking function	
5.6.2.6	Setting the ramp time	
5.6.2.7	Setting the Imax controller	
5.6.2.8	Setting the Vdc controller	
5.6.2.9	Setting the load torque monitoring function	
5.6.3	Commissioning advanced functions	
5.6.3.1	Starting the motor in super torque mode	
5.6.3.2	Starting the motor in hammer start mode	
5.6.3.3	Starting the motor in blockage clearing mode	
5.6.3.4	Running the converter in economy mode	
5.6.3.5	Setting the UL61800-5-1-compliant motor overtemperature protection	
5.6.3.6	Motor protection with PTC sensor	
5.6.3.7	Setting the free function blocks (FFBs)	
5.6.3.8	Setting the flying start function	
5.6.3.9	Setting the automatic restart function	
5.6.3.10	Running the converter in frost protection mode	
5.6.3.11	Running the converter in condensation protection mode	
5.6.3.12	Running the converter in hibernation mode	
5.6.3.13	Setting the wobble generator	
5.6.3.14	Running the converter in motor staging mode	
5.6.3.15	Running the converter in cavitation protection mode	138
5.6.3.16	Setting the user default parameter set	
5.6.3.17	Setting the dual ramp function	
5.6.3.18	Setting the DC coupling function	
5.6.3.19	Setting high/low overload (HO/LO) mode	
5.7	Restoring to defaults	
	oning via the SINAMICS V20 Smart Access	
	-	
6.1	System requirements	
6.2	Accessing the SINAMICS V20 Web pages	148
6.2.1	Overview of the steps	
6.2.2	Fitting SINAMICS V20 Smart Access to the converter	149
6.2.3	Establishing the wireless network connection	150
6.2.4	Accessing the Web pages	152

6

	6.3	Overview of the Web pages	. 153
	6.4	Viewing connection status	. 154
	6.5	Viewing converter information	. 154
	6.6 6.6.1 6.6.2 6.6.3 6.6.4 6.6.5	Making optional Web access settings Configuring Wi-Fi Changing the display language Synchronizing the time Upgrading Viewing additional information	. 155 . 157 . 157 . 157 . 157
	6.7	Quick commissioning	. 158
	6.8	Setting parameters	. 163
	6.9	Starting motor test run (JOG/HAND)	. 168
	6.10	Monitoring	. 171
	6.11	Diagnosing	. 171
	6.12 6.12.1 6.12.2	Backing up and restoring Backing up Restoring	. 174
	6.13	Upgrading	. 178
	6.14	Viewing the support information	. 181
7	Commun	icating with the PLC	. 183
	7.1	USS communication	. 183
	7.2	MODBUS communication	. 188
8	Paramete	er list	. 201
	8.1	Introduction to parameters	. 201
	8.2	Parameter list	
9		d alarms	
	9.1	Faults	
	9.2	Alarms	
А		specifications	
В		ind spare parts	
	B.1	Options	
	B.1.1	Parameter Loader	. 367
	B.1.2	External BOP and BOP Interface Module	
	B.1.3	Dynamic braking module	
	B.1.4	Braking resistor	
	B.1.5	Line reactor	
	B.1.6	Output reactor	
	B.1.7	External line filter	
	B.1.8	Shield connection kits	
	B.1.9	Memory card	
	B.1.10	RS485 termination resistor	. 407

	Index		429
С	General l	icense conditions	423
	B.2	Spare parts - replacement fans	416
	B.1.16	User documentation	416
	B.1.15	I/O Extension Module	
	B.1.14	SINAMICS V20 Smart Access	412
	B.1.13	Migration mounting kit for FSAA FSAD	409
	B.1.12	DIN rail mounting kits (only for FSAA, AB, AC, A, and B)	409
	B.1.11	Residual current circuit breaker (RCCB)	407

# **Fundamental safety instructions**

# 1.1 General safety instructions



#### WARNING

#### Electric shock and danger to life due to other energy sources

Touching live components can result in death or severe injury.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Generally, the following steps apply when establishing safety:

- 1. Prepare for disconnection. Notify all those who will be affected by the procedure.
- 2. Isolate the drive system from the power supply and take measures to prevent it being switched back on again.
- 3. Wait until the discharge time specified on the warning labels has elapsed.
- 4. Check that there is no voltage between any of the power connections, and between any of the power connections and the protective conductor connection.
- 5. Check whether the existing auxiliary supply circuits are de-energized.
- 6. Ensure that the motors cannot move.
- 7. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water. Switch the energy sources to a safe state.
- 8. Check that the correct drive system is completely locked.

After you have completed the work, restore the operational readiness in the inverse sequence.



#### WARNING

# Risk of electric shock and fire from supply networks with an excessively high impedance

Excessively low short-circuit currents can lead to the protective devices not tripping or tripping too late, and thus causing electric shock or a fire.

- In the case of a conductor-conductor or conductor-ground short-circuit, ensure that the short-circuit current at the point where the converter is connected to the line supply at least meets the minimum requirements for the response of the protective device used.
- You must use an additional residual-current device (RCD) if a conductor-ground short circuit does not reach the short-circuit current required for the protective device to respond. The required short-circuit current can be too low, especially for TT supply systems.



#### WARNING

Risk of electric shock and fire from supply networks with an excessively low impedance

Excessively high short-circuit currents can lead to the protective devices not being able to interrupt these short-circuit currents and being destroyed, and thus causing electric shock or a fire.

• Ensure that the prospective short-circuit current at the line terminal of the converter does not exceed the breaking capacity (SCCR or Icc) of the protective device used.



# 

#### Electric shock if there is no ground connection

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

• Ground the device in compliance with the applicable regulations.



### WARNING

#### Electric shock due to connection to an unsuitable power supply

When equipment is connected to an unsuitable power supply, exposed components may carry a hazardous voltage. Contact with hazardous voltage can result in severe injury or death.

• Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV-(Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.



# 

#### Electric shock due to equipment damage

Improper handling may cause damage to equipment. For damaged devices, hazardous voltages can be present at the enclosure or at exposed components; if touched, this can result in death or severe injury.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- Do not use any damaged devices.



## WARNING

#### Electric shock due to unconnected cable shield

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

As a minimum, connect cable shields and the conductors of power cables that are not used (e.g. brake cores) at one end at the grounded housing potential.



## 

#### Arcing when a plug connection is opened during operation

Opening a plug connection when a system is operation can result in arcing that may cause serious injury or death.

• Only open plug connections when the equipment is in a voltage-free state, unless it has been explicitly stated that they can be opened in operation.



#### WARNING

#### Electric shock due to residual charges in power components

Because of the capacitors, a hazardous voltage is present for up to 5 minutes after the power supply has been switched off. Contact with live parts can result in death or serious injury.

• Wait for 5 minutes before you check that the unit really is in a no-voltage condition and start work.

#### NOTICE

#### Damage to equipment due to unsuitable tightening tools.

Unsuitable tightening tools or fastening methods can damage the screws of the equipment.

- Only use screw inserts that exactly match the screw head.
- Tighten the screws with the torque specified in the technical documentation.
- Use a torque wrench or a mechanical precision nut runner with a dynamic torque sensor and speed limitation system.
- Adjust the tools used regularly.

#### NOTICE

#### Property damage due to loose power connections

Insufficient tightening torques or vibration can result in loose power connections. This can result in damage due to fire, device defects or malfunctions.

- Tighten all power connections to the prescribed torque.
- Check all power connections at regular intervals, particularly after equipment has been transported.

### 

#### Spread of fire from built-in devices

Built-in devices can cause a fire and a pressure wave in the event of a fault. Fire and smoke can escape from the control cabinet and cause serious personal injury and property damage.

- Install built-in appliances in a robust metal control cabinet that is suitable for protecting people from fire and smoke.
- Only operate built-in devices with the control cabinet doors closed.
- Ensure that smoke can only escape via controlled and monitored paths.

# WARNING

#### Active implant malfunctions due to electromagnetic fields

Converters generate electromagnetic fields (EMF) in operation. Electromagnetic fields may interfere with active implants, e.g. pacemakers. People with active implants in the immediate vicinity of an converter are at risk.

- As the operator of an EMF-emitting installation, assess the individual risks of persons with active implants.
- Observe the data on EMF emission provided in the product documentation.

### 

#### Unexpected machine movement caused by radio devices or mobile phones

Using radio devices, cellphones, or mobile WLAN devices in the immediate vicinity of the components can result in equipment malfunction. Malfunctions may impair the functional safety of machines and can therefore put people in danger or lead to property damage.

- Therefore, if you move closer than 20 cm to the components, be sure to switch off radio devices, cellphones or WLAN devices.
- Use the "SIEMENS Industry Online Support app" only on equipment that has already been switched off.

#### NOTICE

#### Damage to motor insulation due to excessive voltages

When operated on systems with grounded line conductors or in the event of a ground fault in the IT system, the motor insulation can be damaged by the higher voltage against ground. If you use motors that have insulation that is not designed for operation with grounded line conductors, you must perform the following measures:

- IT system: Use a ground fault monitor and eliminate the fault as quickly as possible.
- TN or TT systems with grounded line conductor: Use an isolating transformer on the line side.

#### WARNING

#### Fire due to inadequate ventilation clearances

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

• Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

#### NOTICE

#### Overheating due to inadmissible mounting position

The device may overheat and therefore be damaged if mounted in an inadmissible position.Only operate the device in admissible mounting positions.

# 

#### Unrecognized dangers due to missing or illegible warning labels

Dangers might not be recognized if warning labels are missing or illegible. Unrecognized dangers may cause accidents resulting in serious injury or death.

- Check that the warning labels are complete based on the documentation.
- Attach any missing warning labels to the components, where necessary in the national language.
- Replace illegible warning labels.

#### NOTICE

#### Device damage caused by incorrect voltage/insulation tests

Incorrect voltage/insulation tests can damage the device.

• Before carrying out a voltage/insulation check of the system/machine, disconnect the devices as all converters and motors have been subject to a high voltage test by the manufacturer, and therefore it is not necessary to perform an additional test within the system/machine.

#### 

#### Unexpected movement of machines caused by inactive safety functions

Inactive or non-adapted safety functions can trigger unexpected machine movements that may result in serious injury or death.

- Observe the information in the appropriate product documentation before commissioning.
- Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.
- Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.
- Perform a function test.
- Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.

#### Note

#### Important Safety instructions for Safety Integrated

If you want to use Safety Integrated functions, you must observe the Safety instructions in the Safety Integrated documentation.

# 

#### Malfunctions of the machine as a result of incorrect or changed parameter settings

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization against unauthorized access.
- Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

# 1.2 Equipment damage due to electric fields or electrostatic discharge

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



#### NOTICE

#### Equipment damage due to electric fields or electrostatic discharge

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g conductive foam rubber of aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
  - Wearing an ESD wrist strap
  - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

# 1.3 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment or any eventuality which may arise. Application examples do not represent specific customer solutions, but are only intended to provide support for typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

## 1.4 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

1.5 Residual risks of power drive systems

For additional information on industrial security measures that may be implemented, please visit

https://www.siemens.com/industrialsecurity (https://www.siemens.com/industrialsecurity).

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

https://www.siemens.com/cert (https://www.siemens.com/cert).

Further information is provided on the Internet:

Industrial Security Configuration Manual

(https://support.industry.siemens.com/cs/ww/en/view/108862708)

## 

#### Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
- Make sure that you include all installed products into the holistic industrial security concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- On completion of commissioning, check all security-related settings.

## 1.5 Residual risks of power drive systems

When assessing the machine- or system-related risk in accordance with the respective local regulations (e.g., EC Machinery Directive), the machine manufacturer or system installer must take into account the following residual risks emanating from the control and drive components of a drive system:

1.5 Residual risks of power drive systems

- 1. Unintentional movements of driven machine or system components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware and/or software errors in the sensors, control system, actuators, and cables and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Parameterization, programming, cabling, and installation errors
  - Use of wireless devices/mobile phones in the immediate vicinity of electronic components
  - External influences/damage
  - X-ray, ionizing radiation and cosmic radiation
- 2. Unusually high temperatures, including open flames, as well as emissions of light, noise, particles, gases, etc., can occur inside and outside the components under fault conditions caused by, for example:
  - Component failure
  - Software errors
  - Operation and/or environmental conditions outside the specification
  - External influences/damage
- 3. Hazardous shock voltages caused by, for example:
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
- 4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
- 5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly
- 6. Influence of network-connected communication systems, e.g. ripple-control transmitters or data communication via the network

For more information about the residual risks of the drive system components, see the relevant sections in the technical user documentation.

1.5 Residual risks of power drive systems


# Introduction

# 2.1 Converter variants

The SINAMICS V20 is a range of converters designed for controlling the speed of three phase asynchronous motors.

#### Three phase AC 400 V variants

The three phase AC 400 V converters are available in the following frame sizes.



#### Introduction

#### 2.1 Converter variants

Component	Rated	Rated	Rated	Output current	Article number	
	output power	input current	output current	at 480 V at 4kHz/40°C	unfiltered	filtered
FSA	0.37 kW	1.7 A	1.3 A	1.3 A	6SL3210-5BE13-7UV0	6SL3210-5BE13-7CV0
(without fan)	0.55 kW	2.1 A	1.7 A	1.6 A	6SL3210-5BE15-5UV0	6SL3210-5BE15-5CV0
	0.75 kW	2.6 A	2.2 A	2.2 A	6SL3210-5BE17-5UV0	6SL3210-5BE17-5CV0
	0.75 kW <sup>1)</sup>	2.6 A	2.2 A	2.2 A	-	6SL3216-5BE17-5CV0
FSA	1.1 kW	4.0 A	3.1 A	3.1 A	6SL3210-5BE21-1UV0	6SL3210-5BE21-1CV0
(with single fan)	1.5 kW	5.0 A	4.1 A	4.1 A	6SL3210-5BE21-5UV0	6SL3210-5BE21-5CV0
	2.2 kW	6.4 A	5.6 A	4.8 A	6SL3210-5BE22-2UV0	6SL3210-5BE22-2CV0
FSB	3.0 kW	8.6 A	7.3 A	7.3 A	6SL3210-5BE23-0UV0	6SL3210-5BE23-0CV0
(with single fan)	4.0 kW	11.3 A	8.8 A	8.24 A	6SL3210-5BE24-0UV0	6SL3210-5BE24-0CV0
FSC (with single fan)	5.5 kW	15.2 A	12.5 A	11 A	6SL3210-5BE25-5UV0	6SL3210-5BE25-5CV0
FSD	7.5 kW	20.7 A	16.5 A	16.5 A	6SL3210-5BE27-5UV0	6SL3210-5BE27-5CV0
(with two fans)	11 kW	30.4 A	25 A	21 A	6SL3210-5BE31-1UV0	6SL3210-5BE31-1CV0
	15 kW	38.1 A	31 A	31 A	6SL3210-5BE31-5UV0	6SL3210-5BE31-5CV0
FSE (with two fans)	18.5 kW (HO) <sup>2)</sup>	45 A	38 A	34 A	6SL3210-5BE31-8UV0	6SL3210-5BE31-8CV0
	22 kW (LO)	54 A	45 A	40 A		
	22 kW (HO)	54 A	45 A	40 A	6SL3210-5BE32-2UV0	6SL3210-5BE32-2CV0
	30 kW (LO)	72 A	60 A	52 A		

<sup>1)</sup> This variant refers to the Flat Plate converter with a flat plate heatsink.

<sup>2)</sup> "HO" and "LO" indicate high overload and low overload respectively. You can set the HO/LO mode through relevant parameter settings.

#### Single phase AC 230 V variants

The single phase AC 230 V converters are available in the following frame sizes.

Frame size AA/AB (FSAA/FSAB)	Frame size AC (FSAC)	Frame size AD (FSAD)

Component	Rated output	Rated input	Rated output	Article number	
	power	current	current	unfiltered	filtered
FSAA	0.12 kW	2.3 A	0.9 A	6SL3210-5BB11-2UV1	6SL3210-5BB11-2BV1
(without fan)	0.25 kW	4.5 A	1.7 A	6SL3210-5BB12-5UV1	6SL3210-5BB12-5BV1
	0.37 kW	6.2 A	2.3 A	6SL3210-5BB13-7UV1	6SL3210-5BB13-7BV1
FSAB	0.55 kW	7.7 A	3.2 A	6SL3210-5BB15-5UV1	6SL3210-5BB15-5BV1
(without fan)	0.75 kW	10 A	4.2 A	6SL3210-5BB17-5UV1	6SL3210-5BB17-5BV1
FSAC	1.1 kW	14.7 A	6.0 A	6SL3210-5BB21-1UV1	6SL3210-5BB21-1BV1
(with single fan)	1.5 kW	19.7 A	7.8 A	6SL3210-5BB21-5UV1	6SL3210-5BB21-5BV1
FSAD	2.2 kW	27.2 A	11 A	6SL3210-5BB22-2UV1	6SL3210-5BB22-2BV1
(with single fan)	3.0 kW	32 A	13.6 A	6SL3210-5BB23-0UV1	6SL3210-5BB23-0BV1

#### **Options and spare parts**

For more information about the options and spare parts, refer to Appendixes "Options (Page 367)" and "Spare parts - replacement fans (Page 416)".

#### Third-party motors that can be operated

You can use the converter to operate standard asynchronous motors from other manufacturers.

#### NOTICE

#### Motor damage due to the use of an unsuitable third-party motor

A higher load occurs on the motor insulation in converter mode than with mains operation. Damage to the motor winding may occur as a result.


• Please observe the notes in the System Manual "Requirements for third-party motors"

Additional information is provided on the Internet: Requirements for third-party motors (https://support.industry.siemens.com/cs/ww/en/view/79690594)

2.2 Converter rating plate

# 2.2 Converter rating plate

The figure below shows an example of the converter rating plate:



Part number

(2)

④ Energy efficiency class, and relative power loss in %

#### Serial number explanation (example)

S	Z	V	H	7	<u>Y</u>	1	6	0	0	1	4	2	0
l Siemens	SN				٦	I Type ID			Se	quenc	l e numb	er	

#### Code \* Code \* Calendar year Month А 1990, 2010 1 Janauary в 2 February 1991, 2011 С 3 1992, 2012 March 4 D 1993, 2013 April Е 5 May 1994, 2014 F 6 June 1995, 2015 7 н July 1996, 2016 J 8 Auguest 1997, 2017 9 κ September 1998, 2018 0 1999, 2019 October L М 2000, 2020 Ν November Ν D December 2001, 2021 Р \* In accordance with DIN EN 60062 2002, 2022 R 2003, 2023 s 2004, 2024 т 2005, 2025 U 2006, 2026 V 2007, 2027 w 2008, 2028 Х 2009, 2029

Production data (year/month)

#### Introduction

2.2 Converter rating plate

# **Mechanical installation**

#### Protection against the spread of fire

The device may be operated only in closed housings or in control cabinets with protective covers that are closed, and when all of the protective devices are used. The installation of the device in a metal control cabinet or the protection with another equivalent measure must prevent the spread of fire and emissions outside the control cabinet.

#### Protection against condensation or electrically conductive contamination

Protect the device, e.g. by installing it in a control cabinet with degree of protection IP54 according to IEC 60529 or NEMA 12. Further measures may be necessary for particularly critical operating conditions.


If condensation or conductive pollution can be excluded at the installation site, a lower degree of control cabinet protection may be permitted.

## 3.1 Mounting orientation and clearance

The converter must be mounted in an enclosed electrical operating area or a control cabinet.


#### **Mounting orientation**

Always mount the converter vertically to a flat and non-combustible surface.



#### **Mounting clearance**

Тор	≥ 100 mm
Bottom	≥100 mm (for frame sizes AA AD, B E, and frame size A without fan)
	$\geq$ 85 mm (for fan-cooled frame size A)
Side	≥ 0 mm




# 3.2 Mounting in a control cabinet


You can mount the converter directly on the surface of the mounting panel in a suitable control cabinet.


Two additional mounting methods are also available for different frame sizes. For more information, refer to the following sections:

- Push-through mounting (frame sizes B ... E) (Page 34)
- DIN rail mounting (frame sizes AA, AB, AC, A, and B) (Page 37)



#### Outline dimensions and drill patterns





3.3 Mounting a SINAMICS V20 Flat Plate variant

# 3.3 Mounting a SINAMICS V20 Flat Plate variant

The SINAMICS V20 Flat Plate variant is designed to allow greater flexibility in the installation of the converter. Adequate measures must be taken to ensure the correct heat dissipation, which may require an additional external heatsink outside the electrical enclosure.



# 

#### Additional heat load

Operation with an input voltage greater than 400 V and 50 Hz or with a pulse frequency greater than 4 kHz will cause an additional heat load on the converter. These factors must be taken into account when designing the installation conditions and must be verified by a practical load test.

# 

#### **Cooling considerations**

The minimum vertical clearance of 100 mm above and below the converter must be observed. Stacked mounting is not allowed for the SINAMICS V20 converters.

#### **Technical data**

Flat Plate variant	Average power output		
6SL3216-5BE17-5CV0	370 W	550 W	750 W
Operating temperature range	-10 °C to 40 °C		
Max. heatsink loss	24 W	27 W	31 W
Max. control loss *	9.25 W	9.25 W	9.25 W
Recommended thermal resistance of heatsink	1.8 K/W	1.5 K/W	1.2 K/W
Recommended output current	1.3 A	1.7 A	2.2 A

\* With I/O fully loaded

#### Installing

- 1. Prepare the mounting surface for the converter using the dimensions given in Section "Mounting in a control cabinet (Page 28)".
- 2. Ensure that any rough edges are removed from the drilled holes, the flat plate heatsink is clean and free from dust and grease, and the mounting surface and if applicable the external heatsink are smooth and made of unpainted metal (steel or aluminum).
- 3. Apply a non-silicone heat transfer compound with a minimum thermal transfer co-efficient of 0.9 W/m.K evenly to the rear surface of the flat plate heatsink and the surface of the rear plate.
- 4. Mount the converter securely using four M4 screws with a tightening torque of 1.8 Nm (tolerance: ± 10%).
- 5. If it is required to use an external heatsink, first apply the paste specified in Step 3 evenly to the surface of the external heatsink and the surface of the rear plate, and then connect the external heatsink on the other side of the rear plate.
- 6. When the installation is completed, run the converter in the intended application while monitoring r0037[0] (measured heatsink temperature) to verify the cooling effectiveness.

The heatsink temperature must not exceed 90 °C during normal operation, after the allowance has been made for the expected surrounding temperature range for the application.

#### Example:

If the measurements are made in 20 °C surrounding, and the machine is specified up to 40 °C, then the heatsink temperature reading must be increased by [40-20] = 20 °C, and the result must remain below 90 °C.

If the heatsink temperature exceeds the above limit, then further cooling must be provided (for example, with an extra heatsink) until the conditions are met.

#### Note

The converter will trip with fault condition F4 if the heatsink temperature rises above 100 °C. This protects the converter from potential damage due to high temperatures.


3.4 Push-through mounting (frame sizes B ... E)

# 3.4 Push-through mounting (frame sizes B ... E)

The frame sizes B to E are designed to be compatible with "push-through" applications, allowing you to mount the heatsink of the converter through the back of the cabinet panel. When the converter is mounted as the push-through variant, no higher IP rating is achieved. Make sure that the required IP rating for the enclosure is maintained.


Two additional mounting methods are also available for different frame sizes. For more information, refer to the following sections:

- Mounting in a control cabinet (Page 28)
- DIN rail mounting (frame sizes AA, AB, AC, A, and B) (Page 37)



#### Outline dimensions, drill patterns, and cut-outs


3.4 Push-through mounting (frame sizes B ... E)



<sup>1)</sup> Depth inside the cabinet


3.4 Push-through mounting (frame sizes B ... E)

# Mounting



#### Note

A gap is reserved at the bottom of the cut-out area to allow fan removal from outside the cabinet without removing the converter.



# 3.5 DIN rail mounting (frame sizes AA, AB, AC, A, and B)

By means of the optional DIN rail mounting kit, you can mount the frame size AA, AB, AC, A, or B to the DIN rail.

Two additional mounting methods are also available for different frame sizes. For more information, refer to the following sections:

- Mounting in a control cabinet (Page 28)
- Push-through mounting (frame sizes B ... E) (Page 34)

#### Note


To install or remove the converter, use a cross-tip or flat-bit screwdriver.

The protective conductor for the DIN rail mounting kit provides a sufficient earth connection. To increase the robustness, the protective conductor connection can be designed with a larger cross-section (e.g. 2.5 mm<sup>2</sup> for input earth connection and 4.0 mm<sup>2</sup> for output earth connection).


### Installing and removing FSAA/FSAB/FSAC to and from the DIN rail

For more information, see Section "Migration mounting kit for FSAA ... FSAD (Page 409)".


# Installing FSA/FSAC to the DIN rail




# Removing FSA/FSAC from the DIN rail



# Installing FSB to the DIN rail



# Removing FSB from the DIN rail




I/O Extension Module (option,

# **Electrical installation**

#### 4.1 Typical system connections

# Typical system connections



<sup>1)</sup> For more information on the permissible types for these branch circuit protection devices, see the Product Information of Protective Devices for SINAMICS V20 Converter (https://support.industry.siemens.com/cs/ww/en/view/109799776).

#### 4.1 Typical system connections

#### Note

#### Requirements for United States/Canadian installations (UL/cUL)

For configurations in conformance with UL/cUL, use the UL/cUL approved fuses, circuit breakers and Type E combination motor controllers (CMC). Refer to the Product Information of Protective Devices for SINAMICS V20 Converter

(<u>https://support.industry.siemens.com/cs/ww/en/view/109799776</u>) for specific types of branch circuit protection for each converter and corresponding Short-Circuit Current Rating (SCCR). For each frame size, use 75 °C copper wire only.

This equipment is capable of providing internal motor overload protection according to UL61800-5-1. In order to comply with UL61800-5-1, parameter P0610 must not be changed from its factory setting of 6.

For Canadian (cUL) installations the converter mains supply must be fitted with any external recommended suppressor with the following features:

- Surge-protective devices; device shall be a Listed Surge-protective device (Category code VZCA and VZCA7)
- Rated nominal voltage 480/277 VAC (for 400 V variants) or 240 VAC (for 230 V variants), 50/60 Hz, three phase (for 400 V variants) or single phase (for 230V variants)
- Clamping voltage VPR = 2000 V (for 400 V variants)/1000 V (for 230 V variants), IN = 3 kA min, MCOV = 508 VAC (for 400 V variants)/264 VAC (for 230V variants), short circuit current rating (SCCR) = 40 kA
- Suitable for Type 1 or Type 2 SPD application
- Clamping shall be provided between phases and also between phase and ground



### WARNING

Danger to life caused by high leakage currents for an interrupted protective conductor

The converter components conduct a high leakage current via the protective conductor. The earth leakage current of the SINAMICS V20 converter may exceed 3.5 mA AC.

Touching conductive parts when the protective conductor is interrupted can result in death or serious injury.

A fixed earth connection or a multicore supply cable with connectors for industrial applications according to IEC 60309 is required and the minimum size of the protective earth conductor shall comply with the local safety regulations for high leakage current equipment.

# 


Danger to life due to fire spreading because of an unsuitable or improperly installed braking resistor

Using an unsuitable or improperly installed braking resistor can cause fires and smoke to develop. Fire and smoke development can cause severe personal injury or material damage.

- Only use braking resistors that are approved for the converter.
- Install the braking resistor in accordance with regulations.
- Monitor the temperature of the braking resistor.

4.1 Typical system connections

# Wiring diagram




#### Note

The resistance of the potentiometer for each analog input must be  $\ge 4.7 \text{ k}\Omega$ .

#### 4.1 Typical system connections

The optional I/O Extension Module can expand the number of V20 I/O terminals. See the following for the wiring diagram of the I/O Extension Module:





# 

#### Electric shock and danger to life due to connection to an unsuitable power system

If DO3 and DO4 are used in a power supply system that exceeds overvoltage category II (OVC II), contact with live parts of the V20 converter and its options including expansion ports, SELV (Safety Extra Low Voltage) terminals, and connected wires can result in death or severe injury.

• Use DO3 and DO4 only in the power system whose voltage does not exceed OVC II.


#### Note

- To use the DIs on both the V20 and the I/O Extension Module as a single group of DIs, connect the V20 DI C to the DI C on the I/O Extension Module (see the previous figure).
- To use the DIs on both the V20 and the I/O Extension Module as two separate groups of DIs, do not connect the V20 DI C to the DI C on the I/O Extension Module.

For more information about the wiring diagram, see Section "Setting connection macros (Page 71)".

# 4.2 Terminal description

**Terminal layout** 




#### Note


To disconnect the integrated EMC filter on FSE from the ground, you can use a Pozidriv or flat-bit screwdriver to remove the EMC screw next to the mains terminals L1 to L3.

#### 4.2 Terminal description

#### User terminals for FSAA to FSAD:



#### User terminals for FSA to FSE:




#### NOTICE

#### Converter damage due to overvoltage

Using signal cables of more than 30 m at the digital inputs and 24 V power supply can lead to overvoltage during switching operations. This can result in damage to the converter.

• Make sure that you use signal cables of equal to or smaller than 30 m at the digital inputs and 24 V power supply.

#### User terminals for I/O Extension Module (option):




# Recommended cable cross-sections, crimp types and screw tightening torques

#### Fork crimp

Ring crimp

Material	
Crimp body: copper	
Insulation: nylon	
Plating: tin	





Frame	Rated	Crimp	Mains and PE terminals				Motor/DC/braking resistor/output earth terminals					
size	output power (kW)	type	Cable cross- section <sup>1)</sup>	d (mm)	W (mm)	L (mm)	Screw tightening torque (Nm/lbf.in) 2)	Cable cross- section <sup>1)</sup>	d (mm)	W (mm)	L (mm)	Screw tightening torque (Nm/lbf.in) <sup>2)</sup>
400 V						-						
A	0.37 0.75	U	1.0 mm <sup>2</sup> (14) 1.5 mm <sup>2</sup> (14)	≥ 3.7	< 8	> 22	1.0/8.9	1.0 mm <sup>2</sup> (14) 1.5 mm <sup>2</sup> (14)	≥ 3.7	< 8	> 22	1.0/8.9
В	3.0 4.0		4 mm <sup>2</sup> (10)	≥ 3.7	< 8	> 25		2.5 mm <sup>2</sup> (12)	≥4.2	< 8	> 22	1.5/13.3
С	5.5		4 mm <sup>2</sup> (10)	≥ 5.2	< 12	> 25	2.4/21.2	4 mm <sup>2</sup> (10)	≥ 5.2	< 12	> 25	2.4/21.2
D	7.5 11 15		6 mm <sup>2</sup> (10) 10 mm <sup>2</sup> (6)	≥ 5.2	< 12	> 28		6 mm <sup>2</sup> (10) 10 mm <sup>2</sup> (6)	≥ 5.2	< 12	> 28	
E	18.5 22 30	0	10 mm <sup>2</sup> (6) 16 mm <sup>2</sup> (4) 25 mm <sup>2</sup> (3)	≥ 5.2	< 13	> 30		6 mm <sup>2</sup> (8) 10 mm <sup>2</sup> (6) 16 mm <sup>2</sup> (4)	≥ 5.2	< 13	> 30	
230 V		1			1				1			
AA/AB	0.12 0.25 0.37 0.55	U	1.0 mm <sup>2</sup> (14) 1.5 mm <sup>2</sup> (14)	≥ 4.2	< 7	> 22	1.0/8.9	1.0 mm <sup>2</sup> (14)	≥ 3.2	< 7	> 22	1.0/8.9
	0.75	]	2.0 mm <sup>2</sup> (14)									
AC	1.1 1.5		4.0 mm <sup>2</sup> (12)					2.5 mm <sup>2</sup> (12)				
AD	2.2 3.0		6 mm² (8)		< 10	> 25	1.6/14.2	4.0 mm <sup>2</sup> (12)	≥ 3.7	< 7.5	> 25	1.0/8.9

<sup>1)</sup> Data in brackets indicates the corresponding AWG values.

<sup>2)</sup> Tolerance:  $\pm$  10%

#### NOTICE

#### Damage to the mains terminals

During electrical installation of the converter frame sizes AA to D, only cables with UL/cULcertified fork crimps can be used for the mains terminal connections; for frame size E, only cables with UL/cUL-certified ring crimps can be used for the mains terminal connections. 4.2 Terminal description

Converter	Maximum cable length										
variant	EMC compliant		Without outpu	it reactor	With output r	eactor					
400 V	With integrated EMC filter <sup>1)</sup>	With external line filter <sup>2)</sup>	Unshielded	Shielded	Unshielded	Shielded					
FSA	10 m	25 m	50 m	25 m	150 m	150 m					
FSB to FSD	25 m	25 m	50 m	25 m	150 m	150 m					
FSE	50 m	25 m	100 m	50 m	300 m	200 m					
230 V	With integrated EMC filter	With external line filter	Unshielded	Shielded	Unshielded	Shielded					
FSAA/FSAB	5 m <sup>3)</sup>	5 m <sup>3)</sup>	50 m	25 m	200 m	200 m					
FSAC	10 m <sup>3)</sup>	10 m <sup>2)</sup>	50 m	25 m	200 m	200 m					
FSAD	5 m <sup>3)</sup> , 25 m <sup>2)</sup>	5 m <sup>3)</sup>	50 m	25 m	200 m	200 m					

### Maximum motor cable lengths

<sup>1)</sup> EMC (RE/CE C3) compliant, second environment (industrial area). RE/CE C3 refers to EMC compliance to EN61800-3 Category C3 (level equivalent to EN55011, Class A2) for Radiated and Conducted Emissions.


<sup>2)</sup> EMC (RE/CE C2) compliant, first environment (residential area). RE/CE C2 refers to EMC compliance to EN61800-3 Category C2 (level equivalent to EN55011, Class A1) for Radiated and Conducted Emissions. See Section B.1.7 for the specifications of external line filters.

<sup>3)</sup> EMC (RE/CE C1) compliant, first environment (residential area). RE/CE C1 refers to EMC compliance to EN61800-3 Category C1 (level equivalent to EN55011, Class B) for Radiated and Conducted Emissions.

### Star-delta connection of the motor

Select delta connection under one of the following conditions:

- a 230 V/400 V motor (operating at 87 Hz instead of 50 Hz) on a 400 V converter
- a 120 V/230 V motor (operating at 87 Hz instead of 50 Hz) on a 230 V converter



# **User terminals**

10 V	AI 1	AI 2	AO 1	0 V	P +	N -	DI 1	DI 2	DI 3	DI 4	DIC	24 V	0 V	DO 1+	DO 1-			DO 2
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	NC 17	NO 18	19

The illustration below takes the user terminal layout for FSA to FSE for example.

	No.	Terminal marking	Description			
	1	10V	10 V output (tolerance $\pm$ 2% for the temperature range of 20 °C to 30 °C) referred to 0 V, maximum 11 mA, short circuit protected			
Analog inputs	2 3	AI1 AI2	Mode:	Al1: Single-ended, bipolar current and voltage mode Al2: Single-ended, unipolar current and voltage mode		
			Isolation to control circuit:	None		
			Voltage range:	Al1: -10 V to 10 V; Al2: 0 V to 10 V		
			Current range:	0 mA to 20 mA (4 mA to 20 mA - software selectable)		
			Voltage mode accuracy:	$\pm$ 1% full scale for the temperature range of 20 °C to 30 °C		
			Current mode accuracy:	$\pm$ 1% full scale for the temperature range of 20 °C to 30 °C		
			Input impedance:	Voltage mode: > 30 K		
				Current mode: 235 R		
			Resolution:	12-bit		
			Wire break detect:	Yes		
			Threshold $0 \Rightarrow 1$ (used as DI):	4.0 V		
			Threshold $1 \Rightarrow 0$ (used as DI):	1.6 V		
			Response time (digital input mode):	4 ms ± 4 ms		
Analog	4	AO1	Mode:	Single-ended, unipolar current mode		
output			Isolation to control circuit:	None		
			Current range:	0 mA to 20 mA (4 mA to 20 mA - software selectable)		
			Accuracy (0 mA to 20 mA):	$\pm$ 0.5 mA for the temperature range of -10 °C to 60 °C		
			Output capability:	20 mA into 500 R		
	5	0V	Reference potential for terminals 1, 2	2, 3, 4, 6, 7, and 13		
	6	P+	RS485 P +			
	7	N-	RS485 N -			

### Electrical installation

4.2 Terminal description

	No.	Terminal marking	Description				
Digital inputs *	8 9 10 11	DI1 DI2 DI3 DI4	Mode: Isolation to control circuit: Absolute maximum voltage: Operating voltage: Threshold $0 \Rightarrow 1$ (maximum):	PNP (reference terminal low)NPN (reference terminal high)Characteristics values are inverted for NPN mode.Electrically isolated± 35 V for 500 ms every 50 seconds- 3 V to 30 V11 V			
			Threshold 1 ⇒ 0 (minimum): Input current (guaranteed off): Input current (maximum on): 2-wire Bero compatibility: Response time: Pulse train input:	5 V 0.6 mA to 2 mA 15 mA No 4 ms ± 4 ms No			
	12 13	DI C 24V	Reference potential for digital inp 24 V output (tolerance: - 15 % to - isolated	uts + 20 %) referred to 0 V, maximum 50 mA, non-			
Digital outputs (transistor)	14 15 16	0V DO1 + DO1 -	Reference potential for terminalsMode:Isolation to control circuit:Maximum voltage across terminals:Maximum load current:Response time:	1, 2, 3, 4, 6, 7, and 13 Normally open voltage-free terminals, polarised 500 VDC (functional low voltage) ± 35 V 100 mA 4 ms ± 4 ms			
Digital outputs (relay) *	17 18 19	DO2 NC DO2 NO DO2 C	Mode:         Isolation to control circuit:         Maximum voltage across terminals:         Maximum load current:         Response time:	<ul> <li>Change-over voltage-free terminals, unpolarised</li> <li>4 kV (230 V mains)</li> <li>240 VAC/30 VDC + 10 %</li> <li>0.5 A @ 250 VAC, resistive</li> <li>0.5 A @ 30 VDC, resistive</li> <li>Open: 7 ms ± 7 ms</li> <li>Close: 10 ms ± 9 ms</li> </ul>			

\* The optional I/O Extension Module provides additional DIs and DOs which share the same technical specifications as those on the SINAMICS V20 converter.




WARNING

Risk of electric shock

The input and output terminals, numbered 1 to 16, are safety extra low voltage (SELV) terminals and must only be connected to low voltage supplies.

#### Recommended crimp terminal type and cable cross-sections



Insulated pin terminal

Cable type	Recommended cable cross-section *
Solid or stranded cable	0.5 mm <sup>2</sup> to 1 mm <sup>2</sup> (20 to 18)
Ferrule with insulating sleeve	0.25 mm <sup>2</sup> (24)

\* Data in brackets indicates the corresponding AWG values.

#### **Expansion port**

The expansion port is designed for connecting the converter to the external option module -BOP Interface Module, Parameter Loader, SINAMICS V20 Smart Access, or I/O Extension Module, in order to realize the following functions:

- Operating the converter from the external BOP that is connected to the BOP Interface Module
- Cloning parameters between the converter and a standard SD card through the Parameter Loader
- Powering the converter from the Parameter Loader, when mains power is not available
- Accessing the converter from a connected device (conventional PC with wireless network adapter installed, tablet, or smart phone) with the aid of SINAMICS V20 Smart Access
- Providing additional DIs and DOs to realize more converter control functions through the I/O Extension Module

For more information about these option modules, see Sections "Parameter Loader (Page 367)", "External BOP and BOP Interface Module (Page 372)", "Commissioning via the SINAMICS V20 Smart Access (Page 147)", and "I/O Extension Module (Page 415)".

4.3 Using several single-phase converters in machines and plants

# 4.3 Using several single-phase converters in machines and plants

#### Overview

Evaluate the input currents of single-phase converters in your machine or plant in terms of harmonics and unbalance.

### Description

In unfavorable cases, the harmonic currents of several converters in the neutral conductor (N) add up to a value greater than the currents of the line conductors (L1, L2, L3). The current-carrying capacity of the neutral conductor must be sufficient for this. IEC 60364-5-52:2019, section 524, makes recommendations for sizing the neutral conductor. If no more precise information is available, the standard recommends dimensioning the neutral conductor for 1.45 times the current-carrying capacity of the line conductors.

# 

Fire caused by neutral conductor (N) overload

The neutral conductor can heat up due to the load from harmonic currents and cause a fire.

Consider the harmonic currents when dimensioning the neutral conductor.



# WARNING

#### Electric shock caused by PEN conductor overload

In TN-C supply networks, the protective function of the PEN conductor can be adversely affected by exposure to harmonic currents.


• Consider the harmonic currents when dimensioning the PEN conductor.

# 4.4 EMC-compliant installation

### EMC-compliant installation of the converter

The shield connection kit is supplied as an option for each frame size. For more information about this option, see Appendix "Shield connection kits (Page 402)". It allows easy and efficient connection of the necessary shield to achieve EMC-compliant installation of the converter. If no shield connection kit is used, you can alternatively mount the device and additional components on a metal mounting plate with excellent electrical conductivity and a large contact area. This mounting plate must be connected to the cabinet panel and the PE or EMC bus bar.

4.4 EMC-compliant installation



The following diagram shows an example of EMC-compliant installation of the converter frame size B/C.

### NOTICE

#### Converter damage due to improper mains disconnection

Improper mains disconnection can cause converter damage.

Do not perform mains disconnection on the motor-side of the system if the converter is in operation and the output current is not zero.

#### Note

#### **Cable connection**

Separate the control cables from the power cables as much as possible.

Keep the connecting cables away from rotating mechanical parts.

#### EMC-compliant installation of external line filter options

All 400 V converters must be mounted in a cabinet with a special EMC gasket around the door.

All the following ferrite cores are recommended in accordance with EN 55011.

For 400 V unfiltered frame size D converters fitted with the filters specified in Section B.1.7:

To meet the radiated and conducted emissions Class A, attach 2 x ferrite cores of Type "Wurth 742-715-5" or equivalent in the vicinity of the converter mains terminals; attach 1x ferrite core of Type "Wurth 742-712-21" or equivalent in the vicinity of the external line filter mains terminals.


#### 4.4 EMC-compliant installation

For 400 V unfiltered frame size E converters fitted with the filters specified in Section B.1.7:

To meet the radiated and conducted emissions Class A, attach 1 x ferrite core of Type "Seiwa E04SRM563218" or equivalent in the vicinity of the converter mains terminals; attach 2 x ferrite cores of Type "Seiwa E04SRM563218" or equivalent in the vicinity of the motor terminals of the converter.

For 230 V filtered frame size AA/AB converters:

To meet the radiated and conducted emissions Class B, attach 1 x ferrite core of Type "K3 NF-110-A(N)GY0", or equivalent in the vicinity of the motor output terminals (U, V, and W, excluding the PE terminal) of the converter; attach 1x ferrite core of Type "K3 NF-110-A(N)GY0" or equivalent on the motor cable outside the threaded hole of the cabinet; attach 2 x ferrite cores of Type "K3 NF-110-A(N)GY0" or equivalent on the motor cable in the vicinity of the motor.




For 230 V filtered and unfiltered frame size AC converters with the maximum motor cable length of 10 m:

To meet the radiated and conducted emissions Class B, attach 1 x ferrite core of Type "BRH A2 RC 16\*28\*9 MB", or equivalent in the vicinity of the motor output terminals (U, V, and W, excluding the PE terminal) of the converter.

### **Shielding method**

The following illustration shows an example with and without the shielding plate.




# 4.5 EMC-compliant cabinet design

The most cost-effective method of implementing interference suppression measures within the control cabinet is to ensure that interference sources and potentially susceptible equipment are installed separately from each other.

The control cabinet has to be divided into EMC zones and the devices within the control cabinet have to be assigned to these zones following the rules below.

- The different zones must be electromagnetically decoupled by using separate metallic housings or grounded separation plates.
- If necessary, filters and/or coupling modules should be used at the interfaces of the zones.
- Cables connecting different zones must be separated and must not be routed within the same cable harness or cable channel.



• All communication (e.g. RS485) and signal cables leaving the cabinet must be shielded.

# 4.6 Forming DC link capacitors

#### Overview

You have to reform the DC link capacitors if the converter has been stored for more than one year. Non-formed DC link capacitors can damage the converter in operation.

#### Precondition


The converter has not yet been used, and according to the production date it was made over a year ago.

You can check the serial number of the converter for its production date. The production date of the converter is coded in the 3rd and 4th digits of the serial number on the rating plate and the product packaging label.

Converter rating plate (Page 24)

### **Function description**

You form the DC link capacitors by supplying the converter with a line voltage of  $\leq$  100% of the rated voltage for a defined time.



# Commissioning via the built-in BOP

#### Note

For a detailed description of parameter settings for the quick commissioning, refer to the topic "Quick commissioning (Page 68)".




# 

### Hot surface

During operation and for a short time after the power supply of the converter is switched off, the marked surfaces of the converter can reach a high temperature. Avoid coming into direct contact with these surfaces.

# 5.1 The built-in Basic Operator Panel (BOP)

# 5.1.1 Introduction to the built-in BOP



# **Button functions**

	Stops the converter	
0	Single press	OFF1 stop reaction: the converter brings the motor to a standstill in the ramp-down time set in parameter P1121. Exception:
		The button is inactive if the converter is configured for control from terminals or USS/MODBUS on RS485 (P0700=2 or P0700=5) in AUTO mode.
	Double press (< 2 s) or long press ( > 3 s)	OFF2 stop reaction: the converter allows the motor to coast to a standstill without using any ramp-down times.
	Starts the converter If the converter is started in H	AND/JOG/AUTO mode, the converter running icon ( 📀 ) appears.
	Exception: This button is inactive when t (P0700=2 or P0700=5) in AUT	he converter is configured for control from terminals or USS/MODBUS on RS485 IO mode.
	Multi-function button	
М	Short press ( < 2 s)	Enters the parameter setting menu or moves to the next screen in the setup menu
		Restarts the digit by digit editing on the selected item
		Returns to the fault code display
		• If pressed twice in digit by digit editing, returns to the previous screen without changing the item being edited
	Long press ( > 2 s)	Returns to the status screen
		Enters the setup menu
	Short press ( < 2 s)	Switches between status values
ОК		Enters edit value mode or change to the next digit
		Clears faults
		Returns to the fault code display
	Long press ( > 2 s)	Quick parameter number or value edit
		Accesses fault information data
м	Hand/Jog/Auto	
+	Press to switch between diffe	rent modes:
ОК		м + ок
	Auto mode	OK Hand mode Jog mode
	(No icon)	(With hand icon) (With flashing hand icon)
	Note:	
	Jog mode is only available if t	he motor is stopped.

<ul><li>When navigating through a menu, it moves the selection up through the screens available.</li><li>When editing a parameter value, it increases the displayed value.</li></ul>
• When the converter is in RUN mode, it increases the speed.
• Long press (> 2 s) of the key quickly scrolls up through parameter numbers, indices, or values.
<ul> <li>When navigating through a menu, it moves the selection down through the screens available.</li> <li>When editing a parameter value, it decreases the displayed value.</li> <li>When the converter is in RUN mode, it decreases the speed.</li> <li>Long press (&gt; 2 s) of the key quickly scrolls down through parameter numbers, indices, or values.</li> </ul>
Reverses the direction of rotation of the motor. Pressing the two keys once activates reverse motor rotation. Pressing the two keys once again deactivates reverse rotation of the motor. The reserve icon ( <>> ) on the display indicates that the output speed is opposite to the setpoint. <b>Note</b> : In AUTO mode, if P1113 is not connected to the default BICO parameter r0019.11, the UP + DOWN button combination becomes invalid.

#### Note


Unless otherwise specified, operations of the above keys always indicate short press (< 2 s).

### **Converter status icons**

8	Converter has at least o	Converter has at least one pending fault.				
▲	Converter has at least o	Converter has at least one pending alarm.				
•	Converter is running (motor speed may be 0 rpm).					
•	(flashing):	Converter may be energized unexpectedly (for example, in frost protection mode).				
$\sim$	Motor rotates in the rev	Motor rotates in the reversed direction.				
2	A:	Converter is in HAND mode.				
حر′	좌 (flashing):	Converter is in JOG mode.				


# 5.1.2 Converter menu structure

Menu	Description		
50/60 Hz selection menu	This menu is visible only on first power-up or after a factor reset.		
Main menu			
Display menu (default display)	Basic monitoring view of key parameters such as frequency, voltage, current, DC-link voltage, and so on.		
Setup menu	Access to parameters for quick commissioning of the converter.		
Parameter menu	Access to all available converter parameters.		



# 5.1.3 Viewing converter status

The display menu provides a basic monitoring view of some key parameters such as frequency, voltage, current, and so on.



#### Note

- If you have set P0005 to a non-zero value which represents the parameter number selected in P0005, then the converter displays the value of the selected parameter in the display menu by default. For more information about normal editing of parameters, see Section "Editing parameters (Page 62)".
- For more information about the display menu structure with active faults, see Section "Faults (Page 341)".

# 5.1.4 Editing parameters

This section describes how to edit the parameters.

#### Parameter types

Parameter type		Description			
CDS-dependent par	ameters	<ul> <li>Dependent on Command Data Set (CDS)</li> <li>Always indexed with [02] *</li> <li>Available for CDS switching via P0810 and P0811</li> </ul>			
DDS-dependent par	ameters	<ul> <li>Dependent on Drive Data Set (DDS)</li> <li>Always indexed with [02]</li> <li>Available for DDS switching via P0820 and P0821</li> </ul>			
Other parameters	Multi-indexed parameters	These parameters are indexed with the range of indices dependent on the individual parameter.			
	Index-free parameters	These parameters are not indexed.			

\* Each CDS-dependent parameter has only one default value, despite of their three indices. Exception: By default, P1076[0] and P1076[2] are set to 1 while P1076[1] is set to 0.

### Normal editing of parameters

#### Note


Pressing A or for longer than two seconds to quickly increase or decrease the parameter numbers or indexes is only possible in the parameter menu.

This editing method is best suited when small changes are required to parameter numbers, indexes, or values.

- To increase or decrease the parameter number, index, or value, press or value, press for less than two seconds.
- To quickly increase or decrease the parameter number, index, or value, press or value, press for longer than two seconds.
- To confirm the setting, press **•**.
- To cancel the setting, press .

Example:

**Editing parameter values** 




### **Digit-by-digit editing**

#### Note

Digit-by-digit editing of parameter numbers or indexes is only possible in the parameter menu.

Digit-by-digit editing can be performed on parameter numbers, parameter indexes, or parameter values. This editing method is best suited when large changes are required to parameter numbers, indexes, or values. For information about the converter menu structure, refer to Section "Converter menu structure (Page 59)".

- In any edit or scroll mode, digit-by-digit editing is entered by a long press (> 2 s) on 🚾.
- The digit-by-digit editing always starts with the rightmost digit.
- Each digit is selected in turn by pressing
- Pressing 📕 once moves the cursor to the rightmost digit of the current item.
- Pressing M twice in succession exits the digit-by-digit mode without changing the item being edited.
- Pressing 🚾 on a digit when there are no further digits to the left saves the value.
- If more digits are required to the left, then these must be added by scrolling the existing leftmost digit above 9 to add more digits to the left.
- Pressing 🔺 or 🔽 for over two seconds enters fast digit scrolling.



# 5.1.5 Screen displays

The following two tables show you basic screen displays:

Screen information	Display	Meaning
"8 8 8 8 8"	88888	Converter is busy with internal data processing.
""		Action not completed or not possible
"Pxxxx"	P 0 3 0 4	Writable parameter
"rxxx"	r 0 0 2 6	Read-only parameter
"inxxx"	in 0.0 1	Indexed parameter

Screen information	Display	Meaning
Hexadecimal number	ЕРЭТ	Parameter value in hex format
"bxx x"	b 0 5 0 bit number signal state: 0: Low 1: High	Parameter value in bit format
"Fxxx"	F 3 9 5	Fault code
"Axxx"	R 9 3 0	Alarm code
"Cnxxx"		Settable connection macro
"-Cnxxx"		Current selected connection macro
"APxxx"	R P O 3 O	Settable application macro
"-APxxx"	-8010	Current selected application macro

"A"	Я	"G"	9	"N"	П	"T"	F
"B"	Ь	"H"	ከ	"O"	٥	"U"	Ц
"С"	Ε	"In	1	"P"	Р	"V"	L
"D"	Ь	"ע"	Ц	"Q"	9	"X"	Н
"E"	Ε	"L"	L	"R"	ſ	"Y"	Ч
"F"	F	"M"	П	"S"	5	"Z"	2
0 to 9	0123	1456	789			"?"	٦.

SINAMICS V20 Converter

5.2 Checking before power-on

### 5.1.6 LED states

The SINAMICS V20 has only one LED for status indications. The LED can display orange, green, or red.

If more than one converter state exists, the LED displays in the following order of priority:

- Parameter cloning
- Commissioning mode
- All faults
- Ready (no fault)

For example, if there is an active fault when the converter is in the commissioning mode, the LED flashes green at 0.5 Hz.

Converter state	LED color	
Power up	Orange	
Ready (no fault)	Green	
Commissioning mode	Slow flashing green at 0.5 Hz	
All faults	Fast flashing red at 2 Hz	8
Parameter cloning	Flashing orange at 1 Hz	

# 5.2 Checking before power-on

Perform the following checks before you power on the converter:

- Check that all cables have been connected correctly and that all relevant product and plant/location safety precautions have been observed.
- Ensure that the motor and the converter are configured for the correct supply voltage.
- Tighten all screws to the specified tightening torque.

# 5.3 Setting the 50/60 Hz selection menu

#### Note


The 50/60 Hz selection menu is visible only on first power-up or after a factory reset (P0970). You can make a selection using the BOP or exit the menu without making a selection, and the menu will not be displayed unless a factory reset is performed.

The motor base frequency also can be selected by changing P0100 to the desired value.

### Functionality

This menu is used to set the motor base frequency according to which region of the world that the motor is used in. The menu determines whether power settings (for example, rated motor power P0307) are expressed in [kW] or [hp].

Parameter	Value	Description	
P0100	0	Motor base frequency is 50 Hz ( <b>default</b> ) $\rightarrow$ Europe [kW]	
	1	Motor base frequency is 60 Hz $\rightarrow$ United States/Canada [hp]	
	2	Motor base frequency is 60 Hz $\rightarrow$ United States/Canada [kW]	



5.4 Starting the motor for test run

# 5.4 Starting the motor for test run

This section describes how to start the motor for a test run to check that the motor speed and rotation direction are correct.

#### Note

To run the motor, the converter must be in the display menu (default display) and power-on default state with P0700 (selection of command source) = 1.

If you are now in the setup menu (the converter displays "P0304"), press in for over two seconds to exit the setup menu and enter the display menu.

You can start the motor in HAND or JOG mode.

### Starting the motor in HAND mode

- 1. Press **I** to start the motor.
- 2. Press **O** to stop the motor.

### Starting the motor in JOG mode

- 1. Press M + 📧 to switch from HAND to JOG mode (the 🕿 icon flashes).
- 2. Press **I** to start the motor. Release **I** to stop the motor.

# 5.5 Quick commissioning

5.5.1 Quick commissioning through the setup menu


#### 5.5.1.1 Structure of the setup menu

#### Functionality of the setup menu

The setup menu guides you through the steps required for quick commissioning of the converter. It consists of the following four sub-menus:

	Sub-menu	Functionality
1	Motor data	Sets nominal motor parameters for quick commissioning
2	Connection macro selection	Sets macros required for standard wiring arrangements
3	Application macro selection	Sets macros required for certain common applications
4	Common parameter selection	Sets parameters required for converter performance optimization

### Menu structure



# 5.5.1.2 Setting motor data

# Functionality

This menu is designed for easy setup of nominal motor nameplate data.

### Text menu

If you set P8553 to 1, parameter numbers in this menu are replaced with short text.

5.5 Quick commissioning

# Setting parameters

#### Note

In the table below, " $\bullet$ " indicates that the value of this parameter must be entered according to the rating plate of the motor.

Parameter	Access level	Function	Text menu (if P8553 = 1)
P0100	1	50/60 Hz selection =0: Europe [kW], 50 Hz (factory default) =1: North America [hp], 60 Hz =2: North America [kW], 60 Hz	Е U - U 5 (EU - US)
P0304[0] ●	1	Rated motor voltage [V] Note that the input of rating plate data must correspond with the wiring of the motor (star/delta)	
P0305[0] ●	1	Rated motor current [A] Note that the input of rating plate data must correspond with the wiring of the motor (star/delta)	
P0307[0] ●	1	Rated motor power [kW/hp] If P0100 = 0 or 2, motor power unit = [kW] If P0100 = 1, motor power unit = [hp]	P0100 = 0 or 2:         ПаЕР         (MOT P)         P0100 = 1:         ПаЕҺР         (MOT HP)
P0308[0] ●	1	Rated motor power factor (cosφ) Visible only when P0100 = 0 or 2	
P0309[0] ●	1	Rated motor efficiency [%] Visible only when P0100 = 1 Setting 0 causes internal calculation of value.	
P0310[0] ●	1	Rated motor frequency [Hz]	M FrE 9
P0311[0] ●	1	Rated motor speed [RPM]	<mark>П г Р П</mark> (М RPM)
P1900	2	Select motor data identification = 0: Disabled = 2: Identification of all parameters in standstill	

# 5.5.1.3 Setting connection macros

#### NOTICE

#### **Connection macro settings**

When commissioning the converter, the connection macro setting is a one-off setting. Make sure that you proceed as follows before you change the connection macro setting to a value different from your last setting:

- 1. Do a factory reset (P0010 = 30, P0970 = 1)
- 2. Repeat the quick commissioning and change the connection macro

Failure to observe may cause the converter to accept the parameter settings from both the currently and the previously selected macros, which may lead to undefined and unexplainable converter operation.

However, communication parameters P2010, P2011, P2021 and P2023 for connection macros Cn010 and Cn011 are not reset automatically after a factory reset. If necessary, reset them manually.

After changing P2023 setting for Cn010 or Cn011, power-cycle the converter. During the power-cycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power.

#### Note

The wiring diagrams later in this section use PNP control mode as examples.


## Functionality

This menu selects which macro is required for standard wiring arrangements. The default one is "Cn000" for connection macro 0.


All connection macros only change the CDS0 (command data set 0) parameters. The CDS1 parameters are used for the BOP control.

Connection macro	Description	Display example
Cn000	Factory default setting. Makes no parameter changes.	
Cn001	BOP as the only control source	- [ - 0 0 0
Cn002	Control from terminals (PNP/NPN)	
Cn003	Fixed speeds	
Cn004	Fixed speeds in binary mode	
Cn005	Analog input and fixed frequency	The minus sign indicates that this macro is
Cn006	External push button control	the currently selected macro.
Cn007	External push buttons with analog setpoint	
Cn008	PID control with analog input reference	
Cn009	PID control with the fixed value reference	
Cn010	USS control	
Cn011	MODBUS RTU control	

# Setting connection macros



# Connection macro Cn001 - BOP as the only control source





Parameter	Description	Factory default	Default for Cn001	Remarks
P0700[0]	Selection of command source	1	1	BOP
P1000[0]	Selection of frequency	1	1	BOP MOP
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active
P0771[0]	CI: Analog output	21	21	Actual frequency
P0810[0]	BI: CDS bit 0 (Hand/Auto)	0	0	Hand mode

## Connection macro Cn002 - Control from terminals (PNP/NPN)

External control - Potentiometer with setpoint

Both NPN and PNP can be realized with the same parameters. You can change the connection of the digital input common terminal to 24 V or 0 V to decide the mode.






Parameter	Description	Factory default	Default for Cn002	Remarks
P0700[0]	Selection of command source	1	2	Terminal as command source
P1000[0]	Selection of frequency	1	2	Analog setpoint 1
P0701[0]	Function of digital input 1	0	1	ON/OFF
P0702[0]	Function of digital input 2	0	12	Reverse
P0703[0]	Function of digital input 3	9	9	Fault acknowledgement
P0704[0]	Function of digital input 4	15	10	JOG forward
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active

## Connection macro Cn003 - Fixed speeds

Three fixed speeds with ON/OFF1

If more than one fixed frequency is selected at the same time, the selected frequencies are summed, that is, FF1 + FF2 + FF3.




Parameter	Description	Factory default	Default for Cn003	Remarks
P0700[0]	Selection of command source	1	2	Terminal as command source
P1000[0]	Selection of frequency	1	3	Fixed frequency
P0701[0]	Function of digital input 1	0	1	ON/OFF
P0702[0]	Function of digital input 2	0	15	Fixed speed bit 0
P0703[0]	Function of digital input 3	9	16	Fixed speed bit 1
P0704[0]	Function of digital input 4	15	17	Fixed speed bit 2
P1016[0]	Fixed frequency mode	1	1	Direct selection mode
P1020[0]	BI: Fixed frequency selection bit 0	722.3	722.1	DI2
P1021[0]	BI: Fixed frequency selection bit 1	722.4	722.2	DI3
P1022[0]	BI: Fixed frequency selection bit 2	722.5	722.3	DI4
P1001[0]	Fixed frequency 1	10	10	Speed low
P1002[0]	Fixed frequency 2	15	15	Speed middle
P1003[0]	Fixed frequency 3	25	25	Speed high
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active

# Connection macro Cn004 - Fixed speeds in binary mode

Fixed speeds with ON command in binary mode

Up to 16 different fixed frequency values (0 Hz, P1001 to P1015) can be selected by the fixed frequency selectors (P1020 to P1023). For more information about the fixed frequencies in binary mode, see the parameter descriptions of P1001 to P1016 in Section "Parameter list (Page 206)".




Connection macro settings:

Parameter	Description	Factory default	Default for Cn004	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P1000[0]	Selection of frequency	1	3	Fixed frequency
P0701[0]	Function of digital input 1	0	15	Fixed speed bit 0
P0702[0]	Function of digital input 2	0	16	Fixed speed bit 1
P0703[0]	Function of digital input 3	9	17	Fixed speed bit 2
P0704[0]	Function of digital input 4	15	18	Fixed speed bit 3
P1001[0]	Fixed frequency 1	10	10	Fixed speed 1
P1002[0]	Fixed frequency 2	15	15	Fixed speed 2
P1003[0]	Fixed frequency 3	25	25	Fixed speed 3
P1004[0]	Fixed frequency 4	50	50	Fixed speed 4
P1016[0]	Fixed frequency mode	1	2	Binary mode
P0840[0]	BI: ON/OFF1	19.0	1025.0	Converter starts at the fixed speed selected
P1020[0]	BI: Fixed frequency selection bit 0	722.3	722.0	DI1
P1021[0]	BI: Fixed frequency selection bit 1	722.4	722.1	DI2
P1022[0]	BI: Fixed frequency selection bit 2	722.5	722.2	DI3
P1023[0]	BI: Fixed frequency selection bit 3	722.6	722.3	DI4
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active

# Connection macro Cn005 - Analog input and fixed frequency


The analog input works as an additional setpoint.

If digital input 2 and digital input 3 are active together, the selected frequencies are summed, that is, FF1 + FF2.



#### **Function diagram**

When the fixed speed is selected, the additional setpoint channel from the analog is disabled. If there is no fixed speed setpoint, the setpoint channel connects to the analog input.




Connection macro settings:

Parameter	Description	Factory default	Default for Cn005	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P1000[0]	Selection of frequency	1	23	Fixed frequency + analog setpoint 1
P0701[0]	Function of digital input 1	0	1	ON/OFF
P0702[0]	Function of digital input 2	0	15	Fixed speed bit 0
P0703[0]	Function of digital input 3	9	16	Fixed speed bit 1
P0704[0]	Function of digital input 4	15	9	Fault acknowledgement
P1016[0]	Fixed frequency mode	1	1	Direct selection mode
P1020[0]	BI: Fixed frequency selection bit 0	722.3	722.1	DI2
P1021[0]	BI: Fixed frequency selection bit 1	722.4	722.2	DI3
P1001[0]	Fixed frequency 1	10	10	Fixed speed 1
P1002[0]	Fixed frequency 2	15	15	Fixed speed 2

Parameter	Description	Factory default	Default for Cn005	Remarks
P1074[0]	BI: Disable additional setpoint	0	1025.0	FF disables the additional setpoint
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active

# Connection macro Cn006 - External push button control


Note that the command sources are pulse signals.



Parameter	Description	Factory default	Default for Cn006	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P1000[0]	Selection of frequency	1	1	MOP as setpoint
P0701[0]	Function of digital input 1	0	2	OFF1/hold
P0702[0]	Function of digital input 2	0	1	ON pulse
P0703[0]	Function of digital input 3	9	13	MOP up pulse
P0704[0]	Function of digital input 4	15	14	MOP down pulse
P0727[0]	Selection of 2/3-wire method	0	3	3-wire ON pulse + OFF1/hold + Reverse
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	Bl: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	Bl: Function of digital output 2	52.7	52.3	Converter fault active
P1040[0]	Setpoint of the MOP	5	0	Initial frequency
P1046[0]	MOP step increment	0.1	0.1	Not used for PID-MOP
P1047[0]	MOP ramp-up time of the RFG	10	10	Ramp-up time from zero to maximum frequency
P1048[0]	MOP ramp-down time of the RFG	10	10	Ramp-down time from maximum frequency to zero

# Connection macro Cn007 - External push buttons with analog control


0~10 V=0~50/60 Hz OFF hold Forward pulse + ON L Reverse pulse + ON T Fault acknowledgement pulse 12 13 14 11 9 3 5 8 10 10V AI1 AI2 0V DI1 DI2 DI3 DI4 DIC 24V 0V -[-007 DO2 V A01 0V D01+ D01ſ o 🚺 🖬 💌 P+ N-Lal 3 17] 220V O 6 16 4 15 18 19  $\otimes$ Ν Running Fault Speed 0~20 mA=0~50/60 Hz



Connection macro settings:

Parameter	Description	Factory default	Default for Cn007	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P1000[0]	Selection of frequency	1	2	Analog setpoint 1
P0701[0]	Function of digital input 1	0	1	OFF hold
P0702[0]	Function of digital input 2	0	2	Forward pulse + ON
P0703[0]	Function of digital input 3	9	12	Reverse pulse + ON
P0704[0]	Function of digital input 4	15	9	Fault acknowledgement
P0727[0]	Selection of 2/3-wire method	0	2	3-wire STOP + Forward pulse + Reverse pulse
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active

Note that the command sources are pulse signals.




# Connection macro Cn008 - PID control with analog reference

#### Note

If a negative setpoint for the PID control is desired, change the setpoint and feedback wiring as needed.

When you switch to Hand mode from PID control mode, P2200 becomes 0 to disable the PID control. When you switch it back to Auto mode, P2200 becomes 1 to enable the PID control again.


Parameter	Description	Factory default	Default for Cn008	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P0701[0]	Function of digital input 1	0	1	ON/OFF
P0703[0]	Function of digital input 3	9	9	Fault acknowledgement
P2200[0]	BI: Enable PID controller	0	1	Enable PID
P2253[0]	CI: PID setpoint	0	755.0	PID setpoint = AI1
P2264[0]	CI: PID feedback	755.0	755.1	PID feedback = $AI2$
P0756[1]	Type of analog input	0	2	AI2, 0 mA to 20 mA
P0771[0]	CI: Analog output	21	21	Actual frequency
P0731[0]	BI: Function of digital output 1	52.3	52.2	Converter running
P0732[0]	BI: Function of digital output 2	52.7	52.3	Converter fault active



# Connection macro Cn009 - PID control with the fixed value reference

Parameter	Description	Factory default	Default for Cn009	Remarks
P0700[0]	Selection of command source	1	2	Terminals as command source
P0701[0]	Function of digital input 1	0	1	ON/OFF
P0702[0]	Function of digital input 2	0	15	DI2 = PID fixed value 1
P0703[0]	Function of digital input 3	9	16	DI3 = PID fixed value 2
P0704[0]	Function of digital input 4	15	17	DI4 = PID fixed value 3
P2200[0]	BI: Enable PID controller	0	1	Enable PID
P2201[0]	Fixed PID setpoint 1 [%]	10	10	-
P2202[0]	Fixed PID setpoint 2 [%]	20	20	-
P2203[0]	Fixed PID setpoint 3 [%]	50	50	-
P2216[0]	Fixed PID setpoint mode	1	1	Direct selection
P2220[0]	BI: Fixed PID setpoint select bit 0	722.3	722.1	BICO connection DI2
P2221[0]	BI: Fixed PID setpoint select bit 1	722.4	722.2	BICO connection DI3
P2222[0]	BI: Fixed PID setpoint select bit 2	722.5	722.3	BICO connection DI4
P2253[0]	CI: PID setpoint	0	2224	PID setpoint = fixed value
P2264[0]	CI: PID feedback	755.0	755.1	PID feedback = AI2

# Connection macro Cn010 - USS control




Connection macro settings:

Parameter	Description	Factory default	Default for Cn010	Remarks
P0700[0]	Selection of command source	1	5	RS485 as the command source
P1000[0]	Selection of frequency	1	5	RS485 as the speed setpoint
P2023[0]	RS485 protocol selection	1	1	USS protocol
P2010[0]	USS/MODBUS baudrate	6	8	Baudrate 38400 bps
P2011[0]	USS address	0	1	USS address for converter
P2012[0]	USS PZD length	2	2	Number of PZD words
P2013[0] 1)	USS PKW length	127	127	Variable PKW words
P2014[0]	USS/MODBUS telegram off time	2000	500	Time to receive data

<sup>1)</sup> If you want to use USS function blocks in TIA Portal to communicate with the converter, make sure that you set P2013[0] = 4.

# Connection macro Cn011 - MODBUS RTU control



#### Connection macro settings:

Parameter	Description	Factory default	Default for Cn011	Remarks
P0700[0]	Selection of command source	1	5	RS485 as the command source
P1000[0]	Selection of frequency	1	5	RS485 as the speed setpoint
P2023[0]	RS485 protocol selection	1	2	MODBUS RTU protocol
P2010[0]	USS/MODBUS baudrate	6	6	Baudrate 9600 bps
P2021[0]	MODBUS address	1	1	MODBUS address for converter
P2022[0]	MODBUS reply timeout	1000	1000	Maximum time to send reply back to the master
P2014[0]	USS/MODBUS telegram off time	2000	100	Time to receive data
P2034	MODBUS parity on RS485	2	2	Parity of MODBUS telegrams on RS485
P2035	MODBUS stop bits on RS485	1	1	Number of stop bits in MODBUS telegrams on RS485

## 5.5.1.4 Setting application macros

#### NOTICE

#### **Application macro settings**

When commissioning the converter, the application macro setting is a one-off setting. Make sure that you proceed as follows before you change the application macro setting to a value different from your last setting:

1. Do a factory reset (P0010 = 30, P0970 = 1)

2. Repeat the quick commissioning and change the application macro

Failure to observe may cause the converter to accept the parameter settings from both the currently and the previously selected macros, which may lead to undefined and unexplainable operation.


## Functionality

This menu defines certain common applications. Each application macro provides a set of parameter settings for a specific application. After you select an application macro, the corresponding settings are applied to the converter to simplify the commissioning process.

The default application macro is "AP000" for application macro 0. If none of the application macros fits your application, select the one that is the closest to your application and make further parameter changes as desired.

Application macro	Description	Display example
AP000	Factory default setting. Makes no parameter changes.	
AP010	Simple pump applications	- R P O O O
AP020	Simple fan applications	
AP021	Compressor applications	RPD ID
AP030	Conveyor applications	
		The minus sign indicates that this macro is the currently selected macro.

# Setting application macros



# Application macro AP010 - Simple pump applications

Parameter	Description	Factory default	Default for AP010	Remarks
P1080[0]	Minimum frequency	0	15	Converter running at a lower speed inhibited
P1300[0]	Control mode	0	7	Quadratic V/f
P1110[0]	BI: Inhibit negative frequency setpoint	0	1	Reverse pump rotation inhibited
P1210[0]	Automatic restart	1	2	Restart after mains blackout
P1120[0]	Ramp-up time	10	10	Ramp-up time from zero to maximum frequency
P1121[0]	Ramp-down time	10	10	Ramp-down time from maximum frequency to zero

# Application macro AP020 - Simple fan applications

Parameter	Description	Factory default	Default for AP020	Remarks
P1110[0]	BI: Inhibit negative frequency setpoint	0	1	Reverse fan rotation inhibited
P1300[0]	Control mode	0	7	Quadratic V/f
P1200[0]	Flying start	0	2	Search for the speed of the running motor with a heavy inertia load so that the motor runs up to the setpoint
P1210[0]	Automatic restart	1	2	Restart after mains blackout
P1080[0]	Minimum frequency	0	20	Converter running at a lower speed inhibited
P1120[0]	Ramp-up time	10	10	Ramp-up time from zero to maximum frequency
P1121[0]	Ramp-down time	10	20	Ramp-down time from maximum frequency to zero

# Application macro AP021 - Compressor applications

Parameter	Description	Factory default	Default for AP021	Remarks
P1300[0]	Control mode	0	0	Linear V/f
P1080[0]	Minimum frequency	0	10	Converter running at a lower speed inhibited
P1312[0]	Starting boost	0	30	Boost only effective when accelerating for the first time (standstill)
P1311[0]	Acceleration boost	0	0	Boost only effective when accelerating or braking
P1310[0]	Continuous boost	50	50	Additional boost over the complete frequency range
P1120[0]	Ramp-up time	10	10	Ramp-up time from zero to maximum frequency
P1121[0]	Ramp-down time	10	10	Ramp-down time from maximum frequency to zero

# Application macro AP030 - Conveyor applications

Parameter	Description	Factory default	Default for AP030	Remarks
P1300[0]	Control mode	0	1	V/f with FCC
P1312[0]	Starting boost	0	30	Boost only effective when accelerating for the first time (standstill)
P1120[0]	Ramp-up time	10	5	Ramp-up time from zero to maximum frequency
P1121[0]	Ramp-down time	10	5	Ramp-down time from maximum frequency to zero

# 5.5.1.5 Setting common parameters

# Functionality

This menu provides some common parameters for converter performance optimization.

## Text menu

If you set P8553 to 1, parameter numbers in this menu are replaced with short text.

# Setting parameters

Parameter	Access level	Function	Text menu (if P8553 = 1)	Parameter	Access level	Function	Text menu (if P8553 =1)
P1080[0]	1	Minimum motor frequency		P1001[0]	2	Fixed frequency setpoint 1	F , H F I
P1082[0]	1	Maximum motor frequency	(MIN F)	P1002[0]	2	Fixed frequency setpoint 2	(FIX F1)
P1120[0]	1	Ramp-up time	г П Р Ц Р	P1003[0]	2	Fixed frequency setpoint 3	F , HF3
P1121[0]	1	Ramp-down time	(RMP UP)	P2201[0]	2	Fixed PID frequency setpoint 1	(FIX F3)
P1058[0]	2	JOG frequency	(IOG P)	P2202[0]	2	Fixed PID frequency setpoint 2	(Pid F 2)
P1060[0]	2	JOG ramp-up time		P2203[0]	2	Fixed PID frequency setpoint 3	(PID F3)
P1061[0]	2	JOG ramp-down time	<b>J o 9 d n</b> (JOG DN)				

# 5.5.2 Quick commissioning through the parameter menu

As an alternative to quick commissioning through the setup menu, commissioning using the parameter menu provides the other solution for quick commissioning. This would be helpful for those who are used to commissioning the converter in this way.

## Quick commissioning methods

#### • Conventional quick commissioning

This method requires you to complete quick commissioning with all the motor data given in the parameter setting table below.

#### Estimated quick commissioning

This method provides an easier way to complete quick commissioning with limited motor data. Instead of entering all the motor data, you enter the rated motor power (P0301, in kW) and then the converter estimates and then sets the values of the rest of the motor data including P0304, P0305, P0307, P0308, P0310 and P0311.

#### Restrictions on the estimated quick commissioning:

- This functionality is recommended at the rated supply voltage.
- This functionality is designed around the data for Siemens motors 1LE0001, 1TL0001, 1LE1 and 1LA7 although it may make reasonable approximations for other motor types.
- This functionality gives an estimate of the motor data values; however, if the motor is to operate near the limits of its capability (rated power and current), then you must carry out the conventional quick commissioning.
- The value calculations only work with motors connected in star configuration and assume the supply frequency is 50 Hz.
- The calculations use the DC link voltage measurement and thus only work if mains is connected.
- The calculations are accurate only for 4-pole motors.
- The 87 Hz characteristic is not supported.

# Setting parameters

#### Note

In the table below, "•" indicates that you must enter the value of this parameter according to the rating plate of the motor when you carry out the conventional quick commissioning.

Parameters for conventional quick commissioning	Parameters for estimated quick commissioning	Function	Setting
P0003 = 3	P0003 = 3	User access level	= 3 (Expert access level)
P0010 = 1	P0010 = 1	Commissioning parameter	= 1 (quick commissioning)
P0100	P0100 = 0	50/60 Hz selection	Set a value, if necessary:
			=0: Europe [kW], 50 Hz (factory default)
			=1: North America [hp], 60 Hz
			=2: North America [kW], 60 Hz
			Note:
			Set this parameter to 0 if you want to carry out the estimated quick commissioning.
P0301 = 0	P0301 > 0	Rated motor power [kW]	Range: 0 to 2000
			= 0: Conventional quick commissioning (factory default)
			> 0: Estimated quick commissioning
			Once you set this parameter to a non-zero value, you only need to enter the rated motor power and then the converter calculates and sets the values of the rest of the motor data (P0304, P0305, P0307, P0308, P0310 and P0311).
P0304[0] •	-	Rated motor voltage [V]	Range: 10 to 2000
			Note:
			The input of rating plate data must correspond with the wiring of the motor (star/delta).
P0305[0] •	-	Rated motor current [A]	Range: 0.01 to 10000
			Note:
			The input of rating plate data must correspond with the wiring of the motor (star/delta).
P0307[0] •	-	Rated motor power [kW/hp]	Range: 0.01 to 2000.0
			Note:
			If P0100 = 0 or 2, motor power unit = [kW]
			If P0100 = 1, motor power unit = [hp]
P0308[0] •	-	Rated motor power factor	Range: 0.000 to 1.000
		(cosφ)	Note:
			This parameter is visible only when P0100 = 0 or 2.
P0309[0] •	-	Rated motor efficiency [%]	Range: 0.0 to 99.9
			Note:
			Visible only when P0100 = 1
			Setting 0 causes internal calculation of value.
P0310[0] •	-	Rated motor frequency [Hz]	Range: 12.00 to 550.00
P0311[0] •	-	Rated motor speed [RPM]	Range: 0 to 40000

Parameters for conventional quick commissioning	Parameters for estimated quick commissioning	Function	Setting
P0335[0]	P0335[0]	Motor cooling	Set according to the actual motor cooling method = 0: Self-cooled (factory default) = 1: Force-cooled = 2: Self-cooled and internal fan = 3: Force-cooled and internal fan
P0640[0]	P0640[0]	Motor overload factor [%]	Range: 10.0 to 400.0 (factory default: 150.0) <b>Note:</b> The parameter defines motor overload current limit relative to P0305 (rated motor current).
P0700[0]	P0700[0]	Selection of command source	<ul> <li>= 0: Factory default setting</li> <li>= 1: Operator panel (factory default)</li> <li>= 2: Terminal</li> <li>= 5: USS/MODBUS on RS485</li> </ul>
P1000[0]	P1000[0]	Selection of frequency setpoint	Range: 0 to 77 (factory default: 1) = 0: No main setpoint = 1: MOP setpoint = 2: Analog setpoint 1 = 3: Fixed frequency = 5: USS/MODBUS on RS485 = 7: Analog setpoint 2 For additional settings, see Chapter "Parameter list (Page 201)".
P1080[0]	P1080[0]	Minimum frequency [Hz]	Range: 0.00 to 550.00 (factory default: 0.00) <b>Note:</b> The value set here is valid for both clockwise and counter-clockwise rotation.
P1082[0]	P1082[0]	Maximum frequency [Hz]	Range: 0.00 to 550.00 (factory default: 50.00) <b>Note:</b> The value set here is valid for both clockwise and counter-clockwise rotation
P1120[0]	P1120[0]	Ramp-up time [s]	Range: 0.00 to 650.00 (factory default: 10.00) <b>Note:</b> The value set here means the time taken for motor to accelerate from standstill up to the maximum motor frequency (P1082) when no rounding is used.
P1121[0]	P1121[0]	Ramp-down time [s]	Range: 0.00 to 650.00 (factory default: 10.00) Note: The value set here means the time taken for motor to decelerate from the maximum motor frequency (P1082) down to standstill when no rounding is used.

Parameters for conventional quick commissioning	Parameters for estimated quick commissioning	Function	Setting
P1300[0]	P1300[0]	Control mode	<ul> <li>= 0: V/f with linear characteristic (factory default)</li> <li>= 1: V/f with FCC</li> <li>= 2: V/f with quadratic characteristic</li> <li>= 3: V/f with programmable characteristic</li> <li>= 4: V/f with linear eco</li> <li>= 5: V/f for textile applications</li> <li>= 6: V/f with FCC for textile applications</li> <li>= 7: V/f with quadratic eco</li> <li>= 19: V/f control with independent voltage setpoint</li> </ul>
P3900 = 3	P3900 = 3	End of quick commissioning	<ul> <li>= 0: No quick commissioning (factory default)</li> <li>= 1: End quick commissioning with factory reset</li> <li>= 2: End quick commissioning</li> <li>= 3: End quick commissioning and initiate motor data calculation</li> <li>Note:</li> <li>After completion of calculation, P3900 and P0010 are automatically reset to their original value 0.</li> <li>The converter displays "8.8.8.8.8" which indicates that it is busy with internal data processing.</li> </ul>
P1900 = 2	P1900 = 2	Select motor data identification	= 0: Disabled (factory default) = 2: Identification of all parameters in standstill

# 5.6 Function commissioning

# 5.6.1 Overview of converter functions

The list below provides an overview of the main functions that the SINAMICS V20 supports. For detailed description of individual parameters, see Chapter "Parameter list (Page 201)".

- 2/3 wire control (P0727)
- 50/60 Hz customization (Page 67) (P0100)
- Adjustable PWM modulation (P1800 to P1803)
- Analog input terminal function control (P0712, P0713, r0750 to P0762)
- Analog output terminal function control (P0773 to r0785)
- Automatic restart (Page 128) (P1210, P1211)
- BICO function (r3978)
- Blockage clearing mode (Page 120) (P3350 to P3353, P3361 to P3364)
- Cavitation protection (Page 138) (P2360 to P2362)
- Command and setpoint source selection (P0700, P0719, P1000 to r1025, P1070 to r1084)
- Command data set (CDS) and drive data set (DDS) (r0050, r0051, P0809 to P0821)
- Condensation protection (Page 130) (P3854)
- Continuous boost, acceleration boost and starting boost level control (Page 96) (P1310 to P1316)
- Converter keep-running operation (P0503)
- Converter status at fault (Page 341) (r0954, r0955, r0956, r0957 and r0958)
   This function enables you to read the relevant fault information through parameters concerned.
- DC coupling function (Page 141)
- DC-link voltage control (Page 113) (P0210, P1240 to P1257)
- Digital input terminal function control (P0701 to P0713, r0722, r0724)
- Digital output terminal function control (P0731, P0732, P0747, P0748)
- Dual ramp operation (Page 140) (r1119 to r1199, P2150 to P2166)
- Economy mode (Page 122) (P1300, r1348)
- Energy consumption monitoring (r0039, P0040, P0042, P0043)
- Fault and warning reaction setting (r0944 to P0952, P2100 to P2120, r3113, P3981)
- Flying start (Page 127) (P1200 to r1204)
- Free function blocks (FFBs) (Page 126) (P2800 to P2890)
- Frost protection (Page 129) (P3852, P3853)
- Hammer start mode (Page 118) (P3350 to P3354, P3357 to P3360)

- Hibernation mode (Page 131) (P2365 to P2367)
- High/low overload (HO/LO) modes (Page 144) (P0205)

A new parameter P0205 is added to enable the HO/LO selection for heavy/low load applications.

- Imax control (Page 111) (P1340 to P1346)
- JOG mode operation (Page 94) (P1055 to P1061)
- List of modified parameters (P0004)

A new value is added to parameter P0004 to enable the parameter filter which allows you to view the modified parameters.

• MODBUS parity/stop bit selection (P2034, P2035)

New parameters P2034 and P2035 are added to enable MODBUS parity/stop bit selection.

- Motor blocking, load missing, belt failure detection (Page 114) (P2177 to r2198)
- Motor brake controls (Page 100) (holding brake, DC brake, compound brake and dynamic brake) (P1215 to P1237)
- Motor frequency display scaling (P0511, r0512)
- Motor protection with PTC sensor (Page 124) (P610)
- Motor staging (Page 135) (P2370 to P2380)
- Motorized potentiometer (MOP) mode selection (P1031 to r1050)
- ON/OFF2 function for digital inputs (P0701)

A new value is added to parameter P0701 to run the motor with the ON command or cancel the converter pulses with the OFF2 command.

- Parameter cloning (Page 367) (P0802 to P0804, P8458)
- PID controller (Page 98) (P2200 to P2355)
- Pre-configured connection macros and application macros (P0507, P0717) (see also "Setting connection macros (Page 71)" and "Setting application macros (Page 82)".)
- Programmable V/f coordinates (P1320 to P1333)
- Protection of user-defined parameters (P0011, P0012, P0013)
- Skip frequency and resonance damping (P1091 to P1101, P1338)
- Slip compensation (P1334 to P1338)
- Super torque mode (Page 116) (P3350 to P3356)
- Text menu display (P8553) (see also "Setting motor data (Page 69)" and "Setting common parameters (Page 84)".)
- User access level control (P0003)
- USS/MODBUS communication on RS485 (P2010 to P2037) (Page 183)
- Various stop mode selection (Page 92) (P0840 to P0886)
- Wobble function (Page 134) (P2940 to r2955)

# 5.6.2 Commissioning basic functions


## 5.6.2.1 Selecting the stop mode

#### **Functionality**

Both the converter and the user have to respond to a wide range of situations and stop the converter if necessary. Thus operating requirements as well as converter protective functions (e.g. electrical or thermal overload), or rather man-machine protective functions, have to be taken into account. Due to the different OFF functions (OFF1, OFF2, OFF3) the converter can flexibly respond to the mentioned requirements. Note that after an OFF2/OFF3 command, the converter is in the state "ON inhibit". To switch the motor on again, you need a signal low  $\rightarrow$  high of the ON command.

## OFF1

The OFF1 command is closely coupled to the ON command. When the ON command is withdrawn, OFF1 is directly activated. The converter is braked by OFF1 with the ramp-down time P1121. If the output frequency falls below the parameter value P2167 and if the time in P2168 has expired, then the converter pulses are cancelled.




#### Note

- OFF1 can be entered using a wide range of command sources via BICO parameter P0840 (BI: ON/OFF1) and P0842 (BI: ON/OFF1 with reversing).
- BICO parameter P0840 is pre-assigned by defining the command source using P0700.
- The ON and the following OFF1 command must have the same source.
- If the ON/OFF1 command is set for more than one digital input, then only the digital input, that was last set, is valid.
- OFF1 is active low.
- When various OFF commands are selected simultaneously, the following priority applies: OFF2 (highest priority) OFF3 OFF1.
- OFF1 can be combined with DC current braking or compound braking.
- When the motor holding brake MHB (P1215) is activated, for an OFF1, P2167 and P2168 are not taken into account.

## OFF2

The converter pulses are immediately cancelled by the OFF2 command. Thus the motor coasts down and it is not possible to stop in a controlled way.




#### Note

- The OFF2 command can have one or several sources. The command sources are defined using BICO parameters P0844 (BI: 1. OFF2) and P0845 (BI: 2. OFF2).
- As a result of the pre-assignment (default setting), the OFF2 command is set to the BOP. This source is still available even if another command source is defined (e.g. terminal as command source  $\rightarrow$  P0700 = 2 and OFF2 is selected using digital input 2  $\rightarrow$  P0702 = 3).
- OFF2 is active low.
- When various OFF commands are selected simultaneously, the following priority applies: OFF2 (highest priority) OFF3 OFF1.

# OFF3

The braking characteristics of OFF3 are identical with those of OFF1 with the exception of the independent OFF3 ramp-down time P1135. If the output frequency falls below parameter value P2167 and if the time in P2168 has expired, then the converter pulses are cancelled as for the OFF1 command.



#### Note

- OFF3 can be entered using a wide range of command sources via BICO parameters P0848 (BI: 1. OFF3) and P0849 (BI: 2. OFF3).
- OFF3 is active low.
- When various OFF commands are selected simultaneously, the following priority applies: OFF2 (highest priority) – OFF3 – OFF1

#### 5.6.2.2 Running the converter in JOG mode


## Functionality

The JOG function can be controlled by either the (built-in) BOP or the digital inputs. When controlled by the BOP, pressing the RUN button will cause the motor to start and rotate at the pre-set JOG frequency (P1058). The motor stops when the RUN button is released.

When using the digital inputs as the JOG command source, the JOG frequency is set by P1058 for JOG right and P1059 for JOG left.

The JOG function allows:

- to check the functionality of the motor and converter after commissioning has been completed (first traversing motion, checking the direction of rotation, etc.)
- to bring a motor or a motor load into a specific position
- to traverse a motor, e.g. after a program has been interrupted



## **Setting parameters**

Parameter	Function	Setting
P1055[02]	BI: Enable JOG right	This parameter defines source of JOG right when P0719 = 0 (Auto selection of command/setpoint source).
		Factory default: 19.8
P1056[02]	BI: Enable JOG left	This parameter defines source of JOG left when P0719 = 0 (Auto selection of command/setpoint source).
		Factory default: 0
P1057	JOG enable	= 1: Jogging is enabled (default)
P1058[02]	JOG frequency [Hz]	This parameter determines the frequency at which the converter will run while jogging is active.
		Range: 0.00 to 550.00 (factory default: 5.00)
P1059[02]	JOG frequency left [Hz]	This parameter determines the frequency at which the converter will run while JOG left is selected.
		Range: 0.00 to 550.00 (factory default: 5.00)
P1060[02]	JOG ramp-up time [s]	This parameter sets jog ramp-up time which is used while jogging is active.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1061[02]	JOG ramp-down time [s]	This parameter sets jog ramp-down time which is used while jogging is active.
		Range: 0.00 to 650.00 (factory default: 10.00)

# 5.6.2.3 Setting the voltage boost

## Functionality

For low output frequencies, the V/f characteristics only give a low output voltage. The ohmic resistances of the stator winding play a role at low frequencies, which are neglected when determining the motor flux in V/f control. This means that the output voltage can be too low in order to:

- implement the magnetization of the asynchronous motor
- hold the load
- overcome losses in the system.

The output voltage can be increased (boosted) in the converter using the parameters as shown in the table below.


Parameter	Boost type	Description
P1310	Continuous boost [%]	This parameter defines boost level relative to P0305 (rated motor current) applicable to both linear and quadratic V/f curves.
		Range: 0.0 to 250.0 (factory default: 50.0)
		The voltage boost is effective over the complete frequency range whereby the value continually decreases at high frequencies.
		V Vmax (P0304) V (P0304) V ConBoost 0 $f_n$ $f_{max}$ f (P0310) (P1082)

Parameter	Boost type	Description
P1311	Acceleration boost [%]	This parameter applies boost relative to P0305 (rated motor current) following a positive setpoint change and drops back out once the setpoint is reached. Range: 0.0 to 250.0 (factory default: 0.0) The voltage boost is only effective when accelerating or braking.
P1312	Starting boost [%]	This parameter applies a constant linear offset relative to P0305 (rated motor current) to active V/f curve (either linear or quadratic) after an ON command and is active until: <ul> <li>ramp output reaches setpoint for the first time respectively</li> <li>setpoint is reduced to less than present ramp output</li> <li>Range: 0.0 to 250.0 (factory default: 0.0)</li> <li>The voltage boost is only effective when accelerating for the first time (standstill).</li> </ul>
		V <sub>StartBoost</sub> RFG active f <sub>set</sub> f <sub>n</sub> (P0310) (P1082)

# 5.6.2.4 Setting the PID controller

# Functionality

The integrated PID controller (technology controller) supports all kinds of simple process control tasks, e.g. controlling pressures, levels, or flowrates. The PID controller specifies the speed setpoint of the motor in such a way that the process variable to be controlled corresponds to its setpoint.



# **Setting parameters**

Parameter	Function	Setting
Main function p	arameters	
P2200[02]	BI: Enable PID controller	This parameter allows user to enable/disable the PID controller. Setting to 1 enables the PID closed-loop controller.
		Setting 1 automatically disables normal ramp times set in P1120 and P1121 and the normal frequency setpoints.
		Factory default: 0
P2235[02]	BI: Enable PID-MOP (UP-cmd)	This parameter defines source of UP command.
		Possible sources: 19.13 (BOP), 722.x (Digital Input), 2036.13 (USS on RS485)
P2236[02]	BI: Enable PID-MOP (DOWN-cmd)	This parameter defines source of DOWN command.
		Possible sources: 19.14 (BOP), 722.x (Digital Input), 2036.14 (USS on RS485)
Additional com	missioning parameters	
P2251	PID mode	= 0: PID as setpoint (factory default)
		= 1: PID as trim source
P2253[02]	CI: PID setpoint	This parameter defines setpoint source for PID setpoint input. Possible sources: 755[0] (Analog input 1), 2018.1 (USS PZD 2), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID- MOP)
P2254[02]	CI: PID trim source	This parameter selects trim source for PID setpoint.
		Possible sources: 755[0] (Analog input 1), 2018.1 (USS PZD 2), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID-MOP)

Parameter	Function	Setting	
P2255	PID setpoint gain factor Range: 0.00 to 100.00 (factory default: 100.00)		
P2256	PID trim gain factor	Range: 0.00 to 100.00 (factory default: 100.00)	
P2257	Ramp-up time for PID setpoint [s]	Range: 0.00 to 650.00 (factory default: 1.00)	
P2258	Ramp-down time for PID setpoint [s]	Range: 0.00 to 650.00 (factory default: 1.00)	
P2263	PID controller type	= 0: D component on feedback signal (factory default)	
		= 1: D component on error signal	
P2264[02]	CI: PID feedback	Possible sources: 755[0] (Analog input 1), 2224 (Actual fixed PID setpoint), 2250 (Output setpoint of PID-MOP)	
		Factory default: 755[0]	
P2265	PID feedback filter time constant [s]	Range: 0.00 to 60.00 (factory default: 0.00)	
P2267	Maximum value for PID feedback [%]	Range: -200.00 to 200.00 (factory default: 100.00)	
P2268	Minimum value for PID feedback [%]	Range: -200.00 to 200.00 (factory default: 0.00)	
P2269	Gain applied to PID feedback	Range: 0.00 to 500.00 (factory default: 100.00)	
P2270	PID feedback function selector	= 0: Disabled (factory default)	
		= 1: Square root (root(x))	
		= 2: Square $(x^*x)$	
		= 3: Cube (x*x*x)	
P2271	PID transducer type	= 0 : Disabled (factory default)	
		= 1: Inversion of PID feedback signal	
P2274	PID derivative time [s]	Range: 0.000 to 60.000	
		Factory default: 0.000 (the derivative time does not have any effect)	
P2280	PID proportional gain Range: 0.000 to 65.000 (factory default: 3.000)		
P2285	PID integral time [s] Range: 0.000 to 60.000 (factory default: 0.000)		
P2291	PID output upper limit [%]	Range: -200.00 to 200.00 (factory default: 100.00)	
P2292	PID output lower limit [%]	Range: -200.00 to 200.00 (factory default: 0.00)	
P2293	Ramp-up/-down time of PID limit [s] Range: 0.00 to 100.00 (factory default: 1.00)		
P2295	Gain applied to PID output Range: -100.00 to 100.00 (factory default: 100.00)		
P2350	PID autotune enable	<ul> <li>= 0: PID autotuning disabled (factory default)</li> <li>= 1: PID autotuning via Ziegler Nichols (ZN) standard</li> <li>= 2: PID autotuning as 1 plus some overshoot (O/S)</li> <li>= 3: PID autotuning as 2 little or no overshoot (O/S)</li> <li>= 4: PID autotuning PI only, quarter damped response</li> </ul>	
P2354	PID tuning timeout length [s] Range: 60 to 65000 (factory default: 240)		
P2355	PID tuning offset [%]	Range: 0.00 to 20.00 (factory default: 5.00)	
Output values			
r2224	CO: Actual fixed PID setpoint [%]		
r2225.0	BO: PID fixed frequency status		
r2245	CO: PID-MOP input frequency of the RFG [%]		
r2250	CO: Output setpoint of PID-MOP [%]		
r2260	CO: PID setpoint after PID-RFG [%]		
P2261	PID setpoint filter time constant [s]		
r2262	CO: Filtered PID setpoint after RFG [%]		
r2266	CO: PID filtered feedback [%]		
r2272	CO: PID scaled feedback [%]		
r2273	CO: PID error [%]		
r2294	CO: Actual PID output [%]		

# 5.6.2.5 Setting the braking function

## Functionality

The motor can be electrically or mechanically braked by the converter via the following brakes:

- Electrical brakes
  - DC brake
  - Compound brake
  - Dynamic brake
- Mechanical brake
  - Motor holding brake

## DC braking

DC braking causes the motor to stop rapidly by applying a DC braking current (current applied also holds shaft stationary). For DC braking, a DC current is impressed in the stator winding which results in a significant braking torque for an asynchronous motor.


DC braking is selected as follows:

- Sequence 1: selected after OFF1 or OFF3 (the DC brake is released via P1233)
- Sequence 2: selected directly with the BICO parameter P1230

## Sequence 1


- 1. Enabled using P1233
- 2. DC braking is activated with the OFF1 or OFF3 command (see figure below)
- 3. The converter frequency is ramped down along the parameterized OFF1 or OFF3 ramp down to the frequency at which DC braking is to start P1234.
- 4. The converter pulses are inhibited for the duration of the de-magnetizing time P0347.
- 5. The required braking current P1232 is then impressed for the selected braking time P1233. The status is displayed using signal r0053 bit 00.

The converter pulses are inhibited after the braking time has expired.



# Sequence 2

- 1. Enabled and selected with the BICO parameter P1230 (see figure below).
- 2. The converter pulses are inhibited for the duration of the de-magnetizing time P0347.
- 3. The requested braking current P1232 is impressed for the time selected and the motor is braked. This state is displayed using signal r0053 bit 00.
- 4. After DC braking has been cancelled, the converter accelerates back to the setpoint frequency until the motor speed matches the converter output frequency.



# **Setting parameters**

Parameter	Function	Setting
P1230[02]	BI: Enable DC braking	This parameter enables DC braking via a signal applied from an external source. The function remains active while external input signal is active.
		Factory default: 0
P1232[02]	DC braking current [%]	This parameter defines level of DC current relative to rated motor current (P0305).
		Range: 0 to 250 (factory default: 100)
P1233[02]	Duration of DC braking [s]	This parameter defines duration for which DC braking is active following an OFF1 or OFF3 command.
		Range: 0.00 to 250.00 (factory default: 0.00)
P1234[02]	DC braking start frequency [Hz]	This parameter sets the start frequency for DC braking.
		Range: 0.00 to 550.00 (factory default: 550.00)
P0347[02]	Demagnetization time [s]	This parameter changes time allowed after OFF2/fault condition, before pulses can be re-enabled.
		Range: 0.000 to 20.000 (factory default: 1.000)

# 

#### Motor overheat

For DC current braking, the motor kinetic energy is converted into thermal energy in the motor. If braking lasts too long, then the motor can overheat.

#### Note


The "DC braking" function is only practical for induction motors.

DC braking is not suitable to hold suspended loads.

While DC braking, there is no other way of influencing the converter speed using an external control. When parameterizing and setting the converter, it should be tested using real loads as far as possible.

## **Compound braking**

For compound braking (enabled using P1236), DC braking is superimposed with regenerative braking (where the converter regenerates into the DC-link supply as it brakes along a ramp). Effective braking is obtained without having to use additional components by optimizing the ramp-down time (P1121 for OFF1 or when braking from f1 to f2, P1135 for OFF3) and using compound braking P1236.



P1254 = 0:  $V_{DC-Comp} = 1.13 \cdot \sqrt{2} \cdot P0210$ P1254  $\neq$  0:  $V_{DC-Comp} = 0.98 \cdot r1242$ 

Parameter	Function	Setting
P1236[02]	Compound braking current [%]	This parameter defines DC level superimposed on AC waveform after exceeding DC-link voltage threshold of compound braking. The value is entered in [%] relative to rated motor current (P0305).
		Range: 0 to 250 (factory default: 0)
P1254	Auto detect Vdc switch-on levels	This parameter enables/disables auto-detection of switch-on levels for Vdc_max controller.
		= 0: Disabled
		= 1: Enabled (factory default)
		It is recommended to set $P1254 = 1$ (auto detection of Vdc switch-on levels enabled). Note that auto detection only works when the converter has been in standby for over 20s.

## **Setting parameters**

# WARNING

## Motor overheat

For compound braking, regenerative braking is superimposed on the DC braking (braking along a ramp). This means that components of the kinetic energy of the motor and motor load are converted into thermal energy in the motor. This can cause the motor to overheat if this power loss is too high or if the brake operation takes too long!

#### Note


The compound braking depends on the DC link voltage only (see threshold in the above diagram). This will happen on OFF1, OFF3 and any regenerative condition. Compound braking is deactivated, if:

- flying start is active
- DC braking is active.

## **Dynamic braking**


Dynamic braking converts the regenerative energy, which is released when the motor decelerates, into heat. An internal braking module or an external dynamic braking module, which can control an external braking resistor, is required for dynamic braking. The converter or the external dynamic braking module controls the dynamic braking depending on the DC link voltage. Contrary to DC and compound braking, this technique requires that an external braking resistor is installed.

#### Frame size AA to C



For more information about the dynamic braking module, see Appendix "Dynamic braking module (Page 377)".

#### Frame size D and E




The continuous power  $P_{DB}$  and the duty cycle for the braking resistor can be modified using the dynamic braking module (for frame size AA to C) or parameter P1237 (for frame size D and E).

#### NOTICE

#### Damage to the braking resistor

The average power of the dynamic braking module cannot exceed the power rating of the braking resistor.



Dynamic braking switch-on level:

P1254 = 0:  $V_{DC-Chopper} = 1.13 \cdot \sqrt{2} \cdot P0210$ P1254  $\neq$  0:  $V_{DC-Chopper} = 0.98 \cdot r1242$ 

Duty cycle	ton (s)	toff (s)	tcycle (s)	Ров
5%	12.0	228.0	240.0	0.05
10%	12.6	114.0	126.6	0.10
20%	14.2	57.0	71.2	0.20
50%	22.8	22.8	45.6	0.50
100%	Infinite	0	Infinite	1.00

## Setting parameters

Parameter	Function	Setting
P1237	Dynamic braking	This parameter defines the rated duty cycle of the braking resistor. Dynamic braking is active when the function is enabled and DC-link voltage exceeds the dynamic braking switch-on level.
		= 0: Disabled (factory default)
		= 1: 5% duty cycle
		= 2: 10% duty cycle
		= 3: 20% duty cycle
		= 4: 50% duty cycle
		= 5: 100% duty cycle
		<b>Note:</b> This parameter is only applicable for converters of frame size D and E. For frame sizes AA to C, the duty cycle of the braking resistor can be selected with the dynamic braking module.
P1240[02]	Configuration of Vdc controller	This parameter enables/disables Vdc controller.
		= 0: Vdc controller disabled
		<b>Note:</b> This parameter must be set to 0 (Vdc controller disabled) to activate the dynamic braking.
P1254	Auto detect Vdc switch-on levels	This parameter enables/disables auto-detection of switch-on levels for Vdc_max controller.
		= 0: Disabled
		= 1: Enabled (factory default)
		It is recommended to set P1254 = 1 (auto detection of Vdc switch-on levels enabled). Note that auto detection only works when the converter has been in standby for over 20s. When P1240 = 0, P1254 is only applicable for frame size D and E converters.


# 


#### Risks with the use of inappropriate braking resistors

Braking resistors, which are to be mounted on the converter, must be designed so that they can tolerate the power dissipated. If an unsuitable braking resistor is used, there is a danger of fire and the associated converter will be significantly damaged.

## Motor holding brake

The motor holding brake prevents the motor from undesirable turning when the power supply of the converter is switched-off. The converter has internal logic to control the motor holding brake.






<sup>1)</sup> If the motor frequency setpoint during the normal motor operation is less than the minimum frequency set in P1080, the motor runs at the minimum frequency P1080 irrespecitve of the frequency setpoint.

## **Setting parameters**

Parameter	Function	Setting
P1215	Holding brake enable	This parameter enables/disables holding brake function. The motor holding brake (MHB) is controlled via status word 1 r0052 bit 12.
		= 0: Motor holding brake disabled (factory default)
		= 1: Motor holding brake enabled at the freugency set in P1080
		= 3: Motor holding brake enabled at the freugency set in P1219
P1216	Holding brake release delay[s]	This parameter defines period during which converter runs at the valid minimum frequency (P1080 or P1219) before ramping up.
		Range: 0.0 to 20.0 (factory default: 1.0)
P1217	Holding time after ramp down [s]	This parameter defines time for which the converter runs at the valid minimum frequency (P1080 or P1219) after ramping down.
		Range: 0.0 to 20.0 (factory default: 1.0)
P1219[02]	Minimum frequency for motor holding brake [Hz]	This parameter sets the minimum motor frequency at which the motor holding brake (MHB) operates.
		Range: 0.00 to 550.00 (factory default: 0.00)
		Note:
		This parameter is valid only if P1215 = 3 and P1219 < P1080.

### Connecting the motor holding brake

The motor holding brake can be connected to the converter via digital outputs (DO1/DO2). An additional relay is also required to allow the digital output to enable or disable the motor holding brake.



## 

#### Potentially hazardous load

If the converter controls the motor holding brake, then a commissioning may not be carried out for potentially hazardous loads (e.g. suspended loads for crane applications) unless the load has been secured.

It is not permissible to use the motor holding brake as operating brake. The reason for this is that generally it is only designed for a limited number of emergency braking operations.


## 5.6.2.6 Setting the ramp time

## Functionality

The ramp-function generator in the setpoint channel limits the speed of setpoint changes. This causes the motor to accelerate and decelerate more smoothly, thereby protecting the mechanical components of the driven machine.

### Setting ramp-up/down time

- The ramp-up and ramp-down time can be set respectively in P1120 and P1121.
- When the required ramp-up or ramp-down time exceeds the maximum value of P1120 or P1121, you can expand the maximum value by using a scaling factor specified in P1138 or P1139. In this case, calculate the ramp-up or ramp-down time as follows:
  - Ramp-up time = P1120 \* P1138
  - Ramp-down time = P1121 \* P1139




Parameter	Function	Setting
P1082[02]	Maximum frequency [Hz]	This parameter sets maximum motor frequency at which motor will run irrespective of the frequency setpoint.
		Range: 0.00 to 550.00 (factory default: 50.00)
P1120[02]	Ramp-up time [s]	This parameter sets the time taken for motor to accelerate from standstill up to maximum motor frequency (P1082) when no rounding is used.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1121[02]	Ramp-down time [s]	This parameter sets the time taken for motor to decelerate from maximum motor frequency (P1082) down to standstill when no rounding is used.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1138	Ramp-up time scaling factor	This parameter sets the scaling factor for the ramp-up time.
		Range: 1.00 to 10.00 (factory default: 1.00)
P1139	Ramp-down time scaling factor	This parameter sets the scaling factor for the ramp-down time.
		Range: 1.00 to 10.00 (factory default: 1.00)

### Setting ramp-up/down rounding time

Rounding times are recommended, since they prevent an abrupt response, thus avoiding detrimental effects on the mechanics.

Rounding times are not recommended when analog inputs are used, since they would result in overshoot/undershoot in the converter response.




Parameter	Function	Setting
P1130[02]	Ramp-up initial rounding time [s]	This parameter defines rounding time at start of ramp-up. Range: 0.00 to 40.00 (factory default: 0.00)
P1131[02]	Ramp-up final rounding time [s]	This parameter defines rounding time at end of ramp-up. Range: 0.00 to 40.00 (factory default: 0.00)
P1132[02]	Ramp-down initial rounding time [s]	This parameter defines rounding time at start of ramp-down. Range: 0.00 to 40.00 (factory default: 0.00)
P1133[02]	Ramp-down final rounding time [s]	This parameter defines rounding time at end of ramp-down. Range: 0.00 to 40.00 (factory default: 0.00)

## 5.6.2.7 Setting the Imax controller

## Functionality

If ramp-up time is too short, the converter may display the alarm A501 which means the output current is too high. The Imax controller reduces converter current if the output current exceeds the maximum output current limit (r0067). This is achieved by reducing the converter's output frequency or output voltage.



## **Setting parameters**


You only have to change the factory default settings of the Imax controller if the converter tends to oscillate when it reaches the current limit or it is shut down due to overcurrent.

Parameter	Function	Setting
P0305[02]	Rated motor current [A]	This parameter defines the nominal motor current from rating plate.
P0640[02]	Motor overload factor [%]	This parameter defines motor overload current limit relative to P0305 (rated motor current).
P1340[02]	Imax controller proportional gain	This parameter defines the proportional gain of the Imax controller.
		Range: 0.000 to 0.499 (factory default: 0.030)
P1341[02]	Imax controller integral time [s]	This parameter defines the integral time constant of the Imax controller. Setting P1341 to 0 disables the Imax controller.
		Range: 0.000 to 50.000 (factory default: 0.300)
P1345[02]	Imax voltage controller proportional gain	This parameter sets the proportional gain of Imax voltage controller. If the output current (r0068) exceeds the maximum current (r0067), the converter is dynamically controlled by reducing the output voltage.
		Range: 0.000 to 5.499 (factory default: 0.250)
P1346[02]	Imax voltage controller integral time [s]	This parameter defines the integral time constant of the Imax voltage controller.
		Range: 0.000 to 50.000 (factory default: 0.300)
r0056.13	Status of motor control: Imax controller active	

## 5.6.2.8 Setting the Vdc controller

## Functionality

If ramp-down time is too short, the converter may display the alarm A911 which means the DC link voltage is too high. The Vdc controller dynamically controls the DC link voltage to prevent overvoltage trips on high inertia systems.



### **Setting parameters**

Parameter	Function	Setting
P1240[02]	Configuration of Vdc controller	This parameter enables/disables Vdc controller. = 0: Vdc controller disabled = 1: Vdc_max controller enabled (factory default) = 2: Kinetic buffering (Vdc_min controller) enabled = 3: Vdc_max controller and kinetic buffering (KIB) enabled
		<b>Note:</b> This parameter must be set to 0 (Vdc controller disabled) if a braking resistor is used.
P0210	Supply voltage [V]	<ul> <li>This parameter defines the supply voltage. Its default value depends upon the type of converter.</li> <li>Range:</li> <li>380 to 480 (for three phase AC 400 V converters)</li> <li>200 to 240 (for single phase AC 230 V converters)</li> </ul>

## 5.6.2.9 Setting the load torque monitoring function

### Functionality

The load torque monitoring function allows the mechanical force transmission between the motor and driven load to be monitored. This function can detect whether the driven load is blocked, or the force transmission has been interrupted.

The converter monitors the load torque of the motor in different ways:

- Motor blocking detection
- No-load monitoring
- Speed-dependent load torque monitoring

Parameter	Function	Setting
P2177[02]	Delay time for motor is blocked [ms]	Defines the delay time for identifying that the motor is blocked.
		Range: 0 to 10000 (factory default: 10)
P2179	Current limit for no load identified [%]	This parameter defines the threshold current for A922 (no load applied to converter) relative to P0305 (rated motor current).
		Range: 0.0 to 10.0 (factory default: 3.0)
P2180	Delay time for no-load identification	Defines the delay time for detecting a missing output load.
	[ms]	Range: 0 to 10000 (factory default: 2000)
P2181[02]	Load monitoring mode	The load monitoring is achieved by comparing the actual frequency/torque curve with a programmed envelope (defined by parameters P2182 to P2190). If the curve falls outside the envelope, a warning or trip is generated.
		= 0: Load monitoring disabled (factory default)
		= 1: Warning: Low torque/frequency
		= 2: Warning: High torque/frequency
		= 3: Warning: High/low torque/frequency
		= 4: Trip: Low torque/frequency
		= 5: Trip: High torque/frequency
		= 6: Trip: High/low torque/frequency
P2182[02]	Load monitoring threshold frequency 1 [Hz]	Range: 0.00 to 550.00 (factory default: 5.00)
P2183[02]	Load monitoring threshold frequency 2 [Hz]	Range: 0.00 to 550.00 (factory default: 30.00)
P2184[02]	Load monitoring threshold frequency 3 [Hz]	Range: 0.00 to 550.00 (factory default: 30.00)
P2185[02]	Upper torque threshold 1 [Nm]	Range: 0.0 to 99999.0 (factory default: value in r0333)
P2186[02]	Lower torque threshold 1 [Nm]	Range: 0.0 to 99999.0 (factory default: 0.0)
P2187[02]	Upper torque threshold 2 [Nm]	Range: 0.0 to 99999.0 (factory default: value in r0333)
P2188[02]	Lower torque threshold 2 [Nm]	Range: 0.0 to 99999.0 (factory default: 0.0)
P2189[02]	Upper torque threshold 3 [Nm]	Range: 0.0 to 99999.0 (factory default: value in r0333)
P2190[02]	Lower torque threshold 3 [Nm]	Range: 0.0 to 99999.0 (factory default: 0.0)
P2192[02]	Load monitoring delay time [s]	Range: 0 to 65 (factory default: 10)

## 5.6.3 Commissioning advanced functions

## 5.6.3.1 Starting the motor in super torque mode

## Functionality

This startup mode applies a torque pulse for a given time to help start the motor.

## Typical application field

Sticky pumps


Parameter	Function	Setting
P3350[02]	Super torque modes	= 1: Enable super torque mode
		<b>Note:</b> When the value of P3350 is changed, the value of P3353 is changed as follows:
		• P3350 = 2: P3353 = 0.0s
		• P3350 ≠ 2: P3353 = default
		The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use.
P3351[02]	BI: Super torque enable	This parameter defines the source of the super torque enable. The setting is effective when P3352 = 2.
		Factory default: 0 (never enabled)
P3352[02]	Super torque startup mode	This parameter defines when the super torque function becomes active.
		= 0: Enabled on first run after power-up
		= 1: Enabled on every run
		<ul> <li>= 2: Enabled by digital input (enable source is defined by P3351;</li> <li>0 = never enabled, 1 = enabled on every run)</li> </ul>
P3353[02]	Super torque ramp time [s]	This parameter defines the ramp time to be used when ramping up to the super torque frequency.
		Range: 0.0 to 650.0 (factory default: 5.0)
P3354[02]	Super torque frequency [Hz]	This parameter defines the frequency at which the additional boost is applied for super torque mode.
		Range: 0.0 to 550.0 (factory default: 5.0)
P3355[02]	Super torque boost level [%]	This parameter sets the temporary boost level for super torque mode.
		It applies boost in [%] relative to P0305 (rated motor current) once the super torque frequency has been reached for the time specified in P3356.
		Range: 0.0 to 200.0 (factory default: 150.0)
P3356[02]	Super torque boost time [s]	This parameter sets the time for which the additional boost is applied, when the output frequency is held at P3354.
		Range: 0.0 to 20.0 (factory default: 5.0)

## **Function diagram**

Description:

The Super Torque mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramps up to P3354 Hz with the boost level specified by P1310, P1311, and P1312
- Maintains for P3356 s with the boost level specified by P3355
- Reverts boost level to that specified by P1310, P1311, and P1312
- Reverts to "normal" setpoint and allows output to ramp using P1120



## 5.6.3.2 Starting the motor in hammer start mode

## Functionality

This startup mode applies a sequence of torque pulses to start the motor.

## Typical application field

Very sticky pumps


Parameter	Function	Setting
P3350[02]	Super torque modes	= 2: Enable hammer start mode
		<b>Note:</b> When the value of P3350 is changed, the value of P3353 is changed as follows:
		• P3350 = 2: P3353 = 0.0s
		• P3350 ≠ 2: P3353 = default
		The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use.
P3351[02]	BI: Super torque enable	This parameter defines the source of the super torque enable. The setting is effective when $P3352 = 2$ .
		Factory default: 0 (never enabled)
P3352[02]	Super torque startup mode	This parameter defines when the super torque function becomes active.
		= 0: Enabled on first run after power-up
		= 1: Enabled on every run
		= 2: Enabled by digital input (enable source is defined by P3351; 0 = never enabled, 1 = enabled on every run)
P3353[02]	Super torque ramp time [s]	This parameter defines the ramp time to be used when ramping up to the super torque frequency.
		Range: 0.0 to 650.0 (factory default: 5.0)
P3354[02]	Super torque frequency [Hz]	This parameter defines the frequency at which the additional boost is applied for super torque mode.
		Range: 0.0 to 550.0 (factory default: 5.0)
P3357[02]	Hammer start boost level [%]	This parameter sets the temporary boost level for hammer start mode.
		It applies boost in [%] relative to P0305 (rated motor current) once the super torque frequency has been reached for the time specified in P3356.
		Range: 0.0 to 200.0 (factory default: 150.0)
P3358[02]	Number of hammer cycles	This parameter defines the number of times the hammer start boost level is applied.
		Range: 1 to 10 (factory default: 5)
P3359[02]	Hammer on time [ms]	This parameter sets the time for which the additional boost is applied for each repetition (must be at least 3 x motor magnetization time).
		Range: 0 to 1000 (factory default: 300)
P3360[02]	Hammer off Time [ms]	This parameter sets the time for which the additional boost is removed for each repetition (must be at least 3 x motor magnetization time).
		Range: 0 to 1000 (factory default: 100)

## **Function diagram**

Description:

The hammer start mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramp up to P3354 Hz with the boost level specified by P1310, P1311, and P1312
- Revert boost level to that specified by P1310, P1311, and P1312
- Revert to "normal" setpoint and allow output to ramp using P1120



## 5.6.3.3 Starting the motor in blockage clearing mode

## Functionality

This startup mode momentarily reverses the motor rotation to clear a pump blockage.

## Typical application field

Pump clearing


Parameter	Function	Setting
P3350[02]	Super torque modes	= 3: Enable blockage clearing mode
		<b>Note:</b> When the value of P3350 is changed, the value of P3353 is changed as follows:
		• P3350 = 2: P3353 = 0.0s
		<ul> <li>P3350 ≠ 2: P3353 = default</li> </ul>
		The ramp time of 0s gives an additional 'kicking' effect when hammer start is in use.
		If blockage clearing mode is enabled (P3350 = 3), make sure that reverse direction is not inhibited, i.e. P1032 = P1110 = 0.
P3351[02]	BI: Super torque enable	This parameter defines the source of the super torque enable. The setting is effective when $P3352 = 2$ .
		Factory default: 0 (never enabled)
P3352[02]	Super torque startup mode	This parameter defines when the super torque function becomes active.
		= 0: Enabled on first run after power-up
		= 1: Enabled on every run
		= 2: Enabled by digital input (enable source is defined by P3351; 0 = never enabled, 1 = enabled on every run)
P3353[02]	Super torque ramp time [s]	This parameter defines the ramp time to be used when ramping up to the super torque frequency.
		Range: 0.0 to 650.0 (factory default: 5.0)
P3361[02]	Blockage clearing frequency [Hz]	This parameter defines the frequency at which the converter runs in the opposite direction to the setpoint during the blockage clearing reverse sequence.
		Range: 0.0 to 550.0 (factory default: 5.0)
P3362[02]	Blockage clearing reverse time [s]	This parameter sets the time for which the converter runs in the opposite direction to the setpoint during the reverse sequence.
		Range: 0.0 to 20.0 (factory default: 5.0)
P3363[02]	Enable rapid ramp	This parameter selects whether the converter ramps to, or starts directly from, the blockage clearing frequency
		= 0: Disable rapid ramp for blockage clearing (use ramp time specified in P3353)
		= 1: Enable rapid ramp for blockage clearing (jump to the reverse frequency - this introduces a "kicking" effect which helps to clear the blockage)
		Range: 0 to 1 (factory default: 0)
P3364[02]	Number of blockage clearing cycles	This parameter sets the number of times the blockage clearing reversing cycle is repeated.
		Range: 1 to 10 (factory default: 1)

## **Function diagram**

Description:

The blockage clearing mode is enabled when an ON command is issued, and the following sequence is performed:

- Ramp or step (depending on P3363) to P3361 Hz in opposite direction to the setpoint
- For P3364 repetitions:
  - Ramp down to 0 Hz using normal ramp time as specified in P1121
  - Ramp or step (depending on P3363) to P3361 Hz in opposite direction to the setpoint
- Revert to "normal" setpoint and allow output to ramp using P1120.



## 5.6.3.4 Running the converter in economy mode

### Functionality

Economy mode works by slightly changing the output voltage either up or down in order to find the minimum input power.

#### Note

The economy mode optimization is only active when operating at the requested frequency setpoint. The optimization algorithm becomes active 5 seconds after the setpoint has been reached, and is disabled on a setpoint change or if the  $I_{max}$  or  $V_{max}$  controller is active.


### **Typical applications**

Motors with stable or slowly changing loads

### Setting parameters

Parameter	Function	Setting
P1300[02]	Control mode	= 4: V/f Eco Mode with linear characteristic
		= 7: V/f Eco Mode with quadratic characteristic
r1348	Economy mode factor [%]	This parameter displays the calculated economy mode factor (range: 80% to 120%) applied to the demanded output voltage.
		If this value is too low, the system may become unstable.

### **Function diagram**



## 5.6.3.5 Setting the UL61800-5-1-compliant motor overtemperature protection

## Functionality

The function protects the motor from overtemperature. The function defines the reaction of the converter when motor temperature reaches warning threshold. The converter can remember the current motor temperature on power-down and reacts on the next power-up based on the setting in P0610. Setting any value in P0610 other than 0 or 4 will cause the converter to trip (F11) if the motor temperature is 10% above the warning threshold P0604.

#### Note

In order to comply with UL61800-5-1, parameter P0610 must not be changed from its factory setting of 6.

Parameter	Function	Setting
P0610[02]	Motor I <sup>2</sup> t temperature reaction	This parameter defines reaction when motor temperature reaches warning threshold.
		Settings 0 to 2 do not recall the motors temperature (stored at power-down) on power-up:
		= 0: Warning only
		= 1: Warning with Imax control (motor current reduced) and trip (F11)
		= 2: Warning and trip (F11)
		Settings 4 to 6 recall the motors temperature (stored at power- down) on power-up:
		= 4: Warning only
		= 5: Warning with Imax control (motor current reduced) and trip (F11)
		= 6: Warning and trip (F11)


### 5.6.3.6 Motor protection with PTC sensor

#### Functionality

The converter uses a PTC sensor to protect the motor against overtemperature. The converter interprets a resistance > approximately 1500 Ohm as being an overtemperature and responds according to the setting for P0610.

#### **EMC**-compliant installation

You must fit the PTC sensor to the motor and then connect it to the converter control terminals as shown below:



#### Note

To enable the trip function, set one of the digital inputs using DI1 (P0701), DI2 (P0702), DI3 (P0703), or DI4 (P0704) to 29 (external trip).

To achieve EMC-compliant installation, take the following actions when connecting the PTC sensor:

- Terminate the ends of the cable neatly, ensuring that the unshielded wires are as short as possible.
- Separate the sensor cable from the power cables as much as possible, using separate trunking. Cross them if necessary at 90° to each other.
- Use shielded or armored cables for the motor connections and ground the cable shields at both ends using the cable clamps.

## **Cable lengths**

As long as the above mentioned instructions are observed, PTC cables of several hundred meters can be used. For longer cables, increase the conductor cross-section to avoid measurement errors. For more information about the V20 signal cable cross-section and user terminals, see Section "Terminal description (Page 45)".


Parameter	Function	Setting
P0610[02]	Motor I <sup>2</sup> t temperature reaction	This parameter defines reaction when motor temperature reaches warning threshold.
		Settings 0 to 2 do not recall the motors temperature (stored at power-down) on power-up:
		= 0: Warning only
		= 1: Warning with Imax control (motor current reduced) and trip (F11)
		= 2: Warning and trip (F11)
		Settings 4 to 6 recall the motors temperature (stored at power- down) on power-up:
		= 4: Warning only
		= 5: Warning with Imax control (motor current reduced) and trip (F11)
		= 6: Warning and trip (F11)

## 5.6.3.7 Setting the free function blocks (FFBs)

## Functionality

Additional signal interconnections in the converter can be established by means of the free function blocks (FFBs). Every digital and analog signal available via BICO technology can be routed to the appropriate inputs of the free function blocks. The outputs of the free function blocks are also interconnected to other functions using BICO technology.

### Example



### **Setting parameters**

Parameter	Function	Setting	
P0702	Function of digital input 2	= 99: Enable BICO paran	neterization for digital input 2
P0703	Function of digital input 3	= 99: Enable BICO param	neterization for digital input 3
P2800	Enable FFBs	= 1: Enable (general ena	able for all free function blocks)
P2801[0]	Activate FFBs	= 1: Enable AND 1	
P2810[0]	BI: AND 1	= 722.1 P2810[0	] and P2810[1] define inputs of AND 1
P2810[1]		= 722.2 element	, and output is r2811.0.
P0731	BI: Function of digital output 1	This parameter defines source of digital output 1.	
		= r2811.0: Use the AND	(DI2, DI3) to switch on LED


For more information about FFBs and additional settings of individual parameter, see Chapter "Parameter list (Page 201)".

## 5.6.3.8 Setting the flying start function

## Functionality

The flying start function (enabled using P1200) allows the converter to be switched onto a motor which is still spinning by rapidly changing the output frequency of the converter until the actual motor speed has been found. Then, the motor runs up to setpoint using the normal ramp time.

Flying start must be used in cases where the motor may still be turning (e.g. after a short mains break) or can be driven by the load. Otherwise, overcurrent trips will occur.



Parameter	Function	Setting
P1200	Flying start	Settings 1 to 3 search in both directions:
		= 0: Flying start disabled
		= 1: Flying start always active
		= 2: Flying start active after power on, fault, OFF2
		= 3: Flying start active after fault, OFF2
		Settings 4 to 6 search only in the direction of the setpoint:
		= 4: Flying start always active
		= 5: Flying start active after power on, fault, OFF2
		= 6: Flying start active after fault, OFF2
P1202[02]	Motor-current: flying start [%]	This parameter defines search current used for flying start.
		Range: 10 to 200 (factory default: 100)
		<b>Note:</b> Search current settings in P1202 that are below 30% (and sometimes other settings in P1202 and P1203) may cause motor speed to be found prematurely or too late, which can result in F1 or F2 trips.
P1203[02]	Search rate: flying start [%]	This parameter sets factor (in V/f mode only) by which the output frequency changes during flying start to synchronize with turning motor.
		Range: 10 to 500 (factory default: 100)
		<b>Note:</b> A higher value produces a flatter gradient and thus a longer search time. A lower value has the opposite effect.

## 5.6.3.9 Setting the automatic restart function

### Functionality

After a power failure (F3 "Undervoltage"), the automatic restart function (enabled using P1210) automatically switches on the motor if an ON command is active. Any faults are automatically acknowledged by the converter.

When it comes to power failures (line supply failure), then a differentiation is made between the following conditions:


- "Line undervoltage (mains brownout)" is a situation where the line supply is interrupted and returns before the built-in BOP display has gone dark (this is an extremely short line supply interruption where the DC link hasn't completely collapsed).
- "Line failure (mains blackout)" is a situation where the built-in BOP display has gone dark (this represents a longer line supply interruption where the DC link has completely collapsed) before the line supply returns.

Parameter	Function	Setting	
P1210	Automatic restart	This parameter configures automatic restart function.	
		= 0: Disabled	
		= 1: Trip reset after power on, P1211 disabled	
		= 2: Restart after mains blackout, P1211 disabled	
		= 3: Restart after mains brownout or fault, P1211 enabled	
		= 4: Restart after mains brownout, P1211 enabled	
		= 5: Restart after mains blackout and fault, P1211 disabled	
		= 6: Restart after mains brown- /blackout or fault, P1211 enabled	
		= 7: Restart after mains brown- /blackout or fault, trip when P1211 expires	
		= 8: Restart after mains brown- /blackout with F3 and leave an interval in seconds determined by P1214, P1211 disabled	
		= 9: Restart after mains brown- /blackout with F3 during the attempt time determined by P1214, P1211 disabled	
		= 10: Restart after mains brown- /blackout with F3 during the attempt time determined by P1214 or manual fault acknowledgement, P1211 disabled	
		= 11: Trip reset at power on after mains brown-/blackout with F3 and if no ON command is active; P1211 disabled	
P1211	Number of restart attempts	This parameter specifies number of times converter will attempt to restart if automatic restart P1210 is activated.	
		Range: 0 to 10 (factory default: 3)	
P1214	Restart time interval	This parameter has either of the following functions:	
		• Specifying the restart interval when P1210 = 8	
		• Specifying the total restart attempt time when P1210 = 9 or P1210 = 10	
		Range: 0 to 1000 (factory default: 30)	

## 5.6.3.10 Running the converter in frost protection mode

## Functionality

If the surrounding temperature falls below a given threshold, motor turns automatically to prevent freezing.




- OFF1/OFF3: The frost protection function is disabled when OFF3 is activated and enabled again when OFF1 is activated.
- OFF2/fault: The motor stops and the frost protection is deactivated.

Parameter	Function	Setting
P3852[02]	BI: Enable frost protection	This parameter defines command source of protection enable command. If binary input is equal to one, then protection will be initiated (factory default: 0).
		If P3853 $\neq$ 0, frost protection is applied by applying the given frequency to the motor.
		Note that the protection function may be overridden under the following circumstances:
		<ul> <li>If converter is running and protection signal becomes active, signal is ignored</li> </ul>
		<ul> <li>If converter is turning motor due to active protection signal and a RUN command is received, RUN command overrides frost signal</li> </ul>
		• Issuing an OFF command while protection is active will stop the motor
P3853[02]	Frost protection frequency [Hz]	This parameter specifies the frequency applied to the motor when frost protection is active.
		Range: 0.00 to 550.00 (factory default: 5.00)

## 5.6.3.11 Running the converter in condensation protection mode

## Functionality

If an external condensation sensor detects excessive condensation, the converter applies a DC current to keep the motor warm to prevent condensation.



- OFF1/OFF3: The condensation protection function is disabled when OFF3 is activated and enabled again when OFF1 is activated.
- OFF2/fault: The motor stops and the condensation protection is deactivated.

Parameter	Function	Setting
P3852[02]	BI: Enable frost protection	This parameter defines command source of protection enable command. If binary input is equal to one, then protection will be initiated (factory default: 0).
		If P3853 = 0 and P3854 $\neq$ 0, condensation protection is applied by applying the given current to the motor.
		Note that the protection function may be overridden under the following circumstances:
		<ul> <li>If converter is running and protection signal becomes active, signal is ignored</li> </ul>
		• If converter is turning motor due to active protection signal and a RUN command is received, RUN command overrides frost signal
		• Issuing an OFF command while protection is active will stop the motor
P3854[02]	Condensation protection current [%]	This parameter specifies the DC current (as a percentage of nominal current) which is applied to the motor when condensation protection is active.
		Range: 0 to 250 (factory default: 100)


## 5.6.3.12 Running the converter in hibernation mode

## Functionality


To achieve energy-saving operation, you can enable the converter to run in either frequency hibernation (P2365 = 1) or PID hibernation (P2365 = 2).

• Frequency hibernation: When the demand frequency falls below the minimum frequency (P1080), the OFF delay (P2366) is started. When the OFF delay expires, the converter is ramped down to stop and enters the hibernation mode. The converter has to go through the ON delay (P2367) before restarting.

P2365 = 1



• PID hibernation: When the converter under PID control drops below the PID hibernation setpoint (P2390), the PID hibernation timer (P2391) is started. When the timer expires, the converter is ramped down to stop and enters the hibernation mode. The converter restarts when it reaches the PID hibernation restart point (P2392).




Parameter	Function	Setting
P2365[02]	Hibernation enable/disable	Select or disable the hibernation functionality.
		= 0: Disabled
		= 1: Frequency hibernation (the frequency setpoint as the wakeup trigger)
		= 2: PID hibernation (the PID error as the wakeup trigger)
		Range: 0 to 2 (factory default: 0)
P2366[02]	Delay before stopping motor [s]	With hibernation enabled, this parameter defines the delay before activating the hibernation mode of the converter.
		Range: 0 to 254 (factory default: 5)
P2367[02]	Delay before starting motor [s]	With hibernation enabled, this parameter defines the delay before "waking up" (disabling) the hibernation mode of the converter.
		Range: 0 to 254 (factory default: 2)
P2390	PID hibernation setpoint [%]	The PID hibernation setpoint P2390 is a percentage of the rated motor frequency P0310.
		When the value of P2365 is set to 2 and the converter under PID control drops below the PID hibernation setpoint, the PID hibernation timer P2391 is started. When the PID hibernation timer has expired, the converter is ramped down to stop and enters the PID hibernation mode.
		Range: -200.00 to 200.00 (factory default: 0)
P2391	PID hibernation timer [s]	When the PID hibernation timer P2391 has expired, the converter is ramped down to stop and enters the PID hibernation mode.
		Range: 0 to 254 (factory default: 0)
P2392	PID hibernation restart setpoint [%]	While in the PID hibernation mode, the PID controller continues to generate the error r2273. Once this reaches the restart point P2392, the converter immediately ramps to the setpoint calculated by the PID controller.
		Range: -200.00 to 200.00 (factory default: 0)
r2399	CO/BO: PID hibernation status word	Displays the PID hibernation status word.
		Bit 00: Not used
		Bit 01: PID hibernation enabled (The PID hibernation mode is enabled and the converter is not in the mode.)
		Bit 02: Hibernation active (The PID hibernation mode is enabled and the converter is in the mode.)
		Factory default: 0
P1080[02]	Minimum frequency [Hz]	Sets minimum motor frequency at which motor will run irrespective of frequency setpoint. Value set here is valid both for clockwise and for counterclockwise rotation.
		Range: 0.00 to 550.00 (factory default: 0.00)

## 5.6.3.13 Setting the wobble generator

### Functionality

The wobble generator executes predefined periodical disruptions superimposed on the main setpoint for technological usage in the fiber industry. The wobble function can be activated via P2940. It is independent of the setpoint direction, thus only the absolute value of the setpoint is relevant. The wobble signal is added to the main setpoint as an additional setpoint. During the change of the setpoint the wobble function is inactive. The wobble signal is also limited by the maximum frequency (P1082).




Wobble function disturb signal

Parameter	Function	Setting
P2940	BI: Release wobble function	This parameter defines the source to release the wobble function. Factory default: 0.0
P2945	Wobble signal frequency [Hz]	This parameter sets the frequency of the wobble signal. Range: 0.001 to 10.000 (factory default: 1.000)
P2946	Wobble signal amplitude [%]	This parameter sets the value for the amplitude of the wobble-signal as a proportion of the present ramp function generator (RFG) output.
		Range: 0.000 to 0.200 (factory default: 0.000)
P2947	Wobble signal decrement step	This parameter sets the value for decrement step at the end of the positive signal period.
		Range: 0.000 to 1.000 (factory default: 0.000)
P2948	Wobble signal increment step	This parameter sets the value for the increment step at the end of the negative signal period.
		Range: 0.000 to 1.000 (factory default: 0.000)
P2949	Wobble signal pulse width [%]	This parameter sets the relative widths of the rising and falling pulses.
		Range: 0 to 100 (factory default: 50)


## 5.6.3.14 Running the converter in motor staging mode

## Functionality

Motor staging allows the control of up to 2 additional staged pumps or fans, based on a PID control system. The complete system consists of one pump controlled by the converter and up to 2 further pumps/fans controlled from contactors or motor starters. The contactors or motor starter are controlled by digital outputs from the converter.



The diagram below shows a typical pumping system.




Parameter	Function	Setting
P2370[02]	Motor staging stop mode	This parameter selects stop mode for external motors when motor staging is in use. = 0: Normal stop (factory default)
		= 1: Sequence stop
P2371[02]	Motor staging configuration	This parameter selects configuration of external motors (M1, M2) used for motor staging feature.
		= 0: Motor staging disabled
		= 1: M1 = 1 x MV, M2 = Not fitted
		= 2: M1 = 1 x MV, M2 = 1 x MV
		= 3: M1 = 1 x MV, M2 = 2 x MV
P2372[02]	Motor staging cycling	This parameter enables motor cycling for the motor staging feature.
		= 0: Disabled (factory default)
		= 1: Enabled
P2373[02]	Motor staging hysteresis [%]	P2373 as a percentage of PID setpoint that PID error r2273 must be exceeded before staging delay starts.
		Range: 0.0 to 200.0 (factory default: 20.0)
P2374[02]	Motor staging delay [s]	This parameter defines the time that PID error r2273 must exceed motor staging hysteresis P2373 before staging occurs.
		Range: 0 to 650 (factory default: 30)
P2375[02]	Motor destaging delay [s]	This parameter defines the time that PID error r2273 must exceed motor staging hysteresis P2373 before destaging occurs.
		Range: 0 to 650 (factory default: 30)
P2376[02]	Motor staging delay override [%]	P2376 as a percentage of PID setpoint. When the PID error r2273 exceeds this value, a motor is staged/destaged irrespective of the delay timers.
		Range: 0.0 to 200.0 (factory default: 25.0)
		<b>Note:</b> The value of this parameter must always be larger than staging hysteresis P2373.
P2377[02]	Motor staging lockout timer [s]	This parameter defines the time for which delay override is prevented after a motor has been staged or destaged.
		Range: 0 to 650 (factory default: 30)
P2378[02]	Motor staging frequency f_st [%]	This parameter sets the frequency at which the digital output is switched during a (de) staging event, as the converter ramps from maximum to minimum frequency (or vice versa).
		Range: 0.0 to 120.0 (factory default: 50.0)
r2379.01	CO/BO: Motor staging status word	This parameter displays output word from the motor staging feature that allows external connections to be made.
		Bit 00: Start motor 1 (yes for 1, no for 0)
		Bit 01: Start motor 2 (yes for 1, no for 0)
P2380[02]	Motor staging hours run [h]	This parameter displays hours run for external motors.
		Index:
		[0]: Motor 1 hrs run
		[1]: Motor 2 hrs run
		[2]: Not used
		Range: 0.0 to 4294967295 (factory default: 0.0)

## 5.6.3.15 Running the converter in cavitation protection mode

### Functionality

Cavitation occurs when air bubbles are generated around the surface of the impeller, resulting in pump damage, unexpected noise, and decreased flow or pressure of the pipe system. The cavitation protection will generate a fault/warning when cavitation conditions are deemed to be present. If the converter gets no feedback from the pump transducer, it will trip to prevent cavitation damage. This function saves the maintenance efforts and extends the lifetime expectancy.



**Cavitation Protection Logic Diagram** 

Parameter	Function	Setting
P2360[02]	Enable cavitation protection	This parameter enables the cavitation protection function.
		= 1: Fault
		= 2: Warn
P2361[02]	Cavitation threshold [%]	This parameter defines the feedback threshold over which a fault/warning is triggered, as a percentage (%).
		Range: 0.00 to 200.00 (factory default: 40.00)
P2362[02]	Cavitation protection time [s]	This parameter sets the time for which cavitation conditions have to be present before a fault/warning is triggered.
		Range: 0 to 65000 (factory default: 30)

## 5.6.3.16 Setting the user default parameter set

## Functionality

The user default parameter set allows a modified set of defaults, different from the factory defaults, to be stored. Following a parameter reset these modified default values would be used. An additional factory reset mode would be required to erase the user default values and restore the converter to factory default parameter set.

## Creating the user default parameter set

- 1. Parameterize the converter as required.
- 2. Set P0971 = 21, and the current converter state is now stored as the user default.

## Modifying the user default parameter set

- 1. Return the converter to the default state by setting P0010 = 30 and P0970 = 1. The converter is now in the user default state if configured; otherwise the conveter is in factory default state.
- 2. Parameterize the converter as required.
- 3. Set P0971 = 21 to store current state as the user default.

Parameter	Function	Setting
P0010	Commissioning parameter	This parameter filters parameters so that only those related to a particular functional group are selected. It must be set to 30 in order to store or delete user defaults.
		= 30: Factory setting
P0970	Factory reset	This parameter resets all parameters to their user default/factory default values.
		= 1: Resets all parameters (not user defaults) to user defaults if they have been previously stored with P0971 = 21; otherwise, resets all parameters to factory defaults
		<ul> <li>= 21: Resets all parameters and user defaults to factory defaults</li> </ul>
		= 31: Special factory reset. Resets all user defaults in EEPROM to factory defaults. The converter will then restart.
P0971	Transfer data from RAM to EEPROM	This parameter transfers values from RAM to EEPROM.
		= 1: Start transfer
		= 21: Start transfer and store parameter changes as user default values

### Setting parameters

For information about restoring the converter to factory defaults, refer to Section "Restoring to defaults (Page 145)".

## 5.6.3.17 Setting the dual ramp function

### Functionality


The dual ramp function allows the user to parameterize the converter so that it can switch from one ramp rate to another when ramping up or down to a setpoint. This may be useful for delicate loads, where starting to ramp with a fast ramp-up or ramp-down time may cause damage. The function works as follows:

#### Ramp up:

- Converter starts ramp-up using ramp time from P1120
- When f\_act > P2157, switch to ramp time from P1060

### Ramp down:

- Converter starts ramp-down using ramp time from P1061
- When f\_act < P2159, switch to ramp time from P1121



Note that the dual ramp algorithm uses r2198 bits 1 and 2 to determine (f\_act > P2157) and (f\_act < P2159).

Parameter	Function	Setting
P1175[02]	BI: Dual ramp enable	This parameter defines command source of dual ramp enable command. If binary input is equal to one, then the dual ramp will be applied. The factory default value is 0.
P1060[02]	JOG ramp-up time [s]	This parameter sets the JOG ramp-up time.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1061[02]	JOG ramp-down time [s]	This parameter sets the JOG ramp-down time.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1120[02]	Ramp-up time [s]	This parameter sets the time taken for motor to accelerate from standstill up to maximum frequency (P1082) when no rounding is used.
		Range: 0.00 to 650.00 (factory default: 10.00)
P1121[02]	Ramp-down time [s]	This parameter sets the time taken for motor to decelerate from maximum frequency (P1082) down to standstill when no rounding is used.
		Range: 0.00 to 650.00 (factory default: 10.00)
P2157[02]	Threshold frequency f_2 [Hz]	This parameter defines threshold_2 for comparing speed or frequency to thresholds.
		Range: 0.00 to 550.00 (factory default: 30.00)
P2159[02]	Threshold frequency f_3 [Hz]	This parameter defines threshold_3 for comparing speed or frequency to thresholds.
		Range: 0.00 to 550.00 (factory default: 30.00)

### **Setting parameters**

### 5.6.3.18 Setting the DC coupling function

### Functionality


The SINAMICS V20 converter provides the facility to electrically couple two equal-size converters together by using the DC link connections. The key benefits of this connection are:

- Reducing energy costs by using regenerative energy from one converter as driving energy in the second converter.
- Reducing installation costs by allowing the converters to share one common dynamic braking module when needed.
- In some applications, eliminating the need for the dynamic braking module.

In the most common application, shown in the following figure, linking two SINAMICS V20 converters of equal size and rating allows the energy from one converter, presently decelerating a load, to be fed into the second converter across the DC link. This requires less energy to be sourced from the mains supply. In this scenario, the total electricity consumption is reduced.

## **Connection for DC coupling**

The following figure illustrates the system connection using DC coupling.



PE = Protective Earth

See Section "Terminal description (Page 45)" for the recommended cable cross-sections and screw tightening torques.

See the Product Information of Protective Devices for SINAMICS V20 Converter (https://support.industry.siemens.com/cs/ww/en/view/109799776) for the recommended fuse types.

#### WARNING Т

#### Destruction of converter

It is extremely important to ensure that the polarity of the DC link connections between the converters is correct. If the polarity of the DC terminals' connections is reversed, it could result in the destruction of the converter.

5.6 Function commissioning

## 

#### Safety awareness

The coupled SINAMICS V20 converters must both be of equal power and supply voltage rating.

The coupled converters must be connected to the mains supply through a single contactor and fuse arrangement rated for a single converter of the type in use.

A maximum of two SINAMICS V20 converters can be linked using the DC coupling methodology.

#### NOTICE

#### Integrated braking module

The integrated braking module within the frame size D and E converters is only active if the converter receives an ON command and is actually running. When the converter is powered down, the regenerative energy cannot be pulsed to the external braking resistor.

#### Limitations and restrictions

- The maximum length of the coupling cable is 3 meters.
- For the converters of frame sizes AA to C, if a dynamic braking module is to be used, an additional connector with a current rating the same as the supply cable to one converter must be used to connect the dynamic braking module wires to DC+ and DC- since the converter terminals may not support an additional connection.
- The cable rating to the dynamic braking module needs to be at least 9.5 A for a 5.5 kW full power rating (as measured using a minimum resistor value of 56  $\Omega$ ). Screened cable should be used.
- For the converters of frame size D and E for three phase, the dynamic braking circuit is self-contained and only one external braking resistor has to be attached to one of the converters. Refer to Appendix "Braking resistor (Page 380)" for the selection of an appropriate braking resistor.
- The compound braking must never be activated.

#### Note

#### Performance and potential energy savings

The performance and potential energy savings using the DC coupling function is highly dependent on the specific application. Therefore, Siemens makes no claim regarding the performance and energy saving potential of the DC coupling methodology.

#### Note

#### Standards and EMC disclaimers

The DC coupling configuration with the SINAMICS V20 converters is not certified for use in UL/cUL applications.

No claims are made regarding the EMC performance of this configuration.

#### See also

Typical system connections (Page 41)

5.6 Function commissioning

## 5.6.3.19 Setting high/low overload (HO/LO) mode

## Functionality

Setting HO/LO overload enables you to select the low-overload mode for pumps and fans, the most important target applications of SINAMICS V20 converters. Low-overload mode can improve the rated output current of the converter and therefore allows the converter to drive motors of higher power.

Torque	$M \sim \frac{1}{f}$	M = const.	M ~ f	M ~f <sup>2</sup>
Power	p = const.	p ~ f	p ~ f <sup>2</sup>	p~f <sup>3</sup>
Characteristic	P M f	M P	M /	M p f
Application	Winders Facing lathes Rotary cutting machines	Hoisting gear Belt conveyors Process machines involving forming Rolling mills Planers Compressors	Calenders with viscous friction Eddy-current brakes	Pumps Fans Centrifuges

### Typical application fields

- High overload: conveyors, agitators and centrifuges
- Low overload: pumps and fans

### **Power ratings**

Rated power rating (HO mode)	18.5 kW	22 kW
Rated power rating (LO mode)	22 kW	30 kW

Taking the 22 kW SINAMICS converter as an example, when HO mode is selected, it means the rated power rating is 22 kW; when LO mode is selected, the rated power rating is changed to 30 kW.

• HO mode

Overload capability: 150% of the rated output current for 60 s Cycle time: 300 s


• LO mode:

Overload capability: 110% of the rated output current for 60 s Cycle time: 300 s

## Setting parameter

Parameter	Function	Setting
P0205	Select converter applications	This parameter selects the converter applications on high overload and low overload: =0: high overload
		=1: low overload

## Function diagram



# 5.7 Restoring to defaults

## Restoring to factory defaults

Parameter	Function	Setting
P0003	User access level	= 1 (standard user access level)
P0010	Commissioning parameter	= 30 (factory setting)
P0970	Factory reset	= 21: Resets all parameters and user defaults to factory defaults
		= 31: Special factory reset. Resets all user defaults in EEPROM to factory defaults. The converter will then restart. (Note that this value setting is used only as one remedy for clearing the fault F51.)

## Restoring to user defaults

Parameter	Function	Setting
P0003	User access level	= 1 (standard user access level)
P0010	Commissioning parameter	= 30 (factory setting)
P0970	Factory reset	= 1: Resets all parameters (not user defaults) to user defaults if they have been previously stored with P0971 = 21; otherwise, resets all parameters to factory defaults

After setting the parameter P0970, the converter displays "8 8 8 8 8" and then the screen shows "P0970". P0970 and P0010 are automatically reset to their original value 0.

5.7 Restoring to defaults

Using the optional SINAMICS V20 Smart Access (Page 412) to commission the converter provides you with a smart commissioning solution.


SINAMICS V20 Smart Access is a Web server module with integrated Wi-Fi connectivity. It allows Web-based access to the converter from a connected device (conventional PC with wireless network adapter installed, tablet or smart phone).

With SINAMICS V20 Smart Access, you can easily perform the following operations via Web access to the converter:

- Quick converter commissioning (Page 158)
- Converter parameterization (Page 163)
- Motor operation in JOG/HAND mode (Page 168)
- Converter status monitoring (Page 171)
- Fault/alarm diagnostics (Page 171)
- Data backup and restore (Page 174)

#### Note

To avoid any unauthorized Web access, use the SINAMICS V20 Smart Access with the converter only when you perform the Web-based converter commissioning.



#### Note

To use SINAMICS V20 Smart Access to control the converter, the supported converter firmware version must be 3.93 or later.

#### Firmware versions for downloading

You can find the latest firmware versions of the V20 converter and the V20 Smart Access on the Internet below:

Firmware downloading (https://support.industry.siemens.com/cs/ww/en/ps/13208/pm)

6.1 System requirements

# 6.1 System requirements

Device with wireless network adapter installed	Operating system	Recommended Web browser <sup>1)</sup>
PC	Windows 7	<ul> <li>Google Chrome version 62.0 or later</li> <li>Firefox version 53.0 or later</li> <li>Internet Explorer version 11.0 or later</li> </ul>
	Windows 10	<ul> <li>Google Chrome version 62.0 or later</li> <li>Firefox version 53.0 or later</li> <li>Internet Explorer version 11.0 or later</li> <li>Edge version 42.0 or later</li> </ul>
	Mac OS 10.12.4 or later	<ul><li>Google Chrome version 75.0 or later</li><li>Safari</li></ul>
Smart phone/tablet	Apple iOS 12.2 or later	<ul> <li>Google Chrome version 73.0 or later</li> <li>Firefox version 16.0 or later</li> <li>Safari</li> </ul>
	Android 8.0 or later	<ul><li>Google Chrome version 70.0 or later</li><li>Firefox version 67.0 or later</li></ul>

<sup>1)</sup> Siemens recommends that you use the Web browsers listed above to achieve optimum Web browsing performance.

### Supported minimum resolution

SINAMICS V20 Smart Access displays the pages in a format and size compatible with the device you use to access the Web pages. It supports a minimum resolution of 320 x 480 pixels.

# 6.2 Accessing the SINAMICS V20 Web pages

You can access the SINAMICS V20 Web pages from a PC or a mobile device that connects to the SINAMICS V20 Smart Access.


#### Note

Fitting SINAMICS V20 Smart Access to the converter is required only when you desire to make Web-based access to the converter from your PC or mobile device.

## 6.2.1 Overview of the steps

- 1. Fitting SINAMICS V20 Smart Access to the converter (Page 149)
- 2. Establishing the wireless network connection (Page 150)
- 3. Accessing the Web pages (Page 152)

## 6.2.2 Fitting SINAMICS V20 Smart Access to the converter



Recommended tightening torque: 0.8 Nm ± 10%

## NOTICE

#### Damage to module due to improper installing or removing

Installing or removing SINAMICS V20 Smart Access when its power switch is in the "ON" position can cause damage to the module.

Make sure that you slide the power switch to "OFF" before installing/removing the module.

### NOTICE

#### Equipment malfunctions due to improper installing or removing

Installing or removing the SINAMICS V20 Smart Access when the V20 converter is in poweron state can cause malfunctions of the SINAMICS V20 Smart Access.

• Make sure that the V20 converter is powered off before installing or removing the SINAMICS V20 Smart Access.

#### Note

To reduce human exposure to radio frequency electromagnetic fields, maintain a minimum distance of 2.5 cm between your body and the SINAMICS V20 Smart Access when it is operational.

## 6.2.3 Establishing the wireless network connection

## NOTICE

#### Equipment malfunctions as a result of unauthorized access to the converter

Hacker attack can result in unauthorized access to the converter through the SINAMICS V20 Smart Access. This can cause equipment malfunctions.

- Before logging on to the V20 Web pages, make sure that there is no network security risk.
  - If the status LED lights up green or flashes green, make sure that no unauthorized access to the converter exists.
  - If an unauthorized access to the converter does exist, switch off the power switch on SINAMICS V20 Smart Access and then switch it on again to restart the wireless network connection.

#### Establishing initial wireless network connection

- 1. After you have fitted the SINAMICS V20 Smart Access (Page 412) to the converter, power on the SINAMICS V20 Smart Access by sliding its switch to the "ON" position.
- 2. Activate the Wi-Fi interface inside your PC or mobile device. If you desire to establish the wireless network connection on your PC, make sure that you have previously activated the automatic IP settings.
- 3. Search the wireless network SSID of SINAMICS V20 Smart Access: V20 smart access\_xxxxx ("xxxxxx" stands for the last six characters of the MAC address of SINAMICS V20 Smart Access)
- 4. Enter the wireless network password to launch the connection (default password: 12345678).

You can configure your own Wi-Fi name and channel. For more information, see Section "Configuring Wi-Fi (Page 155)".

5. Enter the SINAMICS V20 Web site (http://192.168.1.1) in the supported browser.

6. After the Web page for password change opens, enter a new password.

To achieve better network access security, enter a new password of 8 to 12 characters that consists all of the following three categories of password characters: ① letters: A-Z, a-z; ② numbers: 0-9; ③ special characters: \_, -, ~, !, @, #, \$, %, ^, &, and \*, and the space character is not allowed.

Note that this password change page includes a security level indicator. This indicator uses different colors to indicate the security strength of your current password. For more information, see the table below:

New password:	Password security level	Description
8-12 letters, numbers, symbols Security: -	Low	Password that consists of only one category of characters
ок	Medium	Password that consists of two categories of characters
To display/hide the password, click 🐨.	High	Password that consists of three categories of characters

After your confirmation of the new password entry, the module restarts automatically.

7. Select the wireless network SSID of the SINAMICS V20 Smart Access and then enter the new Wi-Fi password to launch the connection.

Currently connected to: 4 A	V20 smart access_a4d3eL Wireless Network Properties
Wireless Network Connection	Security type: WPA2-Personal
V20 smart acces_s4d3e1	Network security jey Adjvanced settings

8. Enter the SINAMICS V20 Web site (http://192.168.1.1) to open the home page.

### Wireless network connection examples

#### Prerequisite

Make sure that your device is wireless-enabled.

For Windows 7/Windows 10	For Android and iOS (on tablets/smart phones)
For Windows 7/Windows 10  1. Click on the taskbar on your PC.  2. Select the target network and enter the wireless password to launch the connection.  Not connected  Connections are available  Wireless Network Connection  SWSGP01  V20Web_XHL  ESP_APP_Test V20 smart access a4d3e1	For Android and iOS (on tablets/smart phones) Go to the Wi-Fi settings window on your tablet or smart phone, select the target network and enter the wireless password to launch the connection.
Connect automatically Connect LieBaoWiFi738	Scar Advand

### 6.2.4 Accessing the Web pages


If you have previously established the wireless network connection (Page 150) between your PC or mobile device and the converter via the SINAMICS V20 Smart Access, open a supported Web browser (Page 148) from your PC or mobile device and then enter the Web site (http://192.168.1.1) to open the SINAMICS V20 Web page (home page).

#### Constraint

Some features of SINAMICS V20 Smart Access are restricted if you do not observe the following:

- The standard Web pages use JavaScript. If your Web browser settings have disabled JavaScript, enable it first.
- When accessing the V20 Web pages from a mobile device, do not use landscape mode.

6.3 Overview of the Web pages



# 6.3 Overview of the Web pages

- ① Connection status indication (Page 154)
- ② Fault/alarm indication (Page 171)
- ③ Quick commissioning wizard (Page 158)
- ④ Parameter settings (Page 163)
- (5) Motor test run in JOG/HAND mode (Page 168)
- 6 Converter status monitoring (Page 171)
- ⑦ Diagnostics (Page 171) (faults, alarms, I/O status)
- (8) Data backup & restore (Page 174)
- (9) Navigation sidebar (visible only on lower-level pages)
- <sup>(10)</sup> Advancing backward (visible only on lower-level pages)
- ① Optional Web access settings (Page 155) (Wi-Fi configuration, user interface language settings, time synchronization, and upgrade)
- Converter identification data (Page 154)
- (13 Support information (Page 181)

#### Note

The Web page illustrations from this chapter forward represent only the standard PC Web page appearance.

6.4 Viewing connection status

# 6.4 Viewing connection status

You can view the connection status in the upper-left corner of the V20 Web pages. The connection status is updated every 1.5 seconds.

lcon	Status	Description
	Connected	Communication between the PC/mobile device and the converter is established.
		Note that the green status icon indicates one of the following actual converter statuses (see r0002):
		Commissioning mode
		Converter ready
		Converter fault active
		Converter starting
		Converter running
		Converter stopping
		Converter inhibited
0	Disconnected	Communication between the PC/mobile device and the converter is not established.

# 6.5 Viewing converter information

The converter identification Web page displays detailed information of the currently connected converter:

dentification			X	
Converter type	V20		(	
Article number	6SL3210	-5BB17-	5UV1	2
Firmware version	3.94			
Rated voltage	230V			
Rated power	0.75kW			
Rated current	4.18A			
J		¢	e e	

6.6 Making optional Web access settings

# 6.6 Making optional Web access settings


You can make the following optional Web access settings:

- Wi-Fi configuration (Page 155)
- User interface language selection (Page 157)
- Converter time synchronization with the connected device (Page 157)
- Firmware version upgrade (Page 157)
- Viewing the additional information of the module (Page 158)

WI-FI configuration WI-FI SSID: V20 smart access_d520be channet_1	► Frequenc
Language Current language: English	÷
Time setting Current lime: 12:37 2017-05-08	÷
Upgrade Current version: V01.02.01	+
Additional information	+

# 6.6.1 Configuring Wi-Fi

If you do not want to use the default Wi-Fi settings, you can make Wi-Fi configuration in the following dialog box:



Note that the new Wi-Fi configuration takes effect only after the SINAMICS V20 Smart Access restarts.

6.6 Making optional Web access settings

## Wi-Fi SSID (Service Set Identifier)

Default SSID: V20 smart access\_xxxxx ("xxxxxx" stands for the last six characters of the MAC address of SINAMICS V20 Smart Access)

Example SSID: V20 smart access\_a4d3e1

SSID character restrictions: maximum 30 characters which are limited to A-Z, a-z, 0-9, \_, -, ~, !, @, #, \$, %, ^, &, \*, or space. Note that the first and the last character must not be a space.

#### Wi-Fi password

Default password: 12345678

For detailed information about the password requirements, see Section "Establishing the wireless network connection (Page 150)".

#### **Frequency channel**

Default channel: channel 1.

Total channels: 11. Each channel stands for a transmitting frequency. The frequency difference between two adjacent channels is 5 MHz. You can select a desired channel with the slider. Sliding right increases the transmitting frequency.

#### **Resetting Wi-Fi configuration**

When the converter is in power-on state, pressing the reset button on SINAMICS V20 Smart Access resets the Wi-Fi configuration to defaults.


#### Note

Check and make sure the status LED lights up solid green/solid yellow or flashes green before pressing the reset button to reset the Wi-Fi configuration. After you press the reset button, make sure you keep the button pressed until the status LED flashes yellow. Only then can the Wi-Fi configuration be reset successfully with the reset button.

6.6 Making optional Web access settings

## 6.6.2 Changing the display language

The SINAMICS V20 Web pages support the following user interface languages: English (default), Chinese, German, Italian, and French. Select the desired one from the following list:



## 6.6.3 Synchronizing the time

When the connection between the converter and the PC/mobile device is established, the Web page can display the current time and date information of the connected PC/mobile device (see below). You can enable time synchronization between the converter and the connected PC/mobile device to record the occurrence time of converter faults/alarms. When you enable synchronization, the converter receives the time of day from the connected PC/mobile device.




## 6.6.4 Upgrading

Upgrading includes conventional upgrading and basic upgrading. For more information, see Section "Upgrading (Page 178)".

## 6.6.5 Viewing additional information

The following window provides additional information about the SINAMICS V20 Smart Access:



# 6.7 Quick commissioning

The quick commissioning function enables you to set motor parameters, connection macros, application macros, and important parameters of the SINAMICS V20 converter.

## **Operating sequence**

- 1. Open the quick commissioning Web page by selecting the quick commissioning icon from either the home page or the navigation sidebar.
- 2. Proceed as follows. Quick commissioning will change the following four groups of parameters at a time.

Quick com	missioning includes
Motor dat	a
Connectio	on macros
Applicatio	n macros
Important	parameters
Do you wan commission	it to start quick ing?
No	Yes
No	Yes

3. Perform a factory reset of the converter if the current settings of the converter are unknown.




4. Change the motor parameters settings (Page 69), if desired.


lotor	Connection
P0100 Europe / North America	0
P0304[0]	400 ∨
Rated motor voltage-Driv	e Dataset 0(DDS0)
P0305[0]	1.86 A
Rated motor current-Drive	e Dataset 0 (DDS0)
P0307[0]	0.75
Rated motor power-Drive	Dataset 0 (DDS0)
P0308[0]	0
Rated motor cosPhi-Drive	e Dataset 0 (DDS0)
P0309[0]	0 %
Rated motor efficiency-Di	rive Dataset 0 (DDS0)
P0310[0]	50 Hz
Rated motor frequency-D	irive Dataset 0 (DDS0)
N	lext
• •	

Note that in this step, if you set P1900 = 2, you must perform motor data identification (Page 168).

- Quick Cn001 1 Commissioning ۲ . BOP as the only control source Connection Application P0700 1 Cn000(keep current settings) P1000 1 ۲ Factory default setting. Makes no parameter changes Selection of frequency setpoint P0731 52.2 Cn001 Function of digital output 0 the only control source P0732 52.3 Function of digital output 1 0 J2 P0771 21 ol from terminals(PNP/NPN) Cn003 0 • Fixed speeds Cn004 0 . Fixed speed in binary mode Cn005 . Analog input and fixed frequency Next 6 0 . 1º 0
- 5. Select the desired connection macro (Page 71).


6. Select the desired application macro (Page 82).





7. Set the following parameters based on your particular application.

8. Confirm to start writing the parameter settings to the converter.



9. Confirm completion of the quick commissioning when the following window appears. If the Web page indicates that the optimization fails, you can select to try optimization again.



After your confirmation of completion, the Web page automatically switches to my parameters Web page (Page 163).

arameter ID Go	<b>Y</b> +
My parameters	
P1001 Fixed frequency 1	•
P1002 Fixed frequency 2	•
P1003 Fixed frequency 3	•
P1058 JOG frequency	•
P1060 JOG ramp-up time	•
P1061 JOG ramp-down time	•
P1080 Min. frequency	•
P1082	•

# 6.8 Setting parameters


You can open the parameters Web page by selecting the parameters icon from either the home page or the navigation sidebar.

	ers
Parameter ID Go	I Y +
All parameters	
r0002 Drive state	0
P0003 User access level	1
P0004 Parameter filter	0
P0005 Display selection	0
P0007 Backlight delay time	0
P0010 Commissioning parameter	0
P0011 Lock for user defined parameter	0
P0012 Key for user defined parameter	0
La 📥	0

- ① Searching parameters
- ② Filtering parameters by group
- ③ Specifying user-defined parameters
- ④ Editing parameters
- (5) Resetting parameters
- 6 Saving parameters

## **Editing parameters**

The figure below shows different methods for editing parameters. Note that when editing a BICO parameter (example: P0810), you can use the on-screen numeric keypad or the computer keyboard to quickly navigate to the parameter values that start with the number(s) you enter.



### Searching parameters

You can search parameters by entering a key word, that is, either a complete parameter number or part of it. If you do not enter any key word but directly click the GO icon instead, the page shows a list of all parameters visible on the Web page.



### **Filtering parameters**


You can view and set parameters in the target parameter group.

All parameters			
Modified parameters		Parameter ID Go	
My parameters	13 -	Motor	
Converter	31	P0003 User access level	1
Motor	41	P0004 Parameter filter	0
Technology application/units		P0010	0
Commands, binary I/O	96	Commissioning parameter	932-0
Analog inputs and outputs	29 -	r0035 Act. motor temperature	•
Setpoint channel/RFG	71		
Converter features	38		

- ① Complete list of all visible parameters
- ② List of all modified parameters
- ③ User-defined parameters
- ④ Other parameter groups

### Specifying user-defined parameters

User-defined parameters are stored in "My parameters" group. The common parameters (Page 84)are already added to this parameter group as factory default settings. If you desire to define certain parameters (including any specific indexed parameters) in a target group to be user-defined parameters, proceed as the example given below:



All successfully defined parameters will go to "My parameters" group. Proceed as follows to view these parameters:



## **Resetting parameters to defaults**

You can select to reset all parameters to either user defaults or factory defaults.

You can choose be	ween:
Reset to user d	efaults
Reset to factory	/ defau
Cancel	ок
P0010 Commissioning parameter	0
P0011 Lock for user defined parameter	0
P0012 Key for user defined parameter	0
P0013 User defined parameter	•
Key for user defined parameter P0013	-

## Saving parameters to EEPROM

You can select to save all parameter settings to EEPROM only or save to EEPROM as new user defaults.

(EEPROM). • Save to EEPR	OM only
	M
<ul> <li>Save to EEPR( user defaults</li> </ul>	OM as r
Cancel	ок
r0021 Act. filtered frequency	0.00
r0022 Act. filtered rotor speed	0Rpm
r0024 Act. filt. output frequency	0.00Hz
r0025	0∨
La 📥	


6.9 Starting motor test run (JOG/HAND)

# 6.9 Starting motor test run (JOG/HAND)


You use this Web page to start the motor test run in JOG or HAND mode.

### **Operating sequence**

- 1. Open the JOG Web page by selecting the JOG icon from either the home page or the navigation sidebar.
- 2. Proceed as follows to get control of the motor:



3. Identify the motor data. The step shown below appears only if you have set P1900 = 2 in either the quick commissioning page (Page 158) or the parameters page (Page 163).



6.9 Starting motor test run (JOG/HAND)


4. Run the motor in JOG or HAND mode (default mode: JOG).

Note that if desired, you can also test the motor rotation direction with the corresponding button ("(1)"). The page shows the currently selected rotation direction ("(2)").

• Press the desired button ("①") to run the motor in JOG mode:




• Proceed as follows to run the motor in HAND mode:



6.9 Starting motor test run (JOG/HAND)

5. After you finish the motor test run, proceed as follows to relinquish the control of the motor:



Note that before relinquishing control, make sure that there is no converter output and the motor has come to a standstill. If the motor is still running, the following message appears:

Attention	
Please stop the motor and wait until the motor becomes standstill.	
ОК	

6.10 Monitoring

# 6.10 Monitoring

You can open the converter status monitoring Web page by selecting the monitoring icon from either the home page or the navigation sidebar.

Running status		
Setpoint	5	Hz
Output frequency	0.00	Hz •
Actual speed	0	rpm
Actual power	0	kW.
Motor temperature	20.00	°C
Output voltage	0.00	v
Motor current	0.00	A
Vdc	305.93	v
Converter status Conver	ter ready	

# 6.11 Diagnosing

You can open the diagnostics Web page by selecting the diagnostics icon from either the home page or the navigation sidebar. On this page, you can view faults/alarms, acknowledge all faults or send all faults by e-mail; you can also view I/O status and status bit information.

### Meaning of fault/alarm icons

Fault and alarm icons are shown at the upper-right corner of the V20 Web page. See the following example for possible icon display:


	Fault icons		
① ① ① No active fault present		No active fault present	
	2	Active fault present (in this example: one active fault present)	
$2 - 2^{1} + 2^{2} - 4$	Alarm icons		
	3	No active alarm present	
	4	Active alarms presents (in this example: two active alarms present)	

If the fault/alarm icon indicates presence of active faults/alarms, always go to the diagnostics page to view the detailed information.

## 6.11 Diagnosing

### Fault/alarm diagnostics

On this subpage, you can view the detailed fault/alarm information, acknowledge all faults, or send all faults by e-mail (recommended on PC).




You can use the filter button to display all faults and alarms or the active ones only.

Button status	Description
	Displays the active faults and alarms only
	Displays all faults and alarms

Note: The module does not read the updates of active faults or alarms from the converter until you collapse all faults and alarms.

For more information about the maximum number of faults/alarms that can be recorded, see parameters r0947/r2110 in Section "Parameter list (Page 206)".

## I/O status diagnostics



This subpage displays the detailed I/O status information.

#### **Relevant parameters**

Parameter	Function	
r0722.012	CO/BO: Digital input values	
r0747.01	O/BO: State of digital outputs	
r0752[01]	Actual analog input [V] or [mA]	
P0756[01]	Type of analog input	
P0771[0]	CI: Analog output	
r0774[0]	Actual analog output value [V] or [mA]	

## **Status bit diagnostics**

Diagnostics Diagnostics 1/0 Status bits Status bits Faults/Alarms 00 Converter ready AI 1 01 Converter ready to run AI 1 (T. 2) 0.00 V 1 02 Converter running AI 2 (T. 3) 0.01 V 12 03 Converter fault active 04 OFF2 active 05 OFF3 active AO 1 06 ON inhibit active AO 1 (T. 4) << 21.0 0.00 mA 1 07 Converter warning active 08 Deviation setpoint / act. value 09 PZD control DI 10 |f\_act|>=P1082(f\_max) - DI 1 (T 8) 1 . . . 0

This subpage displays the detailed status bit information.

#### **Relevant parameters**

Parameter	Function
r0052.015	CO/BO: Active status word 1
r0053.011	CO/BO: Active status word 2

# 6.12 Backing up and restoring

You can open the backup & restore Web page by selecting the backup & restore icon from either the home page or the navigation sidebar.


## 6.12.1 Backing up

You can use the backup page to back up the desired parameters to SINAMICS V20 Smart Access and download it (\*.xml file) to your local drive (recommended on PC).

#### Note

The backup process backs up all parameters of access levels  $\leq$  4 and allows you to back up a maximum of 20 files to SINAMICS V20 Smart Access. In case of any further backup attempt, a message appears prompting you to delete some of the existing backup files.

- 1. Open the backup & restore Web page by selecting the backup & restore icon from either the home page or the navigation sidebar.
- 2. Proceed as follows to back up the selected parameter file to SINAMICS V20 Smart Access.



Character restrictions for the file name: maximum 30 characters which are limited to A-Z, a-z, 0-9, \_, -, (, ), dot, or space. If an existing backup file has the same name as the new file you desire to back up, a message prompts asking you if you want to overwrite the existing file.

#### Note:

When you perform the backup operation on a mobile device, if the menus and buttons on the Web page disappear after you finish editing the backup file name, you can click in the blank area of the Web page to restore them.

3. When the following window appears, proceed as follows to complete the backup process. If the Web page indicates that the backup fails, you can select to back up again. Note that download to your local drive (recommended on PC) is only an optional step. If you attempt to download from the V20 Web page via the supported Internet Explorer Web browser, the V20 Web page then opens the file. You must save the backed-up file to your local drive manually.



## 6.12.2 Restoring

You can use the restore page to upload, download, delete, and/or restore the selected file (\*.xml file).

Note


The restore process restores all parameters of access levels  $\leq 4$ .

## Uploading an existing file (recommended on PC)

Restore	Backup	
2017-05-11.x	ml 🕨	Please select a file
2016-10-11.x	ml 🕨	
2016-11-29.x	ml 🕨	
Delete sel	ected file	Upload N
		Cancel
Rest	ore	

Note that you must upload the proper backup file; otherwise, the module outputs the following error message:

Please select a file				
C:\fakepath\userparameters.xml Wrong file! Please select a backup applicable to V20 Smart Access.	Select			
Upload				
Cancel				



## Downloading an existing file (recommended on PC)

If you attempt to download from the V20 Web page via the supported Internet Explorer Web browser, the V20 Web page then opens the file. You must save the backed-up file to your local drive manually.

#### Deleting a selected file



6.13 Upgrading


## Restoring the selected file

1. Proceed as follows to start restoring.



2. The restoring process completes when the following window appears. If the Web page indicates that the restoring fails, you can select to restore again.

Then you can choose to save the parameter settings to the non-volatile memory in the following window:



# 6.13 Upgrading

Upgrading on the SINAMICS V20 Web page upgrades the firmware version of the SINAMICS V20 Smart Access.

There are two upgrading methods for selection:

- Conventional upgrading
- Basic upgrading (applicable when conventional upgrading cannot be performed)

6.13 Upgrading

## **Conventional upgrading**

- 1. Open the following Web site and click "Sales release for SINAMICS V20 Smart Access VXX.XX.XX" (VXX.XX.XX represents the firmware version number of the V20 Smart Access) to download the target upgrade file (\*.bin file) to your local drive (recommended on PC):
  - https://support.industry.siemens.com/cs/ww/en/ps/13208/pm
- 2. Access the V20 Web page: http://192.168.1.1. Proceed as follows to perform the upgrade:



3. Confirm completion of the upgrading process when the following window appears. If the Web page indicates that the upgrading fails, you can select to upgrade again.



- 4. Restart the SINAMICS V20 Smart Access.
- 5. Clear the Web browser cache.
- 6. Refresh your Web application.

## 6.13 Upgrading

# **Basic upgrading**

1. Open the following Web site and click "Sales release for SINAMICS V20 Smart Access VXX.XX.XX" (VXX.XX.XX represents the firmware version number of the V20 Smart Access) to download the target upgrade file (\*.bin file) to your local drive (recommended on PC):

https://support.industry.siemens.com/cs/ww/en/ps/13208/pm

- 2. Power off SINAMICS V20 Smart Access by sliding its power switch to "OFF". Keep the reset button pressed and then slide the power switch to "ON".
- 3. Open the following Web site specific for basic upgrading: http://192.168.1.1/factory/basicupgrade.html
- 4. Proceed as follows:

Connection status: connected	Connection status: connected
Select file:	Select file:
	C:\fakepath\\/20SAM.BIN
Upgrade Format web	Upgrade Format web
Formatting successful!	Upgrading successful! Next steps: 1. Restart the Smart Access module. 2. Clear the browser cache. 3. Refresh your Web application.
Page version:V1.2 Firmware version:V01.02.05.00	Page version:V1.2 Firmware version:V01.02.05.00

- 5. Restart the SINAMICS V20 Smart Access.
- 6. Clear the Web browser cache.
- 7. Refresh your Web application.

#### Note

Refresh the basic upgrading page if the connection status unexpectedly becomes "Disconnected" during upgrading.

6.14 Viewing the support information

# 6.14 Viewing the support information

Proceed as follows to view the support information in case of any service need:



### Editing the support information (for OEM users only)

OEM users can enter their contact telephone and E-mail address in the following dialog box according to the specified rules:




- Telephone number: up to 22 characters starting with "+" and limited to numbers, space, and "-";
- E-mail address: up to 48 characters starting with numbers or letters.

6.14 Viewing the support information

# Communicating with the PLC

The SINAMICS V20 supports communication with Siemens PLCs over USS on RS485. You can parameterize whether the RS485 interface shall apply USS or MODBUS RTU protocol. USS is the default bus setting. A screened twisted pair cable is recommended for the RS485 communication.

Make sure that you terminate the bus correctly by fitting a 120 R bus termination resistor between the bus terminals (P+, N-) of the device at one end of the bus and a termination network between the bus terminals of the device at the other end of the bus. The termination network should be a 1.5 k resistor from 10 V to P+, 120 R from P+ to N- and 470 R from N- to 0 V. A suitable termination network is available from your Siemens dealer.




# 7.1 USS communication


#### Overview

One PLC (master) can connect a maximum of 31 converters (slaves) through the serial link and control them with the USS serial bus protocol. A slave can never transmit without first being initiated by the master so that direct information transfer between individual slaves is not possible.

Data exchanging:



#### 7.1 USS communication



The messages are always sent in the following format (half-duplex communication):

- Response delay time: 20 ms
- Start delay time: depends on baud rate (minimum operation time for 2-character string: 0.12 to 2.3 ms)
- Message transfer sequence:
  - master polls slave 1, then slave 1 responds
  - master polls slave 2, then slave 2 responds
- Fixed framing characters that cannot be altered:
  - 8 data bits
  - 1 parity bit
  - 1 or 2 stop bits

Abbreviation	Significance	Length	Explanation
STX	Start of text	ASCII characters	02 hex
LGE	Telegram length	1 byte	Contains the telegram length
ADR	Address	1 byte	Contains the slave address and the telegram type (binary coded)
1 n.	Net characters	Each 1 byte	Net data, contents are dependent on the request
BCC	Block check character	1 byte	Data security characters

#### **Request and response IDs**

Request and response IDs are written in bits 12 to 15 of the PKW (parameter ID value) part of USS telegram.

#### Request IDs (master $\rightarrow$ slave)

Request ID	Description	Response ID		
		positive	negative	
0	No request	0	7/8	
1	Request parameter value	1/2	7/8	
2	Modify parameter value (word)	1	7/8	
3	Modify parameter value (double word)	2	7/8	
4	Request descriptive element	3	7/8	

7.1 USS communication

Request ID	Description	Response ID	
6	Request parameter value (array)	4/5	7/8
7	Modify parameter value (array, word)	4	7/8
8	Modify parameter value (array, double word)	5	7/8
9	Request number of array elements	6	7/8
11	Modify parameter value (array, double word) and store in EEPROM	5	7/8
12	Modify parameter value (array, word) and store in EEPROM	4	7/8
13	Modify parameter value (double word) and store in EEPROM	2	7/8
14	Modify parameter value (word) and store in EEPROM	1	7/8

# Response IDs (slave $\rightarrow$ master)

Response ID	Description
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
3	Transfer descriptive element
4	Transfer parameter value (array, word)
5	Transfer parameter value (array, double word)
6	Transfer number of array elements
7	Request cannot be processed, task cannot be executed (with error number)
8	No master controller status/no parameter change rights for PKW interface

# Error numbers in response ID 7 (request cannot be processed)

No.	Description
0	Illegal PNU (illegal parameter number; parameter number not available)
1	Parameter value cannot be changed (parameter is read-only)
2	Lower or upper limit violated (limit exceeded)
3	Wrong sub-index
4	No array
5	Wrong parameter type/incorrect data type
6	Setting is not allowed (parameter value can only be reset to zero)
7	The descriptive element is not changeable and can only be read
9	Descriptive data not available
10	Access group incorrect
11	No parameter change rights. See parameter P0927. Must have status as master control.
12	Incorrect password
17	The current converter operating status does not permit the request processing
18	Other error
20	Illegal value. Change request for a value which is within the limits, but it is not allowed for other reasons (parameter with defined single values)
101	Parameter is currently deactivated; parameter has no function in the present converter status
102	Communication channel width is insufficient for response; dependent on the number of PKW and the maximum net data length of the converter
104	Illegal parameter value
105	Parameter is indexed

# 7.1 USS communication

No.	Description
106	Request is not included/task is not supported
109	PKW request access timeout/number of retries is exceeded/wait for response from CPU side
110	Parameter value cannot be changed (parameter is locked)
200/201	Changed lower/upper limits exceeded
202/203	No display on the BOP
204	The available access authorization does not cover parameter changes
300	Array elements differ

# Parameter number

Parameter numbers < 2000	PNU = parameter number. Write the parameter number into the PNU (PKE bit 10 0).
Parameter numbers ≥ 2000	PNU = parameter number - offset. Write the parameter number minus the offset into the PNU (PKE bit 10 0). Write the offset in the page index (IND bit 15 8).

# Offset and page index of the parameter numbers

Parameter	Offset	Page inc	Page index							
number		Hex	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
0000 1999	0	0 hex	0	0	0	0	0	0	0	0
2000 3999	2000	80 hex	1	0	0	0	0	0	0	0
6000 7999	6000	90 hex	1	0	0	1	0	0	0	0
8000 9999	8000	20 hex	0	0	1	0	0	0	0	0
10000 11999	10000	A0 hex	1	0	1	0	0	0	0	0
20000 21999	20000	50 hex	0	1	0	1	0	0	0	0
29000 29999	28000	70 hex	0	1	1	1	0	0	0	0
30000 31999	30000	F0 hex	1	1	1	1	0	0	0	0
60000 61999	60000	74 hex	0	1	1	1	0	1	0	0

# Basic converter settings

Parameter	Function	Setting
P0010	Commissioning parameter	= 30: restores to factory settings
P0970	Factory reset	Possible settings:
		= 1: Resets all parameters (not user defaults) to user defaults if they have been previously stored with P0971 = 21; otherwise, resets all parameters to factory defaults
		= 21: Resets all parameters and user defaults to factory defaults
		= 31: Special factory reset. Resets all user defaults in EEPROM to factory defaults. The converter will then restart.
		<b>Note:</b> If P0970 = 1 or 21, parameters P2010, P2011, P2023 retain their values after a factory reset.
P0003	User access level	= 3
P0700	Selection of command source	= 5: USS/MODBUS on RS485
		Factory default: 1 (operator panel)
P1000	Selection of frequency setpoint	= 5: USS/MODBUS on RS485
		Factory default: 1 (MOP setpoint)
P2023	RS485 protocol selection	= 1: USS (factory default)
		<b>Note:</b> After changing P2023, powercycle the converter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971.
P2010[0]	USS/MODBUS baudrate	Possible settings:
		= 6: 9600 bps (factory default)
		= 7: 19200 bps
		= 8: 38400 bps
		= 12: 115200 bps
P2011[0]	USS address	Sets the unique address for the converter.
		Range: 0 to 31 (factory default: 0)
P2012[0]	USS PZD (process data) length	Defines the number of 16-bit words in PZD part of USS telegram.
		Range: 0 to 8 (factory default: 2)
P2013[0]	USS PKW (parameter ID value) length	Defines the number of 16-bit words in PKW part of USS telegram.
		Possible settings:
		= 0, 3, 4: 0, 3 or 4 words
		= 127: variable length (factory default)
P2014[0]	USS/MODBUS telegram off time [ms]	If time set to 0, no fault is generated (i.e. watchdog disabled).
r2024[0]	USS/MODBUS error statistics	The state of the telegram information on RS485 is reported
		regardless of the protocol set in P2023.
r2031[0]		
r2018[07]	CO: PZD from USS/MODBUS on RS485	Displays process data received via USS/MODBUS on RS485.
P2019[07]	CI: PZD to USS/MODBUS on RS485	Displays process data transmitted via USS/MODBUS on RS485.
P2034	MODBUS parity on RS485	Sets the parity of MODBUS telegrams on RS485.
		Possible settings:
		= 0: no parity
		= 1: odd parity
P2035	MODBUS stop bits on RS485	= 2: even parity Sets the number of stop bits in MODBUS telegrams on RS485.
12033		Possible settings:
		= 1: 1 stop bit
		= 2: 2 stop bits

# 7.2 MODBUS communication

### Overview

In MODBUS, only the master can start a communication and the slave will answer it. There are two ways of sending a message to a slave. One is unicast mode (address 1 to 247), where the master addresses the slave directly; the other is broadcast mode (address 0), where the master addresses all slaves.

When a slave has received a message, which was addressed at it, the Function Code tells it what to do. For the task defined by the Function Code, the slave may receive some data. And for error checking a CRC code is also included.

After receiving and processing a unicast message, the MODBUS slave will send a reply, but only if no error was detected in the received message. If a processing error occurs, the slave will reply with an error message. The following fixed framing characters in a message cannot be altered: 8 data bits, 1 parity bit, and 1 or 2 stop bits.

Start pause		Арр			End pause		
	Slave	Protocol Data Unit		CRC			
>= 3.5 Character run time	Address Function Code		Data	2 bytes		>= 3.5 Character run	
	1 byte	1 byte	0 252 bytes	CRC low	CRC high	time	

### **Supported Function Codes**

The SINAMICS V20 supports only three Function Codes. If a request with an unknown Function Code is received, an error message will be returned.

### FC3 - Read Holding Registers

When a message with FC = 0x03 is received, then 4 bytes of data are expected, that is, FC3 has 4 bytes of data:

- 2 bytes for the starting address of register
- 2 bytes for the number of registers

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Address	FC (0x03)	Start address		Number of registers		CRC	
		High Low		High	Low	High	Low

#### Converter response

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5		Byte N*2 - 1	Byte N*2	Byte N*2 + 1	Byte N*2 + 2
Address	FC (0x03)	Number	Register 1 va	Register 1 value		Register N value		CRC	
		of bytes	High	Low		High	Low	High	Low

## FC6 - Write Single Register

When a message with FC = 0x06 is received, then 4 bytes of data are expected, that is, FC6 has 4 bytes of data:

- 2 bytes for the starting address of register
- 2 bytes for the register value

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Address	FC (0x06)	Start address		New register value		CRC	
		High	Low	High	Low	High	Low

#### Converter response

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Address	FC (0x06)	Start address		New register value		CRC	
		High	Low	High	Low	High	Low

### FC16 - Write Multiple Registers

When a message with FC = 0x10 is received, then 5 + N bytes of data are expected, that is, FC16 has 5 + N bytes of data:

- 2 bytes for the starting address of register
- 2 bytes for the number of registers
- 1 byte for the byte count
- N bytes for the register values

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	 Byte N - 1	Byte N	Byte N + 1	Byte N + 2
Address	FC (0x10)	Start address Number of registers		of	Number of bytes	 Register N value		CRC		
		High	Low	High	Low		High	Low	High	Low

#### Converter response

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Address	FC (0x10)	Start address		Number of registers		CRC	
		High	Low	High	Low	High	Low

### Acyclic communication via MODBUS

Acyclic communication or general parameter access is realized using the Modbus registers 40601 ... 40722.

Acyclic communication is controlled using 40601. 40602 contains the function code (always = 47 = 2F hex) and the number of the following user data. User data are contained in registers 40603 ... 40722.

#### Overview of acyclic communication

	Va	lue in the reg	gister	Explanation
40601	40602		40603 40722	
0	47			Write values for acyclic access
1	47	Request length [bytes]	Request data	Activate acyclic access
2	47	Response length [bytes]	Response data	Response for a successful request
2	47	0	Error code	Response for an erroneous request

#### Error codes

1 hex: Invalid Length (invalid length)

- 2 hex: Invalid State (in the actual converter state, this action is not permitted)
- 3 hex: Invalid function code (FC  $\neq$  2F hex)
- 4 hex: Response not ready (the response has still not been issued)
- 5 hex: Internal Error (general system error)

Incorrect access operations to parameters via data set 47 are logged in registers 40603 ... 40722.

#### Reading and writing parameters acyclically

Via FC16, with one request, up to 122 registers can be written to directly one after the other; while for Write Single Register (FC6) you must individually write the header data for each register.

#### Header

In addition to the slave address, enter the transfer type, the start address and the number of the following registers in the header.

#### User data

You control the access in the user data via register 40601.

In register 40602, you define the acyclic access as well as the length of the request data.

Register 40603 contains the request reference - it is defined by the user - and the access type -reading or writing.

Register 40604 contains the number of the drive object (always 1) and the number of parameters that are read or written.

Register 40605 contains the attribute that you use to control whether you read out the parameter value or the parameter attribute. In the number of elements you specify how many indices are read.

# Example: r0002 read acyclically

Value	Byte	Description
11 h	1	Slave address
10 h	2	Function code (write multiple)
0258 h	3,4	Register start address
0007 h	5,6	Number of registers to be read (40601 40607)
0E h	7	Number of data bytes (7 registers, each 2 bytes = 14 bytes)
0001 h	8,9	40601: DS47 Control = 1 (activate request)
2F0A h	10,11	40602: Function 2F h (47), request length 10 bytes (0A h)
8001 h	12,13	40603: Request reference = 80 h, request identifier = 1 h
0101 h	14,15	40604: DO-Id = 1, number of parameters = 1
1001 h	16,17	40605: Attribute, number of elements = 1
0002 h	18,19	40606: Parameter number = 2
0000 h	20,21	40607: Subindex = 0
xx h	22	CRC "Low"
xx h	23	CRC "High"

Start parameter request: Reading the parameter value of r0002 from slave number 17

Value	Byte	Description			
11 h	1	Slave address			
03 h	2	'unction code (read)			
0258 h	3,4	Register start address			
0007 h	5,6	Number of registers to be read (40601 40607)			
0010 h	7,8	Number of registers			
xx h	9	CRC "Low"			
xx h	10	CRC "High"			

# Response for successful read operation

Value	Byte	Description
11 h	1	Slave address
03 h	2	Function code (read)
20 h	3	Number of following data bytes (20 h: 32 bytes $\hat{=}$ 16
0002 h	4,5	registers)
2F08 h	6,7	40601: DS47 Control = 2 (the request was executed)
8001 h	8,9	40602: Function code 2F h (47), response lengths 8 bytes
		40603: Request reference mirrored = 80 h,
0101 h	10,11	response identifier = 1 (request parameter)
0301 h	12,13	40604: DO-ID = 1, number of parameters = 1
001F h	14,15	40605: Format, number of elements = 1
		40606: Parameter value = 1F h (31)
xx h	16	CRC "Low"
xx h	17	CRC "High"

Value	Byte	Description
11 h	1	Slave address
03 h	2	Function code (read)
20 h	3	Number of following data bytes (20 h: 32 bytes $\hat{=}$ 16
0001 h	4,5	registers)
2F00 h	6,7	40601: Check value 1 = request is processed
0004 h	8,9	40602: Function 2F h(47), response length 0 (fault)
		40603: Error code: 0004 Response Not Ready (response has
		still not been issued)
xx h	10	CRC "Low"
xx h	11	CRC "High"

#### Response for unsuccessful read operation - read request still not completed

# Example: Set p1121 = 12.15

#### Write parameter request: Writing the parameter value of p1121 from slave number 17

Value	Byte	Description
11 h	1	Slave address
10 h	2	Function code (write multiple)
0258 h	3,4	Register start address
000A h	5,6	Number of registers to be written to (40601 40610)
14 h	7	Number of data bytes (10 registers, each 2 bytes = 20
0001 h	8,9	bytes)
2F10 h	10,11	40601: C1 (activate request)
8002 h	12,13	40602: Function 2F h (47), request length 16 bytes (10 h)
0101 h	14,15	40603: Request reference = 80 h, request identifier = 2 h
1001 h	16,17	(write)
0461 h	18,19	40604: DO-Id = 1, number of parameters = 1
0000 h	20,21	40605: Attribute, number of elements = 1
0801 h	22,23	40606: Parameter number = 1121
4142 h	24,25	40607: Subindex = 0
6666 h	26,27	40608: Format + number of values
		40609: Parameter value 12,15
		40610: Parameter value
xx h	28	CRC "Low"
xx h	29	CRC "High"

Start parameter request: Writing the parameter value of p1121 from slave number 17

Value	Byte	Description
11 h	1	Slave address
03 h	2	Function code (read)
0258 h	3,4	Register start address
0007 h	5,6	Number of registers to be written to (40601 40610)
0010 h	7,8	Number of registers
xx h	9	CRC "Low"
xx h	10	CRC "High"

#### Response for successful write operation

Value	Byte	Description
11 h	1	Slave address
03 h	2	Function code (read)
20 h	3	Number of following data bytes (20 h: 32 bytes $\hat{=}$ 16
0002 h	4,5	registers)
2F04 h	6,7	40601: DS47 Control = 2 (request was executed)
8002 h	8,9	40602: Function code 2F h (47), response length 4 bytes
		40603: Request reference mirrored = 80 h,
0101 h	10,11	response identifier = 2 (change parameter)
		40604: DO-ID = 1, number of parameters = 1
xx h	12	CRC "Low"
xx h	13	CRC "High"

Response for unsuccessful	write operation	- write request s	still not completed

Value	Byte	Description
11 h	1	Slave address
03 h	2	Function code (read)
20 h	3	Number of following data bytes (20 h: 32 bytes $\hat{=}$ 16
0001 h	4,5	registers)
2F00 h	6,7	40601: DS47 Control = 1 (request is processed)
0004 h	8,9	40602: Function 2F h(47), response length 0 (fault)
		40603: Error code: 0004 Response Not Ready (response has
		still not been issued)
xx h	10	CRC "Low"
xx h	11	CRC "High"

#### **Exception Responses**

If an error is detected through the MODBUS processing, the slave will respond with the FC of the request, but with most significant bit of the FC high and with the Exception Code in the data field. However, any error detected on the global address 0 does not result in a response since all slaves cannot respond at once.

If an error is detected within the received message (for example, parity error, incorrect CRC and so on), then NO response is sent to the master.

Note that if a request with FC16 is received which contains a write that the converter cannot perform (including write to a zero entry), other valid writes will still be performed even though an exception response is returned.

The following MODBUS Exception Codes are supported by SINAMICS V20:

<b>Exception Code</b>	MODBUS name	Meaning
01	Illegal function code	The function code is not supported – only FC3, FC6 and FC16 are supported.
02	Illegal data address	An invalid address was queried.
03	Illegal data value	An invalid data value was recognized.
04	Slave device failure	An unrecoverable error occurred while the device was processing the action.

The table below shows the cases in which an Exception Code is returned:

Error description	Exception Code
Unknown Function Code	01
Read registers, which are out of boundary	02
Write register, which is out of boundary	02
Read request of too many registers (>125)	03
Write request of too many registers (>123)	03
Incorrect message length	03
Write to a read-only register	04
Write register, error in parameter access	04
Read register, error in Parameter Manager	04
Write to a zero entry	04
Unknown error	04

# **Basic converter settings**

Parameter	Function	Setting
P0010	Commissioning parameter	= 30: restores to factory settings
P0970	Factory reset	Possible settings:
		= 1: Resets all parameters (not user defaults) to user defaults if they have been previously stored with P0971 = 21; otherwise, resets all parameters to factory defaults
		= 21: Resets all parameters and user defaults to factory defaults
		= 31: Special factory reset. Resets all user defaults in EEPROM to factory defaults. The converter will then restart.
		<b>Note:</b> If P0970 = 1 or 21, parameters P2010, P2021, P2023 retain their values after a factory reset.
P0003	User access level	= 3
P0700	Selection of command source	= 5: USS/MODBUS on RS485
		Factory default: 1 (operator panel)
P2010[0]	USS/MODBUS baudrate	Possible settings:
		= 6: 9600 bps (factory default)
		= 7: 19200 bps
		= 8: 38400 bps
		=12: 115200 bps
P2014[0]	USS/MODBUS telegram off time [ms]	If time set to 0, no fault is generated (i.e. watchdog disabled).
P2021	Modbus address	Sets the unique address for the converter.
		Range: 1 to 247 (factory default: 1)
P2022	Modbus reply timeout [ms]	Range: 0 to 10000 (factory default: 1000)
P2023	RS485 protocol selection	= 2: Modbus
		Factory default: 1 (USS)
		<b>Note:</b> After changing P2023, powercycle the converter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971.

Parameter	Function	Setting
r2024[0]  r2031[0]	USS/MODBUS error statistics	The state of the telegram information on RS485 is reported regardless of the protocol set in P2023.
r2018[07]	CO: PZD from USS/ MODBUS on RS485	Displays process data received via USS/MODBUS on RS485.
P2019[07]	CI: PZD to USS/MODBUS on RS485	Displays process data transmitted via USS/MODBUS on RS485.
P2034	MODBUS parity on RS485	Sets the parity of MODBUS telegrams on RS485. Possible settings: = 0: no parity = 1: odd parity = 2: even parity
P2035	MODBUS stop bits on RS485	Sets the number of stop bits in MODBUS telegrams on RS485. Possible settings: = 1: 1 stop bit = 2: 2 stop bits

# Mapping table

The table below shows registers that the SINAMICS V20 converter supports. "R", "W", and "R/W" in the "Access" column stand for read, write, and read/write respectively. Registers with \* are available only when the optional I/O Extension Module is connected.

HSW (speed setpoint), HIW (actual speed), STW (control word), and ZSW (status word) refer to control data. For more information, see parameters r2018 and P2019 in Chapter "Parameter list (Page 201)".

Register No.		Description	Access	Unit	Scaling	Range or On/Off	Read	Write
Converter	MODBUS				factor	text		
0	40001	Watchdog time	R/W	ms	1	0 - 65535	-	-
1	40002	Watchdog action	R/W	-	1	-	-	-
2	40003	Frequency setpoint	R/W	%	100	0.00 - 100.00	HSW	HSW
3	40004	Run enable	R/W	-	1	0 - 1	STW:3	STW:3
4	40005	Forward/reverse command	R/W	-	1	0 - 1	STW:11	STW:11
5	40006	Start command	R/W	-	1	0 - 1	STW:0	STW:0
6	40007	Fault acknowledgement	R/W	-	1	0 - 1	STW:7	STW:7
7	40008	PID setpoint reference	R/W	%	100	-200.0 - 200.0	P2240	P2240
8	40009	PID enable	R/W	-	1	0 - 1	r0055.8	(BICO) P2200
9	40010	Current limit	R/W	%	10	10.0 - 400.0	P0640	P0640
10	40011	Acceleration time	R/W	S	100	0.00 - 650.0	P1120	P1120
11	40012	Deceleration time	R/W	S	100	0.00 - 650.0	P1121	P1121
12	40013	(Reserved)						
13	40014	Digital output 1	R/W	-	1	HIGH LOW	r0747.0	(BICO) P0731
14	40015	Digital output 2	R/W	-	1	HIGH LOW	r0747.1	(BICO) P0732
15	40016	Reference frequency	R/W	Hz	100	1.00 - 550.00	P2000	P2000
16	40017	PID upper limit	R/W	%	100	-200.0 - 200.0	P2291	P2291
17	40018	PID lower limit	R/W	%	100	-200.0 - 200.0	P2292	P2292

Register No.		Description	Access	Unit	Unit Scaling	Range	e or On/Off	Read	Write
Converter	MODBUS				factor	text			
18	40019	Proportional gain	R/W	-	1000	0.000	- 65.000	P2280	P2280
19	40020	Integral gain	R/W	S	1	0 - 60		P2285	P2285
20	40021	Differential gain	R/W	-	1	0 - 60		P2274	P2274
21	40022	Feedback gain	R/W	%	100	0.00 -	500.00	P2269	P2269
22	40023	Low pass	R/W	-	100	0.00 -	60.00	P2265	P2265
23	40024	Frequency output	R	Hz	100	-327.6	58 - 327.67	r0024	r0024
24	40025	Speed	R	RPM	1	-1625	0 - 16250	r0022	r0022
25	40026	Current filtered	R	А	100	0 - 16	3.83	r0027	r0027
26	40027	Torque	R	Nm	100	-325.0	0 - 325.00	r0031	r0031
27	40028	Actual power	R	kW	100	0 - 32	7.67	r0032	r0032
28	40029	Total kWh	R	kWh	1	0 - 32	767	r0039	r0039
29	40030	DC bus voltage	R	V	1	0 - 32	767	r0026	r0026
30	40031	Reference	R	Hz	100	-327.6	58 - 327.67	r0020	r0020
31	40032	Rated power	R	kW	100	0 - 32	7.67	r0206	r0206
32	40033	Voltage output	R	V	1	0 - 32	767	r0025	r0025
33	40034	Forward/reverse	R	-	1	FWD	REV	ZSW:14	ZSW:14
34	40035	Stop/run	R	-	1	STOP	RUN	ZSW:2	ZSW:2
35	40036	Run at maximum frequency	R	-	1	MAX	NO	ZSW:10	ZSW:10
36	40037	Control mode	R	-	1	SERI AL	LOCAL	ZSW:9	ZSW:9
37	40038	Enabled	R	-	1	ON	OFF	ZSW:0	ZSW:0
38	40039	Ready to run	R	-	1	REA DY	OFF	ZSW:1	ZSW:1
39	40040	Analog input 1	R	%	100	-300.0	) - 300.0	r0754[0]	r0754[0]
40	40041	Analog input 2	R	%	100	-300.0	) - 300.0	r0754[1]	r0754[1]
41	40042	Analog output 1	R	%	100	-100.0	) - 100.0	r0774[0]	r0774[0]
43	40044	Actual frequency	R	%	100	-100.0	) - 100.0	HIW	HIW
44	40045	PID setpoint output	R	%	100	-100.0	) - 100.0	r2250	r2250
45	40046	PID output	R	%	100	-100.0	) - 100.0	r2294	r2294
46	40047	PID feedback	R	%	100	-100.0	) - 100.0	r2266	r2266
47	40048	Digital input 1	R	-	1	HIGH	LOW	r0722.0	r0722.0
48	40049	Digital input 2	R	-	1	HIGH	LOW	r0722.1	r0722.1
49	40050	Digital input 3	R	-	1	HIGH	LOW	r0722.2	r0722.2
50	40051	Digital input 4	R	-	1	HIGH	LOW	r0722.3	r0722.3
53	40054	Fault	R	-	1	FAUL T	OFF	ZSW:3	ZSW:3
54	40055	Last fault	R	-	1	0 - 32	767	r0947[0]	r0947[0]
55	40056	Fault 1	R	-	1	0 - 32	767	r0947[1]	r0947[1]
56	40057	Fault 2	R	-	1	0 - 32767		r0947[2]	r0947[2]
57	40058	Fault 3	R	-	1	0 - 32	767	r0947[3]	r0947[3]
58	40059	Warning	R	-	1	WAR N	ОК	ZSW:7	ZSW:7
59	40060	Last warning	R	-	1	0 - 32	767	r2110	r2110
60	40061	Converter version	R	-	100		327.67	r0018	r0018
61	40062	Converter model	R	-	1	0 - 32		r0201	r0201

Register No.		Description	Access	Unit	Jnit Scaling	Range	e or On/Off	Read	Write
Converter	MODBUS				factor	text			
99	40100	STW	R/W	-	1			PZD 1	PZD 1
100	40101	HSW	R/W	-	1			PZD 2	PZD 2
109	40110	ZSW	R	-	1			PZD 1	PZD 1
110	40111	HIW	R	-	1			PZD 2	PZD 2
199	40200	Digital output 1	R/W	-	1	HIGH	LOW	r0747.0	(BICO) P0731
200	40201	Digital output 2	R/W	-	1	HIGH	LOW	r0747.1	(BICO) P0732
201	40202	Digital output 3*	R/W	-	1	HIGH	LOW	r0747.2	(BICO) P0733
202	40203	Digital output 4*	R/W	-	1	HIGH	LOW	r0747.3	(BICO) P0734
219	40220	Analog output 1	R	%	100	-100.0	) - 100.0	r0774[0]	r0774[0]
239	40240	Digital input 1	R	-	1	HIGH	LOW	r0722.0	r0722.0
240	40241	Digital input 2	R	-	1	HIGH	LOW	r0722.1	r0722.1
241	40242	Digital input 3	R	-	1	HIGH	LOW	r0722.2	r0722.2
242	40243	Digital input 4	R	-	1	HIGH	LOW	r0722.3	r0722.3
243	40244	Digital input 5*	R	-	1	HIGH	LOW	r0722.4	r0722.4
244	40245	Digital input 6*	R	-	1	HIGH	LOW	r0722.5	r0722.5
259	40260	Analog input 1	R	%	100	-300.0	) - 300.0	r0754[0]	r0754[0]
260	40261	Analog input 2	R	%	100	-300.0	) - 300.0	r0754[1]	r0754[1]
299	40300	Converter model	R	-	1	0 - 32	767	r0201	r0201
300	40301	Converter version	R	-	100	0.00 -	327.67	r0018	r0018
319	40320	Rated power	R	kW	100	0 - 32	7.67	r0206	r0206
320	40321	Current limit	R/W	%	10	10.0 -	400.0	P0640	P0640
321	40322	Acceleration time	R/W	s	100	0.00 -	650.0	P1120	P1120
322	40323	Deceleration time	R/W	s	100	0.00 -	650.0	P1121	P1121
323	40324	Reference frequency	R/W	Hz	100	1.00 -	650.0	P2000	P2000
324	40325	Fixed frequency 1	R/W	Hz	100	-327.6	68 - 327.67	P1001	P1001
325	40326	Fixed frequency 2	R/W	Hz	100	-327.6	68 - 327.67	P1002	P1002
326	40327	Fixed frequency 3	R/W	Hz	100	-327.6	68 - 327.67	P1003	P1003
327	40328	Fixed frequency 4	R/W	Hz	100	-327.6	68 - 327.67	P1004	P1004
329	40330	Fixed setpoint 1	R/W	%	100	-200 -	200	P2889	P2889
330	40331	Fixed setpoint 2	R/W	%	100	-200 -	200	P2890	P2890
331	40332	Fixed frequency 5	R/W	Hz	100	-327.6	68 - 327.67	P1005	P1005
332	40333	Fixed frequency 6	R/W	Hz	100	-327.6	68 - 327.67	P1006	P1006
333	40334	Fixed frequency 7	R/W	Hz	100	-327.6	58 - 327.67	P1007	P1007
334	40335	Fixed frequency 8	R/W	Hz	100	-327.6	58 - 327.67	P1008	P1008
339	40340	Reference	R	Hz	100	-327.6	58 - 327.67	r0020	r0020
340	40341	Speed	R	RPM	1	-1625	0 - 16250	r0022	r0022
341	40342	Frequency output	R	Hz	100	-327.6	58 - 327.67	r0024	r0024
342	40343	Voltage output	R	V	1	0 - 32	767	r0025	r0025
343	40344	DC bus voltage	R	V	1	0 - 32	767	r0026	r0026
344	40345	Current filtered	R	А	100	0 - 16	3.83	r0027	r0027
345	40346	Torque	R	Nm	100	-325.0	0 - 325.00	r0031	r0031
346	40347	Actual power	R	kW	100	0 - 32	7.67	r0032	r0032
347	40348	Total kWh	R	kWh	1	0 - 32	767	r0039	r0039
348	40349	Hand/auto	R	-	1	HAND	AUTO	r0807	r0807

.

Register No.		Description	Access	Unit	Scaling	Range or On/Off	Read	Write
Converter	MODBUS				factor	text		
349	40350	Current unfiltered	R	А	100	0 - 163.83	r0068	r0068
359	40360	Continuous boost	R/W	%	10	0.0 - 250.0	P1310	P1310
360	40361	Minimum frequency	R/W	Hz	100	0.00 - 250.00	P1080	P1080
361	40362	Maximum frequency	R/W	Hz	100	0.00 - 250.00	P1082	P1082
368	40369	JOG frequency	R/W	Hz	100	0.00 - 650.00	P1058[0]	P1058[0]
369	40370	JOG frequency	R/W	Hz	100	0.00 - 650.00	P1058[1]	P1058[1]
370	40371	JOG frequency	R/W	Hz	100	0.00 - 650.00	P1058[2]	P1058[2]
371	40372	JOG frequency left	R/W	Hz	100	0.00 - 650.00	P1059[0]	P1059[0]
372	40373	JOG frequency left	R/W	Hz	100	0.00 - 650.00	P1059[1]	P1059[1]
373	40374	JOG frequency left	R/W	Hz	100	0.00 - 650.00	P1059[2]	P1059[2]
399	40400	Fault 1	R	-	1	0 - 32767	r0947[0]	r0947[0]
400	40401	Fault 2	R	-	1	0 - 32767	r0947[1]	r0947[1]
401	40402	Fault 3	R	-	1	0 - 32767	r0947[2]	r0947[2]
402	40403	Fault 4	R	-	1	0 - 32767	r0947[3]	r0947[3]
403	40404	Fault 5	R	-	1	0 - 32767	r0947[4]	r0947[4]
404	40405	Fault 6	R	-	1	0 - 32767	r0947[5]	r0947[5]
405	40406	Fault 7	R	-	1	0 - 32767	r0947[6]	r0947[6]
406	40407	Fault 8	R	-	1	0 - 32767	r0947[7]	r0947[7]
407	40408	Warning	R	-	1	0 - 32767	r2110[0]	r2110[0]
498	40499	Parameter error code	R	-	1	0 - 254	-	-
499	40500	PID enable	R/W	-	1	0 - 1	r0055.8	(BICO) P2200
500	40501	PID setpoint reference	R/W	%	100	-200.0 - 200.0	P2240	P2240
509	40510	Low pass	R/W	-	100	0.00 - 60.0	P2265	P2265
510	40511	Feedback gain	R/W	%	100	0.00 - 500.00	P2269	P2269
511	40512	Proportional gain	R/W	-	1000	0.000 - 65.000	P2280	P2280
512	40513	Integral gain	R/W	S	1	0 - 60	P2285	P2285
513	40514	Differential gain	R/W	-	1	0 - 60	P2274	P2274
514	40515	PID upper limit	R/W	%	100	-200.0 - 200.0	P2291	P2291
515	40516	PID lower limit	R/W	%	100	-200.0 - 200.0	P2292	P2292
519	40520	PID setpoint output	R	%	100	-100.0 - 100.0	r2250	r2250
520	40521	PID feedback	R	%	100	-100.0 - 100.0	r2266	r2266
521	40522	PID output	R	%	100	-100.0 - 100.0	r2294	r2294
549	40550	Parameter number	RW	-	1	0 - 65535	-	-
550	40551	Parameter index	RW	-	1	0 - 65535	-	-
551	40552	Reserved	RO	-	-	-	-	-
553	40554	Parameter upper word	RW	-	1	0 - 65535	-	-
554	40555	Parameter lower word	RW	-	1	0 - 65535	-	-
557	40558	Parameter upper word	RO	-	1	0 - 65535	-	-
558	40559	Parameter lower word	RO	-	1	0 - 65535	-	-
600	40601	DS47 control	R/W	-	-	-	-	-
601	40602	DS47 header	R/W	-	-	-	-	-
602	40603	DS47 data 1	R/W	-	-	-	-	-
721	40722	DS47 data 120	R/W	-	-	-	-	-

#### **Program example**

```
The program below gives an example of calculating the CRC for MODBUS RTU.
unsigned int crc_16 (unsigned char *buffer, unsigned int length)
{
 unsigned int i, j, temp bit, temp int, crc;
 crc = 0xFFFF;
 for ( i = 0; i < length; i++ )</pre>
  {
   temp_int = (unsigned char) *buffer++;
   crc ^= temp_int;
   for (j = 0; j < 8; j++)
     temp bit = crc & 0 \times 0001;
     crc >>= 1;
     if ( temp_bit != 0 )
     crc ^= 0xA001;
    }
  }
}
```

#### **Parameter scaling**

Due to the limits of the integer data in the MODBUS protocol, it is necessary to convert the converter parameters before transmitting them. This is done by scaling, so that a parameter, which has a position after decimal point, is multiplied by a factor, to get rid of the fractional part. The scaling factor is as defined in the above table.

#### **BICO** parameters

The updating of BICO parameters will also be done in the parameter processing in the background. Because of the limitations of the register value, it is only possible to write a '0' or a '1' to a BICO parameter. This will set BICO input to a static value of either '0' or '1'. The previous connection to another parameter is lost. Reading the BICO parameter will return the current value of the BICO output.

For example: MODBUS register number 40200. Writing a value 0 or 1 to that register will set the BICO input P0731 statically to that value. Reading will return the BICO output, which is stored in r0747.0.

#### Fault

The converter displays the fault F72 when the following three conditions are met:

- The parameter P2014 (USS/MODBUS telegram off time) is not equal to 0.
- Process data has been received from the master since the converter's start-up.
- The time between receipts of two consecutive process data telegrams exceeds the value of P2014.

Communicating with the PLC

7.2 MODBUS communication

# 8.1 Introduction to parameters

#### Parameter number

Numbers prefixed with an "r" indicate that the parameter is a "read-only" parameter.

Numbers prefixed with a "P" indicate that the parameter is a "writable" parameter.

**[index]** indicates that the parameter is an indexed parameter and specifies the range of indices available. If the index is [0...2] and the meaning is not listed, then see "Data set".

**.0...15** indicates that the parameter has several bits, which can be evaluated or connected individually.

#### Data set

#### Note

The "Index" chapter at the end of this manual provides complete lists of CDS/DDS parameters.

In the converter, the parameters which are used to define the sources for commands and setpoints are combined in the **Command Data Set** (CDS), while the parameters for the open and closed-loop control of the motor are combined in the **Drive Data Set** (DDS).

The converter can be operated from different signal sources by switching over the command data sets. When switching over the drive data sets, it is possible to switch between different converter configurations (control type, motor).

Three independent settings are possible for each data set. These settings can be made using the index [0...2] of the particular parameter.

Index	CDS	DDS
[0]	Command data set 0	Drive data set 0
[1]	Command data set 1	Drive data set 1
[2]	Command data set 2	Drive data set 2

SINAMICS V20 has an integrated copy function which is used to transfer data sets. This can be used to copy CDS/DDS parameters corresponding to the particular application.

Copy CDS	Copy DDS	Remarks
P0809[0]	P0819[0]	The data set which is to be copied (source)
P0809[1]	P0819[1]	The data set into which data is to be copied (target)
P0809[2]	P0819[2]	= 1: Start copying
		= 0: Copying completed

8.1 Introduction to parameters

For example, copying of all values from CDS0 to CDS2 can be accomplished by the following procedure:

- 1. Set P0809[0] = 0: copy from CDS0
- 2. Set P0809[1] = 2: copy to CDS2
- 3. Set P0809[2] = 1: start copy

#### Command data set

The command data sets are changed over using the BICO parameters P0810 and P0811, whereby the active command data set is displayed in parameter r0050. Changeover is possible in both the "Ready" and the "Run" states.

P0810 = 0	CDS0
P0811 = 0	
P0810 = 1	CDS1
P0811 = 0	
P0810 = 0 or 1	CDS2
P0811 = 1	

#### Drive data set

The drive data sets are changed over using the BICO parameters P0820 and P0821, whereby the active drive data set is displayed in parameter r0051. Drive data sets can only be changed over in the "Ready" state.

P0820 = 0	DDS0
P0821 = 0	
P0820 = 1	DDS1
P0821 = 0	
P0820 = 0 or 1	DDS2
P0821 = 1	

#### BI, BO, CI, CO, CO/BO in parameter names


#### Note

The "Index" chapter at the end of this manual provides groups of the BICO parameters.

Certain parameter names include the following abbreviated prefixes: BI, BO, CI, CO and CO/BO followed by a colon. These abbreviations have the following meanings:

BI	=	(0)	Binector input: Parameter selects the source of a binary signal Each BI parameter can connect as the input to any BO or CO/BO parameter.
BO	=	r9999	Binector output: Parameter connects as a binary signal Each BO parameter can connect as the output to any BI parameter.
CI	=	P99999 > (0)	Connector input: Parameter selects the source of an analog signal Each CI parameter can connect as the input to any CO or CO/BO parameter.
СО	=	[99]	Connector output: Parameter connects as an analog signal Each CO parameter can connect as the output to any CI parameter.
CO/BO	=	(19999) (19999)	Connector/binector output: Parameter connects as an analog signal and/or as a binary signal Each CO/BO parameter can connect as the output to any BI or CI parameter.

# **BICO example**



BICO or the binary interconnection technology can help the user to connect internal function and values to realize more customized features.

BICO functionality is a different, more flexible way of setting and combining input and output functions. It can be used in most cases in conjunction with the simple, access level 2 settings.

The BICO system allows complex functions to be programmed. Boolean and mathematical relationships can be set up between inputs (digital, analog, serial etc.) and outputs (converter current, frequency, analog output, digital outputs, etc.).

The default parameter that a BI or CI parameter is connected to is shown in the Factory default column of the parameter list.

8.1 Introduction to parameters

### Access level (P0003)

Defines the level of user access to parameter sets.

Access level	Description	Remarks
0	User-defined parameter list	Defines a limited set of parameters to which the end user has access. See P0013 for details on use.
1	Standard	Allows access into most frequently used parameters.
2	Extended	Allows extended access to more parameters.
3	Expert	For expert use only.
4	Service	Only for use by authorized service personnel, password protected.

#### Data type

The data types available are shown in the table below.

U8	8-bit unsigned
U16	16-bit unsigned
U32	32-bit unsigned
116	16-bit integer
132	32-bit integer
Float	32-bit floating point number

Depending on the data type of the BICO input parameter (signal sink) and BICO output parameter (signal source) the following combinations are possible when creating BICO interconnections:

	BICO input parameter						
	CI parameter	BI parameter					
BICO output parameter	U32/I16 U32/I32		U32/Float	U32/Bin			
CO: U8	$\checkmark$	$\checkmark$	-	-			
CO: U16	$\checkmark$		-	-			
CO: U32	$\checkmark$	$\checkmark$	-	-			
CO: I16			-	-			
CO: I32			-	-			
CO: Float				-			
BO: U8	-	-	-				
BO: U16	-	-	-				
BO: U32	-	-	-				
BO: 116	-	-	-				
BO: 132	-	-	-				
BO: Float	-	-	-	-			
Legend: √: BICO interconnection p -: BICO interconnection n							

#### Scaling

Specification of the reference quantity with which the signal value will be converted automatically.

Reference quantities, corresponding to 100 %, are required for the statement of physical units as percentages. These reference quantities are entered in P2000 to P2004.

In addition to P2000 to P2004 the following normalizations are used:

- TEMP: 100 °C = 100 %
- PERCENT: 1.0 = 100 %
- 4000H: 4000 hex = 100 %

#### Can be changed

Converter state in which the parameter is changeable. Three states are possible:

- Commissioning: C, C(1) or C(30)
- Run: U
- Ready to run: T

This indicates when the parameter can be changed. One, two or all three states may be specified. If all three states are specified, this means that it is possible to change this parameter setting in all three converter states. C shows the parameter is changeable whatever P0010 equals; C(1) shows that the parameter is changeable only when P0010 = 1; C(30) shows that the parameter is changeable only when P0010 = 30.

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r0002	Converter state	-	-	-	-	-	U16	2		
	Displays actual converter state.									
	0 Commissioning mode (P0010 $\neq$ 0)									
	1	Converter ready								
	2	Converter fault active								
	3	Converter start	ing (visible	only while pre-	charging DC li	nk)				
	4	Converter runn	ing							
	5	Stopping (ram	oing down)							
	6	Converter inhib	oited							
0003	User access level	0 - 4	1	U, T	-	-	U16	1		
	Defines user access le	vel to parameter s	ets.			•				
	0	User defined pa	arameter lis	st - see P0013 fo	or details on u	se				
	1	Standard: Allow	vs access in	to most freque	ntly used para	meters				
	2	Extended: Allo	ws extende	d access, for ex	ample, to con	verter I/C	) functio	ons		
	3	Expert: For exp	ert use only	/						
	4	Service: Only fo	or use by au	thorized servic	e, password p	rotected				
P0004	Parameter filter	0 - 24	0	U, T	-	-	U16	1		
	Filters parameters according to functionality to enable a more focused approach to commissioning.									
	0 All parameters									
	2	Converter								
	3	Motor								
	5	Technology ap	plication/ur	nits						
	7	Commands, bir	nary I/O							
	8	Analog input and analog output								
	10	Setpoint chann	el/RFG	-						
	12	Converter featu	ures							
	13	Motor control								
	19	Motor identific	ation							
	20	Communicatio	n							
	21	Warnings/fault	s/monitorin	g						
	22	Technology co	ntroller							
	24	List of modified	d parameter	ſS						
20005	Parameter display selection	0 - 9580	0	C, U, T	-	-	U16	2		
	Selects default display	v parameter (conve	erter display	/).						
xample:	The converter displays				/ default.					
Notice:	If you have set P0005 converter displays the 0 or a non-zero value remains unchanged.	to a non-zero valu value of the selec	ie which re ted parame	presents an acti eter as the defai	ual parameter ult display valı	ue; if you	have se	et P0005		

	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P0007	Backlight delay time	0 - 2000	0	U, T	-	-	U16	3		
	Defines time period after which the backlight of the operator panel display turns off if no buttons have bee pressed.									
	0 Backlight always on									
	1 - 2000			which the back	ight turns off.					
P0010	Commissioning parameter	0 - 30	0	Т	-	-	U16	1		
	Filters parameters so th	at only those re	lated to a pa	articular functio	onal group are	selected	•			
	0	Ready								
	1	Quick commis	sioning							
	2	Converter								
	29	Download								
	30	Factory setting	g							
Dependency:	Reset to 0 for converter P0003 (user access leve		les access tr	narameters						
	<ul> <li>The converter can be commissioned very quickly and easily by setting P0010 = 1. After that only important parameters (e.g.: P0304, P0305, etc.) are visible. The value of these parameters must entered one after the other. The end of quick commissioning and the start of internal calculation done by setting P3900 = 1 - 3. Afterwards parameter P0010 and P3900 will be reset to zero automatically.</li> <li>P0010 = 2</li> <li>For service purposes only.</li> <li>P0010 = 30</li> <li>When resetting the parameters or user default values of converter P0010 must be set to 30.</li> <li>Resetting of the parameters will be started by setting parameter P0970 = 1. The converter will automatically reset all its parameters to their default settings. This can prove beneficial if you exp problems during parameter setup and wish to start again.</li> <li>Resetting of the user default values will be started by setting parameter P0970 = 21. The convert automatically reset all its parameters to the factory default settings. Duration of factory setting w several seconds.</li> </ul>									
	<ul> <li>important parameter entered one after the done by setting P39 automatically.</li> <li>P0010 = 2 For service purposes</li> <li>P0010 = 30 When resetting the Resetting of the para automatically reset problems during para Resetting of the use automatically reset several seconds.</li> </ul>	ers (e.g.: P0304, le other. The en 00 = 1 - 3. After s only. parameters or u ameters will be all its parameter rameter setup a r default values all its parameter	P0305, etc. d of quick co wards parar ser default v started by so rs to their de nd wish to s will be start rs to the fact	) are visible. The ommissioning a meter P0010 an values of conve- etting paramete afault settings. tart again. ted by setting p tory default set	e value of the and the start o nd P3900 will b erter P0010 mu er P0970 = 1. This can prove arameter P097 tings. Duration	se param f internal pe reset t ust be set The conv benefici 70 = 21. <sup>-7</sup> n of facto	eters m l calcula o zero : to 30. erter wi al if you The con ory settir	ust be tion will be experience verter will ng will take		
	<ul> <li>important parameter</li> <li>entered one after the</li> <li>done by setting P39</li> <li>automatically.</li> <li>P0010 = 2</li> <li>For service purposes</li> <li>P0010 = 30</li> <li>When resetting the</li> <li>Resetting of the para</li> <li>automatically reset</li> <li>problems during para</li> <li>Resetting of the use</li> <li>automatically reset</li> </ul>	ers (e.g.: P0304, e other. The en 00 = 1 - 3. After s only. parameters or u ameters will be all its parameter rameter setup a r default values all its parameter r default values onverter will au	P0305, etc. d of quick co wards parar seer default v started by so rs to their de nd wish to s will be start rs to the fact in EEPROM tomatically	) are visible. The ommissioning a meter P0010 and values of conve- etting parameter efault settings. tart again. ted by setting p tory default set will be started reset all its para	e value of the and the start o nd P3900 will b erter P0010 mu er P0970 = 1. This can prove arameter P097 tings. Duration by setting para	se param f internal pe reset t ust be set The conv benefici 70 = 21. <sup>-1</sup> n of facto ameter P(	eters m l calcula o zero : to 30. erter wi al if you The con ory settir	ust be tion will be experience verter will ng will take 31 (special		
P0011	<ul> <li>important parameter entered one after the done by setting P39 automatically.</li> <li>P0010 = 2 For service purposes</li> <li>P0010 = 30 When resetting the Resetting of the para automatically reset problems during para Resetting of the use automatically reset several seconds.</li> <li>Resetting of the use factory reset). The construction</li> </ul>	ers (e.g.: P0304, e other. The en 00 = 1 - 3. After s only. parameters or u ameters will be all its parameter rameter setup a r default values all its parameter r default values onverter will au	P0305, etc. d of quick co wards parar seer default v started by so rs to their de nd wish to s will be start rs to the fact in EEPROM tomatically	) are visible. The ommissioning a meter P0010 and values of conve- etting parameter efault settings. tart again. ted by setting p tory default set will be started reset all its para	e value of the and the start o nd P3900 will b erter P0010 mu er P0970 = 1. This can prove arameter P097 tings. Duration by setting para	se param f internal pe reset t ust be set The conv benefici 70 = 21. <sup>-1</sup> n of facto ameter P(	eters m l calcula o zero : to 30. erter wi al if you The con ory settir	ust be tion will be experience verter will ng will take 31 (special		
P0011	<ul> <li>important parameter entered one after the done by setting P39 automatically.</li> <li>P0010 = 2</li> <li>For service purposes</li> <li>P0010 = 30</li> <li>When resetting the Resetting of the para automatically reset problems during para Resetting of the use automatically reset several seconds.</li> <li>Resetting of the use factory reset). The consettings. Duration of Lock for user-defined</li> </ul>	ers (e.g.: P0304, e other. The en 00 = 1 - 3. After s only. parameters or u ameters will be all its parameter rameter setup a r default values all its parameter r default values onverter will au <u>f factory setting</u>	P0305, etc. d of quick co wards parar ser default v started by s s to their de nd wish to s will be start s to the fact in EEPROM tomatically will take se	) are visible. The provision of the prov	e value of the and the start o nd P3900 will b erter P0010 mu er P0970 = 1. This can prove arameter P097 tings. Duration by setting para ameters in EEP	se param f internal pe reset t ust be set The conv benefici 70 = 21. <sup>-1</sup> n of facto ameter P(	to 30. to 30. erter wi al if you The con ory settir 0970 = 3 the facto	ust be tion will b experience verter will ng will take 31 (special ory default		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P0013[019]		0 - 65535	[016] 0	U, T	-	-	U16	3		
	parameter		[17] 3							
			[18] 10							
			[19] 12							
	Defines a limited set of <b>Instructions for use:</b>	parameters to w	hich the en	d user has acce	255.					
	1. Set P0003 = 3 (expe	rt user).								
	2. Go to P0013 indices		t)							
	3. Enter into P0013 inc		•	equired to be v	isible in the us	ser-defin	ed list.			
	The following values	s are fixed and ca	annot be ch	anged:						
	- P0013 index 17 = 3	3 (user access lev	/el)							
	- P0013 index 18 = 1	10 (commissioni	ng paramet	er filter)						
	- P0013 index 19 = 1	12 (key for user o	defined para	ameter)						
	4. Set P0003 = 0 to act	-	-							
Index:	[0]	1st user param								
	[1]	2nd user param								
	[19]	20th user para	neter							
Dependency:	First, set P0011 ("lock") to a different value then P0012 ("key") to prevent changes to user-defined parameter.									
	Then, set P0003 to 0 to	activate the use	r-defined lis	t.						
	When locked and the user-defined parameter is activated, the only way to exit the user-defined parameter (and view other parameters) is to set P0012 ("key") to the value in P0011 ("lock").									
P0014[02]	Store mode	0 - 1	0	U, T	-	-	U16	3		
	Sets the store mode for	parameters. The	store mode	e can be config	ured for all int	erfaces u	under "li	ndex".		
	0	Volatile ( RAM)								
	1	Non-volatile (E	EPROM)							
Index:	[0]	USS/Modbus or	n RS485							
	[1] USS on RS232 (reserved)									
	[2] Reserved									
Note:	An independent store request may be part of the serial communications (for example, PKE bits 15-12 of Up protocol). See the table below for an influence on the settings of P0014.									
	Value of P0014 [x]	Store request	via USS			Resul	t			
	RAM	EEPROM				EEPRC	M			
	EEPROM	EEPROM				EEPRC	M			
	RAM									
	EEPROM	RAM				EEPRC	M			
	1. PO014 itself will alw	5								
	<ol> <li>P0014 will not be changed by performing a factory reset.</li> <li>When transferring parameter P0014, the converter uses its processor to carry-out internal calculations. Communications - both via USS as well as Modbus - are interrupted for the time that it takes to make these calculations.</li> </ol>									

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
P0016	Parameter e lock on BOP		0 - 1	0	C, U, T	-	-	U16	3	
			ing on the BOP							
	0				on BOP (imme	diately effectiv	e)			
	1							r power-	cvcle)	
Note:	1       Disable parameter editing on BOP (e         In addition to enabling parameter editing with P0016=0, you         enable the editing. Long-press         Image: Image				16=0, you can til "ULOC?" appe	alternatively u	se the BC	OP butto	ons to	
r0017	CO/BO: BOP status		-	-	-	-	-	U16	3	
	Shows the ir	nmediate st	atus of the BOI	P buttons.		I				
	Bit	Signal na				1 signal		0 sign	al	
	00	Run butto				Yes		No		
	01	Stop butt				Yes		No		
	02	· ·	TO button com	bination (O	K + M)	Yes		No		
	03	OK butto			•	Yes		No		
	05	Up butto	า		Yes		No			
	06	Down bu	tton			Yes		No		
	07							No		
Note:	Bit 07 (ON/C the stop but		nain high if the n pressed.	e run button	has been press	ed and release	ed. It will	only be	reset or	
r0018	Firmware v	ersion	-	-	-	-	-	Float	1	
	Displays vers	sion numbe	r of installed fir	mware.						
r0019.014	CO/BO: Ope panel contr		-	-	-	-	-	U16	3	
	Displays status of operator panel commands. The settings below are used as the "source" codes for keypac control when connecting to BICO input parameters.									
	Bit	Signal na	me		1 signal		0 signal			
	00	ON/OFF1				Yes		No		
	01	OFF2: Ele	ctrical stop			No		Yes		
	08	JOG right				Yes		No		
	11	Reverse (	setpoint inversi	ion)		Yes		No		
	13	Motor po	tentiometer M	OP up		Yes		No		
	14	Motor po	tentiometer M	OP down		Yes		No		
Note:	When BICO t status of the		is used to alloca mmand.	ate function	s to panel butto	ons, this param	neter disp	plays the	e actual	
r0020	CO: Frequer setpoint be [Hz]		-	-	-	-	-	Float	3	
	Displays actu (r0020) and	ual frequend unfiltered (	cy setpoint (inp r1119). The act	ut of ramp f tual frequen	unction genera cy setpoint afte	tor). This valuer RFG is displa	e is availa yed in r1	able filte 170.	ered	
r0021	CO: Actual f frequency [		-	-	-	-	-	Float	2	
	Displays actu frequency lin	ual converte mitation in V	er output freque //f mode).	ency (r0024)	) excluding slip	compensatior	n (and res	sonance	dampin	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r0022	Actual filtered rotor speed [RPM]	-	-	-	-	-	Float	3			
		Displays calculated rotor speed based on r0021 (filtered output frequency [Hz] x 120/number of poles). The value is updated every 128 ms.									
Note:	This calculation makes r	no allowance for	<sup>r</sup> load-deper	ndent slip.							
r0024	CO: Actual filtered output frequency [Hz]	-	-	-	-	-	Float	3			
	Displays actual filtered of are included). See also r							limitation			
r0025	CO: Actual output voltage [V]	-	-	-	-	-	Float	2			
	Displays filtered [rms] v (r0072).	oltage applied to	o motor. Th	is value is availat	ole filtered (r0	025) an	ıd unfilt	ered			
r0026[0]	CO: Actual filtered DC-link voltage [V]	-	-	-	-	-	Float	2			
	Displays filtered DC-link	voltage. This va	lue is availa	ble filtered (r002	26) and unfilt						
Index:	[0]	Compensation	DC voltage	channel			- Float and frequency li d (r0066). - Float 025) and unfilter - Float red (r0070). - Float filtered (r0068). - Float - Float 080). sured on the sha				
Note:	r0026[0] = Main DC-link For more about the DC-	-	shold value	s, see P0210.							
r0027	CO: Actual output current [A]	-	-	-	P2002	-	Float	2			
	Displays rms value of m	otor current. Th	is value is a	vailable filtered (	r0027) and u	nfiltered	l (r0068	).			
r0028	CO: Motor current modulus	-	-	-	P2002	-	1	3			
	Displays estimated rms	value of motor o	current calc	ulated from dclin	k current.						
r0031	CO: Actual filtered torque [Nm]	-	-	-	-	-	Float	2			
	Displays electrical torque. This value is available filtered (r0031) and unfiltered (r0080).										
Note:	The electrical torque is windage and friction a					asured c	on the sł	naft. Due t			
r0032	CO: Actual filtered power	-	-	-	r2004	-	Float	2			
	Displays (mechanical) shaft power. Value is displayed in [kW] or [hp] depending on setting for P0100 (operation for Europe/North America). P_mech = 2 * Pi * f * M> r0032[kW] = (2 * Pi/1000) * (r0022/60)[1/min] * r0031[Nm] r0032[hp] = r0032[kW]/0.75										
r0035[02]	CO: Actual motor temperature [°C]	-	-	-	-	DDS	Float	2			
	Displays calculated mot	or temperature.					-				
r0036	CO: Converter overload utilization [%]	-	-	-	PERCENT	-	Float	3			
	Displays converter overload utilization calculated via the I <sup>2</sup> t model. The actual I <sup>2</sup> t value relative to the maximum possible I <sup>2</sup> t value supplies utilization in [%]. If the current exceeds the threshold for P0294 (converter I <sup>2</sup> t overload warning), warning A505 (converter I <sup>2</sup> t) is generated and the output current of the converter reduced via P0290 (converter overload reaction).										
	If 100 % utilization is ex	•				2.101 01	2	5400000			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r0037[01]	CO: Converter temperature [°C]	-	-	-	-	-	Float	3			
	Displays measured heat sink temperature and calculated junction temperature of IGBTs based on thermal model.										
Index:	[0]	Measured heat	sink tempe	erature							
	[1] Total Chip Junction Temperature										
Note:	The values are updated	every 128 ms.									
r0038	CO: Filtered power factor	-	-	-	-	-	Float	3			
	Displays the filtered pow	ver factor.	-		-						
r0039	CO: Energy consumpt. meter [kWh]	-	-	-	-	-	Float	2			
	Displays electrical energe consumption meter).				eset (see POO4	40 - rese	t energy	/			
Dependency:	Value is reset when P00	40 = 1 (reset en	ergy consu	mption meter).							
P0040	Reset energy consumpt. and energy saved meter	0 - 1	0	Т	-	-	U16	2			
	Resets value of r0039 (energy consumption meter) and r0043 (energy saved meter) to zero.										
	0 No reset										
	1 Reset r0039 to 0										
P0042[01]	Energy saving scaling	0.000 - 100.00	0.000	Т	-	-	Float	2			
	Scales the calculated energy saved value										
ndex:	[0] Factor for kWh to currency conversion										
	[1]	Factor for kWh	to CO2 cor	iversion							
0043[02]	Energy saved [kWh]	-	-	-	-	-	Float	2			
	Displays calculated energy saved										
Index:	[0] Energy saving in kWh										
	[1] Energy saving in currency										
	[2]	Energy saving i	in CO2	ſ			1				
r0050	CO/BO: Active command data set	-	-	-	-	-	U16	2			
	Displays currently active command data set.										
	0 Command data set 0 (CDS)										
	1 Command data set 1 (CDS)										
	2 Command data set 2 (CDS)										
Note:	See P0810			1							
r0051[01]	CO: Active drive data set (DDS)	-	-	-	-	-	U16	2			
	Displays currently select			t (DDS).							
	0 Drive data set 0 (DDS0)										
	1 Drive data set 1 (DDS1)										
	2	Drive data set 2									
Index:	[0]	Selected drive									
	[1]	Active drive da	ta set								
Note:	See P0820										

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r0052.015	CO/BO: Activ word 1	ve status	-	-	-	-	-	U16	2
	Displays first	active stat	us word of conve	erter (bit fo	rmat) and can be	e used to diag	nose cor	nverter	status.
	Bit Signal name						1 signal		al
	00	Converter ready					Yes		
	01	Converte	Yes		No				
	02	Operation	Yes		No				
	03	Converte	Yes		No				
	04	OFF2 acti	ve			No		Yes	
	05	OFF3 acti	ve			No		Yes	
	06	ON inhibi	t active			Yes		No	
	07	Converte	r warning active			Yes		No	
	08	Deviation	setpoint/act. va	lue		No		Yes	
	09	PZD cont	rol			Yes		No	
	10	f act >=	P1082 (f max)	Yes		No			
	11	Warning:	Motor current/te	No		Yes			
	12	Brake ope	en	Yes		No			
	13	Motor ov		No		Yes			
	14	Motor ru		Yes		No			
	15						No Yes		
Dependency:	r0052 bit 03 High = No Fa			Itput of bit	3 (Fault) will be	-	igital out		w = Fault,
	High = No Fa r0052 bit 06 OFF3. See r2197 ar	ault); "On inhibit 	fault active": Ou	)FF2 or OFF	3 and becomes	inverted on d	OFF1, N	put (Lo OT OFF	2 and NO
Dependency:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp	ault); "On inhibit nd r2198. ion about t port.industry	fault active": Ou " is active with C he state diagram	)FF2 or OFF		disabled with	OFF1, N	put (Lo OT OFF the FAG net.	2 and NO
Note:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp CO/BO: Activ word 2	ault); "On inhibit nd r2198. ion about t oort.industry ve status	fault active": Ou " is active with C he state diagram /.siemens.com/c -	DFF2 or OFF	3 and becomes er-on and the ON ew/109795851) -	disabled with	OFF1, N	put (Lo OT OFF the FA(	2 and NO
Note:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp CO/BO: Activ word 2 Displays seco	ault); "On inhibit nd r2198. ion about t oort.industry ve status	fault active": Ou " is active with C he state diagram /.siemens.com/c - vord of converte	DFF2 or OFF	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with I/OFF1 comm provided on t	OFF1, N	put (Lo OT OFF the FA( net. U16	2 and NO
Note:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp CO/BO: Activ word 2 Displays seco Bit	ault); "On inhibit ond r2198. ion about t ort.industry ve status ond status v Signal na	fault active": Ou " is active with C he state diagram <u>, siemens.com/c</u> - vord of converte	DFF2 or OFF	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with I/OFF1 comm provided on t - 1 signal	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b>	2 and NO
Note:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp CO/BO: Activ word 2 Displays secc Bit 00	ault); "On inhibit ion about t oort.industry ve status ond status v Signal na DC brake	fault active": Ou " is active with C he state diagram siemens.com/c - vord of converte me active	DFF2 or OFF	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with I/OFF1 comm provided on t - 1 signal Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No	2 and NO
Note:	High = No Fa r0052 bit 06 OFF3. See r2197 ar For informat (https://supp CO/BO: Activ word 2 Displays secc Bit 00 01	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > F	fault active": Ou " is active with C he state diagram siemens.com/c - vord of converte me active 22167 (f_off)	DFF2 or OFF	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with I/OFF1 comm provided on t - 1 signal Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No	2 and NO
Note:	High = No Fa           r0052 bit 06           OFF3.           See r2197 ar           For informat           (https://supp           CO/BO: Activ           word 2           Displays secco           Bit           00           01           02	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > F  f_act  > F	fault active": Ou " is active with C he state diagram siemens.com/c - vord of converte me active 22167 (f_off) 21080 (f_min)	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	I/OFF1 comm provided on t - <b>1 signal</b> Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No No	2 and NO
Note:	High = No Fa           r0052 bit 06           OFF3.           See r2197 ar           For informat           (https://supp           CO/BO: Activ           word 2           Displays secco           Bit           00           01           02           03	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > F Act. curre	fault active": Ou " is active with C he state diagram <u>, siemens.com/c</u> - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	I/OFF1 comm provided on t - 1 signal Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FAt net. U16 <b>0 sign</b> No No No	2 and NO Q 2
Note:	High = No Fa           r0052 bit 06           OFF3.           See r2197 ar           For informat (https://supp           CO/BO: Activ word 2           Displays secco           Bit           00           01           02           03           04	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > I Act. curre  f_act  > I	fault active": Ou " is active with C he state diagram <u>/.siemens.com/c</u> - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1)	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with //OFF1 comm provided on t - 1 signal Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secco         Bit         00         01         02         03         04         05	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > F  f_act  > F  f_act  > F  f_act  <=	fault active": Ou " is active with C he state diagram .siemens.com/c - vord of converte me active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) P2155 (f_1)	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	I/OFF1 comm provided on t - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secco         Bit         00         01         02         03         04         05         06	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake $ f_act  > f$ $Act. curred  f_act  > f f_act  <=f_act  > s$	fault active": Ou " is active with C he state diagram <u>7.siemens.com/c</u> - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) 5 P2155 (f_1) 5 etpoint (f_set)	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	I/OFF1 comm provided on t - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secce         Bit         00         01         02         03         04         05         06         07	ault); "On inhibit ion about t ion about t ort.industry ve status DC brake  f_act  > f Act. curre  f_act  > f  f_act  > s  f_act  > s Act. unfil	fault active": Ou " is active with C he state diagram /.siemens.com/c - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) P2155 (f_1) Ent point (f_set) t. Vdc < P2172	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with //OFF1 comm provided on t - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 <b>0 sign</b> No No No No No No No No	2 and NO
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secco         Bit         00         01         02         03         04         05         06         07         08	ault); "On inhibit ion about t ort.industry ve status DC brake $ f_act  > R$ $ f_act  > R$ $ f_act  < $	fault active": Ou " is active with C he state diagram .siemens.com/c - vord of converte me active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) E2155 (f_1) E2155 (f_1) E2155 (f_1) E2155 (f_2) E2155	DFF2 or OFF after powers/ww/en/vie 	3 and becomes er-on and the ON ew/109795851) -	inverted on d disabled with VOFF1 comm provided on t - Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secco         Bit         00         01         02         03         04         05         06         07         08         09	ault); "On inhibit ion about t ort.industry ve status DC brake $ f_act  > I$ $ f_act  > I$ $ f_act  <=$ $ f_act  <=$ $f_act >=$ $act. curret  f_act  <=act. unfilAct. unfilRamping$	fault active": Ou " is active with C he state diagram .siemens.com/c - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) ep2155 (f_1) ep2155 (f_1) setpoint (f_set) t. Vdc < P2172 finished	2170	3 and becomes a ser-on and the ONew/109795851) - mat).	I/OFF1 comm provided on t - - <b>1 signal</b> Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No No No No No	2 and NO Q 2
	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secco         Bit         00         01         02         03         04         05         06         07         08	ault); "On inhibit ion about t ort.industry ve status ond status v Signal na DC brake  f_act  > F Act. curre  f_act  > F Act. curre  f_act  > F Act. unfil Act. unfil Ramping PID outpu	fault active": Ou " is active with C he state diagram <u>/.siemens.com/c</u> - vord of converte active 22167 (f_off) 21080 (f_min) 21080 (f_min) 2155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_2) 22155 (f_2) 22152 (f_2)	DFF2 or OFF after powe s/ww/en/vie - r (in bit for 2170 22(PID_mir	3 and becomes a ser-on and the ONew/109795851) - mat).	inverted on d disabled with VOFF1 comm provided on t - Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secce         Bit         00         01         02         03         04         05         06         07         08         09         10         11	ault); "On inhibit ion about t ion about t iort.industry ve status ond status v Signal na DC brake  f_act  > F  f_act  > F  f_act  > F  f_act  > S Act. currer  f_act  > S Act. unfil Act. unfil Ramping PID outpu	fault active": Ou " is active with C he state diagram .siemens.com/c - vord of converte active 22167 (f_off) 21080 (f_min) ent  r0068  >= P2 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 32155 (f_1) 32155 (f_2) 400 (f_set) t. Vdc < P2172 t. Vdc > P2172 finished ut r2294 == P229 tt r2294 == P229	DFF2 or OFF after powe s/ww/en/vie - - - - - - - - - - - - - - - - - - -	3 and becomes a ser-on and the ONew/109795851) - mat).	I/OFF1 comm provided on t - - <b>1 signal</b> Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No No No No No	2 and NO Q 2
Note:	High = No Fa         r0052 bit 06         OFF3.         See r2197 ar         For informat         (https://supp         CO/BO: Activ         word 2         Displays secce         Bit         00         01         02         03         04         05         06         07         08         09         10         11	ault); "On inhibit ion about t ion about t iort.industry ve status ond status v Signal na DC brake  f_act  > F  f_act  > F  f_act  > F  f_act  > S Act. currer  f_act  > S Act. unfil Act. unfil Ramping PID outpu	fault active": Ou " is active with C he state diagram <u>/.siemens.com/c</u> - vord of converte active 22167 (f_off) 21080 (f_min) 21080 (f_min) 2155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_1) 22155 (f_2) 22155 (f_2) 22152 (f_2)	DFF2 or OFF after powe s/ww/en/vie - - - - - - - - - - - - - - - - - - -	3 and becomes a ser-on and the ONew/109795851) - mat).	I/OFF1 comm provided on t - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes Yes Yes	OFF1, N	put (Lo OT OFF the FA( net. U16 No No No No No No No No No No No No No	2 and NO Q 2

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
r0054.015	CO/BO: Active control word 1		-	-	-	-	-	U16	3	
	Displays first control word of converter (in bit format) and can be used to diagnose which commands are active.									
	Bit	Signal na	1 signal	1 signal						
	00	ON/OFF1	Yes	Yes						
	01	OFF2: ele	No		Yes					
	02	OFF3: fas	t stop			No		Yes		
	03	Pulse ena	ble			Yes		No		
	04	RFG enab	le			Yes		No		
	05	RFG start			Yes		No			
	06	Setpoint	enable		Yes		No			
	07	Fault ack	nowledge	Yes			No			
	08	JOG right		Yes	Yes		No			
	09	JOG left		Yes		No				
	10	Control fr	om PLC	Yes		No				
	11	Reverse (	setpoint inversi	Yes	Yes					
	13	Motor po	tentiometer M	Yes	Yes		No			
	14	Motor po	tentiometer M	Yes	Yes					
	15	CDS Bit 0	(Hand/Auto)	Yes		No				
Notice:	r0054 is ide	ntical to r20	36 if USS is sel	ected as com	mand source	ia P0700 or P0	)719.	19.		
r0055.015	CO/BO: Acti word 2	ve control	-	-	-	-	-	U16	3	
	Displays additional control word of converter (in bit format) and can be used to diagnose which command are active.									
	Bit	Signal na	ime	1 signal		0 signal				
	00	Fixed free	quency Bit O	Yes		No				
	01	Fixed free	quency Bit 1	Yes		No				
	02	Fixed free	quency Bit 2	Yes		No				
	03	Fixed free	quency Bit 3	Yes	Yes					
	04	Drive dat	a set (DDS) Bit (	Yes	Yes					
	05	Drive dat	a set (DDS) Bit	Yes	Yes					
	05			Yes	Yes					
	06	Quick sto	p disable		Enable PID					
			•			Yes		No		
	06		D			Yes Yes		No No		
	06 08	Enable PI	D C brake							

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r0056.015	CO/BO: Statu motor contr		-	-	-	-	-	U16	3		
	Displays status of motor control (in bit format), which can be used to diagnose converter status.										
	Bit	1 signal	0 signal								
	00	Yes		No							
	01	Motor demagnetizing finished					Yes				
	02	Pulses en	Yes	No							
	03	Voltage s	Yes	No							
	04	Motor ex	citation finished			Yes		No			
	05	Starting boost active						No			
	06	Accelerat	Yes		No						
	07	Frequenc	Yes		No						
	08	Field wea		Yes		No					
	09		oint limited	Yes	No						
	10		ency limited	Yes		No					
	11		_max Freq. limite	Yes		No					
	12		versal selected	Yes	No						
	13	Imax con	Yes		No No						
	14	Vdc_max controller active					Yes				
	15		min control) act			Yes		No			
Notice:	The I-max controller (r0056 bit 13) will be activated when the actual output current (r0027 current limit in r0067.						27) exce	-			
r0066	CO: Actual o frequency [I	Ηz]	-	-	-	-	-	Float	3		
	Displays actual output frequency in Hz. This value is available filtered (r0024) and unfiltered (r0066).										
Note:	The output fr (maximum fr	he output frequency is limited by the values entered in P1080 (minimum frequency) and P1082 maximum frequency).						2			
r0067	CO: Actual o current limit	l output nit [A]		-	-	P2002	-	Float	3		
	Displays valid maximum output current of converter. r0067 is influenced/determined by the following factors:										
	Converter application P0205										
	Rated motor current P0305										
	Motor overload factor P0640										
	Motor protection in dependency of P0610										
	r0067 is less than or equal to maximum converter current r0209										
	Converter protection in dependency of P0290										
Note:			ay indicate a cor	nverter over	load or a motor	overload.	1	1	-		
r0068	CO: Output ( [A]	current	-	-	-	P2002	-	Float	3		
	Displays unfiltered [rms] value of motor current. This value is available filtered (r0027) and unfiltered (r0068).										
Note:	Used for proo through USS		l purposes (in co	ontrast to rC	027, which is fil	tered and is u	sed to d	isplay tł	ne value		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
r0069[05]	CO: Actual phase currents [A]	-	-	-	P2002	-	Float	4				
	Displays measured phas	e currents.			•		•					
Index:	[0]	U Phase/ Emitt	er1/									
	[1]	 Dclink/Emitter2										
	[2]	Dclink										
	[3] Offset U phase/Emitter											
	[4]	Offset dclink										
	[5]	Not used										
r0070	CO: Actual DC-link voltage [V]	-	-	-	-	-	Float	3				
	Displays DC-link voltage	. This value is av	ailable filte	red (r0026) and	unfiltered (r0	070).		1				
Note:	Used for process contro						filtered	).				
r0071	CO: Maximum output voltage [V]	-	-	-	-	-	Float	3				
	Displays maximum outp	out voltage.	•			•	•	•				
Dependency:	· · · ·	-	ds on the ad	tual input suppl	y voltage.							
r0072	CO: Actual output voltage [V]	-	-	-	-	-	Float	3				
	Displays output voltage.	. This value is av	ailable filte	red (r0025) and	unfiltered (r0	072).	•	•				
r0074	CO: Actual modulation [%]	-	-	-	PERCENT	-	Float	4				
		Displays actual modulation index. The modulation index is defined as ratio between the magnitude of the fundamental component in the converter phase output voltage and half of the DC-link voltage.										
r0078	CO: Actual current lsq [A]	-	-	-	P2002	-	Float	3				
	Displays component of	torque generatir	ng current.									
r0080	CO: Actual torque [Nm]	-	-	-	-	-	Float	4				
	Displays actual torque.	This value is ava	ilable filtere	ed (r0031) and u	nfiltered (r00	80).						
r0084	CO: Actual air gap flux [%]	-	-	-	PERCENT	-	Float	4				
	Displays air gap flux rela	ative to the rated	d motor flux	κ.								
r0085	CO: Actual re-active current [A]	-	-	-	P2002	-	Float	3				
	Displays re-active (imag	inary part) of m	otor curren	t.								
Dependency:	Applies when V/f contro	l is selected in P	1300 (cont	rol mode); other	wise, the disp	lay show	vs the v	alue zero				
r0086	CO: Actual active current [A]	-	-	-	P2002	-	Float	3				
	Displays active (real par	t) of motor curre	ent.			•						
Dependency:	See r0085											
r0087	CO: Actual power factor	-	-	-	-	-	Float	3				
f	Displays the actual pow	er factor.		•		•						
			1			1						
r0094	CO: Transformation angle [°]	-	0.0	-	4000H	-	Float	3				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P0095[09]	Cl: Display PZD signals	0 - 4294967295	0	Т	4000H	-	U32	3				
	Selects source of display	for PZD signals.										
Index:	[0]	1st PZD signal										
	[1]	2nd PZD signal										
	[9]	10th PZD signa	I									
r0096[09]	PZD signals [%]	-	-	-	_	-	Float	3				
10030[05]	PZD signals [%]     -     -     -     Float     3       Displays PZD signals.											
Index:	[0] 1st PZD signal											
	[1]	2nd PZD signal										
		[9] 10th PZD signal										
Noto												
Note:	r0096 = 100 % correspo			C(1)		1	1110	1				
P0100	Europe/North America	0 - 2	0	C(1)	-	-	U16	1				
	Determines whether the		•			•						
	The default settings for automatically here, in a	the rated motor ddition to refere	frequency nce frequei	P0310 and maxir ncy P2000.	num frequen	cy P108	2 are se	t				
	0	Europe [kW], m	otor base f	requency is 50 H	z							
	1	North America	[hp], moto	r base frequency	is 60 Hz							
	2	North America	[kW], moto	or base frequency	is 60 Hz							
Dependency:	Where:											
	<ul> <li>Stop converter first (i.e. disable all pulses) before you change this parameter.</li> </ul>											
	<ul> <li>Stop converter first i</li> </ul>	i.e. uisable ali bi	ulses) betoi	e vou change th	is parameter.							
	P0100 can only be c				-	spective	e interfa	ce (for				
		hanged with POC ets all rated mot	)10 = 1 (Co or paramet	mmissioning mo ers as well as oth	de) via the re	•						
r0191[02]	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res</li> </ul>	hanged with POC ets all rated mot	)10 = 1 (Co or paramet	mmissioning mo ers as well as oth	de) via the re	•						
r0191[02]	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu -	010 = 1 (Co or paramet Ilation of m 0	mmissioning mo ers as well as oth otor parameters	de) via the re ner parameter ). -	•	epend c	n the rated				
	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve	mmissioning mo ers as well as oth totor parameters - - ctor) of the conve	de) via the re ner parameter ). - erter.	•	epend c	n the rated				
	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve ponverter an	mmissioning mo ers as well as oth otor parameters	de) via the re ner parameter ). - erter.	•	epend c	n the rated				
	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve ponverter an ponverter	mmissioning mo ers as well as oth otor parameters - ctor) of the conve d power module	de) via the re ner parameter ). - erter.		epend c	n the rated				
Index:	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve ponverter an ponverter	mmissioning mo ers as well as oth otor parameters - ctor) of the conve d power module	de) via the re ner parameter ). - erter.		epend c	n the rated				
Index:	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of co SZL vector of po 0 - 65535	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve poverter an poverter ower modu 0	mmissioning mo ers as well as oth otor parameters - ctor) of the conve d power module le U, T	de) via the re ner parameter ). - erter.		epend c	n the rated				
Index: P0199	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> <li>Specifies the unique equipment equipment</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of co SZL vector of po 0 - 65535	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve poverter an poverter ower modu 0	mmissioning mo ers as well as oth otor parameters - ctor) of the conve d power module le U, T	de) via the re ner parameter ). - erter.		epend c	n the rated				
Index: P0199	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> <li>Specifies the unique equipment Actual power module code number</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of po 0 - 65535 upment system 0 - 65535	010 = 1 (Co or paramet ilation of m 0 ion (SZL ver ponverter an ponverter ower modu 0 number for	mmissioning mo ers as well as oth otor parameters - - - - - - - - - - - - - - - - - - -	de) via the re ner parameter ). - erter. -		epend c U32 U16	n the rated				
Index: P0199 P0201[02]	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> <li>Specifies the unique equitation</li> <li>Actual power module code number</li> <li>Identifies hardware varial</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of co SZL vector of po 0 - 65535 uipment system 0 - 65535	010 = 1 (Co or paramet ilation of m 0 ion (SZL ver ponverter an ponverter power modu 0 number for 0	mmissioning mo ers as well as oth otor parameters - - - - - - - - - - - - - - - - - - -	de) via the re ner parameter ). - erter. -		epend c U32 U16	n the rated				
r0191[02] Index: P0199 P0201[02] Index:	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> <li>Specifies the unique equities the unique equities the unique equities hardware varii</li> <li>[0]</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of po 0 - 65535 upment system 0 - 65535 ant. Converter code	010 = 1 (Co or paramet ilation of m 0 ion (SZL ver onverter an onverter ower modu 0 number for 0	mmissioning mo ers as well as oth totor parameters - - - - - - - - - - - - - - - - - - -	de) via the re ner parameter ). - erter. -		epend c U32 U16	n the rated				
Index: P0199 P0201[02]	<ul> <li>P0100 can only be c example, USS).</li> <li>Changing P0100 res motor parameters (s</li> <li>Configuration converter</li> <li>Displays the actual hard</li> <li>[0]</li> <li>[1]</li> <li>[2]</li> <li>Equipment system number</li> <li>Specifies the unique equitation</li> <li>Actual power module code number</li> <li>Identifies hardware varial</li> </ul>	hanged with POC ets all rated mot ee PO340 - calcu - ware configurati SZL vector of co SZL vector of po 0 - 65535 upment system 0 - 65535 ant. Converter code	010 = 1 (Co or paramet ilation of m 0 ion (SZL ve onverter an onverter ower modu 0 number for 0	mmissioning mo ers as well as oth otor parameters - - - - - - - - - - - - - - - - - - -	de) via the re ner parameter ). - erter. -		epend c U32 U16	n the rate				

Parameter	Function	Rang	e	Factory default	Can b chang		Scaling	Data set	Data type	Acc. Level
r0204	Power modul features	e -		0	-		-	-	U32	3
	Displays hard	vare features of	power n	nodule.						
	Bit	Signal name					1 signal			al
	00	DC input voltage	voltage			Yes				
	01	RFI filter					Yes			
	02	Active line mode	odule			Yes		No		
	03	SLM			Yes				No	
	04	BLM with thryist	tor			Yes			No	
	05	BLM with diode				Yes Yes		No No		
	06	Water cooled								
	07	F3E converter	rerter			Yes		No		
	12	Safe brake	e			Yes		No		
	13	Safety enabled	abled			Yes		No		
	14	Integrated outp				Yes		No		
Note:	Parameter r0204 = 0 indicates that no power module has been identified.									
P0205	Converter ap	plication 0 - 1		0	C1		-	-	U16	3
	Torque	$M \sim \frac{1}{f}$		M = const.		M ~ f		M ~f <sup>2</sup>		
	Power	p = const.		p ~ f		p ~ f <sup>2</sup>		p ~ f <sup>3</sup>		_
	Characteristic	M		M	f		M / / P		M P	 → f
	Application	Winders Facing lathes Rotary cutting machines	i	Hoisting gear Belt conveyors Process mach involving form Rolling mills Planers	ines	Calender viscous f Eddy-cur		Pumps Fans Centrifu	ges	

Parameter	Function	Range	Factory default	Can be	Scaling	Data	Data	Acc.		
	• High overload (HO):		uerault	changed		set	type	Level		
	HO mode is used if th considered to be high pumps.									
	Low overload (LO):									
	LO mode is used if the Low overload offers the	e application has a ne following poss	a parabolic f ibilities with	requency/torque the same conver	characteristic li ter:	ike many	y fans ar	d pumps.		
	<ul> <li>Higher rated conv</li> </ul>									
	<ul> <li>Higher rated conv</li> </ul>	-	6							
	<ul> <li>Higher threshold 1</li> <li>If P0205 is modified in</li> </ul>		oning it imm	odiatoly calculate	s various moto	or norom	otorc			
	– P0305 Rated moto		Jinny it innin		s various moto	n harain	leters.			
	<ul> <li>P0307 Rated motor</li> </ul>									
	<ul> <li>P0640 Motor over</li> </ul>	-								
	It is recommended to	modify P0205 fir	st. Afterward	ds motor paramet	er may be ada	pted.				
	Motor parameter will	be overridden by	changing th	is sequence						
Values:	0	High overload	chunging th	is sequence:						
	1	Low overload								
Notice:	Ise setting 1 (low overload) only for low-overload applications (for example, pumps and fans). Fit is used for high-overload applications, I2t warning will be produced too late, causing overheating in the notor.									
Note:	This parameter selects co (see P0970).	nverter applicatio	n for FSE on	ly. The parameter	r value is not re	eset by t	he facto	ry setting		
r0206	Rated converter power [kW]/[hp]	-	-	-	-	-	Float	2		
	Displays nominal rated m	otor power from	converter.							
Dependency:	Value is displayed in [kW]	or [hp] dependir	ng on setting	for P0100 (opera	ation for Europ	e/North	America	).		
r0207[02]	Rated converter current [A]	-	-	-	-	-	Float	2		
	Displays rated converter of	urrent.								
Index:	[0]	Rated converter	current							
	[1]	Rated LO curren	t							
	[2]	Rated HO curren								
Note:	The rated high overload motors (IEC) for the sele with the HO application Converter current / power	cted load cycle (	207[2] valu (see diagran	n). r0207[2] is tł	suitable 4-po ne default valu ne current	le Siem ie of PO	ens stan 305 in a	dard ssociation		
	% ♠			Short-un	le current					
	r0209 150%	Rated conver	ter current (co	ontinuous)						
	r0207[0] 100%									
	94.5%									
		Base load cur	rent (with ove	erload capability)						
						►t				
	60	s 🖣	— 240 s ——							
r0208	Rated converter voltage [V]	-	-	-	-	-	U32	2		
	Displays nominal AC sup	ply voltage of co	onverter.							
Note:	r0208 = 230: 200 V to 2			0%)						
	r0208 = 400: 380 V to 4									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r0209	Maximum converter current [A]	-	-	-	-	-	Float	2			
	Display the maximum allo	wable output cu	rrent of con	verter.							
Dependency:	In actual applications, Sie pulse frequency P1800, s Operating Instructions.	mens recommen urrounding temp	ds that you erature and	consider the altitude. The	output current data of derati	t derating ng is give	g affecte en in the	d by			
P0210	Supply voltage [V]	380 - 480	400	Т	-	-	U16	3			
	P0210 defines the supply voltage. Its default value depends upon the type of converter. If P0210 does not correspond to the supply voltage, then it must be modified.										
Dependency:	Optimizes Vdc controller, which extends the ramp-down time if regenerative energy from motor would otherwise cause DC-link overvoltage trips.										
	Reducing the value enables controller to cut in earlier and reduce the risk of overvoltage.										
	Set P1254 ("Auto detect Vdc switch-on levels") = 0. Cut-in levels for Vdc controller and compound braking are then derived directly from P0210 (supply voltage):										
	• Vdc_min switch-on level (r1246) = P1245 * sqrt(2) * P0210										
	• Vdc_max switch-on level (r1242) = 1.15 * sqrt(2) * P0210										
	• Dynamic braking switch-on level = 1.13 * sqrt(2) * P0210										
	<ul> <li>Compound braking switch-on level = 1.13 * sqrt(2) * P0210</li> </ul>										
	Set P1254 ("Auto detect Vdc switch-on levels") = 1. Cut-in levels for Vdc controller and compound braking are then derived from r0070 (DC-link voltage):										
	• Vdc_min switch-on level (r1246) = P1245 * r0070										
	• Vdc_max switch-on level (r1242) = 1.15 * r0070										
	• Dynamic braking switch-on level = 0.98 * r1242										
	<ul> <li>Compound braking switch-on level = 0.98 * r1242</li> </ul>										
	Auto-detection calculations are only performed when the converter has been in standby for over 20s. When pulses are enabled, the calculated values are frozen after pulses are ceased for 20s.										
Note:	For best results, it is record P1254 = 0 is only recommendation is being driven. In this case	nended when the	re is a high	degree of flue	ch-on levels (P ctuation of the	1254 = 1 e DC-link	) is used when th	. Setting e motor			
	If mains voltage is higher than value entered, automatic deactivation of the Vdc controller may occur to avoid acceleration of the motor. A warning will be issued in this case (A910).										
_	Default value is dependin	g on converter ty	pe and its r	ating data.				1			
r0231[01]	Maximum cable length [m]	-	-	-	-	-	U16	3			
	Indexed parameter to display maximum allowable cable length between converter and motor.										
Index:	[0] Maximum allowed unscreened cable length										
	[1]	Maximum allow	ed screene	d cable length	ı						
Notice:	For full EMC compliance,	the screened cab	le must not	exceed 25 m	in length whe	en an EM	C filter is	fitted.			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0290	Converter overload reaction	0 - 3	2	Т	-	-	U16	3			
	Selects reaction of conver	ter to an internal	thermal ov	erload condit	ion.						
	0	Reduce output f	requency a	nd output cu	rrent						
	1	No reduction, tr	ip (F4/5/6)	when therma	l limits reache	ed					
	2 Reduce pulse frequency, output current and output frequency										
	3 Reduce pulse frequency only and trip (F6) when overload too high										
Dependency:	Following physical values influence the converter overload protection (see diagram):										
	Heat sink temperature (r0037[0]); causes A504 and F4.										
	• IGBT Junction temperature (r0037[1]); causes F4 or F6.										
	Delta temperature between heat sink and junction temperature; causes A504 and F6.										
	• Converter I <sup>2</sup> t (r0036); causes A505 and F5.										
	Converter overload reaction										
	Converter monitoring P0290										
	$ \begin{array}{c c} r0036 \\ \hline \\ $										
	P0294										
	r0037 Heatsink temperature										
	P0292 IGBT temper P0292	rature	f_pulse	control							
Netter											
Notice:	P0290 = 0, 2:										
	Reduction of output frequency is only effective if the load is also reduced.										
	This is for example valid for light overload applications with a quadratic torque characteristic as pumps or fans.										
	• For settings P0290 = 0 or 2, the I-max controller will act upon the output current limit (r0067) in case of overtemperature.										
	P0290 = 0:										
	With pulse frequencie event of r0027 greate		• •	iency will be	reduced to no	minal im	mediatel	y in the			
	P0290 = 2, 3:										
	• The pulse frequency P 2 Hz.	1800 is reduced	only if high	er than 2 kHz	and if the ope	erating fr	equency	is below			
	• The actual pulse freque displayed in r1801[1].		in r1801[0	] and the mir	nimal pulse fre	equency f	or reduc	tion is			
	• Converter l <sup>2</sup> t acts upo A trip will always result, if	•	•		•	•	-				

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0291[02]	Converter prote	ction	0 - 7	1	U, T	-	DDS	U16	4			
	Bit 00 for enablir benefit is to redu					at output frec	luencies b	elow 2 H	z. The			
	Bit Sig	nal nam	e			1 signal	0 signal					
	00 Pul	se freque	ency reduced belo	ow 2 Hz		Yes	No					
	01 Res	served				Yes	No					
	02 Pha	ase loss d	etection enable			No		Yes				
	03 Res	Reserved						No				
	04 Ou	Output current ripple detection enable						Yes				
	05 Enl	hanced d	ead-time comper	sation ena	ble	No		Yes				
Note:	See P0290											
P0292	Converter temp warning [°C]	erature	0 - 25	5	U, T	-	-	U16	3			
	Defines the temperature difference (in °C) between the overtemperature trip threshold (F4) and the warning threshold (A504) of the converter. The trip threshold is stored internally by the converter and cannot be changed by the user.											
P0294	Converter l <sup>2</sup> t wa [%]	arning	10.0 - 100.0	95.0	U, T	-	-	Float	3			
	Defines the [%] v	Defines the [%] value at which warning A505 (converter I <sup>2</sup> t) is generated.										
	Converter l <sup>2</sup> t calculation is used to determine a maximum tolerable period for converter overload.											
	The $I^2$ t calculation value is deemed = 100 % when this maximum tolerable period is reached.											
Dependency:	The output current of the converter has been reduced.											
			ot exceed 100 %									
Note:	P0294 = 100 % c	orrespon	ds to stationary r	nominal loa	d.							
P0295	Converter fan o time [s]	ff delay	0 - 3600	0	U, T	-	-	U16	3			
	Defines converte	r fan swi	tch-off delay time	e in second	s after convei	rter has stopp	ed.					
Note:	Setting to 0, con	verter fai	n will switch off v	when the co	nverter stops	s, that means	no delay.					
P0296	Response to hig output current r		0 - 2	0	Т	-	-	U16	3			
	Defines the conv	erter res	oonse with increa	ised ripple i	in the output	current.						
	0		No response									
	1		Alarm produced	(A523)								
	2		Fault produced	(F23)								
90301[02]	Easy motor data motor power [k		0 - 2000	0	C(1)	-	DDS	Float	1			
	Rated motor power from the rating plate. No other data is necessary. If this parameter is used, the rest of the motor data are then estimated by the firmware.											
Dependency:		re then e	stimated by the f	irmware.								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0304[02]	Rated motor voltage [V]	10 - 2000	400	C(1)	-	DDS	U16	1			
	Nominal motor voltage from rating plate.										
Dependency:	Changeable only when F Default value is dependi										
Caution:	The input of rating plate delta wiring is used for t IEC Motor	data must corre	v2 W1 W1 V2 V2 V2 V2 V2 V2 V2 V2 V2 V2 V2 V2 V2	he wiring of t		r/delta). T	his mea	ns, if			
Note:	Following diagram show	P031 D-91054 0 1.5 0 220-24C 6,2-5,4/, P030	10 P0304	3Mot. 1LA7096 50107/471101 01 00 ikg IM B3 090L	4-4AA10 1 IEC/EN 60034	E CE	ata.				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0305[02]	Rated motor current [A]	0.01 - 10000.00	1.86	C(1)	-	DDS	Float	1			
	Nominal motor current from rating plate.										
Dependency:	Changeable only when PC	010 = 1 (quick c	ommissioni	ing).							
	Depends also on P0320 (r										
Note:	The maximum value of P0305 depends on the maximum converter current r0209 and the motor type:										
	Asynchronous motor : P0305_max = P0209										
	It is recommended that the ratio of P0305 (rated motor current) and r0207 (rated converter current) should not be lower than: (1/8) <= (P0305/r0207)										
	When the relation of the no exceeds 1.5 an additional of current waves.	ominal motor curre current derating is	ent P0305 a applied. Thi	nd half of the is is necessary	maximal conve to protect the	erter curre converter	ent (r0209 from har	9) monic			
	I <sub>max,Inv</sub>										
	r0209										
	0.7 · r0209										
			•								
	1.5		20305								
	Default value is dependin			ating data							
P0307[02]	Rated motor power	0.01 - 2000.00	0.75	C(1)	-	DDS	Float	1			
10507[02]	Nominal motor power [k]		plate.	. ,							
Dependency:	If P0100 = 1, values will be in [hp].										
. ,	Changeable only when PC		ommissioni	ing).							
Note:	Default value is dependin			0							
P0308[02]	Rated motor cosp	0.000 - 1.000	0.000	C(1)	-	DDS	Float	1			
	Nominal motor power fac	tor (cosφ) from r	ating plate			1					
Dependency:	Changeable only when PC										
	Visible only when $P0100 = 0$ or 2, (motor power entered in [kW]).										
	Setting 0 causes internal	calculation of val	ue. The val	ue is displaye	d in r0332.						
P0309[02]	Rated motor efficiency [%]	0.0 - 99.9	0.0	C(1)	-	DDS	Float	1			
	Nominal motor efficiency	from rating plate	2.								
Dependency:	Changeable only when PC			ing).							
	Visible only when P0100	= 1, (i.e. motor p	ower enter	ed in [hp]).							
	Setting 0 causes internal	calculation of val	ue. The val	ue is displaye	d in r0332.			-			
PO310[02]	Rated motor frequency [Hz]	12.00 - 550.00	50.00	C(1)	-	DDS	Float	1			
	Nominal motor frequency from rating plate.										
Dependency:	Changeable only when PC			ing).							
	Pole pair number recalcul	•		-	ed.						
Note:	Changes to P0310 can inf		<b>F</b> .	-		rmation	see P108	2			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0311[02]	Rated motor speed [RPM]	0 - 40000	1395	C(1)	-	DDS	U16	1			
	Nominal motor speed from	m rating plate.									
Dependency:	Changeable only when PC	010 = 1 (quick c	ommissioni	ng).							
	Setting 0 causes internal	calculation of val	ue.	-							
	Slip compensation in V/f o	control requires ra	ated motor	speed for cor	rect operation	ı <b>.</b>					
	Pole pair number recalcul				d.						
Note:	Default value is dependin	g on converter ty	pe and its r	ating data.	-						
r0313[02]	Motor pole pairs DDS U16 3										
	Displays number of motor pole pairs that the converter is currently using for internal calculations.										
Dependency:	Recalculated automatically when P0310 (rated motor frequency) or P0311 (rated motor speed) is changed r0313 = 1: 2-pole motor r0313 = 2: 4-pole motor 										
P0314[02]	Motor pole pair number	0 - 99	0	C(1)	-	DDS	U16	3			
	Specifies number of pole	pairs of motor.									
Dependency:	Changeable only when P0010 = 1 (quick commissioning).										
	Setting 0 causes r0313 (c r0313. P0314 = 1: 2-pole motor P0314 = 2: 4-pole motor 			o be used du	ing operation	. Setting	10 > 0 00	ennues			
P0320[02]	Motor magnetizing current [%]	0.0 - 99.0	0.0	С, Т	-	DDS	Float	3			
	Defines motor magnetiza	tion current relat	ive to P030	5 (rated moto	or current).						
Dependency:	Setting 0 causes calculation by P0340 = 1 (data entered from rating plate) or by P3900 = 1 - 3 (end of quid commissioning). The calculated value is displayed in r0331.										
r0330[02]	Rated motor slip [%]	-	-	-	PERCENT	DDS	Float	3			
	Displays nominal motor s r0330[%] = ((P0310 - r03				icy) and P031	1 (rated n	notor spe	eed).			
r0331[02]	Rated magnetization current [A]	-	-	-	-	DDS	Float	3			
	Displays calculated magn	etizing current of	motor.		·			•			
r0332[02]	Rated power factor	-	-	-	-	DDS	Float	3			
	Displays power factor for	motor.	•			•	•	•			
Dependency:	Value is calculated interna displayed.		ed motor co	sφ) set to 0; α	otherwise, val	ue entere	d in P03	08 is			
			_	-	-	DDS	Float	2			
r0333[02]	Rated motor torque [Nm]	-						3			
r0333[02]	[Nm]	- ue.						3			
r0333[02] Dependency:		0307 (rated mot		nd P0311 (ra	ted motor spe						
Dependency:	[Nm] Displays rated motor torq Value is calculated from P	0307 (rated mot		T	ted motor spe						
Dependency:	[Nm] Displays rated motor torq Value is calculated from P (P0307[kW] * 1000)/((P0 Motor cooling	0307 (rated mot 311[1/min]/60) * 0 - 3	2 * Pi)	nd P0311 (ra C, T	ted motor spe	ed). r033	] 3[Nm] =	:			
Dependency:	[Nm] Displays rated motor torq Value is calculated from P (P0307[kW] * 1000)/((P0 Motor cooling Selects motor cooling sys	0307 (rated mot 311[1/min]/60) * 0 - 3 tem used.	2 * Pi) 0	С, Т	-	ed). r033	] 3[Nm] =	:			
	[Nm] Displays rated motor torq Value is calculated from P (P0307[kW] * 1000)/((P0 Motor cooling Selects motor cooling sys 0	0307 (rated mot 311[1/min]/60) * 0 - 3 tem used. Self-cooled: Sha	2 * Pi) 0 Ift mounted	C, T I fan attachec	- I motor	ed). r033	] 3[Nm] =	:			
Dependency:	[Nm] Displays rated motor torq Value is calculated from P (P0307[kW] * 1000)/((P0 Motor cooling Selects motor cooling sys	0307 (rated mot 311[1/min]/60) * 0 - 3 tem used.	2 * Pi) 0 Ift mounted eparately po	C, T l fan attachec owered coolir	- I motor	ed). r033	] 3[Nm] =	:			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	
P0340[02]	Calculation of motor parameters	0 - 4	0	Т	-	DDS	U16	2
	Calculates various motor	parameters.						
				P0340 = 1	P0340 = 2	P0340	= 3	P0340 = 4
	P0341[02] Motor inerti	a [kg*m^2]		х				
	P0342[02] Total/motor	inertia ratio		х				
	P0344[02] Motor weigl	nt		х				
	P0346[02] Magnetizati	on time		х		x		
	P0347[02] Demagnetiz	ation time		х		x		
	P0350[02] Stator resist	ance (line-to-lin	e)	х	х			
	P0352[02] Cable resista	ance		х	х			
	P0354[02] Rotor resista	ance		х	х			
	P0356[02] Stator leaka	ge inductance		х	х			
	P0358[02] Rotor leakag	ge inductance		х	х			
	P0360[02] Main induct	ance		х	х			
	P0625[02] Surrounding	g motor tempera	ature	х	х			
	P1253[02] Controller o	utput limitation		х		x		
	P1316[02] Boost end fr	requency		х		x		
	P1338[02] Resonance of	х		x		х		
	P1341[02] Imax contro	х		x		х		
	P1345[02] Imax voltage	х		x		х		
	P1346[02] Imax voltage	х		x		х		
	P2002[02] Reference co	х						
	P2003[02] Reference to	х						
	P2185[02] Upper torqu	х						
	P2187[02] Upper torqu	e threshold 2		х				
	P2189[02] Upper torqu	e threshold 3		Х				
	0	No calculation						
	1	Complete para	ameterization	n				
	2	Calculation of	equivalent c	ircuit data				
	3	Calculation of	V/f control d	ata				
	4	Calculation of	controller se	ettings only				
Note:	This parameter is required mismatch in Power rating correctly. In these cases u	gs of converter t						
	When transferring P0340 Communications to the c				out internal c	alculation	IS.	
	The faults can be acknow calculations can take app				een complete	d in the c	onvert	er. These

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P0341[02]	Motor inertia [kg*m^2]	0.0001 -	0.0018	U, T	-	DDS	Float	3		
		1000.0								
	Sets no-load inertia of mo	tor.								
	Together with P0342 (ine the acceleration torque (r (P1511), and incorporated	1518), which car	n be added t	to any additio						
Dependency:	This parameter is influence	ed by automatic	calculation	s defined by P	0340.					
Note:	The result of P0341 * P03	42 is included in	the speed o	controller calc	ulation.					
	P0341 * P0342 = total mo	otor inertia	·							
	P1496 = 100 % activates acceleration pre-control for the speed controller and calculates the torque from P0341 and P0342.									
P0342[02]	Total/motor inertia ratio	1.000 - 400.00	1.000	U, T	-	DDS	Float	3		
	Specifies ratio between total inertia (load + motor) and motor inertia.									
Dependency:	See P0341									
P0344[02]	Motor weight [kg]	1.0 - 6500.0	9.4	U, T	-	DDS	Float	3		
	Specifies motor weight [kg].									
Dependency:	See P0341									
Note:	This value is used in the motor thermal model. It is normally calculated automatically from P0340 (motor parameters) but can also be entered manually. Default value is depending on converter type and its rating data.									
r0345[02]	Motor start-up time [s]	-	-	-	-	DDS	Float	3		
	Displays motor start-up ti the time taken to reach ra	me. This time cor ted motor speed	responds to from stand	the standard still at acceler	ized motor ine ation with rat	ertia. The ed moto	e start-up r torque	time is (r0333).		
P0346[02]	Magnetization time [s]	0.000 - 20.000	1.000	U, T	-	DDS	Float	3		
	Sets magnetization time [ magnetization builds up of motor data and correspor	luring this time. I	Magnetizati	on time is nor	e and start of ra rmally calculat	amp-up. ed autor	Motor natically	from the		
Dependency:	See P0341									
Notice:	An excessive reduction of	this time can res	ult in insuff	icient motor i	magnetization					
Note:	If boost settings are highe converter type and its rati		agnetizatior	n time may be	reduced. Defa	ault valu	e is depe	nding on		
P0347[02]	Demagnetization time [s]	0.000 - 20.000	1.000	U, T	-	DDS	Float	3		
	Changes time allowed aft	er OFF2/fault cor	dition, befo	ore pulses can	be re-enabled	l.				
Dependency:	See P0341									
Notice:	Not active following a not occur if the time is decrea		ramp-dow	n, e.g. after O	FF1, OFF3 or J	OG. Ove	rcurrent	trips will		
Note:		occur if the time is decreased excessively. The demagnetization time is approximately 2.5 x rotor time constant in seconds. Default value is depending on converter type and its rating data.								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Leve			
P0350[02]	Stator resistance (line) [Ω]	0.00001 - 2000.0	2.0000	U, T	-	DDS	Float	3			
	Stator resistance value fo resistance.	r connected mot	or (line valu	e). The paran	neter value do	esn't incl	ude the o	cable			
Dependency:	See P0341										
Note:	There are three ways to d	etermine the val	ue for this p	arameter:							
	Calculate using										
	– P0340 = 1 (data er	ntered from ratin	g plate) or								
	<ul> <li>P0010 = 1, P3900 = 1, 2 or 3 (end of quick commissioning).</li> </ul>										
	<ul> <li>Measure using P1900 = 2 (standard motor data identification - value for stator resistance is overwritten).</li> </ul>										
	Measure manually using an Ohmmeter.										
	Since the manually measured value has to be value.	ured resistor is a	line-to-line								
	The value entered in PO35 converter type and its rat		ained by the	e method last	used. Default	value is o	dependir	ng on			
P0352[02]	Cable resistance [Ω]	0.0 - 120.0	0.0	U, T	-	DDS	Float	3			
	Cable resistance value be	tween converter	and motor	for one phase	2.						
Dependency:	See P0341	1			1	_	-				
P0354[02]	Rotor resistance [Ω]	0.0 - 300.0	10.0	U, T	-	DDS	Float	3			
	Sets rotor resistance of m	•									
Dependency:	Calculated automatically parameter is influenced b	using the motor y automatic calc	model or de ulations def	termined usi ined by P034	ng P1900 (mo 0.	tor identi	fication)	. This			
P0356[02]	Stator leakage inductance [mH]	0.00001 - 1000.0	10.000	U, T	-	DDS	Float	3			
	Sets stator leakage induct	ance of motor e	quivalent ci	rcuit (phase v	alue).						
Dependency:	See P0354		1					-			
P0358[02]	Rotor leakage inductance [mH]	0.0 - 1000.0	10.0	U, T	-	DDS	Float	3			
	Sets rotor leakage inductance of motor equivalent circuit (phase value).										
Dependency:	See P0354		1	1			-	T			
P0360[02]	Main inductance [mH]	0.0 - 10000.0	10.0	U, T	-	DDS	Float	3			
	Sets main inductance of t	he motor equiva	lent circuit (	(phase value)	•						
Dependency:	See P0354										
Caution:	The data of equivalent cir available therefore must l										
r0370[02]	Stator resistance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays standardized stat	or resistance of	motor equiv	alent circuit (	(phase value).						
r0372[02]	Cable resistance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays standardized cab of the stator resistance.	le resistance of r	notor equiv	alent circuit (	phase value).	t is estim	nated to I	be 20 %			
r0373[02]	Rated stator resistance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays rated stator resistance of the motor equivalent circuit (phase value).										
r0374[02]	Rotor resistance [%]	-	-	-	PERCENT	DDS	Float	4			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r0376[02]	Rated rotor resistance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays rated rotor resist	ance of the moto	r equivalen	t circuit (phas	e value).		_				
r0377[02]	Total leakage reactance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays standardized tota	al leakage reactar	nce of the m	notor equivale	ent circuit (ph	ase value	).	1			
r0382[02]	Main reactance [%]	-	-	-	PERCENT	DDS	Float	4			
	Displays standardized ma	Displays standardized main reactance of the motor equivalent circuit (phase value).									
r0384[02]	Rotor time constant [ms]	-	-	-	-	DDS	Float	3			
	Displays calculated rotor t	ime constant.		1	-	-		1			
r0386[02]	Total leakage time constant [ms]	-	-	-	-	DDS	Float	4			
	Displays total leakage tim	e constant of mo	tor.								
r0395	CO: Total stator resistance [%]	-	-	-	PERCENT	-	Float	3			
	Displays stator resistance	of motor of com	pined stator	/cable resista	nce.						
P0503[02]	Enable Keep-running Operation	0 - 1	0	Т	-	-	U16	3			
	Enables keep-running operation. This attempts to prevent the converter from tripping by enabling all possible existing de-rating features, and the automatic restart function. May be used with P2113 = 1 (converter warnings disabled) to mask resulting warnings from the user.										
	0 Keep-running mode disabled										
	1 Keep-running mode enabled										
Index:	[0] Drive data set 0 (DDS0)										
	[1] Drive data set 1 (DDS1)										
	[2]	Drive data set 2 (DDS2)									
Notice:	P0503 = 1										
	Sets the following parameter values to minimize likelihood of a trip:										
	• P0290 = 2 (converter overload reaction: reduce pulse frequency, output current and output frequency										
	• P1210 = 7 (automatic restart function: restart after mains brown-/blackout or fault, trip when P1211 expires)										
	• P1211 = 10 (number of	of times converte	r will attem	pt to restart)							
	• P1240 = 3 (configurat P0503 = 0				and kinetic bu	uffering (I	<ib) enal<="" td=""><td>oled)</td></ib)>	oled)			
	Resets the parameters to their default values:										
	• P0290 = 2 (converter			llse frequency		ent and o	utput fre	allency			
	<ul> <li>P1210 = 1 (automatic</li> </ul>		•		•		acput ne	queriey			
	<ul> <li>P1211 = 3 (number of</li> </ul>			-	, 1 12 11 01505	icu)					
			•								
	P1240 = 1(configurati		-	ax controller (	enabled)						
Note:	See also P0290, P1210, P1211, P1240, and P2113										
P0507	Application macro         0 - 255         0         C(1)         -         -         U16         1										
	Selects a given Application macro, which is a set of parameter values for a given application. There are a number of application macros covering a set of basic applications such as simple pump, conveyor, compressor etc.										
Note:	Please note that to guarantee correct setting of the Application macro, the Application macro number should only be changed during Setup directly after a parameter reset.										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P0511[02]	Scaling for display	0.00 - 100.00	[0] 1.00 [1] 1.00 [2] 0.00	U, T	-	-	Float	3				
	Allows operator to enter to Index 0 = value of multipl Index 1 = value of divisor Index 2 = value of constant With the parameter set to and external BOPs is scale The formula used to scale	ier (a) (b) nt (c) a non-default va ed accordingly. No	lue the disp ote - the uni	layed value fo	or frequency a	nd setpo d if the v	int on in value is s	ternal caled.				
Index:	[0] Multiplier for Scaling for display											
	[1]	Divider for Scaling for display										
	[2]	Constant for Scaling for display										
r0512	CO: Scaled filtered frequency	-	-	-	-	-	Float	2				
	Displays actual converter output frequency (r0024) excluding slip compensation (and resonance damping, frequency limitation in V/f mode).											
P0604[02]	Threshold motor temperature [°C]	0.0 - 200.0	130.0	υ, τ	-	DDS	Float	2				
	Enters warning threshold higher than the warning t then converter reacts as c	threshold P0604.										
Dependency:	This value should be at le	ast 40°C higher tł	han the mot	tor surroundir	ng temperatur	e P0625.						
P0610[02]	Motor I <sup>2</sup> t temperature reaction	0 - 6	6	Т	-	DDS	U16	3				
	Defines reaction when me	otor temperature	reaches wa	irning thresho	old.							
	0	Warning only. D power up	oes not rec	all the motor	temperature (	stored at	power	lown) or				
	1	Warning with In recall the motor						s not				
	2	Warning and tri down) on powe		es not recall tl	ne motor temp	perature	(stored a	at power				
	4	Warning only. R up	ecalls the m	notor tempera	ture (stored a	t power (	down) oi	n power				
	5	Warning with Imax control (motor current reduced) and trip (F11). Recalls the motor temperature (stored at power down) on power up										
	6	Warning and trip (F11). Recalls the motor temperature (stored at power down) on power up										
Dependency:	Trip level = P0604 (motor	temperature three	eshold) * 11	10 %								


Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
Note:	• P0610 = 0 (No reactio When temperature reacher reaction is done.	0 ,	lefined in P	0604, the con	verter displays	s warning	g A511,	no			
	• P0610 = 1 (Warning, I When temperature reacher frequency and trips F11, v	es warning level o	lefined in P		verter displays	s warning	g A511,	reduce			
	• P0610 = 2 (Warning and trip F11) When temperature reaches warning level defined in P0604, the converter displays warning A511 and trip F11, when temperature exceeds the trip level.										
	The purpose of motor I <sup>2</sup> t is to calculate the motor temperature and disable the converter if the motor is in danger of overheating.										
	I <sup>2</sup> t operation:										
	The measured motor current is displayed in r0027. The motor temperature in °C is displayed in r0035.										
	This temperature is derived from a calculated value using motor thermal model.										
	The reaction to the warning can be changed from this default using P0610.										
	r0035 is particularly useful to monitor if the calculated motor temperature is rising excessively.										
P0622[02]	Magnetizing time for temp id after start up [ms]	0.000 - 20000	0.000	U, T	-	DDS	Float	3			
	Specifies the magnetization	on time for stator	resistance	identification.							
r0623[02]	CO: Display for the identified stator resistance [Ω]	-	-	-	-	DDS	Float	4			
	Display of the actual iden	tified stator resist	ance after t	emperature id	dentification.						
P0625[02]	Surrounding motor temperature [°C]	-40.0 - 80.0	20.0	C, U, T	-	DDS	Float	3			
	Surrounding temperature value when the motor is o							e the			
Dependency:	This parameter is influence	his parameter is influenced by automatic calculations defined by P0340.									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
P0626[02]	Overtemperature stator iron [°C]	20.0 - 200.0	50.0	U, T	-	DDS	Float	4	
	Overtemperature of state	r iron.				•			
Note:	Temperature rises are val to converter operation (m						perature	rises due	
P0627[02]	Overtemperature stator winding [°C]	20.0 - 200.0	80.0	U, T	-	DDS	Float	4	
	Overtemperature of the s motor identification has t				e the value wl	nen the n	notor is c	old. A	
Note:	See P0626								
P0628[02]	Overtemperature rotor winding [°C]	20.0 - 200.0	100.0	U, T	-	DDS	Float	4	
	Overtemperature of the r	otor winding.							
Note:	See P0626								
r0630[02]	CO: Motor model surrounding temp. [°C]	-	-	-	-	DDS	Float	4	
	Displays the surrounding	temperature of t	he motor m	ass model.					
r0631[02]	CO: Stator iron temperature [°C]	-	-	-	-	DDS	Float	4	
	Displays the iron tempera	ture of the moto	r mass moo	lel.					
r0632[02]	CO: Stator winding temperature [°C]	-	-	-	-	DDS	Float	4	
	Displays the stator windir	ig temperature o	f the motor	mass model.	1	-			
r0633[02]	CO: Rotor winding temperature [°C]	-	-	-	-	DDS	Float	4	
	Displays the rotor winding	g temperature of	the motor	mass model.		-			
P0640[02]	Motor overload factor [%]	10.0 - 400.0	150.0	C, U, T	-	DDS	Float	2	
	Defines motor overload c	urrent limit relati	ve to P030	5 (rated moto	r current).				
Dependency:	Limited to maximum com P0640_max = (min(r0209			f rated motor	current (P030	5), which	never is t	he lower	
Note:	Changes to P0640 will be	effective only af	ter the next	t off state.					
P0700[02]	Selection of command source	0 - 5	1	С, Т	-	CDS	U16	1	
	Selects digital command	source.							
	0	Factory default	setting						
	1	Operator panel	(keypad)						
	2	Terminal							
	5	USS/MODBUS o							
Dependency:	P0701, (function of dig P1022, P1023, P1035, P1	sets (to default) all settings on item selected. These are the following parameters gital input), P0840, P0842, P0844, P0845, P0848, P0849, P0852, P1020, P1021, 1036, P1055, P1056, P1074, P1110, P1113, P1124, P1140, P1141, P1142, P1230, 2200, P2220, P2221, P2222, P2223, P2235, P2236							
Caution:	Be aware, by changing of	P0700 all BI para	ameters are	reset to the c	lefault value.				
Note:	RS485 also supports MOE MODBUS.	·							
	If P0700 = 0, the values o to their defaults: P0701, I				e digital input	tunction	will be re	estricted	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level									
P0701[02]	Function of digital input 1	0 - 99	0	T	-	CDS	U16	2									
	Selects function of digita	l input 1.															
	0	Digital input dis	abled														
	1	ON/OFF1															
	2	ON reverse/OFF	1														
	3	OFF2 - coast to	standstill														
	4	OFF3 - quick rar	np-down														
	5	ON/OFF2															
	9	Fault acknowled	dge														
	10	JOG right															
	11	JOG left															
	12	Reverse															
	13	MOP up (increa	se frequenc	zy)													
	14	MOP down (dec	rease frequ	iency)													
	15     Fixed frequency selector bit0																
	16	Fixed frequency	selector bi	t1													
	17	Fixed frequency	selector bi	t2													
	18	Fixed frequency	selector bi	t3													
	22 QuickStop Source 1																
	23 QuickStop Source 2																
	24 QuickStop Override																
	25 DC brake enable																
	27 Enable PID																
	29 External trip																
	33 Disable additional freq setpoint																
	99 Enable BICO parameterization																
Dependency:	Resetting 99 (enable BICO parameterization) requires:																
	P0700 command sou	rce or															
	• P0010 = 1, P3900 = 1		mmissionin	a) or													
	<ul> <li>P0010 = 30, P0970 =</li> </ul>	•															
Note:	"ON/OFF1" can only be se P0702 = 1 will disable dig command source. "ON/O input.	elected for one dig gital input 1 by se	gital input ( tting P0701	e.g. P0700 = = 0. Only th	e last activate	d digital i	nput serv	/es as a									
P0702[02]	Function of digital input 2	0 - 99	0	Т	-	CDS	U16	2									
	Selects function of digital input 2.																
	See P0701.																
P0703[02]	Function of digital input 3	0 - 99	9	Т	-	CDS	U16	2									
	Selects function of digita	Selects function of digital input 3.															
	See P0701.							See P0701.									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P0704[02]	Function of digital input 4	0 - 99	15	Т	-	CDS	U16	2				
	Selects function of digita See P0701.	ll input 4.										
P0705[02]	Function of digital input 5	0 - 99	16	Т	-	CDS	U16	2				
	Selects function of digita See P0701.											
Note:	This digital input is provi	ded by the optic	onal I/O Exten	sion Module.								
P0706[02]	Function of digital input 6	0 - 99	17	Т	-	CDS	U16	2				
	Selects function of digita See P0701.	ll input 6.										
Note:	This digital input is provi	ded by the optic	onal I/O Exten	sion Module.								
P0712[02]	Analog/digital input 1	0 - 99	0	Т	-	CDS	U16	2				
	Selects function of digita	l input Al1 (via a	analog input)	).		<b>I</b>		1				
Note:	See P0701. Signals abov	e 4 V are active;	signals below	v 1.6 V are in	active.							
P0713[02]	Analog/digital input 2	0 - 99	0	Т	-	CDS	U16	2				
	Selects function of digita	l input AI2 (via a	analog input)	).		- 4		1				
Note:	See P0701. Signals abov	e 4 V are active.	signals below	v 1 6 V are in	active							
P0717	Connection macro	0 - 255	0	C(1)	-	-	U16	1				
	Selects a given connection There are a number of control of the co	onnection macro	os which defi	arameter valu				nection				
Note:	Please note that to guara should only be changed					nection ma	acro nun	nber				
P0719[02]	Selection of command	0 - 57	0	т	-	CDS	U16	4				
	& frequency setpoint	0-57	0	1			016					
	& frequency setpoint Central switch to select of between freely program setpoint sources can be digit chooses the setpoint	control comman mable BICO para	d source for o meters and f	ixed commar	nd/setpoint pr	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be	control comman mable BICO para	d source for o imeters and f ndently. The	ixed commar tens digit cho	nd/setpoint pr poses the com	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin	control comman mable BICO para changed indepent source.	d source for o imeters and f ndently. The arameter, Set	ixed commar tens digit cho tpoint = BICO	nd/setpoint pr poses the com parameter	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0	control comman mable BICO para changed indepent source. Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei	ixed commar tens digit cho tpoint = BICO tpoint = MOP	nd/setpoint proof	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1	control comman mable BICO para changed indepent source. Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Set arameter, Set arameter, Set	ixed commar tens digit cho tpoint = BICO tpoint = MOP tpoint = Analo	nd/setpoint proses the com parameter setpoint og setpoint	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2	control comman mable BICO para changed indepent source. Cmd = BICO p Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei arameter, Sei arameter, Sei	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = Fixed	nd/setpoint pr poses the com parameter setpoint og setpoint I frequency	ofiles. Cor	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3	control comman mable BICO para changed indepent t source. Cmd = BICO p Cmd = BICO p Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei	ixed commar tens digit cho tpoint = BICO tpoint = MOP tpoint = Analo tpoint = Fixed tpoint = USS o	nd/setpoint pr poses the com parameter setpoint og setpoint I frequency on RS232 (res	ofiles. Cor nmand sou	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4	control comman mable BICO para changed indepent t source. Cmd = BICO p Cmd = BICO p Cmd = BICO p Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Set arameter, Set arameter, Set arameter, Set arameter, Set arameter, Set arameter, Set	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = Fixed tpoint = USS of tpoint = USS/I	nd/setpoint pr poses the com setpoint og setpoint I frequency on RS232 (res MODBUS on F	ofiles. Cor nmand sou	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4 5	control comman mable BICO para changed indepent source. Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = Fixed tpoint = USS/I tpoint = USS/I tpoint = Analo	nd/setpoint pr poses the corr parameter setpoint og setpoint I frequency on RS232 (res MODBUS on F og setpoint 2	erved)	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4 5 7	control comman mable BICO para changed indepent t source. Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei RS232 (rese	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = USS o tpoint = USS/I tpoint = Analo rved), Setpoin	nd/setpoint pr parameter setpoint og setpoint I frequency on RS232 (res MODBUS on F og setpoint 2 nt = BICO para	erved) eerved) eerved) eerved) eerved) eerved) eerved) eerved) eerved	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4 5 7 40	control comman mable BICO para changed independ t source. Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei ar	ixed commar tens digit cho tpoint = BICO tpoint = MOP tpoint = Analo tpoint = USS/I tpoint = USS/I tpoint = Analo rved), Setpoir rved), Setpoir	nd/setpoint pr poses the com parameter setpoint og setpoint I frequency on RS232 (res MODBUS on F og setpoint 2 nt = BICO para nt = MOP setp	erved) Served) States ameter point	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4 5 7 40 41	control comman mable BICO para changed indepent source. Cmd = BICO p Cmd = BICO p	d source for o imeters and f ndently. The arameter, Sei arameter, Sei ar	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = USS of tpoint = USS of tpoint = USS of tpoint = Analo rved), Setpoir rved), Setpoir rved), Setpoir	nd/setpoint process the comparameter setpoint og setpoint I frequency on RS232 (res MODBUS on F og setpoint 2 nt = BICO para nt = MOP setp nt = Analog set	erved) erved) erved) estables enveter evoint etpoint	etpoint s nmand a	and				
	Central switch to select of between freely program setpoint sources can be digit chooses the setpoin 0 1 2 3 4 5 7 40 41 42	control comman mable BICO para changed indepent t source. Cmd = BICO p Cmd = USS on Cmd = USS on	d source for o imeters and f ndently. The arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei arameter, Sei RS232 (rese RS232 (rese RS232 (rese	ixed commar tens digit chc tpoint = BICO tpoint = MOP tpoint = Analo tpoint = USS of tpoint = USS/I tpoint = USS/I tpoint = Analo rved), Setpoir rved), Setpoir rved), Setpoir	nd/setpoint pr parameter setpoint og setpoint I frequency on RS232 (res MODBUS on F og setpoint 2 nt = BICO para nt = MOP setp nt = Analog se nt = Fixed free	ofiles. Cor mand sou served) 35485 ameter point etpoint quency	etpoint s mmand a irce and	and				

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
	47		Cmd = USS on R	S232 (reser	ved), Setpoin	t = Analog set	point 2				
	50		Cmd = USS/MO			-					
	51		Cmd = USS/MO								
	52		Cmd = USS/MO	DBUS on RS4	185, Setpoint	= Analog setp	oint				
	53		Cmd = USS/MO[	DBUS on RS4	185, Setpoint	= Fixed freque	ency				
	54		Cmd = USS/MO	DBUS on RS4	185, Setpoint	= USS on RS23	32 (reser	ved)			
	55		Cmd = USS/MO	DBUS on RS4	185, Setpoint	= USS/MODBL	JS on RS4	185			
	57		Cmd = USS/MO	Cmd = USS/MODBUS on RS485, Setpoint = Analog setpoint 2							
Dependency:	the setpo (second s defined. I	int source), P08 ource of OFF2/0 BICO connectior	than P0700 and 44/P0848 (first sc DFF3) apply and t is made previousl	ource of OFF he OFF com y remain ur	2/OFF3) are r mands are ob ichanged.	not effective; i tained via the	nstead, F particula	20845/PG ar source	0849 e		
Notice:			e.g. changing con gs) do not reset t				= 2. Sett	ings in F	0719		
r0720	Number inputs	of digital	-	-	-	-	-	U16	3		
	Displays r	number of digita	l inputs.								
r0722.012	CO/BO: D values	igital input	-	-	-	-	-	U16	2		
	Displays status of digital inputs.										
	Bit	Signal name				1 signal		0 signal			
	00	Digital input	1			Yes	No				
	01	Digital input 2	2			Yes		No			
	02	Digital input	3			Yes		No			
	03	Digital input 4	1			Yes		No			
	04	Digital input !	5			Yes		No			
	05	Digital input (	5			Yes		No			
	11	Analog input	1			Yes		No			
	12	Analog input	2			Yes		No			
Note:	5	is lit when signa al input 5 and 6	al is active. are provided by tl	ne optional	I/O Extension	Module.					
P0724		e time for	0 - 3	3	Т	-	-	U16	3		
	Defines d	ebounce time (f	iltering time) used for digital inputs.								
	0		No debounce time								
	1		2.5 ms debounce time								
	2		8.2 ms debounce time								
	3		12.3 ms debounce time								



Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
	3-wire control				·							
	using STOP as perm	anent signal, FWD	and REVP as	s pulses								
	STOP	_		•								
	(r)	Command igno	red									
	Control FWDP commands			1								
	<u>REVP</u> f_out ▲											
	0		<u> </u>		OFF1	t OFF1						
	• 3 wire control											
	using OFF1/HOLD a	nd REV as perman	ent signal, O Command		nal							
	ON_P	ULSE	Command	Ignored	<b>▲</b>							
			_			_						
	Control OFF1	HOLD			¥	*						
	REV											
	f_out ▲ 0					t OFF1						
	0	Siemens (start/	/dir)									
	1	2-wire (fwd/rev										
	2	3-wire (fwd/rev										
	3	3-wire (start/di										
Note:	REV denotes REVER	<ul> <li>Where:</li> <li>P denotes Pulse</li> <li>FWD denotes FORWARD</li> <li>REV denotes REVERSE</li> <li>When any of the control functions are selected using P0727, the setting for the digital inputs (P0701 -</li> </ul>										
	Settings of P0701 - P0706	P0727 = 0 (S Standard Co		P0727 = 1 Contro	ol) (	0727 = 2 (3-wire Control)		3 (3-wire trol)				
	= 1 (P0840)	ON/OFI	F1	ON_FV	VD	STOP	<u> </u>	PULSE				
	= 2 (P0842)	ON_REV/0	OFF1	ON_R	EV	FWDP	OFF1/	HOLD				
	= 12 (P1113)	REV		REV		REVP	RI	V				
	To use the 2/3-wire cor corresponding to the re	edefined values ha	ve to be set	accordingly.								
	The ON/OFF2 function				not select OI	N/OFF2 un	less P072	27 = 0.				
	Regarding the use of fi	xed frequencies se	e P1000 and	I P1001.								

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Leve	
r0730	Number o outputs	f digital	-	-	-	-	-	U16	3	
	Displays nu	umber of digita	al outputs.			•				
P0731[02]	Bl: Functio	on of digital	0 - 4294967295	52.3	U, T	-	CDS	U32/B in	2	
	Defines so	urce of digital	output 1.			•	•			
Notice:	An inverse	logic can be re	ealized by inverti	ing the digit	al outputs in I	P0748.				
Note:			s inverted on dig ered, and when t				the digita	al output	is set t	
	Monitor fu	nctions ==> se	e r0052, r0053							
		ling brake ==>								
	DC-Brake =	=> see P1232	, P1233							
P0732[02]	output 2	on of digital	0 - 4294967295	52.7	U, T	-	CDS	U32/B in	2	
		urce of digital	T .						T	
P0733[02]	output 3	on of digital	0 - 4294967295	0	U, T	-	CDS	U32/B in	2	
	Defines so	urce of digital	output 3.							
Note:	J J		ided by the opti	onal I/O Exte	ension Modul	e.				
P0734[02]	BI: Function of digital         0 -         0           output 4         4294967295         0				U, T	-	CDS	U32/B in	2	
	Defines source of digital output 4.									
Note:	-	· · · ·	ided by the opti	onal I/O Exte	ension Modul	e.				
r0747.01	outputs	ate of digital	-	-	-	-	-	U16	3	
	Displays status of digital outputs (also includes inversion of digital outputs via P0748).									
	Bit	Signal name				1 signal		0 signal		
	00	Digital outpu				Yes		No		
	01	Digital outpu	ÿ			Yes		No		
	02	Digital outpu	0			Yes		No		
	03	Digital outpu	3			Yes		No		
Dependency:	5	al: Contacts o	•							
	Ű	al: Contacts cl		<u> </u>						
Note:	-		4 are provided b			on Module.	1	1	1	
P0748		tal outputs	-	0000 bin	-	-	-	U16	3	
			tes of digital out	put for a giv	en function.	1		1.		
	Bit	Signal name				1 signal		0 sign	al	
	00	Invert digital output 1				Yes		No		
	01 Invert digital output 2					Yes		No		
	02	Invert digital				Yes		No		
	03					Yes		No		
Note:	-	· ·	4 are provided b	y the option	al I/O Extensi	on Module.			T	
r0750	Number o	fanalog	-	-	-	-	-	U16	3	

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r0751.09	CO/BO: St analog in	atus word of put	-	-	-	-	-	U16	3
	Displays st	tatus of analog	input.						
	Bit	Signal name				1 signal		0 signal	
	00	Signal lost on	analog input 1			Yes	No		
	01	Signal lost on	analog input 2			Yes	No		
	08	No signal lost	on analog input	1		Yes	No		
	09	No signal lost	on analog input	2		Yes		No	
r0752[01]	Actual analog input [V] or [mA]		-	-	-	-	-	Float	2
	Displays s	moothed analog	g input value in v	olts or milli	amps before	the scaling blo	ock.		
Index:	[0]		Analog input 1	(AI1)					
	[1]		Analog input 2	(AI2)					
P0753[01]	Smooth ti input [ms	ime analog ]	0 - 10000	3	U, T	-	-	U16	3
	Defines fil	ter time (PT1 fil	ter) for analog in	put.					
Index:	See r0752								
Note:		) this time (smo ): No filtering	oth) reduces jitte	r but slows	down respor	ise to the ana	log input.		
r0754[01]		alog input er scaling [%]	-	-	-	-	-	Float	2
	Shows sm	oothed value of	f analog input aft	er scaling b	lock.				
Index:	See r0752								
Dependency:	P0757 to I	P0760 define ra	nge (analog inpu						

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
r0755[01]	CO: Actual analog input after scaling [4000h]	-	-	-	4000H	-	116	2				
	Displays analog input, scaled using ASPmin and ASPmax (ASP = analog setpoint).											
	Analog setpoint (ASP) from the analog scaling block can vary from minimum analog setpoint (ASPmin) to maximum analog setpoint (ASPmax).											
	The largest magnitude (value without sign) of ASPmin and ASPmax defines the scaling of 16384.											
	By associating r0755 with an internal value (e.g. frequency setpoint), a scaled value is calculated internal by the converter.											
	The frequency value is calculated using the following equation:											
	r0755 [Hz] = (r0755 [hex]/4000 [hex]) * P2000 * (max ( ASP_max ,  ASP_min )/100%)											
Example:	Case a:											
	ASPmin = 300 %, ASPmax = 100 % then 16384 represents 300 %.											
	This parameter will vary from 5461 to 16384.											
	Case b:											
	ASPmin = -200 %, ASPmax = 100 % then 16384 represents 200 %.											
	This parameter will vary from -16384 to +8192.											
	4000 h = max ( ASP <sub>max</sub>  ,  ASP <sub>min</sub>  )											
	ASP <sub>max</sub> $4000 h \cong 163$ $300\%$ $a$	84 dez	300	)%								
	ASPmin 100% 0		ASP 100	<sup>max</sup> 0	10	V N MA						
	200%	20 mA	ASP 200	min 0% 7FFFh≦	€ -16383 dez	20 mA						
Index:	See r0752											
Note:	This value is used as an (this may be at 10 V). A P0760 (analog input sc	SPmin represents										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level					
P0756[01]	Type of analog input	0 - 4	0	T	-	-	U16	2					
	Defines type of analog in	out and also enab	oles analog i	nput monitor	ina.			<u> </u>					
	0	Unipolar voltage	-										
	1	Unipolar voltage			0 to 10 V)								
	2	Unipolar current input (0 to 20 mA)											
	3     Unipolar current input (of to 20 mA)												
	4 Bipolar voltage input (-10 V to 10 V)												
Index:	4 Bipolar voltage input (-10 v to 10 v) See r0752												
Dependency:	The monitoring function (see P0757 to P0760).	is disabled if the a	analog scali	ng block is pro	ogrammed to	output n	egative	setpoints					
Notice:	the analog input voltage voltage for analog input 2	When monitoring is enabled and a deadband defined (P0761), a fault condition will be generated (F80) if the analog input voltage falls below 50 % of the deadband voltage. It is not possible to select the bipolar oltage for analog input 2. or P0756 = 4, you need to ensure the analog input scaling, for example, if you desire to obtain an output											
	frequency within the range	equency within the range of -50 Hz to 50 Hz, you can set parameters P0757 to P0760 within their gative ranges (examples: P0757 = -10 V, P0758 = -100%).											
Note:	See P0757 to P0760 (ana	5 1 5											
	In current mode, if the in for analog input 2. This w readings for the channel the fault has been reset t	ill result in chann concerned will nc	el switching longer be	g back to volta updated until	age mode. Ar the fault (F80	ialog inpu )) has bee	it param en reset.	eter Once					
P0757[01]	Value x1 of analog input scaling	-20 - 20	0	U, T	-	-	Float	2					
	P0757 - P0760 configure which determine the stra value x1 of analog input s	ight line. The valu											
Index:	See r0752												
Notice:	Analog setpoints repr	esent a [%] of the	normalized	d frequency ir	P2000.								
	Analog setpoints may	be larger than 10	0 %.										
	ASPmax represents hi	ghest analog setp	ooint (this m	nay be at 10 V	' or 20 mA).								
	ASPmin represents low	0 1		5									
	Default values provide	e a scaling of 0 V	or 0 mA = 0	%, and 10 V	or 20 mA = 10	00 %.							
P0758[01]	Value y1 of analog input scaling [%]	-99999.9 - 99999.9	0.0	U, T	-	-	Float	2					
	Sets value of y1 as descri	oed in P0757 (ana	alog input s	caling)									
Index:	See r0752												
Dependency:	Affects P2000 to P2003 ( to be generated.	reference frequer	ncy, voltage	, current or to	orque) depend	ling on w	hich set	point is					
P0759[01]	Value x2 of analog input scaling	-20 - 20	10	U, T	-	-	Float	2					
	Sets value of x2 as descri	ped in P0757 (and	alog input s	caling).									
Index:	See r0752												
Notice:	The value x2 of analog in P0757.	put scaling P0759	9 must be g	reater than th	e value x1 of	analog in	put scal	ing					
P0760[01]	Value y2 of analog input scaling [%]	-99999.9 - 99999.9	100.0	U, T	-	-	Float	2					
	Sets value of y2 as descri	ped in P0757 (and	alog input s	caling).									
Index:	See r0752												
Dependency:	See P0758					_		_					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P0761[01]	Width of analog input deadband	0 - 20	0	U, T	-	-	Float	2		
	Defines width of deadbar	nd on analog inpi	ut.							
Example:	The following example pr 0 Hz to 50 Hz): • P2000 = 50 Hz • P0759 = 8 V P0760 = • P0757 = 2 V P0758 = • P0761 = 2 V • P0756 = 0 or 1 The following example pr "holding point" 0.2 V wid • P2000 = 50 Hz • P0759 = 8.75 V P0760	roduces a 2 V to 7 75 % 0 % roduces a 0 V to 7 e (0.1 V to each s	10 V, 0 Hz τι 10 V analog	input (-50 Hz	z to +50 Hz) v	vith cente	r zero an	ıd a		
	• P0757 = 1.25 V P0758	8 = -75 %								
	• P0761 = 0.1 V									
	• P0756 = 0 or 1									
Index:	See r0752									
Notice:	input scaling) are positive	e or negative resp	to value of P0761, if both values of P0758 and P0760 (y coordinates of analog or negative respectively. However, deadband is active in both directions from is with analog input scaling curve), if sign of P0758 and P0760 are opposite.							
Note:	P0761[x] = 0: No deadba	nd active.								
	Minimum frequency P10	80 should be zero	o when usin	g center zero	setup.					
	There is no hysteresis at t	the end of the de	adband.	_	_					
P0762[01]	Delay for loss of signal action [ms]	0 - 10000	10	U, T	-	-	U16	3		
	Defines time delay betwe	en loss of analog	j setpoint ai	nd appearanc	e of fault cod	e F80.				
Index:	See r0752									
Note:	Expert users can choose	the desired reacti	on to F80 (	default is OFF	2).					
r0770	Number of analog output	-	-	-	-	-	U16	3		
	Displays number of analo	g outputs availal	ble.	•						
P0771[0]	CI: Analog output	0 - 4294967295	21[0]	U, T	-	-	U32	2		
	Defines function of the a	nalog output.	•	•						
Index:	[0]	Analog output	1 (AO1)							
Setting:	21	CO: Actual freq		ed to P2000)						
~	24	CO: Actual outp			2000)					
	25	CO: Actual outp								
	26	CO: Actual DC-I	-							
	27	CO: Actual outp	Ŭ							
P0773[0]	Smooth time analog output [ms]	0 - 1000	2	U, T	-	-	U16	2		
	Defines smoothing time t using a PT1 filter.	for analog output	signal. This	s parameter e	nables smoot	thing for a	nalog ot	utput		
	using a r r r mter.									
Index:	See P0771									

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.				
			default	changed		set	type	Level				
r0774[0]	Actual analog output value [V] or [mA]	-	-	-	-	-	Float	2				
	Shows value of analog output after filtering and scaling.											
Index:	See P0771											
Note:	The analog output is o (4/5) a voltage output	nly a current out with a range of	tput. By cor 0 V to 10 V	necting an exter can be created.	nal resistor of	500 Ω t	to the te	erminals				
P0775[0]	Permit absolute value of analog output	0 - 1	0	Т	-	-	U16	2				
	Decides if the absolute value to be outputted. otherwise it is cleared.											
Index:	See P0771											
P0777[0]	Value x1 of analog output scaling [%]	-99999 - 99999	0.0	U, T	-	-	Float	2				
	Defines x1 output chan P0771 (analog output which determine the s	connector input	). x1 is the t	irst value of the	two pairs of v	ariants >	k1/y1 an	d x2/y2				
Note:	See P0771											
Dependency:	See P0758											
P0778[0]	Value y1 of analog output scaling	0 - 20	0	U, T	-	-	Float	2				
	Defines y1 of output characteristic.											
Index:	See P0771											
P0779[0]	Value x2 of analog output scaling [%]	-99999 - 99999	100.0	U, T	-	-	Float	2				
	Defines x2 of output characteristic.											
Index:	See P0771											
Dependency:	See P0758											
P0780[0]	Value y2 of analog output scaling	0 - 20	20	U, T	-	-	Float	2				
	Defines y2 of output characteristic.											
Index:	See P0771											
P0781[0]	Width of analog output deadband	0 - 20	0	U, T	-	-	Float	2				
	Sets width of dead-bar	nd for analog ou	tput.									
Index:	See P0771											
r0785.0	CO/BO: Status word of analog output	-	-	-	-	-	U16	2				
	Displays status of anal	og output. Bit 0	indicates th	at the value of a	nalog output '	1 is nega	ative.					
	Bit Signal n	ame			1 signal		0 sign	al				
	00 Analog c	utput 1 negative	e		Yes		No					

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P0802	Transfer da EEPROM	ta from	0 - 2	0	C(30)	-	-	U16	3		
	Transfers values from the converter to external device when P0802 $\neq$ 0. P0010 must be set to 30 for this be possible.										
	0		Disabled								
	2		Start data trans	sfer to the S	5D card						
Note:	POO10 will b	e reset to (	ally reset to 0 (c ) on successful c ace exists on the	completion.		ng data (8 KB).					
P0803	Transfer da EEPROM		0 - 3	0	C(30)	-	-	U16	3		
	0		Disabled			·	•				
	2		Start data trans	sfer from th	e SD card						
	3	Start data transfer from the SD card (except the motor data)									
	Transfers pa 30 to activa	nsfers parameter values from the SD clone file to the converter when P0803 $\neq$ 0. P0010 must be set to activate this parameter. See P0802 for parameter values.									
Note:	Parameter is										
	POO10 will b	e reset to (	) on successful o	completion.							
P0804	Select Clon	e file	0 - 99	0	C(30)	-	-	U16	3		
D0006	if P0804 = 1 etc.	, then the f	ile name is clon ile name is clon	e01.bin	Гц <del>т</del>				2		
P0806	BI: Inhibit p access		0 - 4294967295	0	U, T	-	-	U32	3		
			ontrol panel acc	ess through	n external clien	t.			1		
r0807.0	BO: Display access	s client	-	-	-	-	-	U16	3		
	Binector out	put to disp	lay whether con	nmand and	setpoint source	e is connected	to an ext	ternal cl	ient.		
	Bit	Signal na	ame			1 signal		0 sign	al		
	00	Master co	ontrol active		_	Yes		No			
P0809[02]	Copy comm set (CDS)	and data	0 - 2	[0] 0 [1] 1 [2] 0	Т	-	-	U16	2		
			ata set (CDS)' fu the manual.	inction. The	list of all comr	nand data sets	s (CDS) pa	aramete	rs is shown		
Example:	P0809[0] = P0809[1] =	Copying of all values from CDS0 to CDS2 can be accomplished by the following procedure: P0809[0] = 0 Copy from CDS0 P0809[1] = 2 Copy to CDS2 P0809[2] = 1 Start copy									
	P0809[2] =	1 Start cop	y								
Index:		1 Start cop		5							
Index:	[0]	1 Start cop	Copy from CDS	5							
Index:		1 Start cop		5							

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P0810	BI: command data set bit 0 (Hand/Auto)	0 - 4294967295	0	U, T	-	-	U32	2
	Selects command source selected CDS is displayed displayed in r0050.							
Setting:	722.0	Digital input 1	(requires PO	701 to be set to	99, BICO)			
	722.1	Digital input 2	(requires PO	702 to be set to	99, BICO)			
	722.2	Digital input 3	(requires PO	703 to be set to	99, BICO)			
Note:	P0811 is also relevant f	or command dat	ta set (CDS)	selection.				
P0811	Bl: command data set bit 1	0 - 4294967295	0	U, T	-	-	U32	2
	Selects command source	e from which to	read Bit 1 f	or selecting a co	mmand data	set (see	P0810)	
Setting:	See P0810.							
Note:	P0810 is also relevant f	or command dat	ta set (CDS)	selection.				
P0819[02]	Copy drive data set (DDS)	0 - 2	[0] 0 [1] 1 [2] 0	Т	-	-	U16	2
	Calls 'Copy drive data se at the end of the manu		n. The list o	f all drive data se	et (DDS) parar	neters is	s shown	in "Index"
Example:	Copying of all values fro P0819[0] = 0 Copy from P0819[1] = 2 Copy to D P0819[2] = 1 Start copy	n DDS0 IDS2	2 can be ac	complished by th	ne following p	orocedui	re:	
Index:	[0]	Copy from DDS						
	[1]	Copy to DDS						
	[2]	Start copy						
Note:	See P0809							
P0820	Bl: drive data set bit 0	0 - 4294967295	0	Т	-	-	U32	3
	Selects command sourc drive data set (DDS) is c in parameter r0051[1].	displayed in para	read Bit 0 f meter r005	or selecting a dr 1[0]. The actual	ive data set (D active drive da	)DS). Th ata set (	e actua DDS) is	selected displayed
Setting:	See P0810							
Note:	P0821 is also relevant f	or drive data set	(DDS) selec	tion.		<b>r</b>	1	1
P0821	Bl: drive data set bit 1	0 - 4294967295	0	Т	-	-	U32	3
	Selects command source	ce from which Bi	t 1 for selec	ting a drive data	set is to be re	ad in (s	ee P082	20).
Setting:	See P0810							
Note:	P0820 is also relevant f	or drive data set	(DDS) selec	tion.	1	1	1	
P0840[02]	BI: ON/OFF1	0 - 4294967295	19.0	Т	-	CDS	U32	3
	Allows ON/OFF1 comm parameter number of the parameter.							
Setting:	See P0810							
Dependency:	For digital inputs as cor right) is digital input 1 ( (via P0701) before chai	(722.0). Alternat	ive source p					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P0842[02]	BI: ON reverse/OFF1	0 - 4294967295	0	Т	-	CDS	U32	3
	Allows ON/OFF1 revers setpoint is run up coun				). In general a	ı positiv	e freque	ency
Setting:	See P0810							
P0843[02]	BI: ON/OFF2	0 - 4294967295	1	Т	-	CDS	U32/B in	3
	Allows ON/OFF2 comm parameter.	and source to be	e selected u	sing BICO. The d	efault setting	1.0 will	disable	this
Setting:	See P0810							
Dependency:	For digital inputs as con inputs is selected for O immediate pulse-disable enabled. (As long as th	N/OFF2, the con ling; the motor is	verter will r s coasting. (	ot run unless the DFF2 is low-activ	e digital input	is active	e. OFF2	means
Note:	The ON/OFF2 functiona	ality is not suppo	rted in 2/3	wire modes. Do ı	not select ON/	OFF2 ur	nless PO	727 = 0.
P0844[02]	BI: 1. OFF2	0 - 4294967295	19.1	Т	-	CDS	U32	3
	Defines first source of (	OFF2 when P071	9 = 0 (BICC	).				
Setting:	See P0810							
Dependency:	If one of the digital inp	uts is selected fo	or OFF2, the	converter will n	ot run unless <sup>.</sup>	the digit	al input	is active.
Note:	OFF2 means immediate 0 = Pulse disabling. 1 = Operating condition		; the motor	is coasting. OFF	2 is low-active	e, i.e.:		
P0845[02]	BI: 2. OFF2	0 - 4294967295	1	Т	-	CDS	U32	3
	Defines second source	of OFF2.						
Setting:	See P0810							
Dependency:	In contrast to P0844 (fi (selection of command				active, indep	endent	of P071	9
Note:	See P0844				1			1
P0848[02]	BI: 1. OFF3	0 - 4294967295	1	Т	-	CDS	U32	3
	Defines first source of (	OFF3 when P071	9 = 0 (BICC	).				
Setting:	See P0810							
Dependency:	If one of the digital inp	uts is selected fo	or OFF3, the	converter will n	ot run unless	the digit	al input	is active.
Note:	OFF3 means quick ram	p-down to 0.						
	OFF3 is low-active, i.e.							
	0 = Quick ramp-down.							
	1 = Operating condition			-		65.6		
P0849[02]	BI: 2. OFF3	0 - 4294967295	1	Т	-	CDS	U32	3
	Defines second source	of OFF3.						
Setting:	See P0810							
Dependency:	In contrast to P0848 (fi (selection of command				active, indep	endent	of P071	9
Note:	See P0848							

Function		Range	Factory	Can be	Scaling	Data	Data	Acc.		
			default			set	1	Level		
BI: Pulse ena	ble	0 - 4294967295	1	Т	-	CDS	U32	3		
Defines source of pulse enable/disable signal.										
See P0810										
Active only w	hen P071	9 = 0 (Auto sele	ction of cor	nmand/setpoint	source).					
BI: Quick stop 1	o source	0 - 4294967295	1	Т	-	CDS	U32	3		
			be selecte	ed using BICO. T	he signal is ex	pected to	o be act	ive low		
See P0810										
BI: Quick stop 2	o source	0 - 4294967295	1	Т	-	CDS	U32	3		
			be selecte	ed using BICO. T	he signal is ex	pected to	o be act	ive low		
See P0810										
BI: Quick stop override	0	0 - 4294967295	0	Т	-	CDS	U32	3		
Allows quick s high.	stop overr	ide command so	ource to be	selected using l	BICO. The sigr	nal is expe	ected to	be active		
See P0810										
Quick stop in type	put	0 - 4	2	Т	-	CDS	U16	3		
Control Word	for select	selecting the quick stop input type.								
0		Quick stop not	selected							
1		Quick stop inp	ut active hig	gh						
2		Quick stop inp	ut active lov	N						
3		Quick stop inp	ut positive e	edge triggered						
4		Quick stop inp	ut negative	edge triggered						
		0 - 31	31	U, T	-	-	U16	2		
Specifies the i	nterfaces					er allows	the use	r to easily		
Annotation: P	0927 is n	ot password pro	tected.							
Bit	Signal na	ame			1 signal		0 sign	al		
00	Not used				Yes		No			
01	BOP (incl	uding built-in BC	OP and exte	rnal BOP)	Yes		No			
02	USS on R	5232			Yes		No			
03	USS on R	\$485			Yes		No			
04	Script ter	minal on RS485			Yes		No			
			Default: All bits are set.							
Default: All bi	ts are set.									
		ws parameters t	o be chang	ed via any inter	face.					
	BI: Pulse enal Defines source See P0810 Active only with BI: Quick stop 1 Allows quick s (default settin See P0810 BI: Quick stop 2 Allows quick s (default settin See P0810 BI: Quick stop override Allows quick s for a stop override Allows quick stop Allows quick stop Allow	BI: Pulse enable  Defines source of pulse See P0810  Active only when P071  BI: Quick stop source 1  Allows quick stop source 2  Allows quick stop source 3  Allows quick	Bi: Pulse enable0 - 4294967295Defines source of pulse enable/disableSee P0810Active only when P071 = 0 (Auto selectBl: Quick stop source0 - 4294967295Allows quick stop source1 command to (default setting P0886 = 2).See P08100 - 4294967295Bl: Quick stop source 20 - 4294967295Allows quick stop override0 - 4294967295Allows quick stop input quick stop input 20 - 4 2Quick stop input 2Quick stop input quick stop input 3Quick stop input 4Quick stop input quick stop input 4Parameter changeable via specified interfacesQuick stop input possword pro possword pro possw	Introduct of pulseIntroduct of pulseBI: Pulse enable1Defines source of pulse enable/disable signal.See P0810Active only when P071 $\blacksquare$ = 0 (Auto selection of cordination of the post of the	Image default defaultchangedBi: Pulse enable00Defines source of pulse enable/disable signal.See P0810Active only when P0719 = 0 (Auto selection of command/setpointBi: Quick stop source0Auto selection of command/setpointBi: Quick stop source1TAllows quick stop source042949672951TCleated withing P0886 = 2).See P0810Bi: Quick stop source0TAllows quick stop source0TQuick stop source0TCleate with groups of a colspan="2">TQuick stop source0TCleate with groups of a colspan="2">TSee P0810Bi: Quick stop override0TQuick stop inputcolspan="2">TQuick stop inputCleate with group of a colspan="2">Cleate with group of a colspan="2"Quick stop input colspan="2" <t< td=""><td>ImagedefaultchangedBI: Pulse enable0 - 42949672951TDefines source of pulse enable/disable signal.See P0810Active only when P0719 = 0 (Auto selection of command/setpoint source).BI: Quick stop source0 - 42949672951T-Allows quick stop source 1 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672951BI: Quick stop source0 - 42949672951BI: Quick stop source 2 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672951Allows quick stop source 2 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672950See P0810Quick stop override0 - 42TAllows quick stop override command source to be selected using BICO. The signal is ex (default setting P086 = 2)See P0810Quick stop inputQuick stop input setter to be selected using BICO. The signal is ex (default setting P086 = 2).See P0810Quick stop input setter to be selected using BICO. The signal righSee P0810-Quick stop input setter to be selected using BICO. The signal righ.See P0810-Quick stop input setter to be selected using BICO.Quick stop input setterQuick stop input setter</td><td>InterfacesetdefaultchangedsetBI: Pulse enable/ 42949672951TCDSDefines source of pulse enable/disable signal.See P0810Active only when P0719 = 0 (Auto selection of command/setpoint source).BI: Quick stop source01TCDSBI: Quick stop source01TCDSAllows quick stop source0TCDSBI: Quick stop source 10TCDSAllows quick stop source 20TCDSSee P0810See P0810See P0810COSAllows quick stop override command source to be selected using BICO. The signal is expected to default setting P0886 = 2).See P0810See P0810COSQuick stop override command source to be selected using BICO. The signal is expected to default setting P0886 for 2).See P0810Control Word for selecting the quick stop input degradCOSQuick stop input colspan="2"&gt;Control Word for selecting the quick stop input active logQuick stop input active logQuick stop input active logQuick stop input activ</td><td>InitialdefaultchangedsettypeBI: Pulse enable0 - 42949672951T-CDSU32Defines source of pulse enable/disable signalCDSU32See P0810-1T-CDSU32Atlows quick stop source0 -1T-CDSU321T-CDSU32U32U32Allows quick stop source1T-CDSU32See P0810-1T-CDSU32Allows quick stop source0 -1T-CDSU32Allows quick stop source2 command to be selected using BICO. The signal is expected to be act(default setting P0886 = 2).U32See P0810BI: Quick stop source2 command to be selected using BICO. The signal is expected to be act(default setting P0886 = 2).U32See P0810BI: Quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32See P0810BI: Quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32See P0810BI: Quick stop input active low0T-CDSU32See P0810Quick stop input active low</td></t<>	ImagedefaultchangedBI: Pulse enable0 - 42949672951TDefines source of pulse enable/disable signal.See P0810Active only when P0719 = 0 (Auto selection of command/setpoint source).BI: Quick stop source0 - 42949672951T-Allows quick stop source 1 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672951BI: Quick stop source0 - 42949672951BI: Quick stop source 2 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672951Allows quick stop source 2 command to be selected using BICO. The signal is ex (default setting P0886 = 2).TSee P0810-42949672950See P0810Quick stop override0 - 42TAllows quick stop override command source to be selected using BICO. The signal is ex (default setting P086 = 2)See P0810Quick stop inputQuick stop input setter to be selected using BICO. The signal is ex (default setting P086 = 2).See P0810Quick stop input setter to be selected using BICO. The signal righSee P0810-Quick stop input setter to be selected using BICO. The signal righ.See P0810-Quick stop input setter to be selected using BICO.Quick stop input setterQuick stop input setter	InterfacesetdefaultchangedsetBI: Pulse enable/ 42949672951TCDSDefines source of pulse enable/disable signal.See P0810Active only when P0719 = 0 (Auto selection of command/setpoint source).BI: Quick stop source01TCDSBI: Quick stop source01TCDSAllows quick stop source0TCDSBI: Quick stop source 10TCDSAllows quick stop source 20TCDSSee P0810See P0810See P0810COSAllows quick stop override command source to be selected using BICO. The signal is expected to default setting P0886 = 2).See P0810See P0810COSQuick stop override command source to be selected using BICO. The signal is expected to default setting P0886 for 2).See P0810Control Word for selecting the quick stop input degradCOSQuick stop input colspan="2">Control Word for selecting the quick stop input active logQuick stop input active logQuick stop input active logQuick stop input activ	InitialdefaultchangedsettypeBI: Pulse enable0 - 42949672951T-CDSU32Defines source of pulse enable/disable signalCDSU32See P0810-1T-CDSU32Atlows quick stop source0 -1T-CDSU321T-CDSU32U32U32Allows quick stop source1T-CDSU32See P0810-1T-CDSU32Allows quick stop source0 -1T-CDSU32Allows quick stop source2 command to be selected using BICO. The signal is expected to be act(default setting P0886 = 2).U32See P0810BI: Quick stop source2 command to be selected using BICO. The signal is expected to be act(default setting P0886 = 2).U32See P0810BI: Quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32See P0810BI: Quick stop override0 - 42949672950T-CDSU32Allows quick stop override0 - 42949672950T-CDSU32See P0810BI: Quick stop input active low0T-CDSU32See P0810Quick stop input active low		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r0947[063]	CO: Last fault code	-	-	-	-	-	U16	2		
	Displays fault history.		Previous ac		lear					
ndex:		Description (m. 1997)	. (. ). 1							
Index:	[0] Recent fault trip, fault 1									
			( 1.0							
	[7]	Recent fault tri								
	[8]	Recent fault tri	p -1, fault 1							
	[15]	Recent fault tri	•							
	[16]	Recent fault tri	p -2, fault 1							
	[23]	 Recent fault tri	p -2, fault 8							
			, ,							
	[63]	Recent fault tri	p -7, fault 8							
Notice:	It is possible that this parameter is empty but a fault is still indicated by the converter. The reason for this most likely due to a SAFE condition still existing in the system. In this situation the fault is cleared from the parameter and it makes no sense to go back to a READY state. First remove the reason for the SAFE condition and then the converter will be able to change to a READY state (SAFE condition example is "safety function is activated").									
Note:	The function "converte parameters being mon values. Therefore if a h those values which cau	itored at the poi ardware trip occ	nt of a fault	occurring. Some	e recorded pa	rameter	s are filt	ered		
Example:	If a hardware overvolta r0956 may appear to b time to rise to the trip tripped to protect itself	e under the trip evel; however, t	limit. In this	case, the filtere	d DC link valu	ie had n	ot had e	nough		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
r0948[063]	Fault time	-	-		-	-	U32	3				
100 10[000]		when a fault ha	s occurred				052	5				
	Time stamp to indicate when a fault has occurred. P0969 (system run time counter) is the possible source of the time stamp.											
Index:												
muex:		Recent fault trip, fault time 1										
		····	. <u>(</u> . )'									
	[7]	Recent fault tri										
	[8]	Recent fault tri	p -1, fault ti	meil								
	[15]	Recent fault tri	•									
	[16]	Recent fault tri	p -2, fault ti	me 1								
	[23]	Recent fault tri	p -2, fault ti	me 8								
	[63]	Recent fault tri	p -7, fault ti	me 8			•	-				
r0949[063]	CO: Fault value	-	-	-	-	-	U32	3				
	Displays converter faul	t values. It is for	service pur	poses and indic	ates the type o	of fault re	eported					
	The values are not doc	umented. They a	are listed in	the code where	e faults are rep	orted.						
Index:	[0]	Recent fault tri	p, fault va	alue 1								
	[7]	Recent fault tri	p, fault va	alue 8								
	[8]	Recent fault tri	p -1, fault v	alue 1								
	[15]	Recent fault tri	p -1, fault v	alue 8								
	[16]	Recent fault tri										
	[23]	Recent fault tri	n -2 fault v	alue 8								
	[23]		p 2, iduit i									
	[63]	 Recent fault tri	n -7 fault v	aluo 8								
P0952	Total number of trips		$p^{-\gamma}$ , lault v				U16	3				
10952	Displays number of trip		7 (lact fault	(codo)	-		010	J				
Dependency:	Setting 0 resets fault h											
Note:	If the source of a non-r source first and then pl											
	a non-zero value after											
	factory reset or set P09					-						
r0954[02]	CO: Freq. setpoint	-	-	-	-	-	Float	3				
	after RFG at fault											
	[Hz]		 	ntonoous fai li		170)		I				
11.	Displays the setpoint after RFG when the first instantaneous fault occurs (see r1170).											
Index:	[0] Recent trip - Fault information											
	1] Recent trip - 1 Fault information											
	[2]	Recent trip - 2 I										
Note:	Only one set of fault in r0947[07], r0954[1]											

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r0955[02]	CO/BO: Status word 2 at fault	-	-	-	-	-	U16	3		
	Displays status word 2	when the first ir	stantaneou	is fault occurs (s	ee r0053).		•			
Index:	[0] Recent trip - Fault information									
	[1]	Recent trip - 1								
	[2]	Recent trip - 2								
Note:	Only one set of fault in r0947[07], r0955[1]	formation is stor	red per bloc	k of instantaned						
r0956[02]	CO: DC-link voltage at fault [V]	-	-	-	-	-	Float	3		
	Displays the DC link vo	ltage when the f	irst instanta	aneous fault occ	urs (see r0026	).				
Index:	[0]	Recent trip - Fa	ult informa	tion						
	[1]	Recent trip - 1	Fault inforn	nation						
	[2]	Recent trip - 2	Fault inforn	nation						
Note:	Only one set of fault in r0947[07], r0956[1]	formation is stor corresponds to	red per bloc r0947[81	k of instantaned 5] and r0956[2]	ous faults. r095 corresponds t	56[0] co o r0947	orrespon [1623	ds to 3].		
r0957[02]	CO: Act. output current at fault [A]	-	-	-	-	-	Float	3		
	Displays the output cu	rrent RMS when	the first ins	tantaneous fault	t occurs (see r(	0027).				
Index:	[0]	Recent trip - Fa	ult informa	tion						
	[1]	Recent trip - 1	Fault inforn	nation						
	[2]	Recent trip - 2	Fault inforn	nation						
Note:	Only one set of fault in r0947[07], r0957[1]									
r0958[02]	CO: Act. output voltage at fault [V]	-	-	-	-	-	Float	3		
	Displays the output vo	tage when the f	irst instanta	neous fault occi	urs (see r0025	).				
Index:	[0]	Recent trip - Fa	ult informa	tion						
	[1]	Recent trip - 1	Fault inforn	nation						
	[2]	Recent trip - 2	Fault inforn	nation						
Note:	Only one set of fault in r0947[07], r0958[1]									
r0964[06]	Firmware version data	-	-	-	-	-	U16	3		
	Firmware version data	·								
Index:	[0]	Company (Sier	nens <u>=</u> 42)							
	[1]	Product type (\	/20 = 8001	)						
[2] Firmware version										
	[3]	Firmware date	(year)							
	[4]	Firmware date		ו)						
	[5]	Number of con								
	[6]	Firmware versi								
r0967	Control word 1	-	-	-	-	-	U16	3		
	Displays control word	1. See r0054 for	the bit field	description.	1	1	1	-		
r0968	Status word 1	-	-	-	-	-	U16	3		
	Displays active status v active. See r0052 for th			and can be use	d to diagnose	which c				

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.			
			default	changed		set	type	Level			
P0969	Resettable system run time counter	0 - 4294967295	0	Т	-	-	U32	3			
	Resettable system run										
P0970	Factory reset	0 - 31	0	C(30)			U16	1			
F0970	P0970 = 1: Resets all p		-		lts if they have	- boon n		(stored			
	with $P0970 = 11$ ; Resets all p.	wise, resets all p	parameters	to factory defa	ults	e been pi	eviousi	y stored			
	P0970 = 21: Resets all										
	P0970 = 31: Special fac	2			,						
	When resetting all para	meters by settin	ng P0970 =	1 or P0970 = 2	1, please note	the follo	wing as	pects:			
	When you reset parameters through the BOP, parameters in both RAM and EEPROM are reset.										
	• When you select USS/MODBUS communication on RS485 and the volatile storage mode (P0014[C only parameters in RAM are reset.										
	• When you select USS/MODBUS communication on RS485 and the non-volatile storage mode (P001										
	=1), parameters in	both RAM and E	EPROM are	reset.		-					
	0	Disabled									
	1	Parameter reset									
	21 User Default Parameter Reset										
	31 Special factory reset										
Notice:	Setting P0970 = 31 resets all user defaults in EEPROM to factory defaults. The converter will then restart. Note that this value setting is used only as one remedy for clearing the fault F51.										
Dependency:	First set P0010 = 30 (fa	ctory settings).									
	Stop converter (i.e. dis	•	-								
Note:	The following paramet	ers retain their v	alues after	a factory reset	with P0970 =1	or 21:					
	• r0039 CO: Energy c	onsumption me	ter [kWh]								
	P0014 Store mode										
	P0100 Europe/Nort	h America									
	P0205 Converter ap	oplication									
	<ul> <li>P2010 USS/MODBU</li> </ul>										
	P2011 USS address										
	P2021 MODBUS ad	dress									
	P8458 Clone control										
	When transferring P09 Communications are in	70, the converte	er uses its pr e time that	ocessor to car	ry out internal o	calculatio	ons.				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P0971	Transfer data from RAM to EEPROM	0 - 21	0	U, T	-	-	U16	3			
	Transfers values from F	RAM to EEPROM	when set to			·					
	Transfers new user def	ault values from	RAM to EEI	PROM when set	to 21.						
	0	Disabled									
	1	Start transfer									
	21 Start User Defaults transfer										
Note:	All values in RAM are tr	ansferred to EEF	PROM.								
	Parameter is automatic	ally reset to 0 (c	lefault) afte	r successful tra	nsfer.						
	The storage from RAM to EEPROM is accomplished via P0971. The communications are reset, if the trans was successful. During the reset process communications will be interrupted.										
	BOP displays 88888										
	After completion of the transfer process, the communication between the converter and external peripherals (BOP, USS or Modbus Master) is automatically re-established.										
r0980[099]	List of available parameter numbers	0 - 65535	981	-	-	-	U16	4			
	Contains 100 paramete	er numbers inde	x 0 - 99.								
Index:	[0]	Parameter 1									
	[1]	Parameter 2									
	[98] Parameter 99										
	[99]	Next paramete	er list								
Note:	The parameter list array has 2 elements to reduce memory consumption. On each access to an element index 0 - 99, the individual result is determined dynamically by the 'BeforeAccess' function. The last element contains the number of the following parameter array, 0 indicates end of list.										
r0981[099]	List of available parameter numbers	0 - 65535	982	-	-	-	U16	4			
	Contains 100 paramete	er numbers inde	x 100 - 199								
Index:	See r0980										
Note:	See r0980										
r0982[099]	List of available parameter numbers	0 - 65535	983	-	-	-	U16	4			
	Contains 100 parameter	er numbers inde	x 200 - 299	•							
Index:	See r0980										
Note:	See r0980	•					-	-			
r0983[099]	List of available parameter numbers	0 - 65535	984	-	-	-	U16	4			
	Contains 100 paramete	er numbers inde	x 300 - 399	•							
Index:	See r0980										
Note:	See r0980										
r0984[099]	List of available parameter numbers	0 - 65535	985	-	-	-	U16	4			
	Contains 100 parameter numbers index 400 - 499.										
Index:	See r0980										
Note:	See r0980										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r0985[099]	List of available parameter numbers	0 - 65535	986	-	-	-	U16	4
	Contains 100 parameter	numbers index 5	00 - 599.					
Index:	See r0980							
Note:	See r0980			•		-		
r0986[099]	List of available parameter numbers	0 - 65535	987	-	-	-	U16	4
	Contains 100 parameter	numbers index 6	00 - 699.					
Index:	See r0980							
Note:	See r0980	1	T	1	•	-	1	1
r0987[099]	List of available parameter numbers	0 - 65535	988	-	-	-	U16	4
	Contains 100 parameter	numbers index 7	00 - 799.					
Index:	See r0980							
Note:	See r0980	1			-	•		
r0988[099]	List of available parameter numbers	0 - 65535	989	-	-	-	U16	4
	Contains 100 parameter	numbers index 8	00 - 899.					
Index:	See r0980							
Note:	See r0980	1			-	•		
r0989[099]	List of available parameter numbers	0 - 65535	0	-	-	-	U16	4
	Contains 100 parameter	numbers index 9	00 - 999.					
Index:	See r0980							
Note:	See r0980	1	T	1	•	-	1	1
P1000[02]	Selection of frequency setpoint	0 - 77	1	С, Т	-	CDS	U16	1
	Selects frequency setpo position) and the additi denote main setpoints Output frequency Run command	onal setpoint is g that have no add	given by the litional setp tional bint	e most significar	at digit (left-ha	and posi	Time	ngle digits
	1	MOP setpoint						
	2	Analog setpoin	t 1					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
	3	Fixed frequen				1	1-512-5				
	5	USS/MODBUS	-								
	7	Analog setpoi									
	10	No main setpo		etpoint							
	11	MOP setpoint									
	12	Analog setpoi									
	13	Fixed frequen									
	15	USS/MODBUS	-								
	17	Analog setpoi	Analog setpoint 2 + MOP setpoint No main setpoint + Analog setpoint 1 MOP setpoint + Analog setpoint 1 Analog setpoint 1 + Analog setpoint 1								
	20										
	21										
	22										
	23	Fixed frequen	Fixed frequency + Analog setpoint 1								
	25	USS/MODBUS	USS/MODBUS on RS485 + Analog setpoint 1								
	27		Analog setpoint 2 + Analog setpoint 1								
	30	No main setpo	oint + Fixed	frequency							
	31	MOP setpoint	+ Fixed freq	uency							
	32	Analog setpoi	nt 1 + Fixed	frequency							
	33	Fixed frequen	cy + Fixed fr	equency							
	35	USS/MODBUS	on RS485 +	Fixed frequency	1						
	37	Analog setpoi	nt 2 + Fixed	frequency							
	50	No main setpo	oint + USS/M	ODBUS on RS48	5						
	51	MOP setpoint	+ USS/MOD	BUS on RS485							
	52	Analog setpoi	nt 1 + USS/N	10DBUS on RS48	35						
	53	Fixed frequen	cy + USS/MC	DBUS on RS485							
	55	USS/MODBUS	on RS485 +	USS/MODBUS or	n RS485						
	57	Analog setpoi	nt 2 + USS/N	10DBUS on RS48	35						
	70	No main setpo	oint + Analog	g setpoint 2							
	71	MOP setpoint	+ Analog se	tpoint 2							
	72	Analog setpoi	nt 1 + Analo	g setpoint 2							
	73	Fixed frequen	cy + Analog	setpoint 2							
	75	USS/MODBUS	on RS485 +	Analog setpoint	2						
77 Analog setpoint 2 + Analog setpoint 2											
Dependency:	Related paramete	er: P1074 (BI: Disable	additional s	etpoint)							
Caution:	P1070, P1071, P1 If P1000 = 1 or 1>	ameter sets (to defa 075, P1076 (, and P1032 (inhibit		-							
Note:	MODBUS. To alter	r the setpoint using t	s MODBUS protocol as well as USS. All USS options on RS485 are also applicable to he setpoint using the BOP when the command source P0700 is not set to 1, you must set to r0019 bit 13 and P1036 is set to r0019 bit 14.								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P1001[02]	Fixed frequency 1 [Hz]	-550.00 - 550.00	10.00	U, T	-	DDS	Float	2		
	Defines fixed frequence		ere are 2 tvr	l les of fixed freq	uencies:					
	Direct selection (P1	5			acticics.					
		fixed frequency	selector (P1	020 to P1023)	selects 1 fixed	frequen	су (Р10	01 to		
	P1004).	ince inequency		020 101 1025)		nequen		0110		
	<ul> <li>If several inputs are active together, the selected frequencies are summed.</li> </ul>									
	Example: fixed frequency 1 (P1001) + fixed frequency 2 (P1002) + fixed frequency 3 (P1003) + fixed frequency 4 (P1004).									
	• Binary coded selection (P1016 = 2):									
	<ul> <li>Up to 16 different fixed frequency values can be selected using this method.</li> </ul>									
	Fixed frequency selection	on bit Binary code	Fixed frequ	ency 1 to 15 (Hz)	]					
	P1023 P1022 P1021 P	1020								
	-	0		0						
		1 1 2		P1001 P1002						
		1 3		P1002	-					
	1	4		P1004						
		1 <u>5</u> 6		P1005 P1006	-					
		1 7	F	P1007						
	1	8		<u>21008</u>	-					
		<u>1 9</u> 10		2 <u>1009</u> 21010						
		1 11		P1011						
		12		P1012						
		<u>1 13</u> 14		P <u>1013</u> P1014						
		1 15		P1015	]					
	See P1020 to P1023 for assigning desired digital inputs to the fixed frequency bits.									
Dependency:	Select fixed frequency									
	Converter requires ON connected to P0840 to		art in the ca	se of direct sele	ction. Therefo	re r1025	must b	e		
Note:	Fixed frequencies can	be selected using	g the digita	inputs.	1		1			
P1002[02]	Fixed frequency 2 [Hz]	-550.00 - 550.00	15.00	U, T	-	DDS	Float	2		
	Defines fixed frequence	y setpoint 2.								
Note:	See P1001			1			T			
P1003[02]	Fixed frequency 3 [Hz]	-550.00 - 550.00	25.00	U, T	-	DDS	Float	2		
	Defines fixed frequence	y setpoint 3.								
Note:	See P1001	1	1	1			1	1		
P1004[02]	Fixed frequency 4 [Hz]	-550.00 - 550.00	50.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 4.									
Note:	See P1001									

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.		
			default	changed		set	type	Level		
P1005[02]	Fixed frequency 5 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 5.									
Note:	See P1001									
P1006[02]	Fixed frequency 6 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 6.									
Note:	See P1001									
P1007[02]	Fixed frequency 7 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 7.									
Note:	See P1001									
P1008[02]	Fixed frequency 8 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 8.									
Note:	See P1001									
P1009[02]	Fixed frequency 9 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2		
	Defines fixed frequency setpoint 9.									
Note:	See P1001									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1010[02]	Fixed frequency 10 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2			
	Defines fixed frequence	y setpoint 10.									
Note:	See P1001										
P1011[02]	Fixed frequency 11 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2			
	Defines fixed frequence	y setpoint 11.									
Note:	See P1001										
P1012[02]	Fixed frequency 12 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2			
	Defines fixed frequency setpoint 12.										
Note:	See P1001										
P1013[02]	Fixed frequency 13 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2			
	Defines fixed frequency setpoint 13.										
Note:	See P1001										
P1014[02]	Fixed frequency 14 [Hz]	-550.00 - 550.00	0.00	U, T	-	DDS	Float	2			
	Defines fixed frequence	y setpoint 14.									
Note:	See P1001										
P1015[02]	Fixed frequency 15 [Hz]	-550.00 - 550.00	0.00	υ, τ	-	DDS	Float	2			
	Defines fixed frequency setpoint 15.										
Note:	See P1001										
P1016[02]	Fixed frequency mode	1 - 2	1	Т	-	DDS	U16	2			
	Fixed frequencies can be selected in two different modes. P1016 defines the mode.										
	1 Direct selection										
	2	Binary selectio	n								
Note:	See P1001 for descript	ion of how to us	e fixed free	quencies.							
P1020[02]	BI: Fixed frequency selection Bit 0	0 - 4294967295	722.3	Т	-	CDS	U32	3			
	Defines origin of fixed	frequency selec	tion.								
Example:	= 722.0	Digital input 1	(requires P	0701 to be set	to 99, BICO)						
	= 722.1	Digital input 2	(requires P	0702 to be set	to 99, BICO)						
	= 722.2	Digital input 3	(requires P	0703 to be set	to 99, BICO)						
	= 722.3	Digital input 4	(requires P	0704 to be set	to 99, BICO)						
Dependency:	Accessible only if P070	1 - P070x = 99 (	function of	digital inputs	= BICO)						
P1021[02]	BI: Fixed frequency selection Bit 1	0 - 4294967295	722.4	Т	-	CDS	U32	3			
	See P1020										
P1022[02]	BI: Fixed frequency selection Bit 2	0 - 4294967295	722.5	Т	-	CDS	U32	3			
	See P1020										
P1023[02]	BI: Fixed frequency selection Bit 3	0 - 4294967295	722.6	Т	-	CDS	U32	3			
	See P1020				•						

Parameter	Functio	on	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r1024		tual fixed ncy [Hz]	-	-	-	-	-	Float	3		
	Display	s sum total of se	elected fixed fre	quencies.							
r1025.0	BO: Fix status	ed frequency	-	-	-	-	-	U16	3		
	Display	s the status of f	ixed frequencies	5.							
	Bit	Signal name				1 signal		0 sign	al		
	00	Status of FF				Yes		No			
P1031[02]	MOP m	node	0 - 3	1	U, T	-	DDS	U16	2		
	MOP m	ode specificatio	on.	•			•		•		
	Bit	Signal name				1 signal		0 sign	al		
	00	Setpoint store				Yes		No			
	01		or MOP necessa	rv		Yes No					
Note:	Defines	Pefines the operation mode of the motorized potentiometer. See P1040.									
P1032 Inhibit r			0 - 1	1	T	-	-	U16	2		
	Inhibits	s reverse setpoir	nt selection of th	e MOP.	•		•				
	0	•	Reverse directi		ed						
	1		Reverse directi	on inhibite	d						
Note:	frequer	It is possible to change motor direction using the motor potentiometer setpoint (increase/decrease frequency). Setting 0 enables a change of motor direction using the motor potentiometer setpoint (increase/decrease									
	frequency). If $P1032 = 1$ and $P1000 = 1$ or 1X, then reverse motor direction will be inhibited.										
P1035[02]		ble MOP (UP-	0 - 4294967295	19.13	Т	-	CDS	U32	3		
	Defines	source for mot	or potentiomete	er setpoint i	ncrease frequ	ency.					
Setting:	722.0		Digital input 1			-					
~	722.1		Digital input 2	· · ·							
	722.2		Digital input 3								
Notice:		en the signal is	bled by short pu enabled longer t	lses of less	than 1 second	l, the frequency					
P1036[02]		ble MOP I-command)	0 - 4294967295	19.14	Т	-	CDS	U32	3		
	Defines	s source for mot	or potentiomete	er setpoint	decrease frequ	ency.					
Setting:	See P10	035									
Notice:	If this command is enabled by short pulses of less than 1 second, the frequency is changed in steps of 0.1 Hz. When the signal is enabled longer than 1 second the ramp generator decelerates with the rate of P1048.										

	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.			
			default	changed		set	type	Level			
P1040[02]	Setpoint of the MOP [Hz]	-550.00 - 550.00	5.00	U, T	-	DDS	Float	2			
	Determines setpoint fo	r motor potenti	ometer con	trol (P1000 = 1)							
Dependency:	Motor potentiometer (	P1040) must be	chosen as	main setpoint or	additional set	tpoint (ι	ising P1	000).			
Note:	If motor potentiometer setpoint is selected either as main setpoint or additional setpoint, the reverse direction will be inhibited by default of P1032 (inhibit reverse direction of MOP). To re-enable reverse direction, set P1032 = 0.										
	A short press of the 'up' or 'down' keys (e.g.: operator panel) will change the frequency setpoint in steps 0.1 Hz. A longer press will cause an accelerated frequency setpoint change.										
	The start value gets active (for the MOP output) only at the start of the MOP. P1031 influences the start value behavior as follows:										
	P1031 = 0: Last MOP setpoint not saved in P1040										
	MOP UP/DOWN requires an ON command to become active.										
	• P1031 = 1: Last MOP setpoint saved in P1040 on every OFF										
	MOP UP/DOWN requires an ON command to become active (default).										
	• P1031 = 2: Last MOP setpoint not saved in P1040										
	MOP UP/DOWN active without additional ON command.										
	• P1031 = 3: Last MOP setpoint saved in P1040 on powering-up										
	MOP UP/DOWN acti	ve without addi	tional ON c	ommand.							
P1041[02]	BI: MOP select	0 -	0	Т	-	CDS	U32	3			
	setpoint automatically/manu ally	4294967295									
	Sets the signal source to change over from manual to automatic mode. If using the motorized potentiometer in the manual mode the setpoint is changed using two signals for up and down e.g. P1035 and P1036. If using the automatic mode the setpoint must be interconnected via the connector input (P1042).										
	0: manually										
	1: automatically										
Notice:	Refer to: P1035, P1036	, P1042									
P1042[02]	CI: MOP auto setpoint	0 - 4294967295	0	Т	-	CDS	U32	3			
	serpoint	4294907295									
	Sets the signal source f selected.		of the moto	rized potentiom	l eter if automa	atic mod	le P1041	is			
Notice:	Sets the signal source f		of the moto	l prized potentiom	l eter if automa	atic mod	le P1041	T			
	Sets the signal source f selected.		of the moto	rized potentiom	eter if automa	CDS	U32	is 3			
	Sets the signal source f selected. Refer to: P1041 BI: MOP accept rampgenerator	or the setpoint o 0 - 4294967295 or the setting co	0 ommand to	T accept the setti	- ng value for th	CDS ne moto	U32	T			
Notice: P1043[02] Notice:	Sets the signal source f selected. Refer to: P1041 BI: MOP accept rampgenerator setpoint Sets the signal source f	or the setpoint o 0 - 4294967295 or the setting co	0 ommand to	T accept the setti	- ng value for th	CDS ne moto	U32	T			
P1043[02]	Sets the signal source f selected. Refer to: P1041 BI: MOP accept rampgenerator setpoint Sets the signal source f potentiometer. The val	or the setpoint o 0 - 4294967295 or the setting co	0 ommand to	T accept the setti	- ng value for th	CDS ne moto	U32	T			
P1043[02] Notice:	Sets the signal source f selected. Refer to: P1041 BI: MOP accept rampgenerator setpoint Sets the signal source f potentiometer. The val Refer to: P1044 CI: MOP rampgenerator	or the setpoint of 4294967295 or the setting co ue becomes effo 0 - 4294967295	0 ommand to ective for a	T accept the setti 0/1 edge of the T	- ng value for th setting comm -	CDS ne moto and.	U32 rized U32	3			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
r1045	CO: MOP input frequency of the RFG [Hz]	-	-	-	-	-	Float	3		
	Displays the motorized	potentiometer	setpoint be	fore it passed t	he MOP RFG.					
P1046	MOP step increment [Hz]	0.1-10	0.1	U, T	-	DDS	Float	3		
	Sets the MOP step incr	ement.								
Notice:	Step increment is used	only for MOP ra	ather than F	PID-MOP.						
Note:	Short press of the Up of the value set in P1046 Long press of the Up of change rate depending the RFG[s]). With long ramps up along with M	r Down button i g on P1047 (MO press, the MOP	ncreases or P ramp-up input goes	decreases the time of the RFG to the maximu	MOP setpoint [s]) or P1048 (	respectiv (MOP rar	ely at a np-dowi	frequency 1 time of		
P1047[02]	MOP ramp-up time of the RFG [s]	0.00 - 1000.00	10.00	U, T	-	DDS	Float	2		
	Sets the ramp-up time for the internal MOP ramp-function generator. The setpoint is changed from ze up to limit defined in P1082 within this time.									
Notice:	Refer to: P1048, P1082	2								
P1048[02]	MOP ramp-down time of the RFG [s]	0.00 - 1000.0	10.00	U, T	-	DDS	Float	2		
		Sets the ramp-down time for the internal MOP ramp-function generator. The setpoint is changed from limit defined in P1082 down to zero within this time.								
Notice:	Refer to: P1047, P1082									
r1050	CO: Actual output freq. of the MOP [Hz]	-	-	-	-	-	Float	2		
	Displays output freque	ncy of motor po	tentiomete	r setpoint.						
P1055[02]	BI: Enable JOG right	0 - 4294967295	19.8	Т	-	CDS	U32	3		
	Defines source of JOG	right when P07	19 = 0 (Aut	o selection of c	ommand/setpo	oint sour	ce).			
P1056[02]	BI: Enable JOG left	0 - 4294967295	0	Т	-	CDS	U32	3		
	Defines source of JOG	left when P0719	9 = 0 (Auto	selection of co	mmand/setpoi	nt source	e).	n		
P1057	JOG enable	0 - 1	1	Т	-	-	U16	3		
	While JOG enable is '0'		and P1055	is disabled. W	/hen '1' Joggin	g is enab	led.	1		
P1058[02]	JOG frequency [Hz]	0.00 - 550.00	5.00	U, T	-	DDS	Float	2		
	Jogging increases the motor speed by small amounts. The JOG mode allows the operator to perfor specific number of revolutions and position the rotor manually. In JOG mode, the RUN button on t operator panel for jogging uses a non-latching switch on one of the digital inputs to control the m speed. While jogging, P1058 determines the frequency at which the converter will run. The motor increased as long as 'JOG left' or 'JOG right' are selected and until the left or right JOG frequency is reached.									
Dependency:	P1060 and P1061 set up and down ramp times respectively for jogging. Rounding times (P1130 - P1133) rounding type (P1134) and P2167 will also have influence on the JOG ramp.									
P1059[02]	JOG frequency left [Hz]	0.00 - 550.00	5.00	U, T	-	DDS	Float	2		
	While JOG left is select	ed, this parame	ter determi	nes the frequer	ncy at which th	ie convei	rter will	run.		
Dependency:	P1060 and P1061 set up and down ramp times respectively for jogging.									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1060[02]	JOG ramp-up time [s]	0.00 - 650.00	10.00	U, T	-	DDS	Float	2			
	Sets jog ramp-up time.	This is the time	used while	jogging is act	ive.						
Dependency:	See also P3350, P3353			, , , , , , , , , , , , , , , , , , , ,							
Notice:	Ramp times will be use										
	• P1060/P1061 : JOG										
	<ul> <li>P1120/P1121 : Nor</li> </ul>		NEE) is activ	10							
	• P1060/P1061 : Nor										
NI - 1 -	-	he rounding of P1130 - P1133 also applies to the JOG ramping. the SuperTorque function is enabled, the converter will initially ramp using the value in P3353.									
Note:				1	y ramp using '						
P1061[02]	JOG ramp-down time [s]		10.00	U, T	-	DDS	Float	2			
	Sets ramp-down time. This is the time used while jogging is active.										
Dependency:	See also P3350, P3353.										
Note:	See P1060	•	I	Т							
P1070[02]	CI: Main setpoint	0 - 4294967295	1050[0]	Т	-	CDS	U32	3			
	Defines source of main	setpoint.									
Setting:	755	Analog input 1	setpoint								
	1024   Fixed frequency setpoint										
	1050	Motor potentic	ometer (MC	)P) setpoint							
P1071[02]	CI: Main setpoint scaling	0 - 4294967295	1	Т	4000H	CDS	U32	3			
	Defines source of the main setpoint scaling.										
Setting:	See P1070	•									
P1074[02]	BI: Disable additional setpoint	0 - 4294967295	0	U, T	-	CDS	U32	3			
	Disables additional setpoint.										
Setting:	See P1070										
P1075[02]	CI: Additional setpoint	0 - 4294967295	0	Т	-	CDS	U32	3			
	Defines source of the additional setpoint (to be added to main setpoint).										
Setting:	See P1070										
P1076[02]	CI: Additional setpoint scaling	0 - 4294967295	[0] 1 [1] 0 [2] 1	Т	4000H	CDS	U32	3			
	Defines source of scali	l na for additional		i be added to	main setnoint	+)					
Setting:		Scaling of 1.0 (		to be added to	main setpoint	ι).					
setting.	755		, ,								
	1024	1	y selpoint								
1078	1050 CO: Total frequency	MOP setpoint	_		_	-	Float	3			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r1079	CO: Selected frequency setpoint [Hz]	-	-	-	-	-	Float	3			
	Displays selected frequency setpoint. Following frequency setpoints are displayed:										
	r1078 Total frequency setpoint										
	P1058 JOG frequency right										
	P1059 JOG frequency left										
Dependency:	P1055 (BI: Enable JOG left respectively.	right) or P1056	(BI: Enable	JOG left) define	command so	urce of J	OG right	or JOG			
Note:	P1055 = 0 and P1056 =	P1055 = 0 and P1056 = 0 ==> Total frequency setpoint is selected.									
P1080[02]	Minimum frequency [Hz]	0.00 - 550.00	0.00	C, U, T	-	DDS	Float	1			
	frequency P1080 represents a masking frequency of 0 Hz for all frequency target value sources e.g. analog input, MOP, FF, USS with the exception of the JOG target value source (analogous to P1091). Thus the frequency band +/-P1080 is run through in optimum time by means of the acceleration/deceleration ramps. Dwelling in the frequency band is not possible. Furthermore, an overshoot of the actual frequency f_act upper minimum frequency P1080 is output by the signal function  f_act  > f_min.										
Note:	Value set here is valid to Under certain condition					minimuı	n fregue	ency.			
P1082[02]	Maximum frequency [Hz]			С, Т	-	DDS	Float	1			
	Sets maximum motor f set here is valid for bot Furthermore, the moni this parameter.	h clockwise and	counterclo	ckwise rotation		-					
Example:	f_act   P1082 P1082 - 3 Hz  f_act   ≥P1082(f_max) r0052 1 Bit10 0					►t					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
Dependency:	The maximum value of 550.0 Hz). As consequency and the pu frequency according the second seco	uence P1082 can lse frequency dep	be affected bending on	if P0310 is char	nged to a sma	ller valu	e. The n	naximum			
				P180	0						
		2 kl	Ηz	4 kHz	6 kHz		8 - 16 kHz				
	f <sub>max</sub> P1082	0 - 133	3.3 Hz	0 - 266.6 Hz	5 0 - 400 I	Hz	0 - 55	0.0 Hz			
	Example: If P1082 is set to 350 Hz a pulse frequency from at least 6 kHz is necessary. If P1800 is smaller than 6 kHz										
	the parameter is changed P1800 = 6 kHz.										
	The maximum output frequency of converter can be exceeded if one of the following is active:										
	- P1335 ≠ 0 (Slip compensation active):										
	$f_{max}$ (P1335) = $f_{max}$ + $f_{slip,max}$ = P1082+ $\frac{P1336}{100} \cdot \frac{r0330}{100} \cdot P0310$										
	- P1200 ≠ 0 (Flying restart active):										
	fmax (P1200)= fmax +2.fslip,nom =P1082+2. <u>r0330</u> .P0310										
Note:	When using the setpoint source										
	Analog Input										
	• USS										
	the setpoint frequenc	y (in Hz) is cyclica	ally calculate	ed using							
	• a percentage value(e.g. for the analog input r0754)										
	• a hexadecimal value (e.g. for the USS r2018[1])										
	and the reference frequency P2000.										
	If for example P1082 = 80 Hz, P2000 = 50 Hz and the analog input is parameterized with P0757 = 0 V, P0758 = 0 %, P0759 = 10 V, P0760 = 100 %, a setpoint frequency of 50 Hz will be applied at 10 V of the analog input. When Quick Commissioning is carried out P2000 is changed as follows: P2000 = P1082.										
r1084	Resultant maximum frequency [Hz]	-	-	-	-	-	Float	3			
	Displays resultant max	kimum frequency	·.				T				
P1091[02]	Skip frequency [Hz]			U, T	-	DDS	Float	3			
	Defines skip frequenc +/-P1101 (skip freque	ncy bandwidth).			-	-	-				
Notice:	Stationary operation is not possible within the suppressed frequency range; the range is merely passed through (on the ramp). For example, if P1091 = 10 Hz and P1101 = 2 Hz, it is not possible to operate continuously between 10 Hz +/- 2 Hz (i.e. between 8 and 12 Hz).										
Note:	The function is disable	ed if P1091 = 0.		•							
P1092[02]	Skip frequency 2 [Hz]	0.00 - 550.00	0.00	U, T	-	DDS	Float	3			
	Defines skip frequenc +/-P1101 (skip freque		effects of m	echanical reson	ance and sup	presses	frequen	cies within			
Note:	See P1091										
P1093[02]	Skip frequency 3 [Hz]	0.00 - 550.00	0.00	U, T	-	DDS	Float	3			
	Defines skip frequenc +/-P1101 (skip freque		effects of m	echanical reson	ance and sup	presses	frequen	cies within			
Note:	See P1091										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P1094[02]	Skip frequency 4 [Hz]	0.00 - 550.00	0.00	U, T	-	DDS	Float	3				
	Defines skip frequency +/-P1101 (skip frequen		effects of r	nechanical reso	nance and su	ppresses	frequen	cies within				
Note:	See P1091			_								
P1101[02]	Skip frequency bandwidth [Hz]	0.00 - 10.00	2.00	U, T	-	DDS	Float	3				
	Delivers frequency bandwidth to be applied to skip frequencies.											
Note:	See P1091		•	-	-							
P1110[02]	BI: Inhibit negative frequency setpoint	0 - 4294967295	0	Т	-	CDS	U32	3				
	to the set-point channel	This parameter suppresses negative setpoints. Therefore, modification of the motor direction is inhibited to the set-point channel. If a minimum frequency (P1080) and a negative setpoint are given, the motor is accelerated by a positive value in relationship to the minimum frequency.										
Setting:	0	Disabled										
	1	Enabled										
P1113[02]	BI: Reverse	0 - 4294967295	19.11	Т	-	CDS	U32	3				
	Defines source of reverse command used when P0719 = 0 (Auto selection of command/setpoint source).											
Setting:	722.0	Digital input 1	(requires P	0701 to be set t	to 99, BICO)							
	722.1											
	722.2	Digital input 3	(requires P	0703 to be set t	to 99, BICO)							
r1114	CO: Freq. setpoint after direction control [Hz]	-	-	-	-	-	Float	3				
	Displays setpoint frequ	ency after chan	ge of direct	ion.	•							
r1119	CO: Freq. setpoint before RFG [Hz]	-	-	-	-	-	Float	3				
	Displays frequency set functions, e.g.: • P1110 BI: Inhibit ne • P1091 - P1094 skip • P1080 min. frequen • P1082 max. freque This value is available f	eg. freq. setpoin frequencies, ncy, ncy,	t,		nerator after n	nodificati	ion by of	ther				
P1120[02]	Ramp-up time [s]	0.00 - 650.00	10.00	C, U, T	-	DDS	Float	1				
	Time taken for motor t rounding is used. Setti											
Dependency:	Rounding times (P1130 also have influence on See also P3350, P3353	the ramp.	ding type (	P1134), and rar	np-up time sc	aling fact	tor (P11	38) will				
Notice:	Ramp times will be use P1060/P1061 : JOG P1120/P1121 : Nor P1060/P1061 : Nor Set ramp-up time = rar	mode is active mal mode (ON/0 mal mode (ON/0	OFF) and P1	124 is active	up time (P112	20).		_				
Note:	If an external frequence optimum converter pe the PLC. Changes to P1 converter will initially r	y setpoint with s rformance is to s 120 will be imm	set ramp ra set ramp tir nediately ef	tes is used (e.g. mes in P1120 ar fective. If the Si	from a PLC), nd P1121 sligi	the best htly short	er than t	those of				

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.			
			default	changed		set	type	Level			
P1121[02]	Ramp-down time [s]	0.00 - 650.00	10.00	C, U, T	-	DDS	Float	1			
	Time taken for motor to rounding is used.	o decelerate froi	m maximur	n motor frequer	ncy (P1082) d	own to s	standstill	when no			
Dependency:	Ramp-down time scalin	ig factor (P1139	) will also h	nave influence o	n the ramp.						
	See also P3350, P3353										
Notice:	Setting the ramp-down time too short can cause the converter to trip (overcurrent F1/overvoltage F2).										
	Ramp times will be used as follows:										
	• P1060/P1061 : JOG	mode is active									
	P1120/P1121 : Normal mode (ON/OFF) is active										
		• P1060/P1061 : Normal mode (ON/OFF) and P1124 is active Set ramp-down time = ramp-down time scaling factor (P1139) x ramp-down time (P1121).									
Note:			-				, .				
	Changes to P1121 will be immediately effective. See P1120										
P1124[02]	BI: Enable JOG ramp	0 -	0	Т	-	CDS	U32	3			
	times	4294967295									
		Defines source for switching between jog ramp times (P1060, P1061) and normal ramp times (P1120, P1121) as applied to the RFG. This parameter is valid for normal mode (ON/OFF) only.									
Dependency:	See also P1175.										
	will be used all the time		mp functio		ng P1175, ran	np times	will swit	tch			
	between normal (P112 P2150, P2157 and P21 Dual Ramp.	0, P1121) and J	mp functio OG (P1060	n is selected usir , P1061) ramp ti	ng P1175, ran mes, depend	np times ing on th	will swith ne setting	tch gs of			
P1130[02]	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial	0, P1121) and J	mp functio OG (P1060	n is selected usir , P1061) ramp ti	ng P1175, ran mes, depend	np times ing on th	will swith ne setting	tch gs of			
P1130[02]	between normal (P112 P2150, P2157 and P21 Dual Ramp. See P1120.	0, P1121) and J 59. Therefore, it 0.00 - 40.00	mp function OG (P1060 is not reco	n is selected usir , P1061) ramp ti mmended that . U, T	ng P1175, ran mes, depend	np times ing on th elected a	will swit ne setting at the sa	tch gs of me time			
P1130[02] Notice:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s]	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r	ng P1175, ran mes, depend JOG ramp is s - - response, thu	np times ing on th elected a DDS s avoidir	will swit he setting at the sa Float	tch gs of me time			
	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended in the converter nes (P1120, P11	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	np times ing on th elected a DDS s avoidir y would n	will swit he setting at the sa Float ng detrim result in	tch gs of me time 2 nental			
Notice: Note:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended in the converter nes (P1120, P11	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	np times ing on th elected a DDS s avoidir y would n	will swit he setting at the sa Float ng detrim result in	tch gs of me time 2 nental			
Notice: Note:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended in the converter nes (P1120, P11 me (t_down) wi 0.00 - 40.00	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS	Float result in total ran	tch gs of me time 2 nental			
Notice: Note: P1131[02]	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final rounding time [s]	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended in the converter nes (P1120, P11 me (t_down) wi 0.00 - 40.00	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS	Float result in total ran	tch gs of me time 2 nental			
Notice: Note: P1131[02] Notice:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final rounding time [s] Defines rounding time	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended in the converter nes (P1120, P11 me (t_down) wi 0.00 - 40.00	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS	Float result in total ran	tch gs of me time 2 nental			
Notice: Note: P1131[02] Notice:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final rounding time [s] Defines rounding time See P1130 Ramp-down initial	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended, sin t recommended, sin cs. t recommended, sin cs. t recommended, sin cs. t recommended, sin t rec	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00 up. 0.00	n is selected usir , P1061) ramp ti mmended that . -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS boxed and the second and the sec	Float result in Float Float Float	tch gs of me time 2 nental np up tim 2			
Notice:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. <b>Ramp-up initial</b> rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti <b>Ramp-up final</b> rounding time [s] Defines rounding time See P1130 <b>Ramp-down initial</b> rounding time [s]	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended, sin t recommended, sin cs. t recommended, sin cs. t recommended, sin cs. t recommended, sin t rec	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00 up. 0.00	n is selected usir , P1061) ramp ti mmended that . -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS boxed and the second and the sec	Float result in Float Float Float	tch gs of me time 2 nental np up tim 2			
Notice: P1131[02] Notice: P1132[02] Notice:	between normal (P112 P2150, P2157 and P212 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final rounding time [s] Defines rounding time See P1130 Ramp-down initial rounding time [s] Defines rounding time	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended, sin t recommended, sin cs. t recommended, sin cs. t recommended, sin cs. t recommended, sin t rec	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00 up. 0.00	n is selected usir , P1061) ramp ti mmended that . -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130.	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	DDS boxed and the second and the sec	Float result in Float Float Float	tch gs of me time 2 nental np up tim 2			
Notice: Note: P1131[02] Notice: P1132[02]	between normal (P112 P2150, P2157 and P213 Dual Ramp. See P1120. Ramp-up initial rounding time [s] Defines rounding time Rounding times are rec effects on the mechani Rounding times are not overshoot/undershoot If short or zero ramp tir (t_up) or ramp down ti Ramp-up final rounding time [s] Defines rounding time See P1130 Ramp-down initial rounding time [s] Defines rounding time See P1130 Ramp-down final	0, P1121) and J 59. Therefore, it 0.00 - 40.00 in seconds at sta ommended, sin cs. t recommended, sin cs. t recommended t	mp function OG (P1060 is not reco 0.00 art of ramp ce they pre when anal response. 121 < P113 Il not depe 0.00 up. 0.00 -down.	n is selected usir , P1061) ramp ti mmended that U, T -up. vent an abrupt r og inputs are us 0, P1131, P1132 nd on P1130. U, T	ng P1175, ran mes, depend JOG ramp is s - response, thu ed, since they	np times ing on the elected a DDS s avoidin / would n set, the DDS DDS	Float Float Float Float Float Float Float	tch gs of me time 2 nental 2 2 2			

	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1134[02]	Rounding type	0 - 1	0	U, T	-	DDS	U16	2			
	Defines the smoothing new setpoint, OFF1, O and	which is active FF3, REV). This s	by setpoint moothing i	modifications	during accele e motor is ram	ration or o ped-up o	decelera r rampe	tion (e.g. d-down			
	• P1134 = 0,										
	<ul> <li>P1132 &gt; 0, P1133 &gt; 0 and</li> </ul>										
	the setpoint is not yet reached.										
	0	Continuous sm	noothing								
	1	Discontinuous	smoothing								
Dependency:	Effect only when P113 (Ramp-down initial rou						ling time	e) or P113			
21135[02]	OFF3 ramp-down time [s]	0.00 - 650.00	5.00	C, U, T	-	DDS	Float	2			
	Defines ramp-down tir P1134 will have no eff approximately 10% of f(P1134) = 1.1 * P113	ect on OFF3 ram P1135 is howev	np-down ch er included	aracteristic. Ar	initial ramp-o	lown roui	nding tir	ne of			
Note:	This time may be exce	eded if the Vdc_	max level is	reached.							
Note: P1138[02]	Ramp-up time scaling factor	1.00 - 10.00	1.00	C, U, T	-	DDS	Float	1			
	Defines the scaling factor for the ramp-up time. This is a ramp-up time multiplier, extending the maximum ramp-up time to 6500 s. Set ramp-up time = ramp-up time scaling factor (P1138) x ramp-up time (P1120)										
	ramp-up time to 6500	s. Set ramp-up t	ime = ramp	-up time scalir							
	ramp-up time to 6500 This time may be exce	s. Set ramp-up t	ime = ramp	-up time scalir			p-up tim				
<b>Note:</b> P1139[02]	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00	ime = ramp max level is 1.00	-up time scalir reached. C, U, T	ng factor (P11)	38) x ram DDS	p-up tim Float	ne (P1120)			
	ramp-up time to 6500 This time may be exce Ramp-down time	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s.	ime = ramp max level is 1.00 -down time	-up time scalir reached. C, U, T .This is a ramp	ng factor (P11)	38) x ram DDS nultiplier,	p-up tim Float extendir	ne (P1120)			
	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21).	ime = ramp max level is 1.00 -down time Set ramp-d	-up time scalir reached. C, U, T .This is a ramp own time = rar	ng factor (P11)	38) x ram DDS nultiplier,	p-up tim Float extendir	ne (P1120)			
P1139[02] Note:	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21).	ime = ramp max level is 1.00 -down time Set ramp-d	-up time scalir reached. C, U, T .This is a ramp own time = rar	ng factor (P11)	38) x ram DDS nultiplier,	p-up tim Float extendir	ne (P1120)			
P1139[02] Note:	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112 This time may be excer	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21). eded if the VDC_ 0 - 4294967295 rce of RFG enabl utput will be set	ime = ramp max level is 1.00 -down time Set ramp-d max level is 1 e command	-up time scalir reached. C, U, T .This is a ramp own time = ran s reached. T d (RFG: ramp fu ly to 0.	-down time m -down time m np-down time	38) x ram DDS nultiplier, e scaling f CDS	P-up tim Float extendir actor (P U32	ne (P1120)			
P1139[02] Note: P1140[02]	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112) This time may be excer BI: RFG enable Defines command sou to zero then the RFG o BI: RFG start	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21). eded if the VDC_ 0 - 4294967295 rce of RFG enabl utput will be set 0 - 4294967295	ime = ramp max level is 1.00 -down time Set ramp-d max level is 1 e command immediate	-up time scalir reached. C, U, T .This is a ramp own time = ran s reached. T d (RFG: ramp fu ly to 0. T	- -down time m np-down time - unction genera	38) x ram DDS oultiplier, e scaling f CDS ator). If bi	P-up tim Float extendir actor (P U32 nary inp U32	1 1 1 1 1 1 1 1 1 1 1 1 1 1			
P1139[02] Note: P1140[02] P1141[02]	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112 This time may be excer BI: RFG enable Defines command sou to zero then the RFG of BI: RFG start Defines command sou zero then the RFG outp	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21). eded if the VDC_ 0 - 4294967295 rce of RFG enabl utput will be set 0 - 4294967295 rce of RFG start out is held at its	ime = ramp max level is 1.00 -down time Set ramp-d max level is 1 e command immediate	-up time scalir reached. C, U, T .This is a ramp own time = ran s reached. T d (RFG: ramp fu ly to 0. T RFG: ramp fun	- -down time m np-down time - unction genera	38) x ram DDS nultiplier, e scaling f CDS ator). If bina	p-up tim Float extendir actor (P U32 inary inp U32 ury input	e (P1120) 1 1 1 1 1 1 1 1 1 1 3 0 1 3 3 is equal to			
P1139[02] Note: P1140[02] P1141[02]	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112 This time may be excer BI: RFG enable Defines command sou to zero then the RFG o BI: RFG start Defines command sou zero then the RFG outp BI: RFG enable setpoint	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21). eded if the VDC_ 0 - 4294967295 rce of RFG enabl utput will be set 0 - 4294967295 rce of RFG start put is held at its 0 - 4294967295	ime = ramp max level is 1.00 -down time Set ramp-d max level is 1 e command immediate 1 command ( present valu	-up time scalir reached. C, U, T .This is a ramp own time = ran s reached. T d (RFG: ramp fun ly to 0. T RFG: ramp fun ue. T	- -down time m mp-down time - unction generator - ction generator	38) x ram DDS nultiplier, e scaling f CDS ator). If bina CDS or). If bina	P-up tim Float extendir actor (P U32 U32 ury input U32	ae (P1120)          1         ng the         139) x         3         out is equal         3         3         3         3         3         3         3         3         3         3         3         3         3         3			
P1139[02] Note: P1140[02]	ramp-up time to 6500 This time may be excer Ramp-down time scaling factor Defines the scaling fac maximum ramp-down ramp-down time (P112 This time may be excer BI: RFG enable Defines command sou to zero then the RFG of BI: RFG start Defines command sou zero then the RFG outp BI: RFG enable	s. Set ramp-up t eded if the Vdc_ 1.00 - 10.00 tor for the ramp time to 6500 s. 21). eded if the VDC_ 0 - 4294967295 rce of RFG enabl utput will be set 0 - 4294967295 rce of RFG start o but is held at its 0 - 4294967295 rce of RFG start o but is held at its	ime = ramp max level is 1.00 -down time Set ramp-d max level is 1 e command immediate 1 command ( present valu 1 e setpoint o	-up time scalir reached. C, U, T .This is a ramp own time = ran s reached. T d (RFG: ramp fun ly to 0. T RFG: ramp fun ue. T	- -down time m mp-down time - unction generate - ction generate - ction generate	38) x ram DDS outtiplier, e scaling f CDS ator). If bina CDS or). If bina	P-up tim Float extendir actor (P U32 inary input U32 ury input U32 ttor). If b	e (P1120). 1 ng the 1139) x 3 out is equal 3 is equal to 3			

	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
P1175[02]	BI: Dual r	ramp enable		0	T	-	CDS	U32	3	
	Defines co ramp will Ramp Co W Ramp Co W Outr (Hz) P2159 (H P2157 (H -P2159 (H	ommand sou be applied. T -up: onverter start: hen f_act > P. -down: onverter start: hen f_act < P. put frequency	4294967295 rce of dual ramp his works as foll s ramp-up using 2157, switch to r s ramp-down usi 2159, switch to r JOG r Ramp-up	ows: ramp time ramp time f ng ramp tir	from P1120 rom P1060 ne from P1061	y input is equa	Ramp- down time P1121	then the		
Dependency:	See P2150, P2157, P2159, r2198.									
Note:	The dual is used to make the	ramp algorith apply hyster dual ramp fu ction with JO	nm uses r2198 bi esis to these sett Inction more res	ings, so the	e user may wish	to change the	e value o	f this pa	rameter to	
r1199.712	CO/BO: R word	FG status	-	-	-	-	-	U16	3	
	Displays s	status of ramp	o function gener	ator (RFG).				-		
		Signal name	!			1 signal		0 sign	al	
	07	Ramp #0 acti	ve			Yes		No		
	08	Ramp #1 acti	ve			Yes		No		
	09 Ramping finished					Yes No				
	09	Ramping fini.								
						Yes				
	10	Direction righ	nt/left			Yes Yes		No		
	10 11		nt/left 7(f_2)			Yes Yes Yes				

Parameter	Functio	n	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P1200	Flying	start	0 - 6	0	U, T	-	-	U16	2		
	Starts c	onverter onto a	a rotating motor is been found. Th								
	0		Flying start dis	abled							
	1		Flying start alv	vays active;	searches in both	n directions					
	2		Flying start act	ive after po	wer on, fault, O	FF2; searches	in both	directio	ns		
	3		Flying start act	ive after fau	ult, OFF2; search	nes in both dir	ections				
	4										
	5		Flying start act only	Flying start active after power on, fault, OFF2; searches in direction of setpoint							
	6		Flying start active after fault, OFF2; searches in direction of setpoint only								
Notice:	Flying s can be o	tart must be us driven by the lo	nust be used in cases where the motor may still be turning (e.g. after a short mains break) or by the load. Otherwise, overcurrent trips will occur.								
Note:	Useful f only in	or motors with direction of set	high inertia load point.	ds. Settings	1 to 3 search in	both direction	ns. Settir	ngs 4 to	6 search		
P1202[02]		current: tart [%]	10 - 200	100	U, T	-	DDS	U16	3		
	Defines	search current	used for flying s	start. Value	is in [%] based c	on rated motor	current	nt (P0305).			
Note:	very hig P1202 a F2 trips	Jĥ. However, se and P1203) ma	urrent may impro earch current set y cause motor sp	tings in P12 beed to be f	202 that are belo ound premature	ow 30% (and s	ometim which c	es othei an resu	settings i It in F1 or		
P1203[02]	Search start [%	rate: flying ]	10 - 500	100	U, T	-	DDS	U16	3		
	with tu	rning motor. Th	e only) by which nis value is enter ences the time t	ed in [%]. It	defines the reci	procal initial g	ing start radient	to sync in the se	hronize earch		
Example:	For a m	otor with 50 H	z, 1350 rpm, 100	) % would p	oroduce a maxim	num search tir	ne of 60	0 ms.			
Note:	A highe	motor with 50 Hz, 1350 rpm, 100 % would produce a maximum search time of 600 ms. Ther value produces a flatter gradient and thus a longer search time. A lower value has the opposite									
	effect.	r value produc	es a flatter gradio	ent and thu	s a longer searcl	h time. A lowe	r value l	has the	opposite		
r1204	effect.	word: flying	es a flatter gradi	ent and thu	s a longer searcl	h time. A lowe	r value    -	U16	opposite 4		
r1204	effect. Status start V/	word: flying f	es a flatter gradio - king and monito	-	-	h time. A lowe	-	1	T		
r1204	effect. Status start V/	word: flying f	- king and monito	-	-	h time. A lowe	-	1	4		
r1204	effect. Status start V/ Bit para	word: flying f meter for chec Signal name	- king and monito	-	-	-	r value    -	U16	4		
r1204	effect. Status start V/ Bit para Bit	word: flying f meter for chec Signal name Current appli	- king and monito	-	-	- 1 signal	r value    -	U16 <b>0 sign</b>	4		
r1204	effect. Status start V/ Bit para Bit 00	word: flying f meter for chec Signal name Current appli	king and monito e ied d not be applied	-	-	- <b>1 signal</b> Yes	r value    -	U16 <b>0 sign</b> No	4		
r1204	effect. Status start V/ Bit para Bit 00 01	word: flying f meter for chec Signal name Current appli Current could	king and monito e ied d not be applied ced	-	-	- <b>1 signal</b> Yes Yes	r value    -	U16 <b>0 sign</b> No No	4		
r1204	effect. Status start V/ Bit para Bit 00 01 02	word: flying f meter for chec Signal name Current appli Current could Voltage redu	king and monito e ied d not be applied ced tarted	-	-	- <b>1 signal</b> Yes Yes Yes	-	U16 <b>0 sign</b> No No	4		
r1204	effect. Status v start V/ Bit para Bit 00 01 02 03	word: flying f meter for chec Signal name Current appli Current could Voltage redu Slope-filter s	king and monito e ied d not be applied ced tarted threshold	-	-	- <b>1 signal</b> Yes Yes Yes Yes	-	U16 <b>0 sign</b> No No No	4		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1210	Automatic restart	0 - 11	1	U, T	-	-	U16	2			
	Configures automatic	restart functio	n.		•						
	0	Disabled									
	1	Trip reset aft	er power on,	, P1211 disable	ed						
	2	Restart after	mains black	out, P1211 disa	abled						
	3	Restart after	mains brown	nout or fault, P	1211 enabled						
	4	Restart after	mains brown	nout, P1211 er	nabled						
	5	Restart after mains blackout and fault, P1211 disabled									
	6	Restart after mains brownout/blackout or fault, P1211 enabled									
	7	Restart after mains brownout/blackout or fault, trip when P1211 expires									
	8	Restart after mains brownout/blackout with F3 and leave an interval in seconds determined by P1214, P1211 disabled									
Dependency: Caution: Notice:	9	Restart after mains brownout/blackout with F3 during the attempt time determined by P1214, P1211 disabled									
	10	Restart after mains brownout/blackout with F3 during the attempt time determined by P1214 or manual fault acknowledgment, P1211 disabled									
	11         Trip reset at power on after mains brownout/blackout with F3 and if no ON command is active; P1211 disabled										
	Automatic restart requires constant ON command via a digital input wire link.										
	Setting P1210 =2 10 can cause the motor to restart automatically without toggling the ON command! A "mains brownout" is a very short mains break, where the DC link has not fully collapsed before the										
	<ul> <li>A "mains blackout" is a long mains break, where the DC link has fully collapsed before the power is reapplied.</li> <li>"Delay Time" is the time between attempts of quitting fault. The "Delay Time" of first attempt is 1 second, then it will be doubled every next attempt.</li> <li>The "Number of Restart Attempts" can be set in P1211. This is the number of restarts the converter will try to quit fault.</li> <li>When faults are quit and after 4 seconds of no fault condition, "Number of Restart Attempts" will be reset to P1211 and "Delay Time" will be reset to 1 second.</li> </ul>										
	P1210 = 0:										
	Automatic restart is di	sabled.									
	P1210 = 1:										
	P1210 = 1: The converter will acknowledge (reset) faults i.e. it will reset a fault when the power is re-applied. This means the converter must be fully powered down, a brownout is not sufficed. The converter will not run until the ON command has been toggled. P1210 = 2:										
	The converter will ack the ON command is w				blackout and r	estarts. It i	s necessa	ary that			
	P1210 = 3:										
	For these settings it is of the faults (F3, etc.) brownout. It is necess	. The converter	r will acknow	ledge the faul	t and restarts	the conve	rter after				
	P1210 = 4: For these settings it is fundamental that the converter only restarts if it has been in a RUN state at the tim of the fault (F3). The converter will acknowledge the fault and restarts the converter after a brownout. It is necessary that the ON command is wired via a digital input (digital input).										
	P1210 = 5: The converter will ack that the ON command					and restar	ts. It is ne	ecessary			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
	P1210 = 6:							•		
	The converter will ack is necessary that the C restart immediately. P1210 = 7:									
		The converter will acknowledge the faults (F3 etc.) at power on after blackout or brownout and restart is necessary that the ON command is wired via a digital input (digital input). Setting 7 causes the moto restart immediately. The difference between this mode and Mode 6 is that the fault status bit (r0052.3) is not set until the number of restarts defined by P1211 have been exhausted.								
	can be driven by the lo	Flying start must be used in cases where the motor may still be turning (e.g. after a short mains brea can be driven by the load (P1200).								
	P1210 = 8:									
	The converter will ack necessary that the ON immediately. The inter P1210 = 9:	command is v	vired via a di	gital input (DI).	Setting 8 caus					
	The converter will ack necessary that the ON 0.5 s. P1214 sets the t time set in P1214, the	command is votal restart att	vired via a di empt time. If	gital input (DI). an F3 occurs a	The interval be and cannot be a	etween re acknowle	estarts is dged wit	fixed at hin the		
	P1210 = 10:				-	-				
	• The converter will is necessary that th fixed at 1.0 s. P12' F3 occurs and can must be acknowled	ne ON comman 14 sets the tota not be acknow	nd is wired vi al restart atte ledged withi	a a digital inpu mpt time, but n the time set i	t (DI). The inte it must be equa	rval betw al to or le	een resta ss than 8	rts is s. If an		
	• If a fault (the conv	erter cannot re	ecover from F	6, F51, F52, F8	85, F100, and F	101) occ	urs, the f	ault mus		
	be acknowledged					e convert	ter restart	s. It is		
	necessary that the			<b>o</b> .						
	Flying start must be us can be driven by the lo	sed in cases w bad (P1200).	here the mot	or may still be	turning (e.g. af	ter a sho	rt mains l	oreak) or		
	P1210 = 11: The converter will ack cleared only if there a	nowledge the	fault (F3) at j ive faults and	oower on after I there is no ac	blackout or bro	ownout. <sup>-</sup> and after	The fault	F3 can b		
P1211	Number of restart attempts	0 - 10	3	U, T	-	-	U16	3		
	Specifies number of ti	mes converter	will attempt	to restart if au	tomatic restart	P1210 is	activated	1.		
P1214	Restart time interval [s]	0 - 1000	30	-	-	-	U16	3		
	This parameter has eit	her of the follo	owing function	ons:						
	Specifying the rest	art interval wł	nen P1210 = 8	3						
	Specifying the tota	l restart attem	ipt time whei	n P1210 = 9 or	P1210 = 10					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1215	Holding brake enable	0 - 3	0	С, Т	-	-	U16	2			
	Enables/disables holdi r0052 bit 12. This sign			or holding bra	ke (MHB) is co	ntrolled v	ia status	word 1			
	• status word of the			-00E2 hit 12)							
	<ul> <li>digital outputs (e.g. DO1: ==&gt; P0731 = 52.C (r0052 bit 12))</li> <li>Motor holding brake disabled</li> </ul>										
	0         Motor holding brake disabled           1         Motor holding brake enabled at the frequency set in P1080										
	1Motor holding brake enabled at the frequency set in P10803Motor holding brake enabled at the frequency set in P1219										
Note:	To make P1215=3 vali P1080.		-		,		e value s	et in			
Caution:	If the converter contro potentially hazardous secured.	loads (e.g. sus	pended load	s for crane app	lications) unle	ss the loa	d has bee	en			
	It is not permissible to limited number of eme				brake, as it is g	enerally o	only desig	ned for a			
P1216	Holding brake release delay[s]	0.0 - 20.0	1.0	С, Т	-	-	Float	2			
	Defines period during ramping up.	which the con	verter runs a	t the valid min	imum frequen	су (Р1080	) or P121	9) before			
P1217	Holding time after ramp down [s]	0.0 - 20.0	1.0	С, Т	-	-	Float	2			
	Defines time for which ramping down.	the converter	r runs at the	valid minimum	frequency (P1	080 or P	1219) aft	er			
Note:	If P1217 > P1227, P12	27 will take pr	ecedence.								
P1218[02]	BI: Motor holding brake override	0 - 429496729 5	0	U, T	-	CDS	U32	3			
	Enables the motor hole separate control.	ding brake out	tput to be ov	erridden, allow	ving the brake	to be ope	ned unde	er			
P1219[02]	Minimum frequency for MHB [Hz]	0.00 - 550.00	0.00	С, Т	-	DDS	Float	1			
	Sets the minimum mo	tor frequency	at which the	motor holding	brake (MHB) (	operates.					
Note:	This parameter is valid inadvertently set P121										
	The value set here is va example, ramping, cur							itions (for			
P1227[02]	Zero speed detection monitoring time [s]	0.0 - 300.0	4.0	U, T	-	DDS	Float	2			
	Sets the monitoring tir	me for the star	ndstill identif	ication.							
	When braking with OF speed has fallen below time and then the puls	/ P2167. After	this, the bral								
Note:	time and then the pulses are cancelled. P1227 = 300.0: function is deactivated										
		P1227 = 300.0: function is deactivated P1227 = 0.0: pulses are locked immediately									
			,								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1230[02]	BI: Enable DC braking	0 - 429496729 5	0	U, T	-	CDS	U32	3			
	Enables DC braking via a signal applied from an external source. Function remains active while external input signal is active. DC braking causes the motor to stop rapidly by applying a DC braking current (current applied also holds shaft stationary). When the DC braking signal is applied, the converter output pulses are blocked and the DC current is not										
	applied until the moto (demagnetization time in P1232 (DC braking o	r has been suf e). If this delay	ficiently dem is too short,	agnetized. This overcurrent tri	s delay time is s ps can occur. T	et in P03 he level o	47 of DC bral	king is set			
Caution:	With the DC braking, the could overheat if it ren					he motor	. The cor	iverter			
P1232[02]	DC braking current [%]	0 - 250	100	U, T	-	DDS	U16	2			
	Defines level of DC cur observing the followin			current (PO3C	95). The DC bra	king can l	be issued				
	<ul> <li>OFF1/OFF3 ==&gt; see</li> </ul>	• OFF1/OFF3 ==> see P1233									
	• BICO ==> see P123	0									
P1233[02]	Duration of DC braking [s]	0.00 - 250.00	0.00	U, T	-	DDS	Float	2			
	Defines duration for w When an OFF1 or OFF Hz. When the output frequ P1232 for the time du	3 command is iency reaches	received by t the value set	he converter, t	he output freq	uency sta					
Caution:	See P1230										
Notice:	The DC braking function causes the motor to stop rapidly by applying a DC braking current. When the DC braking signal is applied, the converter output pulses are blocked and the DC cu applied until the motor has been sufficiently demagnetized (demagnetization time is calculat automatically from motor data).							nt not			
Note:	P1233 = 0 means that		not activated								
P1234[02]	DC braking start frequency [Hz]	0.00 - 550.00	550.00	U, T	-	DDS	Float	2			
	Sets start frequency fo When an OFF1 or OFF Hz. When the output frequinjects a DC braking cu	3 command is iency reaches	the value set	in start freque	ncy of DC braki	2					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1236[02]	Compound braking current [%]	0 - 250	0	U, T	-	DDS	U16	2			
	braking. The value is er (V_DC,Comp):										
	If P1254 = 0> V_DC,Comp = 1.13 * sqrt(2) * V_mains = 1.13 * sqrt(2) * P0210										
	otherwise V_DC,Comp = 0.98 * r1242 The Compound Brake is an overlay of the DC brake function with regenerative braking (effective braking at the										
	The Compound Brake is ramp) after OFF1 or OF returned to the motor. braking without additic	F3. This enable Through optimi	s braking wit zation of the	h controlled mo ramp-down tin	tor frequency a	nd a minir	num of er	nergy			
Dependency:	Compound braking dep and any regenerative co	ends on the DC ondition. It is di	link voltage sabled, when	only (see thresh ::	nold above). Th	is will happ	pen on OF	F1, OFF3			
	• DC braking is active										
	Flying start is active	1									
Notice:	Increasing the value wi overcurrent trip may re	ll generally imp	rove braking	performance; h	owever, if you	set the val	ue too hig	ıh, an			
			as well comp	ound braking w	ill take priority.						
	If used with dynamic braking enabled as well compound braking will take priority. If used with the Vdc_max controller enabled the converter behavior when braking may be worsened particularly with high values of compound braking.										
Note:	P1236 = 0 means that of	compound brak	ing is not act	ivated.							
P1237	Dynamic braking	0 - 5	0	U, T	-	-	U16	2			
	Dynamic braking absorbs the braking energy in a braking resistor. This parameter defines the rated duty cycle of the braking resistor. Dynamic braking is active when the function is enabled and DC-link voltage exceeds the dynamic braking switch-on level.										
	Dynamic braking switch	n-on level (V_DO	C,Chopper) :								
	If P1254 = 0> V_DC,C	hopper = 1.13	* sqrt(2) * V_	_mains = 1.13 *	sqrt(2) * P021	C					
	otherwise V_DC,Chopp	er = 0.98 * r124	12								
	0	Disabled									
	1	5 % duty cycle	9								
	2	10 % duty cyc									
	2     10 % duty cycle       3     20 % duty cycle										
	3										
	3 4		le								
	-	20 % duty cyc	le le								
Note:	4 5 This parameter is only a the braking resistor can	20 % duty cyc 50 % duty cyc 100 % duty cy pplicable for cc	le le /cle onverters of f	rame size D and ic braking mod	E. For frame si ule (see Append	zes AA to ( dix "Dynam	C, the dut	y cycle of g module			
Note: Dependency:	4 5 This parameter is only a	20 % duty cyc 50 % duty cyc 100 % duty cy pplicable for cc be selected wi	le rcle proverters of f th the dynam raking enabl	ic braking mod	ule (see Append	dix "Dynam	nic braking	g module			
	4 5 This parameter is only a the braking resistor car (Page 377)"). If dynamic braking is u compound braking wi	20 % duty cyc 50 % duty cyc 100 % duty cy pplicable for cc be selected wi used with DC b Il take priority.	le le vcle onverters of f th the dynam raking enabl	ic braking mod ed as well as c	ule (see Append	dix "Dynam	nic braking	g module			
	4 5 This parameter is only a the braking resistor can (Page 377)"). If dynamic braking is u	20 % duty cyc 50 % duty cyc 100 % duty cy pplicable for cc be selected wi ised with DC b Il take priority.	le vcle proverters of f th the dynam raking enabl	ic braking mod	ule (see Append	dix "Dynam	nic braking	g module			
	4 5 This parameter is only a the braking resistor can (Page 377)"). If dynamic braking is u compound braking wi	20 % duty cyc 50 % duty cyc 100 % duty cy pplicable for cc be selected wi used with DC b Il take priority.	le vcle proverters of f th the dynam raking enabl	ic braking mod ed as well as c Dynamic braking	ule (see Appendon ompound brak	dix "Dynam	nic braking	g module			

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.		
			default	changed		set	type	Level		
Notice:	Initially the brake will approached. The duty to operate at this level $V_{DC, act}$	cycle specified	d by this para	meter will ther	the DC link lev be imposed. T t <sub>Chopper, ON</sub>	he resist	or should	la limit is		
	T-   L	· ΔV ' V								
	V <sub>DC</sub> , Chopper		237		ΔV = 17.0 \	/ for 380 ·	- 480 V			
		uty cycle onitoring	is equivalent		n A535 running at 95	% duty cy	vcle. The	dutv cvcle		
	will be limited when it	was running	12 seconds a	t 95 % duty cyc	le.					
P1240[02]	Configuration of Vdc controller	0 - 3	1	С, Т	-	DDS	U16	3		
	Enables/disables Vdc controller. The Vdc controller dynamically controls the DC link voltage to prevent overvoltage trips on high inertia systems.									
	0 Vdc controller disabled									
	1	Vdc_max cor	ntroller enabl	ed						
	2	Kinetic buffe	ring (Vdc_mi	n controller) ei	nabled					
	3	Vdc_max cor	ntroller and k	inetic buffering	g (KIB) enabled					
Caution:	If P1245 increased too	much, it may	interfere wit	h the converte	r normal opera	tion.				
Note:	<ul> <li>Vdc_max controller: Vdc_max controller automatically increases ramp-down times to keep the DC-link voltage (r0026) within limits (r1242).</li> <li>Vdc_min controller:</li> </ul>									
	Vdc_min is activated if DC-link voltage falls below the switch on level P1245. The kinetic energy of the motor is then used to buffer the DC-link voltage, thus causing deceleration of the converter. If the converter trips with F3 immediately, try increasing the dynamic factor P1247 first. If still tripping with F3 try then increasing the switch on level P1245.									
r1242	CO: Switch-on level of Vdc_max [V]	-	-	-	-	-	Float	3		
	Displays switch-on leve	el of Vdc_max	controller.							
	Following equation is	-								
	r1242 = 1.15 * sqrt(2)	* V_mains =	1.15 * sqrt(2	) * P0210						
	otherwise r1242 is inte	, j	ted.					_		
P1243[02]	Dynamic factor of Vdc_max [%]	10 - 200	100	U, T	-	DDS	U16	3		
	Defines dynamic factor for DC link controller.									
Dependency:	P1243 = 100 % means P1250, P1251 and P1252 (gain, integration time and differential time) are used as set. Otherwise, these are multiplied by P1243 (dynamic factor of Vdc_max).									
Note:	Vdc controller adjustm	ent is calculat	ed automatio	ally from moto	or and converte	r data.				

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.					
			default	changed		set	type	Level					
P1245[02]	Switch on level kinetic buffering [%]	65 - 95	76	U, T	-	DDS	U16	3					
	Enter switch-on level f	or kinetic buff	ering (KIB) in	n [%] relative t	o supply voltag	e (P0210	).						
	r1246[V] = (P1245[%]	(100) * sqrt(2)	) * P0210										
Warning:	Increasing the value to	o much, may	interfere wit	h the converte	er normal opera	ition.							
Note:	P1254 has no effect on the switch-on-level for kinetic buffering.												
	P1245 default for the	single phase v	ariants is 74 <sup>0</sup>	%.	1		-						
r1246[02]	CO: Switch-on level kinetic buffering [V]	-	-	-	-	DDS	Float	3					
	Displays switch-on level of kinetic buffering (KIB, Vdc_min controller). If the dc-link voltag the value in r1246, kinetic buffering will be activated. That means the motor frequency w order to keep Vdc within the valid range. If there is not enough regenerative energy, the o with undervoltage.												
P1247[02]	Dynamic factor of kinetic buffering [%]	10 - 200	100	U, T	-	DDS	U16	3					
	and P1252 (gain, integ	Enters dynamic factor for kinetic buffering (KIB, Vdc_min controller). P1247 = 100 % means P1250, P1251 and P1252 (gain, integration time and differential time) are used as set. Otherwise, these are multiplied by P1247 (dynamic factor of Vdc_min).											
Note:	Vdc controller adjustm	ent is calculat	ed automati	cally from mot	or and convert	er data.							
P1250[02]	Gain of Vdc controller	0.00 - 10.00	1.00	U, T	-	DDS	Float	3					
	Enters gain for Vdc cor	ntroller.						_					
P1251[02]	Integration time Vdc controller [ms]	0.1 - 1000.0	40.0	U, T	-	DDS	Float	3					
	Enters integral time co	nstant for Vdo	controller.										
P1252[02]	Differential time Vdc controller [ms]	0.0 - 1000.0	1.0	υ, τ	-	DDS	Float	3					
	Enters differential time	e constant for	Vdc controll	er.									
P1253[02]	Vdc controller output limitation [Hz]	0.00 - 550.00	10.00	U, T	-	DDS	Float	3					
	Limits maximum effect	t of Vdc_max o	controller.										
Dependency:	This parameter is influ	enced by auto	matic calcul	ations defined	by P0340.								
Note:	The Factory setting depends on converter power.												
P1254	Auto detect Vdc switch-on levels	0 - 1	1	С, Т	-	-	U16	3					
	Enables/disables auto- recommended to set P only recommended wh driven. Note that the a	1254 = 1 (aut nen there is a	o-detection high degree	of Vdc switch-o of fluctuation	on levels enable of the DC-link v	ed). Settir vhen the	ng P1254 motor is	being					
	0	Disabled											
	1	Enabled											
Dependency:	See P0210												

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1256[02]	Reaction of kinetic buffering	0 - 2	0	С, Т	-	DDS	U16	3			
	Enters reaction for kir the frequency limit de regeneration is produ	fined in P125	7 is used to e	either hold the	speed or disab	ng on the ble pulses.	setting se If not end	elected, ough			
	0	Maintain DC	-link until tri	p							
	1	Maintain DC	link until tri	p/stop							
	2	Control stop	1								
Note:	P1256 = 0: Maintain DC-link volta is kept above the freq P1256 = 1: Maintain DC-link volta disabled when freque P1256 = 2:	uency limit pro ige until main ncy falls belov	ovided in P12 s is returned v the limit in	257. or converter is P1257.	tripped with u	undervolta	-				
	This option ramps down the frequency to standstill even when mains return. If mains do not return, frequency brought down under the control of Vdc_min controller until P1257 limit Then pulses are disabled or undervoltage has occurred. If mains return, then an OFF1 is active until P1257 limit. Then pulses are disabled.										
P1257[02]	Frequency limit for kinetic buffering [Hz]	0.00 - 550.00	2.50	U, T	-	DDS	Float	3			
	Frequency which kinetic buffering (KIB) either hold speed or disable pulses depending on P1256.										
P1300[02]	Control mode	0 - 19	0	С, Т	-	DDS	U16	2			
	Parameter to select the control method. Controls relationship between speed of motor and voltage supplied by converter.										
	0 V/f with linear characteristic										
	1	V/f with FCC									
	2	V/f with quadratic characteristic									
	3			haracteristic							
	4	V/f with line									
	5		e application								
	6		for textile a	pplications							
	7 19	V/f with qua		dent voltage s							
	V Vn P1300 = 0 P1300 = 0	300 = 2	f	U	·						

Parameter	Function		Range	Factory default	Can be changed	Scaling		Data et	Data type	Acc. Level
Note:	P1300 = 1	: V/f with FC	C (flux current	t control)						
	Mainta	ains motor flu	ix current for	improved eff	iciency					
		is chosen, lin			-					
					uencies					
		2: V/f with a q								
		ole for centrifu		•						
	P1300 = 3	3: V/f with a p	rogrammable	characteristi	с					
	User d	lefined charad	teristic (see F	P1320)						
	P1300 = 4	ነ: V/f with line	ear characteri	stic and Econ	omy Mode					
	Linear	characteristi	with Econor	ny Mode	-					
		ies the output		-	concumption					
		5,6: V/f for tex	-	•	consumption					
				5115						
	• Slip co	ompensation	disabled.							
	• Imax o	controller mo	difies the out	put voltage o	nly.					
	Imax of	controller doe	s not influend	ce the output	frequency.					
					conomy Mode					
		atic character			j ···					
				-						
		ies the output	-	•	•					
		9: V/f control		-						
		ving table pre dependencies		rview of cont	rol parameters	(V/f) that car	ı be	modi	fied in rela	itionship
	Par No.	Parameter name	9			Level	V/f			
							· ·	= 00		
							، ام ا	1 2 1:	3 5 6 19	
	<b>B</b> ( 0.0 0 0 0 1									
		Control mode	ot			2	x y	x x x	кххх	
	P1310[3]	Continuous boo				2	x x x x	x x x x x x	<	
	P1310[3] P1311[3]	Continuous boo Acceleration bo					x x x x	x x x x x x x x x	K X X X K X X X K X X X	
	P1310[3] P1311[3] P1312[3]	Continuous boo	ost			2	x x x x x x	x x x x x x x x x x x x x x	K X X X K X X X K X X X	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable	ost ency //f freq. coord. 1			2 2 2 3 3	x x x x x x	x x x x x x x x x x x x x x x	<pre></pre>	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3] P1321[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable	ost ency //f freq. coord. 1 //f volt. coord. 1			2 2 2 3 3 3 3	x x x x x x	x x x x x x x x x x x x x x x	x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3] P1321[3] P1322[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable	ost ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2			2 2 3 3 3 3 3 3	x x x x x x	x x x x x x x x x x x x x x x x x x x 2 2	x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3] P1321[3] P1322[3] P1322[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable V	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2			2 2 2 3 3 3 3 3 3 3 3	x x x x x x	x x x x x x x x x x x x x x x x x x x 2 2	x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x       x     x     x	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3] P1321[3] P1322[3] P1323[3] P1323[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f freq. coord. 3			2 2 2 3 3 3 3 3 3 3 3 3 3 3	x x x x x x	x x x x x x x x x x x x x x x x x x x 2 2	x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x	
	P1310[3] P1311[3] P1312[3] P1316[3] P1320[3] P1322[3] P1322[3] P1323[3] P1324[3] P1325[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable Programmable	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f freq. coord. 3 //f volt. coord. 3			2 2 2 3 3 3 3 3 3 3 3	x x x x x x	x x x x x x x x x x x x x x x x x x x 2 2	x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x	
	P1310[3]           P1311[3]           P1312[3]           P1316[3]           P1320[3]           P1321[3]           P1322[3]           P1323[3]           P1324[3]           P1325[3]           P1330[3]           P1333[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable Programmable Cl: Voltage setp Start frequency	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f freq. coord. 3 //f volt. coord. 3 oint for FCC			2 2 2 3 3 3 3 3 3 3 3 3 3 3 3	x     x       x     x       x     x       x     x       x     x	x x x x x x x x x x x x x x x x x x x 2 2	x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x       x     x     x     x	
	P1310[3]           P1311[3]           P1312[3]           P1316[3]           P1320[3]           P1321[3]           P1322[3]           P1323[3]           P1324[3]           P1325[3]           P1330[3]           P1333[3]           P1335[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable Cl: Voltage setp Start frequency Slip compensati	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f freq. coord. 3 //f volt. coord. 3 oint for FCC			2 2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	x     x       x     x       x     x       x     x       x     x	x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3	K     X     X     X       X     X     X     X	
	P1310[3]           P1311[3]           P1312[3]           P1316[3]           P1320[3]           P1322[3]           P1323[3]           P1325[3]           P1325[3]           P1330[3]           P1333[3]           P1335[3]           P1336[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable \ Programmable \ Programmable \ Programmable \ Ci: Voltage setp Start frequency Slip compensati CO: Slip limit	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f freq. coord. 3 //f volt. coord. 3 oint for FCC on			2 2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	x     x       x     x       x     x       x     x       x     x       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -	x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -       - <td>K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X</td> <td></td>	K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X	
	P1310[3]           P1311[3]           P1312[3]           P1316[3]           P1320[3]           P1322[3]           P1323[3]           P1325[3]           P1325[3]           P1325[3]           P1330[3]           P1333[3]           P1335[3]           P1336[3]           P1338[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable \ Programmable \ Programmable \ Programmable \ CI: Voltage setp Start frequency Slip compensati CO: Slip limit Resonance dam	ency //f freq. coord. 1 //f volt. coord. 1 //f volt. coord. 2 //f volt. coord. 2 //f volt. coord. 3 //f volt. coord. 3 //f volt. coord. 3 oint for FCC on pping gain V/f			2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 2 2 2 2 3	x     x       x     x       x     x       x     x       x     x       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -       -     -	x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       x     x     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     3       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -     -       -     -       - <td>K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X       X     X<td></td></td>	K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       K     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X     X       X     X     X       X     X <td></td>	
	P1310[3]           P1311[3]           P1312[3]           P1312[3]           P1320[3]           P1322[3]           P1322[3]           P1324[3]           P1320[3]           P1324[3]           P1325[3]           P1330[3]           P1333[3]           P1335[3]           P1338[3]           P1338[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable Programmable CI: Voltage setp Start frequency Slip compensati CO: Slip limit Resonance dan Imax freq. contr	ency //f freq. coord. 1 //f volt. coord. 1 //f volt. coord. 2 //f volt. coord. 2 //f volt. coord. 3 oint for FCC on pping gain V/f oller prop. gain			2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 2 2 2 2	x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3           x         3	X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       Z     -     -       Z     -     -       Z     -     -       Z     -     -       X     X     X       X     X     X       X     X     X	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	
	P1310[3]           P1311[3]           P1312[3]           P1312[3]           P1320[3]           P1322[3]           P1322[3]           P1324[3]           P1325[3]           P1325[3]           P1333[3]           P1335[3]           P1336[3]           P1338[3]           P1340[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable * Programmable * Programmable * Programmable * Programmable * CI: Voltage setp Start frequency Stip compensati CO: Slip limit Resonance dan Imax freq. contr Imax controller	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f volt. coord. 3 oint for FCC on pping gain V/f oller prop. gain ntegral time			2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 2 2 2 2	x         3           x         3	X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       Z     -     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	
	P1310[3]           P1311[3]           P1312[3]           P1312[3]           P1320[3]           P1322[3]           P1322[3]           P1324[3]           P1330[3]           P1330[3]           P1333[3]           P1336[3]           P1338[3]           P1340[3]           P1340[3]           P1340[3]           P1345[3]	Continuous boo Acceleration bo Starting boost Boost end frequ Programmable Programmable Programmable Programmable Programmable CI: Voltage setp Start frequency Slip compensati CO: Slip limit Resonance dan Imax freq. contr	ency //f freq. coord. 1 //f volt. coord. 1 //f freq. coord. 2 //f volt. coord. 2 //f volt. coord. 3 oint for FCC on pping gain V/f oller prop. gain ntegral time prop. gain			2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 2 2 2 2	x         3           x         3	X     X       X     X	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P1310[02]	Continuous boost [%]	0.0 - 250.0	50.0	U, T	PERCENT	DDS	Float	2				
	Defines boost level in V/f curves.	[%] relative to	P0305 (rate	d motor curren	t) applicable to	both line	ear and q	uadratic				
	At low output frequen voltage may be too low	cies the outpu w for the follow	t voltage is l wing:	ow to keep the	e flux level cons	tant. Hov	vever, the	e output				
	• magnetization the	asynchronous	motor									
	<ul> <li>hold the load</li> </ul>											
	overcome losses in	the system.										
	The converter output v 0 Hz, or maintaining th	voltage can be ne magnetizat	increased vion.	ia P1310 for th	e compensatior	n of losse	s, holding	g loads at				
	The magnitude of the	boost in Volt a	it a frequenc	y of zero is def	ined as follows	:						
	V_ConBoost,100 = P03	305 * Rsadj * (	P1310/100)									
	Where:											
	Rsadj = stator resistanc	,										
	Rsadj = (r0395/100) *											
Note:	Increasing the boost le			0 1 3	at standstill).							
		Setting in P0640 (motor overload factor [%]) limits the boost:										
	sum(V_Boost)/(P0305 * Rsadj) <= P1310/100											
	The boost values are c parameters (accelerati parameters as follows:	on boost P131	n continuou: 1 and starti	s boost (P1310 ng boost P1312	) used in conjur 2). However pri	nction wi orities ar	th other l e allocate	boost d to these				
	P1310 > P1311 > P1312											
	The total boost is limit	ed by followin	g equation:									
	sum(V_Boost) <= 3 * F	R_S * I_Mot = 3	3 * P0305 *	Rsadj								
P1311[02]	Acceleration boost [%]	0.0 - 250.0	0.0	U, T	PERCENT	DDS	Float	2				
	Applies boost in [%] re drops back out once th			or current) foll	owing a positiv	e setpoir	nt change	and				
	P1311 will only produce acceleration and decel		g ramping, a	ind is therefore	e useful for addi	tional to	rque duri	ng				
	As opposed to P1312, is always effect during	which is only an acceleration	active on the on and decel	e first accelerat eration when i	ion issued after ssued.	the ON o	command	l, P1311				
	The magnitude of the	boost in volt a	t a frequenc	y of zero is def	ined as follows:	:						
	V_AccBoost,100 = P03	05 * Rsadj * (	P1311/100)									
	Where:											
	Rsadj = stator resistanc	•	•									
	Rsadj = (r0395/100) *	(P0304/(sqrt(3	3) * P0305))	* P0305 * sqr	t(3)							
Note:	See P1310											

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
P1312[02]	Starting boost [%]	0.0 - 250.0	0.0	U, T	PERCENT	DDS	Float	2	
1912[02]	Applies a constant line linear or quadratic) aft	ear offset (in [9	6] relative to	P0305 (rated r	-				
	1. ramp output reach	les setpoint for	r the first time	e respectively					
	2. setpoint is reduced	d to less than p	oresent ramp	output					
	This is useful for starti converter to limit the frequency.	ng loads with l current, which	high inertia. 9 will in turn r	Setting the states states the states of the	rting boost (P1) out frequency t	312) too o below 1	high will the setpo	cause th int	
	The magnitude of the V_StartBoost, 100 = PC				ned as follows:				
	Where:	an adjusted for	topporture						
	Rsadj = stator resistant Rsadj = (r0395/100) *	-			(2)				
Note:	See P1310	(FUSU4/(Sqrt(2	5) PUSUS))	PUSUS SQL	(5)				
r1315	CO: Total boost				_	-	Float	4	
11313	voltage [V]	-	-	-	-	-	FIUAL	4	
	Displays total value of	voltage boost						1	
P1316[02]	Boost end frequency [%]	0.0 - 100.0	20.0	U, T	PERCENT	DDS	Float	3	
	Defines point at which to P0310 (rated motor V_Boost,min = 2 * (3 -	r frequency). T	he default fre				ssed in [%	6] relativ	
Dependency:	This parameter is influ	enced by auto	matic calcula	tions defined l	oy P0340.				
Note:	The expert user may change this value to alter the shape of the curve, e.g. to increase torque at a particular frequency.								
	Default value is depen			-		1	1.		
P1320[02]	Programmable V/f freq. coord. 1 [Hz]	0.00 - 550.00	0.00	T	-	DDS	Float	3	
	Sets the frequency of characteristic. These p	arameter pairs	s can be used	to provide cor	rect torque at o	correct fre	equency.		
Dependency:	To set parameter, sele starting boost defined	in P1311 and	P1312 are ap	plied to V/f wi	th programmal			st and	
Note:	Linear interpolation w V/f with programmabl points. The 2 non-prog	e characteristi grammable po	c (P1300 = 3)			and 2 noi	n-prograr	nmable	
	Continuous boost								
	Rated motor voltage	ge P0304 at ra	ted motor fre	. ,	1		-		
P1321[02]	Programmable V/f volt. coord. 1 [V]	0.0 - 3000.0	0.0	U, T	-	DDS	Float	3	
	See P1320	1		T	T				
P1322[02]	Programmable V/f freq. coord. 2 [Hz]	0.00 - 550.00	0.00	Т	-	DDS	Float	3	
	See P1320	1	1	T	1		1	1	
P1323[02]	Programmable V/f volt. coord. 2 [V]	0.0 - 3000.0	0.0	U, T	-	DDS	Float	3	
	See P1320	Γ	T	Ι	1		Г	1	
P1324[02]	Programmable V/f freq. coord. 3 [Hz]	0.00 - 550.00	0.00	Т	-	DDS	Float	3	
	See P1320								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P1325[02]	Programmable V/f volt. coord. 3 [V]	0.0 - 3000.0	0.0	U, T	-	DDS	Float	3
	See P1320					•		•
P1330[02]	CI: Voltage setpoint	0 - 429496729 5	0	Т	-	CDS	U32	3
	BICO parameter for sele	ecting source	of voltage se	etpoint for ind	ependent V/f co	ntrol (P1	300 = 19)	
P1333[02]	Start frequency for FCC [%]	0.0 - 100.0	10.0	U, T	PERCENT	DDS	Float	3
	Defines start frequency (P0310).	at which FCC	(flux curren	t control) is er	nabled as [%] of	rated mo	otor frequ	ency
Notice:	If this value is too low,	the system m	ay become u	instable.		-		-
P1334[02]	Slip compensation activation range [%]	1.0 - 20.0	6.0	U, T	PERCENT	DDS	Float	3
	To set the frequency ac motor rated frequency The upper threshold w Range of slip compensat	P0310. ill always stay	·	1334.	ie percentage vi	alue of P	1334 rete	rs to the
	P1335	<del>%</del> +4% 100%	fout fN	P1334 P13	without	compens		
Dependency:	Slip compensation (P13	R35) active			0.2010 0.2040			
Note:	See P1335.							
Note:	The starting frequency	of the slip cou	nnensation i	s P1334 * P03	10			
P1335[02]	Slip compensation [%]	0.0 - 600.0	0.0	U, T	PERCENT	DDS	Float	2
	Parameter dynamically independent of motor	adjusts conve	erter output f	requency so t	hat motor speed	d is kept o	constant	
	In the V/f-control, the r slip frequency. For a gi behavior, typical for ind to enable and fine-tune	notor frequen ven output fre duction motor	equency, the rs, can be co	motor freque	ncy will drop as	load is in	creased.	This
Dependency:	In the V/f-control, the r slip frequency. For a gi behavior, typical for inc	notor frequen ven output fre duction motor e the slip com es fine-tuning	equency, the rs, can be con pensation. of the actua	motor freque mpensated us I motor speed	ncy will drop as ng slip compen	load is in	creased.	This
Dependency: Notice:	In the V/f-control, the r slip frequency. For a gi behavior, typical for ind to enable and fine-tune Gain adjustment enabl P1335 > 0, P1336 > 0, The applied value of th	notor frequen ven output fre duction motor e the slip com es fine-tuning P1337 = 0 if P e slip compen	equency, the s, can be con pensation. of the actua 1300 = 5, 6. sation (scale	motor freque mpensated usi	ncy will drop as ing slip compen	load is in sation. P	icreased. 1335 can	This
	In the V/f-control, the r slip frequency. For a gi behavior, typical for ind to enable and fine-tune Gain adjustment enabl P1335 > 0, P1336 > 0,	notor frequen ven output fre duction motor e the slip com es fine-tuning P1337 = 0 if P e slip compen 30 * (P1336/ bled. at cold motor ird setting for	equency, the rs, can be con pensation. of the actua 1300 = 5, 6. sation (scale 100) (partial load warm stator	motor freque mpensated usi I motor speed d by P1335) is ).	ncy will drop as ing slip compen	load is in sation. P	icreased. 1335 can	This
Notice: Note:	In the V/f-control, the r slip frequency. For a gi behavior, typical for ind to enable and fine-tune Gain adjustment enabl P1335 > 0, P1336 > 0, The applied value of th f_Slip_comp,max = r03 P1335 = 0 %: Slip compensation disa P1335 = 50 % - 70 %: Full slip compensation P1335 = 100 % (standa Full slip compensation	notor frequen ven output fre duction motor e the slip com es fine-tuning P1337 = 0 if P e slip compen 30 * (P1336/ bled. at cold motor at warm moto	equency, the rs, can be com- pensation. of the actuant 1300 = 5, 6. sation (scalent 100) (partial load warm stator or (full load).	motor freque mpensated usi I motor speed d by P1335) is ). ).	ncy will drop as ing slip compen	load is in sation. P	uation:	This be used
Notice:	In the V/f-control, the r slip frequency. For a gi behavior, typical for ind to enable and fine-tune Gain adjustment enabl P1335 > 0, P1336 > 0, The applied value of th f_Slip_comp,max = r03 P1335 = 0 %: Slip compensation disa P1335 = 50 % - 70 %: Full slip compensation P1335 = 100 % (standa	notor frequen ven output fre duction motor e the slip com es fine-tuning P1337 = 0 if P e slip compen 30 * (P1336/ bled. at cold motor at warm motor 0 - 600	equency, the rs, can be compensation. of the actuation 1300 = 5, 6. sation (scale 100) (partial load warm stator or (full load). 250	motor freque mpensated usi Il motor speed ed by P1335) is ). ). ).	ncy will drop as ing slip compen s limited by follo	DDS	uation:	This be used

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.			
			default	changed		set	type	Level			
r1337	CO: V/f slip frequency [%]	-	-	-	PERCENT	-	Float	3			
	Displays actual compe	nsated motor s	slip as [%]. f_	slip [Hz] = r13	37 [%] * PO310	/100					
Dependency:	Slip compensation (P1)	335) active.						<u> </u>			
P1338[02]	Resonance damping gain V/f	0.00 - 10.00	0.00	U, T	-	DDS	Float	3			
	Defines resonance dan increases the resonance	nping gain for ce damping cir	V/f. The di/di cuit decrease	of the active of the converte	current will be s er output freque	scaled by ency.	P1338. I	f di/dt			
Dependency:	This parameter is influe	enced by auto	matic calcula	tions defined l	by P0340.						
Note:	The resonance circuit of operation. In V/ f mode to 80 % of rated motor (forward control effect	es (see P1300) frequency (P0	, the resonar	ice damping ci	ircuit is active i	n a range	from app	orox. 6 %			
P1340[02]	Imax controller proportional gain	0.000 - 0.499	0.030	U, T	-	DDS	Float	3			
	Proportional gain of th	e I_max contro	oller.								
	The Imax controller red (r0067).	duces converte	er current if t	he output curr	ent exceeds the	e maximu	ım motor	current			
	In linear V/f, parabolic controller (see P1340 a						both a fr	equency			
	The frequency controller seeks to reduce current by limiting the converter output frequency (to a minimum of the two times nominal slip frequency).										
	If this action does not s reduced using the I_m			ercurrent cond	lition, the conv	erter out	put volta	je is			
	When the overcurrent ramp-up time set in P1		been remove	ed successfully	, frequency lim	iting is re	emoved u	sing the			
	In linear V/f for textiles reduce current (see P1			al V/f modes o	nly the I_max v	oltage co	ontroller i	s used to			
Note:	The I_max controller ca disables both the frequ				ontroller integr	al time P	1341 to z	ero. This			
	Note that when disable warnings will still be ge conditions.	ed, the I_max enerated, and	controller wi the converte	l take no actio r will trip in ex	n to reduce cur cessive overcu	rrent but rrent or o	overcurre verload	ent			
P1341[02]	Imax controller integral time [s]	0.000 - 50.000	0.300	U, T	-	DDS	Float	3			
	Integral time constant	of the I_max of	ontroller.								
	• P1341 = 0: I_max c	ontroller disat	oled								
	• P1340 = 0 and P13			er enhanced in	teoral						
	<ul> <li>P1340 &gt; 0 and P13</li> </ul>	-	-		-						
Dependency:	This parameter is influe	enced by auto	matic calcula	tions defined l	by P0340.						
Dependency											

Deveneter	Function	Denne	Factory	Combo	Cooling	Data	Data	A
Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r1343	CO: Imax controller	-	-	-	_	-	Float	3
11545	frequency output [Hz]						riout	5
	Displays effective frequency	limitation.						
Dependency:	If I_max controller not in ope	eration, paramet	ter normally sh	iows maximu	ım frequenc	y P1082.		
r1344	CO: Imax controller voltage output [V]	-	-	-	-	-	Float	3
	Displays amount by which th	e I_max control	ler is reducing	the converte	er output vo	ltage.		
P1345[02]	Imax voltage controller proportional gain	0.000 - 5.499	0.250	U, T	-	DDS	Float	3
	If the output current (r0068) controlled by reducing the o							ler.
Dependency:	This parameter is influenced	by automatic ca	alculations defi	ined by P034	0.			
Note:	See P1340 for further inform	ation. The Facto	ory setting dep	1	verter powe	er.		
P1346[02]	Imax voltage controller integral time [s]	0.000 - 50.000	0.300	υ, τ	-	DDS	Float	3
	Integral time constant of the	I_max voltage o	controller.					
	• P1341 = 0: I_max control	ler disabled						
	• P1345 = 0 and P1346 > 0	): I_max voltage	controller enh	anced integr	al			
	• P1345 > 0 and P1346 > 0	: I_max voltage	controller nor	mal PI contro				
Dependency:	This parameter is influenced	-						
Note:	See P1340 for further inform	ation. The Facto	ory setting dep	ends on con		er.	r	
r1348	Economy mode factor [%]	-	-	-	PERCENT	-	Float	2
	Displays the calculated econo	•	-				•	olts.
	Economy mode is used to fir continuous method of hill cli output volts either up or dow decreased, the algorithm cha then the algorithm adjusts th be able to find the minimum	mbing optimiza vn and monitori anges the outpu ne output volts i	tion. Hill climb ng the change t volts in the s n the other dir	bing optimiza in input pow ame direction rection. Usinc	tion works l ver. If the in n. If the inp g this algorit	by slightly put power ut power hm, the	y chang er has has inc	reased
Notice:	If this value is too low, the sy	vstem may beco	me unstable.					
P1350[02]	Voltage soft start	0 - 1	0	U, T	-	DDS	U16	3
	Sets whether voltage is built boost voltage (OFF).		iring magnetiz	ation time (C	N) or whet	her it sim	ply jum	ps to
	0	OFF						
	1	ON						
Note:	The settings for this paramet	er bring benefit	s and drawbac	:ks:				
	• P1350 = 0: OFF (jump to	boost voltage)						
	Benefit: flux is built up qu	uickly						
	Drawback: motor may m	ove						
	• P1350 = 1: ON (smooth v	oltage build-up	)					
	Benefit: motor less likely		-					
	Drawback: flux build-up t	akes longer						

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P1780[02]	Control wor adaption	d of Rs/Rr-	0 - 1	1	U, T	-	DDS	U16	3			
		mal adaptation ( ith speed senso										
	Bit	Signal name				1 signal		0 sigr	nal			
	00	Enable therma	l Rs/Rr-adapt.			Yes		No				
P1800[02]	Pulse freque	ency [kHz]	2 - 16	4	U, T	-	DDS	U16	2			
	Sets pulse fr	equency of pow	er switches in c	onverter. The	frequency ca	n be change	ed in step	os of 2 kl	Hz.			
Dependency:	The minimu	m/maximum/def	ault values of t	ne pulse frequ	uency are dete	ermined by	the used	power r	nodule			
		the minimum p nd P0310 (rated			he parameteri	zation of P	1082 (ma	aximum				
Note:	derating cha	requency is incr racteristic deper	nds on the type	and power o	f the converte	r.		0				
	losses and ra	ation is not abso adio-frequency e	missions.		·	-						
	overtempera	n circumstances iture (see P0290	, the converter and P0291 bit	may reduce t 00).	he pulse frequ	ency to pro	vide prot	1	-			
r1801[01]		equency [kHz]	-	-	-	-	-	U16	3			
		ormation about p	1 2	•	tches in conve	erter.						
		plays the actual	•									
		plays the minim ification" or "cor										
Index:	[0]		Actual pulse f	requency								
	[1]		Minimum puls	se frequency								
Notice:	Under certai	n conditions (co	Under certain conditions (converter overtemperature, see P0290), this can differ from the values selected in P1800 (pulse frequency).									
	1111 1000 (pt	inse nequency).			<del></del>							
P1802	Modulator r		1 - 3	3	U, T	-	-	U16	3			
P1802	Modulator r			3	U, I	-	-	U16	3			
P1802	Modulator r	node			U, I	-	-	U16	3			
P1802	Modulator r Selects conv	node	mode.	VM	U, I	-	-	U16	3			
P1802	Modulator r Selects conv 1	node	mode. Asymmetric S	/M nodulation		-	-	U16	3			
	Modulator r Selects conv 1 2 3 • Asymme	node	mode. Asymmetric S Space vector r SVM/ASVM co modulation (A	VM nodulation ntrolled mod SVM) produce	e es lower switcl	hing losses						
	Modulator r Selects conv 1 2 3 • Asymme modulati • Space ve	node erter modulator tric space vector	mode. Asymmetric S' Space vector r SVM/ASVM co modulation (A nay cause irregu	VM nodulation ntrolled mod SVM) produce lar rotation a	e es lower switc t very low spe	hing losses eds.	than spa	ce vecto	ır			
	Modulator rSelects conv123• Asymme modulati• Space ve high out • Space ve	node erter modulator tric space vector on (SVM), but m ctor modulation	mode. Asymmetric S Space vector r SVM/ASVM co modulation (A nay cause irregu (SVM) with ove	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulatior	e es lower switcl t very low spe n may produce	hing losses eds. e current wa	than spa	ce vecto distortio	ır			
Notice:	Modulator rSelects conv123• Asymmer modulati• Space ve high out• Space ve available	node erter modulator tric space vector fon (SVM), but m ctor modulation put voltages. ctor modulation	mode. Asymmetric S Space vector r SVM/ASVM co modulation (A nay cause irregu (SVM) with ove	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulatior	e es lower switcl t very low spe n may produce	hing losses eds. e current wa	than spa	ce vecto distortio	r n at			
Notice:	Modulator rSelects conv123• Asymme modulati• Space ve high out• Space ve availableMaximum n	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor.	mode. Asymmetric S' Space vector r SVM/ASVM co modulation (A hay cause irregu (SVM) with ove (SVM) without 20.0 - 150.0	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulatior over-modula	e es lower switc t very low spe n may produce tion will reduc	hing losses eds. e current wa	than spa iveform o n output	ce vecto distortio voltage	r n at			
Notice: P1803[02]	Modulator rSelects conv123• Asymmer modulati• Space ve high out• Space ve availableMaximum m Sets maximu	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor. nodulation [%]	mode. Asymmetric S <sup>1</sup> Space vector r SVM/ASVM co modulation (A ay cause irregu (SVM) with ove (SVM) without 20.0 - 150.0 ndex.	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula	e es lower switc t very low spe n may produce tion will reduc	hing losses eds. current wa e maximun	than span weform c n output DDS	ce vecto distortio voltage	r n at			
Notice: P1803[02] Note:	<ul> <li>Modulator r</li> <li>Selects conv</li> <li>1</li> <li>2</li> <li>3</li> <li>Asymme modulati</li> <li>Space ve high out</li> <li>Space ve available</li> <li>Maximum n</li> <li>Sets maximu</li> <li>P1803 = 100</li> </ul>	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor. nodulation [%] um modulation i	mode. Asymmetric S <sup>1</sup> Space vector r SVM/ASVM co modulation (A ay cause irregu (SVM) with ove (SVM) without 20.0 - 150.0 ndex.	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula	e es lower switc t very low spe n may produce tion will reduc U, T r without switc	hing losses eds. current wa e maximun	than span weform c n output DDS	ce vecto distortio voltage	r n at			
Notice: P1803[02] Note:	<ul> <li>Modulator r</li> <li>Selects conv</li> <li>1</li> <li>2</li> <li>3</li> <li>Asymmer modulati</li> <li>Space ve high out</li> <li>Space ve available</li> <li>Maximum n</li> <li>Sets maximu</li> <li>P1803 = 100</li> <li>Control wor</li> </ul>	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor. nodulation [%] Im modulation in 0 %: Limit for ove	mode. Asymmetric S' Space vector r SVM/ASVM co modulation (A nay cause irregu (SVM) with out (SVM) without 20.0 - 150.0 ndex. er-control (for ic 0 - 3	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula 106.0	e es lower switc t very low spe n may produce tion will reduc	hing losses eds. current wa e maximun -	than span iveform of n output DDS	ce vecto distortio voltage	r n at 3			
P1802 Notice: P1803[02] Note: P1810	<ul> <li>Modulator r</li> <li>Selects conv</li> <li>1</li> <li>2</li> <li>3</li> <li>Asymmer modulati</li> <li>Space ve high out</li> <li>Space ve available</li> <li>Maximum n</li> <li>Sets maximu</li> <li>P1803 = 100</li> <li>Control wor</li> </ul>	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor. nodulation [%] im modulation i 0 %: Limit for ove d Vdc control (dc filtering and	mode. Asymmetric S' Space vector r SVM/ASVM co modulation (A nay cause irregu (SVM) with out (SVM) without 20.0 - 150.0 ndex. er-control (for ic 0 - 3	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula 106.0	e es lower switc t very low spe n may produce tion will reduc U, T r without switc	hing losses eds. current wa ce maximun - ching delay	than span iveform of n output DDS	ce vecto distortio voltage Float	r n at 3			
Notice: P1803[02] Note:	<ul> <li>Modulator r</li> <li>Selects conv</li> <li>1</li> <li>2</li> <li>3</li> <li>Asymmer modulati</li> <li>Space ve high out</li> <li>Space ve available</li> <li>Maximum n</li> <li>Sets maximu</li> <li>P1803 = 100</li> <li>Control wor</li> <li>Configures V</li> </ul>	mode erter modulator tric space vector fon (SVM), but m ctor modulation put voltages. ctor modulation to motor. modulation [%] im modulation im 0 %: Limit for ove d Vdc control /dc filtering and Signal name	mode. Asymmetric S <sup>1</sup> Space vector r SVM/ASVM co modulation (A ay cause irregu (SVM) with ove (SVM) without 20.0 - 150.0 ndex. er-control (for ic 0 - 3 compensation.	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula 106.0	e es lower switc t very low spe n may produce tion will reduc U, T r without switc	hing losses eds. current wa e maximun -	than span iveform of n output DDS	ce vecto distortio voltage	r n at 3			
Notice: P1803[02] Note:	<ul> <li>Modulator r</li> <li>Selects conv</li> <li>1</li> <li>2</li> <li>3</li> <li>Asymme modulati</li> <li>Space ve high out</li> <li>Space ve available</li> <li>Maximum n</li> <li>Sets maximu</li> <li>P1803 = 100</li> <li>Control wor</li> <li>Configures V</li> <li>Bit</li> </ul>	node erter modulator tric space vector on (SVM), but m ctor modulation put voltages. ctor modulation to motor. nodulation [%] im modulation i 0 %: Limit for ove d Vdc control (dc filtering and	mode. Asymmetric S' Space vector r SVM/ASVM co modulation (A nay cause irregu (SVM) with out (SVM) without 20.0 - 150.0 ndex. er-control (for ic 0 - 3 compensation.	VM nodulation ntrolled mod SVM) produce lar rotation a er-modulation over-modula 106.0	e es lower switc t very low spe n may produce tion will reduc U, T r without switc	hing losses eds. current wa e maximun - ching delay - <b>1 signal</b>	than span iveform of n output DDS	ce vecto distortio voltage Float U16 0 sigr	r at 3			

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P1820[02]	Reverse outp sequence	ut phase	0 - 1	0	T	-	DDS	U16	2		
	Changes sequ	ence of phases	s without char	nging setpoint	polarity.						
	0	•	Forward								
	1		Reverse the	Motor							
Note:	See P1000		•								
P1825	On-state volt [V]	age of IGBT	0.0 - 20.0	0.9	U, T	-	-	Float	4		
	Corrects on-st	ate voltage of	the IGBTs.								
P1828	Gating unit d	ead time [µs]	0.00 - 3.98	0.01	U, T	-	-	Float	4		
	Sets compens	ation time of g	ating unit inte	erlock.							
P1829	Phase angle v frequency cro [°]	where output ossing zero	0.0 – 180.0	0.0	U, T	-	-	Float	4		
		nase angle at th ncy changes d		e the output fr	. ,	es zero. The	e angle is	only us	1		
P1900	Select motor identification		0 - 2	0	С, Т	-	-	U16	2		
	Performs mote	or data identifi	cation.								
	0		Disabled								
	2		Identification	n of all parame	eters in stands	till					
Dependency:	No measurem	ent if motor da	ata incorrect.								
	P1900 = 2: Ca	P1900 = 2: Calculated value for stator resistance (see P0350) is overwritten.									
Notice:	the following:				0	0					
	The value is a in the read-on motor identifi	ctually adopted ly parameters cation.	d as P0350 par below. Ensure	ameter setting that the moto	g and applied t or holding bral	to the contr ke is not act	ol as wel ive when	l as bein 1 perforr	g showi ning the		
Note:	Before selection	ng motor data	identification,	"Quick comm	issioning" has	to be perfoi	rmed in a	dvance.			
	Before selecting motor data identification, "Quick commissioning" has to be performed in advance. Since the cable length of the applications differs in a wide range, the preset resistor P0352 is only a rough estimation. Better results of the motor identification can be achieved by specifying the cable resistor befor the start of the motor identification by measuring/calculating.										
	measurement	(P1900 > 0), <i>A</i> of motor para	meters.	-							
		ons - both via l calculations. T						t it take	s to		
P1909[02]	Control word data identific	ation	0 - 65519	23552	U, T	-	DDS	U16	4		
		of motor data	identification.								
	Bit	Signal name				1 signal		0 sigr	nal		
	00	Estimation of >	<s< td=""><td></td><td></td><td>Yes</td><td></td><td>No</td><td></td></s<>			Yes		No			
	01	Motor ID at 2 k	Hz			Yes		No			
	02	Estimation of 1	r			Yes		No			
	03	Estimation of L	sigma			Yes		No			
	05	Det. Tr meas. v	vith 2 freq.			Yes		No			
	06	Measurement	of on voltage			Yes		No			
	07	Deadtime detection from Rs measurement Yes No									
	08	MotID with hw deadtime comp activ Yes No									
	09		etection with	2 (		Yes		No			

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
	10	Detect Ls with	LsBlock method			Yes		No		
	11	MotID adaption	n of magnetizing	g current		Yes		No		
	12	MotID adaption	n of main reacta	nce		Yes		No		
	13	MotID switch o	off saturation cu	rve optim.		Yes		No		
	14	MotID saturation	on curve optim.	all framesizes		Yes		No		
	15	MotID saturation	on curve optim.	big framesizes	5	Yes		No		
P1910	Select mot identificat		0 - 23	0	Т	-	-	U16	4	
	Performs a	motor data ident	ification with ex	tended figures	5.					
	Performs st	ator resistance m	easuring.							
	0		Disabled							
	1		Identification of	of all paramete	ers with para	meter chan	ge			
	2		Identification of	of all paramete	ers without p	arameter cl	nange			
	3		Identification of	of saturation c	urve with pa	rameter cha	ange			
	4		Identification of	of saturation c	urve without	parameter	change			
	5		Identification of	of XsigDyn wit	hout parame	ter change				
	6		Identification of	of Tdead witho	out paramete	r change				
	7		Identification of	of Rs without p	barameter ch	ange				
	8		Identification of	of Xs without p	parameter ch	ange				
	9		Identification of	of Tr without p	arameter ch	ange				
	10		Identification of	of Xsigma with	nout paramet	er change				
	20		Set voltage ve	ctor						
	21		Set voltage ve	ctor without fi	ltering in r00	69				
	22		Set voltage vector rectangle signal							
	23		Set voltage ve	ctor triangle si	gnal					
Notice:	Ensure that the motor holding brake is not active when performing the motor identification. P1910 can't be changed while the motor identification with P1900 is active (P1900 = 2 or 3). When the identification is finished P1910 is set to 0. When choosing the setting for measurement, observe the following:									
		arameter change"		80250						
		that the value is a g shown in the re	• •		ameter settin	g and appli	ed to the	control	as wel	
			5 1	lers below.						
	without	it parameter chan	ge							
		that the value is c identified stator r	5 1 5	e. shown for c	hecking purp	oses in the	read-onl	y paran	neter	
	The value is	s not applied to th	ne control.							
Dependency:	ncy: No measurement if motor data incorrect.									
	P1910 = 1:	Calculated value	for stator resista	ance (see PO35	50) is overwri	tten.				
Note:	See P1900								•	
1912[0]	Identified resistance		-	-	-	-	-	Float	4	
	Displays m	easured stator res	istance value (li	ne-to-line). Th	is value also	includes th	e cable re	esistanc	es.	
ndex:	[0]		U_phase							
Notice:	If the value message 4 2 in this ca	identified (Rs = s 1 (motor data ide se).	tator resistance) ntification failur	) does not lie v e) is issued. P(	vithin the rar )949 provide	nge 0.1 % < s further in	Rs [p. u. formation	< 100 n (fault )	% fault value =	
Note:		s measured using	P1900 = 2.							

dentified dynamic         eakage inductance         Displays identified total dynamic         (0)         dentified on-state         voltage [V]         Displays identified on-state voltage         (0)         f the identified on-state voltage if the identified on state voltage if the identified dead time if the identified gating unit         deatified gating unit         dead time [µs]         Displays identified dead time         P2000 represents the refere         bercentage or a hexadecimat         Where:         hexadecimal 4000 H ==>         percentage 100 % ==> P         f a BICO connection is made         the parameters (standardize         automatic conversion to the	U_phase - voltage of IGBT. U_phase tage does not lie ed. P0949 provid - e of gating unit 1.00 - 550.00 nce frequency for al value. > P2000 (e.g.: U2 2000 (e.g.: anal e between two p ed (Hex) or physi	- e within the ra des further in interlock. 50.00 or frequency SS-PZD) og input)	formation (fai	ult value = 2	20 in this - DDS ed/transfe	case). Float Float rred as	4 data 2 2
[0]         dentified on-state         voltage [V]         Displays identified on-state vol-         [0]         f the identified on-state vol-         dentification failure) is issued         dentified gating unit         dead time [µs]         Displays identified dead time         Reference frequency [Hz]         P2000 represents the refere         bercentage or a hexadecima         Where:         hexadecimal 4000 H ==>         percentage 100 % ==> P         f a BICO connection is made         the parameters (standardize         automatic conversion to the	U_phase - voltage of IGBT. U_phase tage does not lie ed. P0949 provid - e of gating unit 1.00 - 550.00 nce frequency for al value. > P2000 (e.g.: U2 2000 (e.g.: anal e between two p ed (Hex) or physi	- e within the ra des further in interlock. 50.00 or frequency SS-PZD) og input)	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	(motor case). Float Float	data 2 2
dentified on-state voltage [V] Displays identified on-state vol- col f the identified on-state vol- dentification failure) is issue dentified gating unit dead time [µs] Displays identified dead time Reference frequency [Hz] P2000 represents the refere bercentage or a hexadecima Where: hexadecimal 4000 H ==> percentage 100 % ==> P f a BICO connection is made the parameters (standardize automatic conversion to the	- voltage of IGBT. U_phase tage does not lie ed. P0949 provid - e of gating unit i 1.00 - 550.00 nce frequency for al value. > P2000 (e.g.: Ut 2000 (e.g.: anal e between two p ed (Hex) or physi	des further in interlock. 50.00 or frequency SS-PZD) og input) parameters or	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	(motor case). Float Float	data 2 2
voltage [V]         Displays identified on-state voltage         0]         f the identified on-state voltage         dentification failure) is issued         dentified gating unit         dead time [µs]         Displays identified dead time         Reference frequency [Hz]         P2000 represents the refere         bercentage or a hexadecima         Where:         hexadecimal 4000 H ==>         percentage 100 % ==> P         f a BICO connection is made         the parameters (standardize         automatic conversion to the	U_phase tage does not lie ed. P0949 provid - e of gating unit i 1.00 - 550.00 nce frequency fo al value. > P2000 (e.g.: Ut 2000 (e.g.: anal e between two p ed (Hex) or physi	des further in interlock. 50.00 or frequency SS-PZD) og input) parameters or	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	(motor case). Float Float	data 2 2
[0]         f the identified on-state volted dentification failure) is issued         dentified gating unit         dead time [µs]         Displays identified dead time         Reference frequency [Hz]         P2000 represents the refere         percentage or a hexadecima         Where:         hexadecimal 4000 H ==>         percentage 100 % ==> P         f a BICO connection is made         automatic conversion to the	U_phase tage does not lie ed. P0949 provid - e of gating unit i 1.00 - 550.00 nce frequency fo al value. > P2000 (e.g.: Ut 2000 (e.g.: anal e between two p ed (Hex) or physi	des further in interlock. 50.00 or frequency SS-PZD) og input) parameters or	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	case). Float Float rred as	2
f the identified on-state vol dentification failure) is issue dentified gating unit dead time [µs] Displays identified dead time Reference frequency [Hz] P2000 represents the refere bercentage or a hexadecima Where: hexadecimal 4000 H ==> percentage 100 % ==> P f a BICO connection is made the parameters (standardize automatic conversion to the	e of gating unit i e of gating unit i 1.00 - 550.00 nce frequency fo al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	des further in interlock. 50.00 or frequency SS-PZD) og input) parameters or	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	case). Float Float rred as	2
dentification failure) is issue dentified gating unit dead time [µs] Displays identified dead time Reference frequency [Hz] P2000 represents the refere bercentage or a hexadecima Where: • hexadecimal 4000 H ==> • percentage 100 % ==> P f a BICO connection is made the parameters (standardize automatic conversion to the	ed. P0949 provid - e of gating unit i 1.00 - 550.00 nce frequency for al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	des further in interlock. 50.00 or frequency SS-PZD) og input) parameters or	formation (fai - T values which	ult value = 2	20 in this - DDS ed/transfe	case). Float Float rred as	2
dead time [µs]         Displays identified dead time         Reference frequency [Hz]         P2000 represents the refere         Decentage or a hexadecima         Where:         hexadecimal 4000 H ==>         percentage 100 % ==> P         f a BICO connection is made         the parameters (standardize         automatic conversion to the	1.00 - 550.00 nce frequency fo al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	50.00 or frequency SS-PZD) og input) parameters or	values which		ed/transfe	Float rred as a	2
Reference frequency [Hz] 22000 represents the refere bercentage or a hexadecima Where: hexadecimal 4000 H ==> percentage 100 % ==> P f a BICO connection is made the parameters (standardize automatic conversion to the	1.00 - 550.00 nce frequency fo al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	50.00 or frequency SS-PZD) og input) parameters or	values which		ed/transfe	rred as a	
<ul> <li>P2000 represents the refere bercentage or a hexadecima</li> <li>Mhere:</li> <li>hexadecimal 4000 H ==&gt;</li> <li>percentage 100 % ==&gt; P</li> <li>f a BICO connection is made the parameters (standardize automatic conversion to the parameters)</li> </ul>	nce frequency fo al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	or frequency SS-PZD) og input) parameters or	values which		ed/transfe	rred as a	
<ul> <li>bercentage or a hexadecima</li> <li>Where:</li> <li>hexadecimal 4000 H ==&gt;</li> <li>percentage 100 % ==&gt; P</li> <li>f a BICO connection is made</li> <li>the parameters (standardize</li> <li>automatic conversion to the</li> </ul>	al value. > P2000 (e.g.: U 2000 (e.g.: anal e between two p ed (Hex) or physi	SS-PZD) og input) parameters or	r alternatively				a
f a BICO connection is made the parameters (standardize automatic conversion to the	e between two p ed (Hex) or physi	arameters or	r alternatively	usina P071	9 or P100		
he parameters (standardize automatic conversion to the	ed (Hex) or physi	arameters or cal (i.e. Hz) v	<sup>r</sup> alternatively	using P071	9 or P100	<u> </u>	
VSS-PZD on RS485 x[Hex]	0 11 USS-PZ RS485 3 y[Hex] P1070 y[	y[Hz]	x]= <u>r0021[Hz]</u> P2000[Hz] ]= <u>r2018[1]</u> 4000[Hex] · P	4000[Hex] 2000			
When Quick Commissioning			-		1082.		
P2000 represents the refere A maximum frequency setpo Jnlike P1082 (Maximum Fre reference frequency. By modification of P2000 it v PZD f (Hex)	oint of 2*P2000 equency) this lim will also adapt th	can be applie nits the conve ne parameter pint	ed via the corr erter frequenc to the new se P1082	esponding y internally ettings.	independ		he
T							
	PZD f (Hex)	PZD f (Hex) f (Hex) f (Hex) f (Hex) f (Hz) Setpo chan	PZD $f$ (Hex) f (Hex) f (Hex) f (Hez) f (Hez)	PZD $f$ (Hex) PZD $f$ (Hex) f (Hex) f (Hz) $f$ (Hz) f (Hz) $f$ (Hz)	PZD $f$ (Hex) PZD $f$ (Hex) f (Hex) f (Hex) f (Hz) f	PZD $f$ (Hex) f (Hex) f (Hex) f (Hz) f	PZD $f$ (Hex) f (H

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.
			default	changed		set	type	
Notice:	Reference parameters are in manner.	tended as an ai	d to presenting	setpoint and	d actual valu	ue signal	s in a un	iform
	This also applies to fixed set	tings optored as	aporcontago					
	A value of 100 % correspond	0			0 0000H in	the case	ofdout	
	values.	us to a process o		50011, 01 400	0 00001111	the case	of dour	ie
	In this respect, the following	g parameters are	e available:					
	P2000 Reference frequency	Hz						
	P2001 Reference voltage	V						
	P2002 Reference current	A						
	P2003 Reference torque	Nm						
	P2004 Reference power	kW f(	P0100)					
		hp (	0100)					
Note:	Changes to P2000 result in a	a new calculatio	n of P2004.					
P2001[02]	Reference voltage [V]	10 - 2000	1000	Т	-	DDS	U16	3
	Full-scale output voltage (i.e	e. 100 %) used o	ver serial link (	corresponds	to 4000H).			
Example:	0000 D0774							
	r0026 P0771		v[Hex] = r0	026[V] 2001[V] · 4000[H	lex]			
			P2	2001[V]				
	1	1						
	x[V]	y[Hex]						
Note:	Changes to P2001 result in a	a new calculatio	n of P2004.					
P2002[02]	Reference current [A]	0.10 -	0.10	Т	-	DDS	Float	3
		10000.0						
	Full-scale output current use	ed over serial lin	k (corresponds	s to 4000H).				
Example:	If a BICO connection is made physical (i.e. A) values) may							
	P2051	1						
	r0027	·		07/11				
		Fieldbus	$y[Hex] = \frac{r00}{P20}$	027[A] 002[A] · 4000[H	ex]			
	$\left  \begin{array}{c} \left  \right\rangle \\ \left  \left  \right\rangle \\ \left  \right\rangle \\ \left  \left  \right\rangle \\ \left  \right\rangle \\ \left  \left  \left  \right\rangle \\ \left  \left  \right\rangle \\ \left  \left  \left  \right\rangle \\ \left  \left  \left  \left $			502[//]				
		y[Hex]						
Dependency:	This parameter is influenced	by automatic c	alculations dof	inad by PO24	0			
Note:	Changes to P2002 result in a	-		ineu by FU34	0.			
P2003[02]	Reference torque [Nm]	0.10 -	0.75	Т		DDS	Float	2
F2005[02]	Reference torque [Mili]	99999.0	0.75		-	2003	FIDAL	2
	Full-scale reference torque u		rial link (corres	ponds to 400	ООН).		1	L
Example:	If a BICO connection is made		-			s (standa	rdized (I	Hex) or
<i>·</i>	physical (i.e. Nm) values) ma							
	P2051	1						
	r0080	I		080[Nm]				
		Fieldbu	s $y[Hex] = \frac{10}{P_2}$	0080[Nm] 2003[Nm]	0[Hex]			
	$\geq [2]$							
		y[Hex]						
Dependency	This paramotor is influenced	l hy automatic c	alculations dof	ined by PO24	0			
Dependency:	This parameter is influenced	,		meu by FU34				
Note:	Changes to P2003 result in a	a new calculatio	11 01 PZUU4.					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P2004[02]	Reference power	0.01 - 2000.0	0.75	Т	-	DDS	Float	3		
	Full-scale reference power u	used over the seri	al link (corres	ponds to 400	ОН).	•		•		
Example:		may differ. In th	is case an aut	e 'unit' of the omatic conve <u>r0032</u> · 4000[H P2004	ersion to the	s (standar e target v	dized ( alue is r	Hex) or nade.		
2010[01]	USS/MODBUS baudrate	6 - 12	6	U, T	-	-	U16	2		
	Sets baud rate for USS/MODBUS communication.									
	-	6 9600 bps								
	7	19200 bps								
	8	38400 bps								
	9	57600 bps								
	10	76800 bps								
	11	93750 bps								
<u>.</u>	12	115200 bps								
Index:	[0]	USS/MODBUS o								
	[1]	USS on RS232 (								
Note:	This parameter, index 0, will				protocol sele	ected in P2	Т			
P2011[01]	USS address	0 - 31	0	U, T	-	-	U16	2		
	Sets unique address for conve									
Index:	[0] USS on RS485									
	[1]									
Note:	You can connect up to a further 30 converters via the serial link (i.e. 31 converters in total) and control them wit the USS serial bus protocol.									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P2012[01]	USS PZD length	0 - 8	2	U, T	-	-	U16	3		
	Defines the number of 16-bit	words in PZD par	t of USS telegra	am. In this are	a, process da	ta (PZD)	) are cont	inually		
	exchanged between the mast to control the converter.	1	e PZD part of th	ne USS telegra	m is used for	the ma	in setpoiı	nt, and		
Index:	[0]	USS on RS485								
	[1]	USS on RS232	(reserved)							
Notice:	USS protocol consists of PZD	and PKW which elegram	n can be chang	jed by the us	er via P2012	and P2	013 resp	ectivel		
	STX LGE ADR Parame	ter Proces PZ	II BCC							
	PKE IND	PWE PZD1	PZD2 PZ	D3 PZD4						
	STX Start of text LGE Length ADR Address PKW Parameter ID valu PZD Process data BCC Block check chara		Sub-index							
	PZD transmits a control word and setpoint or status word and actual values. The number of PZD-words in a USS-telegram are determined by P2012, where the first two words are either: a) control word and main setpoint or b) status word and actual value. When P2012 is greater or equal to 4 the additional control word is transferred as the 4th PZD-word (default setting).									
	STW HSW ZSW HIW PZD1 PZD2 PZD3 P2012 -	STW2 PZD4								
	STW Control word ZSW Status word	HSW HIW	Main setpoint Main actual va							
	PZD Process data			alue						
P2013[01]	PZD Process data USS PKW length	0 - 127	127	U, T	-	-	U16	3		
2013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor	words in PKW pa d, 4-word or vari	rt of USS telegr able word leng	U, T am. The PKW ths can be pa	- area can be v ameterized.	- varied. D The PKW	epending	g on the		
22013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and y	words in PKW pa d, 4-word or vari vrite individual p	rt of USS telegr able word leng	U, T am. The PKW ths can be pa	area can be v ameterized.	- varied. D The PKW	epending	g on the		
2013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0	words in PKW pa d, 4-word or vari vrite individual p No words	rt of USS telegr able word leng	U, T am. The PKW ths can be pa	- area can be v ameterized.	- varied. D The PKW	epending	g on the		
2013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3	words in PKW pa d, 4-word or vari vrite individual p No words 3 words	rt of USS telegr able word leng	U, T am. The PKW ths can be pa	- area can be v rameterized.	- /aried. D The PKW	epending	g on the		
P2013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3 4	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	rt of USS telegr able word leng	U, T am. The PKW ths can be pa	- area can be v rameterized.	- varied. D The PKW	epending	g on the		
	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3	words in PKW pa d, 4-word or vari vrite individual p No words 3 words	rt of USS telegr able word leng	U, T am. The PKW ths can be par s.	rameterized.	- The PKW	epending	g on the		
	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3 4	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	rt of USS telegr able word leng arameter value	U, T am. The PKW ths can be pa	pe	The PKW	V part of	g on the		
	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3 4	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	rt of USS telegr able word leng	U, T am. The PKW ths can be par s.	pe U32 (32 Parameter a	The PKW Bit)	Float	g on the the USS (32 Bit) ter		
P2013[01]	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3 4 127 P2013 = 3	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	rt of USS telegr able word leng arameter value U16 (16 Bit) X	U, T am. The PKW ths can be par s.	pe U32 (32 Parameter a fault	The PKW Bit)	Float Parame access f	g on the the USS (32 Bit) ter fault		
	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and y 0 3 4 127 P2013 = 3 P2013 = 4	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	U16 (16 Bit) X	U, T am. The PKW ths can be par s.	pe U32 (32 Parameter a fault X	The PKW Bit)	Float Parame access f	(32 Bit) (32 Bit) ter ault X		
	USS PKW length Defines the number of 16-bit particular requirement, 3-wor telegram is used to read and v 0 3 4 127 P2013 = 3	words in PKW pa d, 4-word or vari vrite individual p No words 3 words 4 words	rt of USS telegr able word leng arameter value U16 (16 Bit) X	U, T am. The PKW ths can be par s.	pe U32 (32 Parameter a fault	The PKW Bit)	Float Parame access f	g on the the USS (32 Bit) ter fault		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
Notice:	USS protocol consists of PZD P2013 determines the number the PKW words (3 = three wo the PKW words are required.	er of PKW-words	s in a USS-telegr	am. Setting P2	013 to 3 or 4	l determ	ines the l	ength o			
	P2013 = 3 P20 PKE IN 1 word each 16 Bit										
	P2013 = 4 PKE IN PKE Parame IND Sub-ind PWE Parame	ter ID	VE								
	If a fixed PKW length is selected only one parameter value can be transferred.										
	In the case of indexed parameter, you must use the variable PKW length if you wish to have the values of all indices transferred in a single telegram. In selecting the fixed PKW length, it is important to ensure the value in question can be transferred using this										
	PKW length.			ie value in que.		transferi	cu using	uns			
	_	P2013 = 3, fixes PKW length, but does not allow access to many parameter values.									
	A parameter fault is generated when an out-of-range value is used. The value will not be accepted but the converter state will not be affected.										
	Useful for applications where parameters are not changed, but MM3s are also used.										
	Broadcast mode is not possible with this setting.										
	P2013 = 4, fixes PKW length.										
	Allows access to all parameters, but indexed parameters can only be read one index at a time.										
	Word order for single word values are different to setting 3 or 127, see example below.										
	P2013 = 127, most useful setting.										
	PKW reply length varies depending on the amount of information needed.										
	Can read fault information and all indices of a parameter with a single telegram with this setting.										
	Example:										
	Set P0700 to value 5 (P0700	= 2BC (hex))			T		1				
			P2013 = 3		P2013			3 = 127			
	Master → SINAMICS	22BC 0000 0	006		22BC 0000 0006	0000	22BC 00 0006 00				
	SINAMICS $\rightarrow$ Master	12BC 0000 0	006		12BC 0000 0006	0000	12BC 00 0006	000			
Note:	If you want to use USS function P2013[0] = 4.	on blocks in TIA	Portal to comm	unicate with th	ie converter,	make sı	ure that y	ou set			
2014[01]	USS/MODBUS telegram off time [ms]	0 - 65535	2000	Т	-	-	U16	3			
	Index 0 defines a time T_off USS/MODBUS channel RS48		fault will be $\overline{ge}$	nerated (F72)	if no telegra	am is rec	ceived vi	a the			
	Index 1 defines a time T_off USS channel RS232 (reserve		fault will be ge	nerated (F71)	if no telegra	am is reo	ceived vi	a the			
ndex:	[0]	USS/MODBU	S on RS485								
	[1]		2 (reserved)								
Notice:	If time set to 0, no fault is generated (i.e. watchdog disabled).										
Note:	The telegram off time will function on RS485 regardless of the protocol set in P2023.										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r2018[07]	CO: PZD from USS/MODBUS on RS485	-	-	-	4000H	-	U16	3			
	Displays process data re	ceived via USS/M	ODBUS on RS48	5.		1					
	USS on RS485:										
	Bit 00 ON/OFF1 Bit 01 OFF2: Electrical stop Bit 02 OFF3: Fast stop Bit 03 Pulse enable Bit 04 RFG enable Bit 05 RFG start Bit 06 Setpoint enable Bit 07 Fault acknowledge Bit 08 JOG right Bit 09 JOG left Bit 10 Control from PLC Bit 11 Reverse (setpoint inversion) Bit 13 Motor potentiometer MOP up Bit 14 Motor potentiometer MOP down										
			(Bit )	15 CDS Bit 0 (Lo							
					Bit 00	Dit					
					Fixed freq	uency Bit (	J				
					Bit 01 Fixed freq	uency Bit	1				
		,		1	Bit 02 Fixed frequ	uency Bit 2	2				
					Bit 03 Fixed frequ	uency Bit 3	3				
	PZD4 PZD3 PZD STW2 HSW	2 PZD1 / STW1	1 11	CtrlWd2 <- COM 7]) ·····▶[r2037])	Bit 04 Drive data	set (DDS)	) Bit 0				
	P2012 -		STX Start		Drive data	set (DDS)	) Bit 1				
			LGE Leng		Bit 08 PID enable	ed					
			PKW Para	meter ID value	Bit 09 DC brake						
	BCC PZD F Process data Par	PKW ameter ADR LGE	STX PZD Proc		Bit 11	Chableu					
				k check charact	<sup>er</sup> Droop						
	USS t	elegram	STW Cont	rol word	Bit 12 Torque con	ntrol					
	1100	n RS485	HSW Main	setpoint	Bit 13						
		1 1 3403			External fa Bit 15	ault 1					
		PZD ma	pping to paramet	er r2018	Command	data set (	CDS) Bit	1			
	Note:		•								
	Note: Bit 10 must be set in the first PZD word of the telegram received via USS so that the converter will accept the process data as being valid. For this reason, the control word 1 must be transferred to the converter in the first PZD word.										

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.	
	MODBUS on RS485:		default	changed		set	type	Level	
	2010-01-02012/01-03	1.01 21 2							
	HSW (spe 40003 or 4	ed setpoint) 40101			Bit 03 1=Enable oper	ation (pul	202		
					can be enable	1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 -	562		
				-2010	0=Inhibit opera	ation (can	cel		
	······			r2018	pulses)				
			······································	( 1 (01)	Bit 04				
				[2] 1=Operation condition (the [3] ramp-function generator can be					
	Bit: 0 1 2 3 4 5 6	7 8 9 10 11 1	2 13 14 15	: .	enabled)				
			2131415		0=Inhibit ramp (set the ramp-f				
					output to zero)		enerator		
					Bit 05				
		0007 40005		· · · · · · · · · · · · · · · · · · ·	1=Enable the r generator	amp-func	tion		
	STW0 STW3 S	TW7 STW1	L.	i i	0=Stop the ran	np-functio	on		
	40100				generator (free	ze the ra	mp-		
	STW		1		function gener	ator outpu	ut)		
	MODE	BUS telegram —	►	1	Bit 06 1-Enchle cote	aint			
					1=Enable setp 0=Inhibit setpc		e		
	MODI	BUS on RS485 -	•	י רי	ramp-function			i.	
	STW (control word):	M	apping to param	eter r2018	zero)				
	Bit 00 <b>↓</b> =ON (Pulses can be ena	bled)			Bit 07 ↓=Acknowled	lge faults			
	0 =OFF1 (braking with ram		ator, then pulse		⊐ Bit 08 Reserve				
	cancellation and ready-to	-power-up)			Bit 09 1=Reser Bit 10 1=Contr				
	Bit 01	14. L - N			Bit 11 1=Dir of				
	1=No OFF2 (enable is pose 0=OFF2 (immediate pulse	<u>.</u>	ower-on inhibit)		Bit 12 Reserve				
	2. St.	cancenation and j	bower-on minibity	1	Bit 13 1=Motor		ntiomete	er,	
	Bit 02 1=No OFF3 (enable is pos	sible)			setpoint, raise				
	0=OFF3 (braking with the cancellation and power-on	OFF3 ramp p1135	, then pulse		Bit 14 1=Motor setpoint, lower		ntiomete	er,	
	35	8			Bit 15 Reserve	ed			
Index:	[0]	Received wo							
	[1]	Received wo	ord 1						
		 Received wo	ard 7						
Note:	[7] Restrictions:		nu /						
	<ul> <li>If the above serial inter transferred in the 1st F</li> </ul>		e converter (P07	700 or P071	9) then the 1	st contro	ol word	must be	
	<ul> <li>If the setpoint source i 2nd PZD-word.</li> </ul>		000 or P0719, t	hen the mai	in setpoint m	ust be tra	ansferre	ed in the	
	<ul> <li>When P2012 is greater transferred in the 4th I</li> </ul>							0719)	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
2019[07]	CI: PZD to USS/MODBUS on RS485	-	52[0]	Т	4000H	-	U32/ I16	3
	Displays process data transr	nitted via USS/	MODBUS on R	S485.				
	USS on RS485:							
	Bit 00 DC brake ad Bit 01 Act. freq. r0 Bit 02 Act. freq. r0 Bit 03 Act. current Bit 04 Act. freq. r0 Bit 05 Act. freq. r0 Bit 06 Act. freq. r0 Bit 07 Act. Vdc r00 Bit 08 Act. Vdc r00 Bit 09 Ramping fin Bit 10 PID output r Bit 11 PID output r Bit 14 Download d Bit 15 Download d Bit 15 Download d Bit 15 Download d CO/BO: CO: Act. frequency [Hz] r00 r0021	021 > P2167 (f_ 021 > P1080 (f_ r0027 >= P2170 021 >= P2155 (f_ 021 >= setpoint 026 > P2172 026 > P2172 026 > P2172 027 == P2292 028 == P2291 028 ata set 0 from A 0294 == P2291 0294 == P2292 0294 == P2291 0294 == P2291 0294 == P2292 0294 == P2291 0294 == P2292 0294 == P229	min) [_1) (PID_min) (PID_max) OP OP 0P 0 [] [] [] [] [] [] [] [] [] []	Bit 01 Dr Bit 02 Dr Bit 03 Dr Bit 04 Ol Bit 05 Ol Bit 07 Dr Bit 08 De Bit 09 PZ Bit 10 Ma Bit 12 Ma Bit 12 Ma Bit 12 Ma Bit 13 Ma Bit 14 Ma Bit 15 Ca PZD4 PZD3 ZSW2 PZ PZD4 PZD3 ZSW2 PZ	PKW Parameter USS telegra	ve active oint/act. v uency rea r current li brake activ t totad	ched imit ve	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
	MODBUS on RS485:			27.20222	2.5							
				W (actual spee	ed)							
			40	044 or 40111								
	CO/BO: Act StatWd1											
	r0052	r0052										
	10002	> [1]										
	r0021	> [2] > [3]										
	CO: Act. frequency [Hz]		Bit: 0123	3 4 5 6 7	8 9 10 1	1 12 13 1	4 15					
	5	. [7]										
		i										
		400 ZSV	038 / N0 /									
			0039 40035 SW1 ZSW2	40054 4005 ZSW3 ZSW	9 40037 4 7 ZSW9 Z		0034 SW14					
			<u></u>	4011	0		<u> </u>					
		i i		ZSV								
				— MODBUS	telegram -		-					
	Mapping from parameter	P2019		MODBUS or	n RS485 —							
	ZSW (status word):	6	В	Bit 09 1=Contro	l requested							
	Bit 00 1=Ready to power-up			Bit 10 1=f or n c		alue						
	Bit 01 1=Ready to operate (De	C link loaded, puls	es blocked)	eached/exceed	led							
	Bit 02 1=Operation enabled (o	frive follows n_set	) В	Bit 11 1=1, M, o	r P limit not i	reached						
	Bit 03 1=Fault present			Bit 12 Reserved Bit 13 1=No mo		perature al	arm					
	Bit 04 1=No coast down active	e (OFF2 inactive)			tor overteint		ann					
	Bit 05 1=No fast stop active (0	OFF3 inactive)	17	Bit 14	영 방 목	U 924						
	Bit 06 1=Power-on inhibit activ	ve	1	=Motor rotates	s forwards (n	_act >= 0)	K.					
	Bit 07 1=Alarm present		0	=Motor rotates	s backwards	(n_act < 0	))					
	Bit 08 1=Speed setpoint - actu tolerance t_off	ual value deviation	В	Bit 15 1=No ala ower unit	rm, thermal	overload,						
Index:	[0]	Transmitted w	ord 0									
	[1]	Transmitted w										
	[7]	Transmitted w										
Note:	If r0052 not indexed, displa	y does not show	an index (".0")	).								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P2021	Modbus address	1 - 247	1	T	-	-	U16	2				
	Sets unique address for conv	verter.	•				•					
P2022	Modbus reply timeout [ms]	0 - 10000	1000	U, T	-	-	U16	3				
	The time in which the conve needs more time than speci							sponse				
P2023	RS485 protocol selection	0 - 3	1	Т	-	-	U16	1				
	Select the protocol which ru	ns on the RS48	5 link.									
	0											
	1	USS										
	2	Modbus										
	3 Script terminal											
Notice:	After changing P2023, powercycle the converter. During the powercycle, wait until LED has gone off or the display has gone blank (may take a few seconds) before re-applying power. If P2023 has been changed via a PLC, make sure the change has been saved to EEPROM via P0971.											
r2024[01]	USS/MODBUS error-free telegrams	-	-	-	-	-	U16	3				
	Displays number of error-fre	e USS/MODBUS	telegrams re	ceived.	•							
Index:	[0]	USS/MODBUS	on RS485									
	[1]	USS on RS232	(reserved)									
Note:	The state of the telegram in	formation on RS	5485 is report	ed regardless	of the proto	ocol set ir	n P2023					
r2025[01]	USS/MODBUS rejected telegrams	-	-	-	-	-	U16	3				
	Displays number of USS/MO	DBUS telegrams	s rejected.	·	•							
Index:	See r2024		-									
Note:	See r2024											
r2026[01]	USS/MODBUS character frame error	-	-	-	-	-	U16	3				
	Displays number of USS/MO	DBUS character	frame errors.	•	•		•					
Index:	See r2024											
Note:	See r2024											
r2027[01]	USS/MODBUS overrun error	-	-	-	-	-	U16	3				
	Displays number of USS/MO	DBUS with over	run error.	·	•							
Index:	See r2024											
Note:	See r2024											
r2028[01]	USS/MODBUS parity error	-	-	-	-	-	U16	3				
بر ا	Displays number of USS/MO	DBUS telegrams	s with parity e	error.	÷	·	-	-				
Index:	See r2024	~										
Note:	See r2024											
r2029[01]	USS start not identified	-	-	-	-	-	U16	3				
1	Displays number of USS tele	grams with unio	dentified star	t.	1	1		I				
Index:	See r2024	J										
Note:	Not used on MODBUS.											

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level						
r2030[01]	USS/MODBUS BCC/CRC error	-	-	-	-	-	U16	3						
	Displays number of USS/MOI	DBUS telegrams	with BCC/CRC	error.	•	•								
Index:	See r2024	0												
Note:	See r2024													
r2031[01]	USS/MODBUS length error	-	-	-	-	-	U16	3						
	Displays number of USS/MOI	DBUS telegrams	with incorrect	length.										
Index:	See r2024	5		<u> </u>										
Note:	See r2024													
P2034	MODBUS parity on RS485	0 - 2	2	U, T	-	-	U16	2						
	Parity of MODBUS telegrams			-, .				-						
	0	No parity												
	1	Odd parity												
	2	Even parity												
Note:	Also see P2010 for baudrate		ton hit setting	s You must	set P2034 t	0 0 if P20	135-2							
P2035	MODBUS stop bits on RS485	1 - 2	1	U, T	-	-	U16	2						
	Number of stop bits in MODI	I RUS telegrams c	n RS485											
	1	1 stop bit	1113103.											
	2	2 stop bits												
Note:	Also see P2010 for baudrate		parity settings	You must se	t P2035 to	2 if P203	4_0							
r2036.015	BO: CtrlWrd1 from USS/MODBUS on RS485	-	-	-	-	-	U16	3						
	Displays control word 1 from for the bit field description.	USS/MODBUS	on RS485 (i.e.	word 1 withi	n USS/MOD	BUS = PZ	D1). Se	e r0054						
Dependency:	See P2012													
r2037.015	BO: CtrlWrd2 from USS on RS485 (USS)	-	-	-	-	-	U16	3						
	Displays control word 2 from description.	USS on RS485	(i.e. word 4 w	ithin USS = P	ZD4). See r	0055 for 1	the bit f	ield						
Dependency:	See P2012													
Note:	To enable the external fault	(r2037 bit 13) fa	acility via USS,	the followin	g paramete	rs must b	e set:							
	• P2012 = 4		-											
	• P2106 = 1													
r2053[07]	I/O Extension Module identification	-	0	-	-	-	U16	3						
	Displays identification data of	l of the I/O Extens	ion Module											
Index:	[0]	I/O Extension I		abor										
index.	[1]	I/O Extension I			umbor (mai	(or)								
	[2]													
	[3]     I/O Extension Module firmware version number (hot fix)													
	[4] I/O Extension Module firmware version number (internal)													
	[5] Not used													
	[6]													
	[[/]	Company ID (S	siemens = 42)		[7] Company ID (Siemens = 42)									

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r2067.012	CO/BO: D values sta	igital input atus	-	-	-	-	-	U16	3
	Displays s	tatus of digital inpu	ıts.						
	Bit	Signal name				1 signal		0 sigr	nal
	00	Digital input 1				Yes		No	
	01	Digital input 2				Yes		No	
	02	Digital input 3				Yes		No	
	03	Digital input 4			Yes		No		
	04	Digital input 5			Yes		No		
	05	Digital input 6						No	
	11	Digital input Al	Yes		No				
	12	Digital input Al	2			Yes		No	
Note:		ed for BICO connect I input 5 and 6 are				dulo			
P2100[02]	Ű	mber selection	0 - 65535		T	-	-	U16	3
	Selects up	to 3 faults or alarn	ns for non-de	fault reactions	•				
Example:	If, for examented in	mple, an OFF3 is to P2100 and the de	be carried ou sired reaction	ut instead of ar selected in P2	n OFF2 for a fa 101 (in this ca	ult, the fau se (OFF3) P	t numbe 2101 = 3	r has to 3).	be
Index:	[0]		Fault Numbe	er 1					
	[1]		Fault Numbe	er 2					
	[2]		Fault Numbe	er 3					
Note:	All fault co	odes have a default	reaction to C	)FF2.					
		ollowing faults (F1 It reactions.	1,F12,F20,F3	5,F71,F72,F85	5,F200,F221,F2	222, and F4	52) can l	be chan	ged fron

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P2101[02]	Stop reaction value	0 - 4	0	T	-	-	U16	3			
[[]]]	Sets converter stop reaction parameter specifies the sp	on values for faults	selected by	P2100 (alarm rnings defined	number se i n P2100 ii	lection). ndices 0 1	This ind	-			
	0	No reaction, n	o display								
	1	OFF1 stop read	tion								
	2	OFF2 stop read	tion								
	3	OFF3 stop read	tion								
	4	No reaction, w	arning only								
Index:	[0]	Stop reaction v	/alue 1								
	[1]	Stop reaction v	/alue 2								
	[2] Stop reaction value 3										
Note:	Settings 1 - 3 are only avail Setting 4 is only available Index 0 (P2101) refers to f	for warnings.		0).							
P2103[02]	Bl: 1. Faults acknowledgement	0 - 4294967295	722.2	Т	-	CDS	U32	3			
	Defines first source of faul	t acknowledgeme	nt.								
Setting:	722.0	Digital input 1	(requires PO	701 to be set	to 99, BICO	)					
	722.1	Digital input 2	(requires PO	702 to be set	to 99, BICO	)					
	722.2	.2 Digital input 3 (requires P0703 to be set to 99, BICO)									
P2104[02]	Bl: 2. Faults acknowledgement	0 - 4294967295	0	Т	-	CDS	U32	3			
	Selects second source of fa	ault acknowledger	nent.								
Setting:	See P2103										
P2106[02]	Bl: External fault	0 - 4294967295	1	Т	-	CDS	U32	3			
	Selects source of external	faults.									
Setting:	See P2103										
r2110[03]	CO: Warning number	-	-	-	-	-	U16	2			
	Displays warning informat	ion.									
	A maximum of 2 active wa viewed.	arnings (indices 0 a	and 1) and 2	historical wa	rnings (indi	ces 2 and	3) may	be			
Index:	[0]	Recent Warnin	gs, warnir	ng 1							
	[1]	Recent Warnin									
	[2]	Recent Warnin	gs -1, warni	ng 3							
	[3]	Recent Warnin	gs -1, warni	ng 4							
Notice:	Indices 0 and 1 are not sto	red.									
Note:	The LED indicates the war	ning status in this	case. The ke	ypad will flash	n while a wa	arning is a	active.				
P2111	Total number of warning	<b>s</b> 0 - 4	0	Т	-	-	U16	3			
	Displays number of warnir	ng (up to 4) since l	ast reset. Se	t to 0 to reset	the warnin	g history					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P2113[02]	Disable converter warnings	0 - 1	0	Т	-	-	U16	3			
	Switches off reporting of co keep-running operation.	nverter warning	s. Can be used	l in conjuncti	ion with PO!	503 as an	ı adjunc	t to			
	1	Converter war	nings disabled	1							
	0	Converter war	nings enabled								
Index:	[0]	Drive data set	0 (DDS0)								
	[1]	Drive data set	1 (DDS1)								
	[2]	Drive data set	2 (DDS2)								
Note:	See also P0503										
r2114[01]	Run time counter         -         -         -         U16         3										
Example:	Displays run time counter. It is the total time the converter has been powered up. When power is switched off, the value is saved, ar then restored on powerup. The run time counter will be calculate as followed: Multiply the value in r2114[0] by 65536 and then add it to the value in r2114[1]. The resultant answer w be in seconds. This means that r2114[0] is not days. Total powerup time = 65536 * r2114[0] + r2114[1] seconds.										
Example:	If r2114[0] = 1 and r2114[1] = 20864										
Examplei	We get 1 * 65536 + 20864	-	s which equals	s 1 dav.							
Index:	[0]	System Time,									
	[1]	System Time,									
P2115[02]	Real time clock	0 - 65535	257	Т	-	-	U16	4			
	All converters require an on-board clock function with which fault conditions may be time-stamped and logged. However, they have no battery backed Real Time Clock (RTC). Converters may support a software driven RTC which requires synchronization with the RTC supplied via a serial interface. The time is stored in a word array parameter P2115. The time will be set by USS Protocol standard "word array parameter write" telegrams. Once the last word is received in index 2, the software will start running the start running like RTC.										
	the timer itself using internal running 1 millisecond tic. Hence becoming like RTC.										
	If power-cycle takes place, then the real time must be sent again to the converter. Time is maintained in a word array parameter and encoded as follows - the same format will be used in fault report logs.										
	Time is maintained in a wor fault report logs.			-	e converter.		ill be us	-			
		d array paramete		d as follows	e converter. - the same f			-			
	fault report logs.	d array paramete	er and encode	d as follows	e converter. - the same f	ormat wi	e (LSB)	_			
	fault report logs. Index	d array paramete Hi Se	er and encode gh Byte (MSB)	d as follows	e converter. - the same f	ormat wi	e (LSB) (0 - 59)	_			
	fault report logs. Index 0	d array paramete Hi Se	er and encode gh Byte (MSB) econds (0 - 59)	d as follows	e converter. - the same f	ormat wi Low Byte Minutes (	e (LSB) (0 - 59) - 31)	_			
	fault report logs. Index 0 1	d array paramete Hi Se H M	er and encode gh Byte (MSB) conds (0 - 59) lours (0 - 23)	d as follows	e converter. - the same f	ormat wi Low Byte Minutes ( Days (1	e (LSB) (0 - 59) - 31)	_			
Index:	fault report logs. Index 0 1 2	d array paramete Hi Se H M	er and encode gh Byte (MSB) conds (0 - 59) lours (0 - 23) lonth (1 - 12)	d as follows	e converter. - the same f	ormat wi Low Byte Minutes ( Days (1	e (LSB) (0 - 59) - 31)	_			
Index:	fault report logs.         Index         0         1         2         The values are in binary form	d array paramete Hi Se H N M	er and encode gh Byte (MSB) econds (0 - 59) Hours (0 - 23) Month (1 - 12) conds + Minute	d as follows	e converter. - the same f	ormat wi Low Byte Minutes ( Days (1	e (LSB) (0 - 59) - 31)	_			
Index:	fault report logs.         Index         0         1         2         The values are in binary form         [0]	d array paramete Hi Se H M M Real Time, Sec	er and encode gh Byte (MSB) conds (0 - 59) Hours (0 - 23) Honth (1 - 12) conds + Minute urs + Days	d as follows	e converter. - the same f	ormat wi Low Byte Minutes ( Days (1	e (LSB) (0 - 59) - 31)	_			
	fault report logs. Index 0 1 2 The values are in binary form [0] [1]	d array paramete Hi Se H M M Real Time, Sec Real Time, Hor	er and encode gh Byte (MSB) conds (0 - 59) Hours (0 - 23) Honth (1 - 12) conds + Minute urs + Days	d as follows	e converter. - the same f	ormat wi Low Byte Minutes ( Days (1	e (LSB) (0 - 59) - 31)	-			
	fault report logs.         Index         0         1         2         The values are in binary form         [0]         [1]         [2]	d array paramete Hi Se H N N Real Time, Sec Real Time, Hou Real Time, Mo 0 - 65535	er and encode gh Byte (MSB) conds (0 - 59) dours (0 - 23) donth (1 - 12) conds + Minute urs + Days nth + Year 0	d as follows	- the same f	Format wi Low Byte Minutes ( Days (1 Years (00	e (LSB) (0 - 59) - 31) - 250)	ed in			
Index: P2120 P2150[02]	fault report logs.         Index         0         1         2         The values are in binary form         [0]         [1]         [2]         Indication counter         Indicates total number of fa	d array paramete Hi Se H N N Real Time, Sec Real Time, Hou Real Time, Mo 0 - 65535	er and encode gh Byte (MSB) conds (0 - 59) dours (0 - 23) donth (1 - 12) conds + Minute urs + Days nth + Year 0	d as follows	- the same f	Format wi Low Byte Minutes ( Days (1 Years (00	e (LSB) (0 - 59) - 31) - 250)	ed in 4 arning			
P2120	fault report logs.         Index         0         1         2         The values are in binary form         [0]         [1]         [2]         Indication counter         Indicates total number of farevent occurs.         Hysteresis frequency	d array paramete Hi Se H M n. Real Time, Sec Real Time, Hou Real Time, Mo 0 - 65535 ult/warning ever 0.00 - 10.00	er and encode gh Byte (MSB) conds (0 - 59) Hours (0 - 23) Month (1 - 12) conds + Minute urs + Days nth + Year 0 nts. This paran 3.00	d as follows	- mented wh	Cormat wi Low Byte Minutes ( Days (1 Years (00 - - enever a	e (LSB) (0 - 59) - 31) - 250) U16 fault/wa	ed in 4 arning			
P2120	fault report logs.         Index         0         1         2         The values are in binary form         [0]         [1]         [2]         Indication counter         Indicates total number of farevent occurs.         Hysteresis frequency         f_hys [Hz]	d array paramete Hi Se H M n. Real Time, Sec Real Time, Hou Real Time, Mo 0 - 65535 ult/warning ever 0.00 - 10.00	er and encode gh Byte (MSB) conds (0 - 59) Hours (0 - 23) Month (1 - 12) conds + Minute urs + Days nth + Year 0 nts. This paran 3.00	d as follows	- mented wh	Cormat wi Low Byte Minutes ( Days (1 Years (00 - - enever a	e (LSB) (0 - 59) - 31) - 250) U16 fault/wa	ed in 4 arning			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2151[02]	CI: Speed setpoint for messages	0 - 4294967295	1170[0]	U, T	-	DDS	U32	3
	Selects the source of setpoin frequency deviation (see mo			cy is compared	with this f	requency	to dete	ct
P2155[02]	Threshold frequency f_1 [Hz]	0.00 - 550.00	30.00	U, T	-	DDS	Float	3
	Sets a threshold for compari status bits 4 and 5 in status	ng actual speed word 2 (r0053).	or frequency	y to threshold	values f_1.	This thre	shold co	ontrols
P2156[02]	Delay time of threshold freq f_1 [ms]	0 - 10000	10	U, T	-	DDS	U16	3
	Sets delay time prior to three	shold frequency	f_1 compari	son (P2155).	_			-
P2157[02]	Threshold frequency f_2 [Hz]	0.00 - 550.00	30.00	U, T	-	DDS	Float	2
	Threshold_2 for comparing s	speed or frequer	ncy to thresh	olds.				
Dependency:	See P1175.							
Note:	If P1175 is set, P2157 is also	used to control	the Dual Rai	mp function.				
P2158[02]	Delay time of threshold freq f_2 [ms]	0 - 10000	10	U, T	-	DDS	U16	2
	When comparing speed or fr cleared.	equency to thre	shold f_2 (P	2157) this is tl	he time dela	ay before	status k	oits are
P2159[02]	Threshold frequency f_3 [Hz]	0.00 - 550.00	30.00	U, T	-	DDS	Float	2
	Threshold_3 for comparing s	speed or frequer	ncy to thresh	olds.				
Dependency:	See P1175.							
Note:	If P1175 is set, P2159 is also	used to control	the Dual Rai	mp function.				
P2160[02]	Delay time of threshold freq f_3 [ms]	0 - 10000	10	U, T	-	DDS	U16	2
	When comparing speed or fr set.	equency to thre	shold f_3 (P	2159) this is tl	he time dela	ay before	status k	oits are
P2162[02]	Hysteresis freq. for overspeed [Hz]	0.00 - 25.00	3.00	U, T	-	DDS	Float	3
	Hysteresis speed (frequency) maximum frequency.	) for overspeed o	detection. Fo	or V/f control r	nodes the h	ysteresis	acts be	low the
P2164[02]	Hysteresis frequency deviation [Hz]	0.00 - 10.00	3.00	U, T	-	DDS	Float	
	Hysteresis frequency for dete frequency controls bit 8 in st	ecting permitted atus word 1 (r0	l deviation (1 052).	from setpoint)	or frequen	cy or spe	ed. This	
P2166[02]	Delay time ramp up completed [ms]	0 - 10000	10	U, T	-	DDS	U16	3
	Delay time for signal that inc	licates completi	on of ramp-u	Jp.	1			
P2167[02]	Switch-off frequency f_off [Hz]	0.00 - 10.00	1.00	U, T	-	DDS	Float	3
	Defines the threshold of the functions:	monitoring fund	ction  f_act	> P2167 (f_of	f). P2167 in	fluences	followir	ıg
	• If the actual frequency fa (r0053) is reset.	Ils below this th	reshold and	the time dela	y has expire	ed, bit 1 i	n status	word 2
		naliad and hit 1	ic rocot the	convortor	dicable +1	nulse (O	<b>LL</b> 2)	
	If an OFF1 or OFF3 was a	ipplied and bit I	is reset the	converter will	uisable the	puise (O	FFZ).	

	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Leve	
P2168[02]	Delay time T_off [ms]	0 - 10000	0	U, T	-	DDS	U16	3	
12100[02]	Defines time for which the co		-		P2167)	-		-	
Dependency:	Active if holding brake (P1215	ý .		iten-on neque	(1 2 1 0 7 )	Delote 3	witch on	occurs	
P2170[02]	<b>.</b>	0.00 - 400.0	100.0	U, T		DDS	Float	3	
P2170[02]	Threshold current I_thresh [%]				<u> </u>				
	Defines threshold current rela I_Thresh. This threshold contr				ed in compai	isons of I	_act and		
P2171[02]	Delay time current [ms]	0 - 10000	10	U, T	-	DDS	U16	3	
[2171[02]	Defines delay time prior to act			-		005	010	5	
P2172[02]	Threshold DC-link voltage	0 - 2000	800	U, T	_	DDS	U16	3	
12172[02]	[V]	0 - 2000	800	0,1		005	010		
	Defines DC link voltage to be ( (r0053).	compared to act	ual voltage. Th	nis voltage con	trols bits 7 a	nd 8 in st	atus wo	rd 3	
22173[02]	Delay time DC-link voltage [ms]	0 - 10000	10	U, T	-	DDS	U16	3	
2177[02]	Defines delay time prior to act	ivation of thresh	old compariso	on.		•	•		
P2177[02]	Delay time for motor is blocked [ms]	0 - 10000	10	U, T	-	DDS	U16	3	
	Delay time for identifying that	the motor is blo	ocked.			•	•		
P2179	Current limit for no load identified [%]	0.00 - 10.0	3.0	U, T	-	-	Float	3	
	Threshold current for A922 (no load applied to converter) relative to P0305 (rated motor current).								
Notice:	If a motor setpoint cannot be applied) is issued when delay	entered and the	current limit (					oad	
Note:	It may be that the motor is no			be missing.					
P2180	Delay time for no-load detection [ms]	0 - 10000	2000	U, T	-	-	U16	3	
	Delay time for detecting a mis	sing output load	l.		•	•			
P2181[02]	Load monitoring mode	0 - 6	0	Т	-	DDS	U16	3	
	Sets load monitoring mode.		•	•					
		a of modelessis		CONVORTO		CONVE		1+	
	This function allows monitorinalso detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ	d, such as a ja ency/torque c	m. P2182 -P21 urve with a pr	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ	d, such as a ja iency/torque c , a warning AS	m. P2182 -P21 urve with a pr	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ de the envelope Load monitorii	d, such as a ja hency/torque c , a warning A9 ng disabled	m. P2182 -P21 urve with a pr 952 or trip F45	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi 0	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ de the envelope Load monitorin Warning: Low	d, such as a ja ency/torque c , a warning AS ng disabled torque/frequer	m. P2182 -P21 urve with a pr 952 or trip F45 ncy	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi 0 1	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ de the envelope Load monitorin Warning: Low Warning: High	ency/torque c , a warning A9 ng disabled torque/frequei torque/freque	m. P2182 -P21 urve with a pr 252 or trip F45 ncy	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi 0 1 2 3	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ de the envelope Load monitorin Warning: Low Warning: High Warning: High	ency/torque c , a warning AS ng disabled torque/freque (low torque/fre	m. P2182 -P21 urve with a pr 252 or trip F45 ncy ency equency	90 are set to ogrammed e	o the follo	owing va	lues	
	also detect conditions which of when this parameter is chang P2182 = P1080 (Fmin) P2183 = P1082 (Fmax) * 0.8 P2184 = P1082 (Fmax) P2185 = r0333 (rated motor t P2186 = 0 P2187 = r0333 (rated motor t P2188 = 0 P2189 = r0333 (rated motor t P2190 = r0333 (rated motor t This is achieved by comparing P2190). If the curve falls outsi 0 1 2	ause an overloa ed from 0. orque) * 1.1 orque) * 1.1 orque) * 1.1 orque)/2 the actual frequ de the envelope Load monitorin Warning: Low Warning: High	d, such as a ja ency/torque c , a warning AS ng disabled torque/freque torque/freque (low torque/fre ue/frequency	m. P2182 -P21 urve with a pr 252 or trip F45 ncy equency	90 are set to ogrammed e	o the follo	owing va	lues	

Parameter	Function	Range	Factory	Can be	Scaling	Data	Data	Acc.
			default	changed		set	type	
P2182[02]	Load monitoring threshold frequency 1 [Hz]	0.00 - 550.00	5.00	U, T	-	DDS	Float	
	Sets the lower frequency the frequency torque envelope i the other 6 define the low a	s defined by 9 p	arameters -	3 are frequend	cy paramete	ers (P218)	effective 2 - P218	e. The 4), and
Dependency:	See P2181 for calculated det							
Note:	Below the threshold in P218 In this case the values for no							
P2183[02]	Load monitoring threshold frequency 2 [Hz]	0.00 - 550.00	30.00	U, T	-	DDS	Float	3
	Sets the frequency threshold P2182.	f_2 for defining	g the envelo	pe in which th	e torque va	lues are v	valid. Se	e
Dependency:	See P2181 for calculated det	fault value.			- <b>-</b>	-		
P2184[02]	Load monitoring threshold frequency 3 [Hz]	0.00 - 550.00	50.00	U, T	-	DDS	Float	3
	Sets the upper frequency the P2182.	reshold f_3 for d	efining the a	area where the	e load moni	toring is	effective	e. See
Dependency:	See P2181 for calculated det	fault value.						
P2185[02]	Upper torque threshold 1 [Nm]	0.0 - 99999.0	Value in r0333	U, T	-	DDS	Float	3
	Upper limit threshold value	1 for comparing	actual torqu	ie.				
Dependency:	This parameter is influenced See P2181 for calculated det	,	alculations d	efined by PO3	40.			
Note:	The factory setting depends	on rating data c	f Power Mo	dule and Moto	or.			
P2186[02]	Lower torque threshold 1 [Nm]	0.0 - 99999.0	0.0	U, T	-	DDS	Float	3
	Lower limit threshold value	1 for comparing	actual torqu	ie.	•	•		
Dependency:	See P2181 for calculated det	fault value.						
P2187[02]	Upper torque threshold 2 [Nm]	0.0 - 99999.0	Value in r0333	U, T	-	DDS	Float	3
	Upper limit threshold value 2	2 for comparing	actual torqu	ie.				
Dependency:	This parameter is influenced	by automatic ca	alculations d	efined by PO3	40.			
	See P2181 for calculated det	fault value.						
Note:	See P2185							
P2188[02]	Lower torque threshold 2 [Nm]	0.0 - 99999.0	0.0	U, T	-	DDS	Float	3
	Lower limit threshold value	2 for comparing	actual torqu	ie.				
Dependency:	See P2181 for calculated det	fault value.				-	-	
P2189[02]	Upper torque threshold 3 [Nm]	0.0 - 99999.0	Value in r0333	U, T	-	DDS	Float	3
	Upper limit threshold value	3 for comparing	actual torqu	ie.				
Dependency:	This parameter is influenced See P2181 for calculated det		alculations d	efined by PO3	40.			
		aant vuide.						

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Leve
P2190[02]	Lower torque thre [Nm]	shold 3	0.0 - 99999.0	0.0	U, T	-	DDS	Float	3
	Lower limit thresho	ld value	3 for comparing	actual torqu	Je.				
Dependency:	See P2181 for calcu								
P2192[02]	Load monitoring d time [s]	elay	0 - 65	10	U, T	-	DDS	U16	3
	P2192 defines a de	ay befor	e warning/trip b	ecomes acti	ve.				
	- It is used to elimin	ate even	ts caused by tra	nsient condi	tions.				
	- It is used for both	methods	of fault detection	on.			_		
r2197.012	CO/BO: Monitoring	word 1	-	-	-	-	-	U16	3
	Monitoring word 1 function.	which in	dicates the state	of monitor	functions. Eac	h bit repres	ents one	monito	r
	Bit Signa	name				1 signal		0 sigr	nal
	00  f_act	f_act  <= P1080 (f_min)						No	
	01  f_act	f_act  <= P2155 (f_1)						No	
	02  f_act	f_act  > P2155 (f_1)						No	
	03 f_act >	>= zero				Yes		No	
	04 f_act >	f_act >= setp. (f_set)						No	
	05  f_act	f_act  <= P2167 (f_off)					Yes		
	06  f_act	$ f_act  >= P1082 (f_max)$					Yes		
	07 f_act =	$f_act == setp. (f_set)$					Yes		
	08 Act. cu	urrent  rC	0027  >= P2170			Yes		No	
	09 Act. u	nfilt. Vdc	< P2172			Yes		No	
	10 Act. u	nfilt. Vdc	> P2172			Yes		No	
	11 Outpu	t load is	not present			Yes		No	
	12  f_act	> P1082	2 with delay			Yes		No	
r2198.012	CO/BO: Monitoring	word 2	-	-	-	-	-	U16	3
	Monitoring word 2 function.	which in	dicates the state	of monitor	functions. Eac	h bit repres	ents one	monito	r
	Bit Signa	name				1 signal		0 sigr	nal
	00  f_act	<= P215	57 (f_2)			Yes		No	
	01  f_act	> P2157	′ (f_2)			Yes		No	
	02  f_act	<= P215	59 (f_3)			Yes		No	
	03  f_act	> P2159	9 (f_3)			Yes		No	
	04 Unuse	d				Yes		No	
	05 Reserv	ed				Yes		No	
	06 Reserv	ed				Yes		No	
	07 Reserv	ed				Yes		No	
	08 Reserv	ed				Yes		No	
	09 Reserv	ed				Yes		No	
	10 Reserv	ed				Yes		No	
	11 Load r	nonitorir	ng signals an ala	rm		Yes		No	
	12 Load r	nonitorir	ng signals a fault			Yes		No	

	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P2200[02]	BI: Enable PID controller	0 - 4294967295	0	U, T	-	CDS	U32	2				
	Allows user to enable/disabl	e the PID contro	ller. Setting	to 1 enables tl	he PID close	d-loop co	ontroller					
Dependency:	Setting 1 automatically disa setpoints.											
	Following an OFF1 or OFF3 ramp time set in P1121 (P1	command, how 135 for OFF3).	ever, the cor	nverter freque	ncy will ram	ip down	to zero ι	ising the				
Notice:	The minimum and maximur to P1094) remain active on	the converter or	itput.			e skip fred	quencies	s (P1091				
	However, enabling skip freq			produce insta	abilities.							
Note:	The PID setpoint source is se	0										
	The PID setpoint and the PID	0	•									
	The output of the PID contro (reference frequency) when	PID is enabled.		hen normalize	ed into [Hz]	through	P2000					
	The reverse command is no											
	Attention: P2200 and P2803 cannot be active at same tin	ne.			PID and FFI	3 of the s						
P2201[02]	Fixed PID setpoint 1 [%]	-200.00 - 200.00	10.00	U, T	-	DDS	Float	2				
	Defines fixed PID setpoint 1	. There are 2 typ	es of fixed fr	equencies:								
	1. Direct selection (P2216 = 1):											
	<ul> <li>In this mode of operation 1 Fixed Frequency selector (P2220 to P2223) selects 1 fixed frequency.</li> </ul>											
	<ul> <li>If several inputs are a</li> <li>PID-FF3 + PID-FF4.</li> </ul>	active together,	the selected	frequencies a	re summed.	E.g.: PID	9-FF1 + P	ID-FF2 -				
	2. Binary coded selection (	P2216 = 2:										
			lues can be	selected using	this metho	d.						
Dependency:	– Up to 16 different fix	ked frequency va			this metho	d.						
Dependency: Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> </ul>	access level 2 to s of frequencies;	enable setpo	oint source.			l if selec	ted				
Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> </ul>	access level 2 to s of frequencies;	enable setpo however, re	int source. member that			l if selec					
Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> </ul>	access level 2 to s of frequencies;	enable setpo	oint source.			l if selec Float					
Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> </ul>	to 4000 hex. -200.00 - 200.00	enable setpo however, re	int source. member that	they will be	summec						
Note: P2202[02]	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> </ul>	ed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00	enable setpo however, re	U, T	they will be	summec	Float	2				
Note: P2202[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> </ul>	ed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -	enable setpo however, re	int source. member that	they will be	summec		2				
Note: P2202[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 3 [%]</li> </ul>	ed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -	enable setpo however, re 20.00	U, T	they will be	summec	Float	2				
Note: P2202[02] Note: P2203[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 3</li> <li>See P2201</li> </ul>	ed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -	enable setpo however, re 20.00	U, T	they will be	summec	Float	2				
Note: P2202[02] Note: P2203[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2 [%]</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 3 [%]</li> <li>See P2201</li> <li>Fixed PID setpoint 4 [%]</li> </ul>	<pre>ced frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpo however, re 20.00	U, T	they will be	summec	Float	2				
Note: P2202[02] Note: P2203[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> </ul>	<pre>ced frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpc however, re 20.00 50.00	U, T U, T U, T	they will be	summec DDS DDS	Float Float	2				
Dependency: Note: P2202[02] Note: P2203[02] Note: P2204[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2 [%]</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 3 [%]</li> <li>See P2201</li> <li>Fixed PID setpoint 4 [%]</li> </ul>	<pre>ced frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpc however, re 20.00 50.00	U, T U, T U, T	they will be	summec DDS DDS	Float Float	2				
Note: P2202[02] Note: P2203[02] Note: P2204[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> </ul>	<pre>ced frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpc however, re 20.00 50.00	U, T U, T U, T	they will be	summec DDS DDS	Float Float	2				
Note: P2202[02] Note: P2203[02] Note: P2204[02]	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2</li> <li>See P2201</li> <li>Fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> </ul>	<pre>xed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpc however, re 20.00 50.00 100.00	U, T U, T U, T U, T	they will be	summed DDS DDS DDS	Float Float Float	2 2 2				
Note: P2202[02] Note: P2203[02] Note: P2204[02] Note:	<ul> <li>Up to 16 different fix</li> <li>P2200 = 1 required in user a</li> <li>You may mix different types together.</li> <li>P2201 = 100 % corresponds</li> <li>Fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 2 [%]</li> <li>Defines fixed PID setpoint 3 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 4 [%]</li> <li>Defines fixed PID setpoint 5 [%]</li> </ul>	<pre>xed frequency va access level 2 to s of frequencies; to 4000 hex. -200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 - 200.00 -</pre>	enable setpc however, re 20.00 50.00 100.00	U, T U, T U, T U, T	they will be	summed DDS DDS DDS	Float Float Float	2 2 2				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
	Defines fixed PID setpoint 6.							
Note:	See P2201							
P2207[02]	Fixed PID setpoint 7 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 7.							
Note:	See P2201							
P2208[02]	Fixed PID setpoint 8 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 8.							
Note:	See P2201							
P2209[02]	Fixed PID setpoint 9 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 9.							
Note:	See P2201							
P2210[02]	Fixed PID setpoint 10 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 10	).		<u>.</u>				
Note:	See P2201							
P2211[02]	Fixed PID setpoint 11 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 1	1.						
Note:	See P2201							
P2212[02]	Fixed PID setpoint 12 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 12	2.						
Note:	See P2201							
P2213[02]	Fixed PID setpoint 13 [%]	-200.00 - 200.00	0.00	υ, τ	-	DDS	Float	2
	Defines fixed PID setpoint 13	3.						
Note:	See P2201							
P2214[02]	Fixed PID setpoint 14 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 14	1.		<u>.</u>				
Note:	See P2201							
P2215[02]	Fixed PID setpoint 15 [%]	-200.00 - 200.00	0.00	U, T	-	DDS	Float	2
	Defines fixed PID setpoint 15	5.		<u>.</u>				
Note:	See P2201							
P2216[02]	Fixed PID setpoint mode	1 - 2	1	Т	-	DDS	U16	2
	Fixed frequencies for PID set	point can be sel	ected in two	o different mo	des. P2216	defines t	he mode	2.
	1	Direct selection	1 <u> </u>					
	2	Binary selectio	n					
P2220[02]	Bl: Fixed PID setpoint select bit 0	0 - 4294967295	722.3	Т	-	CDS	U32	3
	Defines command source of	fixed PID setpoi	nt selection	bit 0.				
P2221[02]	Bl: Fixed PID setpoint select bit 1	0 - 4294967295	722.4	Т	-	CDS	U32	3
	Defines command source of f	xed PID setpoint	selection bit	1.				

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2222[02]	BI: Fixed F bit 2	PID setpoint select	0 - 4294967295	722.5	Т	-	CDS	U32	3
	Defines co	mmand source of fix	ked PID setpoint	selection bit	2.			I	
P2223[02]		PID setpoint select	0 - 4294967295	722.6	Т	-	CDS	U32	3
	Defines co	mmand source of fix	ked PID setpoint	selection bit	3.				
r2224	CO: Actua setpoint [		-	-	-	-	-	Float	2
	Displays to	tal output of PID fix	ed setpoint seled	tion.					
Note:	r2224 = 10	00 % corresponds to	4000 hex.						
r2225.0	BO: PID fix status	ked frequency	-	-	-	-	-	U16	3
	Displays th	e status of PID fixed	frequencies.						
	Bit	Signal name				1 signal		0 sigr	nal
P2231[0 2]	00	Status of FF				Yes		No	
P2231[02]	PID-MOP r	node	0 - 3	0	U, T	-	DDS	U16	2
	PID-MOP n	node specification							
	Bit	Signal name				1 signal		0 sigr	nal
	00	Setpoint store ad	ctive			Yes		No	
	01	No On-state for	MOP necessary			Yes		No	
Note:	Defines the	e operation mode of	the motorized p	otentiomete	er. See P2240.				
P2232	Inhibit rev PID-MOP	verse direction of	0 - 1	1	Т	-	-	U16	2
	Inhibits rev	verse setpoint select	ion of the PID-M	OP.					
	0		Reverse direction	on is allowed					
	1		Reverse direction	on inhibited					
Note:	Setting 0 e frequency)	enables a change of ).	motor direction	using the mo	otor potentiom	eter setpoint	(increase	/decreas	se
P2235[02]	BI: Enable cmd)	PID-MOP (UP-	0 - 4294967295	0	Т	-	CDS	U32	3
	Defines so	urce of UP comman	d.						
Dependency:	To change	setpoint:							
	-	e a digital input as so							
	- Use UP/D	OWN key on operate	or panel.						
Notice:	If this com (P0310). W P2247.	mand is enabled by Vhen the signal is er	short pulses of leaded leader that a short pulses of leader that a short that a short pulses of the short	ess than 1 se In 1 second t	cond, the frequ he ramp gener	iency is char ator accelera	nged in st ates with	eps of 0. the rate	.2 % of
P2236[02]	BI: Enable cmd)	PID-MOP (DOWN-	0 - 4294967295	0	Т	-	CDS	U32	3
		urce of DOWN comr	nand.						
Dependency:	See P2235	1							
Notice:		nmand is enabled b ). When the signal i							

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P2240[02]	Setpoint of PID-MOP [%]	-200.00 - 200.00	10.00	U, T	-	DDS	Float	2			
	Setpoint of the motor potentic	ometer. Allows u	ser to set a dig	gital PID setpo	int in [%].						
Note:	P2240 = 100 % corresponds to	94000 hex.									
	The start value gets active (for behavior as follows:	the MOP output	:) only at the s	tart of the MC	)P. P2231 inf	luences t	he start '	value			
	• P2231 = 0:										
	P2240 gets immediately active in the OFF-state and when changed in the ON-state, it gets active after the next OFF and ON cycle.										
	• P2231 = 1:										
	The last MOP output befor while in ON-state has no e		-		ng is selected	l, so a cha	ange of F	P2240			
	<ul> <li>P2231 = 2:</li> </ul>										
	The MOP is active every tir P2231 to 0.	ne, so the chang	e of P2240 aff	fects after the	next power-	cycle or a	change	of			
	• P2231 = 3:										
	The last MOP output befor the ON-command, a change			0			ndepend	dent fro			
		0 -			Tange of PZ		U32	3			
P2241[02]	BI: PID-MOP select setpoint auto/manu	0 - 4294967295	0	I	-	CDS	032	3			
	Sets the signal source to change over from manual to automatic mode. If using the motorized potentiometer in the manual mode the setpoint is changed using two signals for up and down, e.g. P2235 and P2236. If using the automatic mode the setpoint must be interconnected via the connector input (P2242). 0: manually										
	the manual mode the setpoint If using the automatic mode the 0: manually	is changed usin	g two signals <sup>.</sup>	for up and dov	wn, e.g. P22	35 and P2	236.	neter in			
	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically	is changed usin ne setpoint must	g two signals <sup>.</sup>	for up and dov	wn, e.g. P22	35 and P2	236.	neter in			
Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242	is changed usin ne setpoint must	g two signals be interconne	for up and dovected via the c	wn, e.g. P22	35 and P2 out (P224	236. 2).				
	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically	is changed usin ne setpoint must	g two signals <sup>.</sup>	for up and dov	wn, e.g. P22	35 and P2	236.	aeter in			
	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242	is changed usin ne setpoint must 2 0 - 4294967295	g two signals be interconne	for up and dovected via the c	wn, e.g. P22 onnector inp -	35 and P2 but (P224	2336. 2).	3			
Notice: P2242[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint	is changed usin ne setpoint must 2 0 - 4294967295	g two signals be interconne	for up and dovected via the c	wn, e.g. P22 onnector inp -	35 and P2 but (P224	2336. 2).	3			
P2242[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the set	is changed usin ne setpoint must 2 0 - 4294967295	g two signals be interconne	for up and dovected via the c	wn, e.g. P22 onnector inp -	35 and P2 but (P224	2336. 2).	3			
P2242[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command	g two signals be interconne 0 otorized poter 0 d to accept the	for up and dovected via the c T ntiometer if an T setting value	wn, e.g. P22 onnector inp - utomatic mo	35 and P2 put (P224 CDS de P2241 CDS	2236. 2). U32 is select U32	3 ted. 3			
P2242[02]	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command	g two signals be interconne 0 otorized poter 0 d to accept the	for up and dovected via the c T ntiometer if an T setting value	wn, e.g. P22 onnector inp - utomatic mo	35 and P2 put (P224 CDS de P2241 CDS	2236. 2). U32 is select U32	3 ted. 3			
P2242[02] Notice: P2243[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s	g two signals be interconne 0 otorized poter 0 d to accept the	for up and dovected via the c T ntiometer if an T setting value	wn, e.g. P22 onnector inp - utomatic mo	35 and P2 put (P224 CDS de P2241 CDS	2236. 2). U32 is select U32	3 ted. 3			
P2242[02] Notice: P2243[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295	g two signals be interconne 0 otorized poter 0 d to accept the etting comma	for up and dovected via the contract of the co	wn, e.g. P22 onnector inp - utomatic mo for the mote -	35 and P2 put (P224 CDS de P2241 CDS orized por	2236. 2). U32 is select U32 tentiome U32	3 ted. 3 eter. The			
P2242[02] Notice: P2243[02] Notice: P2244[02]	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setpoint Sets the signal source for the s	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295	g two signals be interconne 0 otorized poter 0 d to accept the etting comma	for up and dovected via the contract of the co	wn, e.g. P22 onnector inp - utomatic mo for the mote -	35 and P2 put (P224 CDS de P2241 CDS orized por	2236. 2). U32 is select U32 tentiome U32	3 ted. 3 eter. The			
P2242[02] Notice: P2243[02] Notice: P2244[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setpoint Sets the signal source for the s sets the signal source for the s	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295	g two signals be interconne 0 otorized poter 0 d to accept the etting comma	for up and dovected via the contract of the co	wn, e.g. P22 onnector inp - utomatic mo for the mote -	35 and P2 put (P224 CDS de P2241 CDS orized por	2236. 2). U32 is select U32 tentiome U32	3 ted. 3 eter. The 3 the			
P2242[02] Notice: P2243[02] Notice: P2244[02] Notice:	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setpoint Sets the signal source for the s setting command. Refer to: P2243 CO: PID-MOP input	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295 setpoint value fo	g two signals be interconne 0 otorized pote 0 d to accept the etting comma 0 r the MOP. The -	for up and dov ected via the c T ntiometer if an T e setting value and. T e value becom	wn, e.g. P22 onnector inp - utomatic mo for the moto - res effective -	35 and P2 put (P224 CDS de P2241 CDS orized por CDS for a 0/1	2236. 2). U32 is select U32 tentiome U32 edge of f	3 ted. 3 eter. The 3 the			
P2242[02] Notice: P2243[02]	the manual mode the setpoint If using the automatic mode th 0: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setpoint Sets the signal source for the s setting command. Refer to: P2243 CO: PID-MOP input frequency of the RFG [%]	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295 setpoint value fo	g two signals be interconne 0 otorized pote 0 d to accept the etting comma 0 r the MOP. The -	for up and dov ected via the c T ntiometer if an T e setting value and. T e value becom	wn, e.g. P22 onnector inp - utomatic mo for the moto - res effective -	35 and P2 put (P224 CDS de P2241 CDS orized por CDS for a 0/1	2236. 2). U32 is select U32 tentiome U32 edge of f	3 3 eter. The 3 the 3			
P2242[02] Notice: P2243[02] Notice: P2244[02] Notice: r2245	the manual mode the setpoint If using the automatic mode th O: manually 1: automatically Refer to: P2235, P1036, P2242 CI: PID-MOP auto setpoint Sets the signal source for the s Refer to: P2241 BI: PID-MOP accept rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setpoint Sets the signal source for the s value becomes effective for a Refer to: P2244 CI: PID-MOP rampgenerator setting command. Refer to: P2243 CO: PID-MOP input frequency of the RFG [%] Displays the motorized poter PID-MOP ramp-up time of	is changed usin ne setpoint must 0 - 4294967295 setpoint of the m 0 - 4294967295 setting command 0/1 edge of the s 0 - 4294967295 setpoint value fo - - ntiometer setpo 0.00 - 1000.0 e internal PID-W	g two signals be interconne 0 otorized pote 0 d to accept the etting comma 0 r the MOP. The - int before it p 10.00	for up and dovected via the context of the context	wn, e.g. P22 onnector inp - utomatic mo - for the moto - nes effective - D-MOP RFG. -	35 and P2 but (P224 CDS de P2241 CDS orized po CDS for a 0/1 -	236. 2). U32 is select U32 U32 edge of f Float	3 ted. 3 eter. The 3 the 3 2			

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data	Data	Acc. Level
P2248[02]	PID-MOP ramp-down time	0.00 - 1000.0	10.00	U, T		set DDS	type Float	2
rzz40[02]	of the RFG [s]				-			
	Sets the ramp-down time for t defined in P1082 down to zer			tion generato	or. The setpo	int is cha	nged fro	om limit
Notice:	Refer to: P2247, P1082							
r2250	CO: Output setpoint of PID- MOP [%]	-	-	-	PERCENT	-	Float	2
	Displays output setpoint of me	otor potentiomet	er.					
P2251	PID mode	0 - 1	0	Т	-	-	U16	3
	Enables function of PID contro	oller.						
	0	PID as setpoint						
	1	PID as trim						
Dependency:	Active when PID loop is enable	ed (see P2200).						
P2253[02]	CI: PID setpoint	0 - 4294967295	0	U, T	4000H	CDS	U32	2
	Defines setpoint source for PII setpoint. Normally, a digital se	D setpoint input. etpoint is selected	This paramete d either using a	r allows the u a fixed PID set	ser to select	the sourc	e of the point.	PID
P2254[02]	CI: PID trim source	0 - 4294967295	0	U, T	4000H	CDS	U32	3
	Selects trim source for PID set	point. This signal	is multiplied b	y the trim ga	in and addec	to the PI	D setpoi	int.
Setting:	755	Analog input 1					-	
2	2224	Fixed PI setpoir	nt (see P2201 t	o P2207)				
	2250	Active PI setpoi	nt (see P2240)					
P2255	PID setpoint gain factor	0.00 - 100.00	100.00	U, T	-	-	Float	3
	Gain factor for PID setpoint. The between setpoint and trim.	ne PID setpoint ir	nput is multipli	ed by this gai	n factor to p	roduce a	suitable	ratio
P2256	PID trim gain factor	0.00 - 100.00	100.00	U, T	-	-	Float	3
	Gain factor for PID trim. This c	ain factor scales	the trim signal		ded to the m	ain PID se	tpoint.	
P2257	Ramp-up time for PID setpoint [s]	0.00 - 650.00	1.00	U, T	-	-	Float	2
	Sets the ramp-up time for the	PID setpoint.		•	•			
Dependency:	P2200 = 1 (PID control is enable setpoint and active only when this ramp to reach its value fro	PID setpoint is c	mal ramp-up t hanged or whe	ime (P1120). en RUN comm	PID ramp tin and is given	ne is effeo (when Pl	tive onl D setpo	y on PIE int uses
Notice:	Setting the ramp-up time too	short may cause	the converter	to trip, on ove	ercurrent for	example.		
P2258	Ramp-down time for PID setpoint [s]	0.00 - 650.00	1.00	U, T	-	-	Float	2
	Sets ramp-down time for PID s	setpoint.						
Dependency:	P2200 = 1 (PID control is enab PID setpoint changes. P1121 ( after OFF1 and OFF3 respectiv	ramp-down time						
Notice:	Setting the ramp-down time t	oo short can cau	se the converte	er to trip on o	vervoltage F	2/overcur	rent F1.	
r2260	CO: PID setpoint after PID- RFG [%]	-	-	-	-	-	Float	2
	Displays total active PID setpo	int after PID-RFG						
Note:	r2260 = 100 % corresponds							

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2261	PID setpoint filter time constant [s]	0.00 - 60.00	0.00	U, T	-	-	Float	3
	Sets a time constant for smo	othing the PID	setpoint.					
Note:	P2261 = 0 = no smoothing.							
r2262	CO: Filtered PID setpoint after RFG [%]	-	-	-	-	-	Float	3
	Displays filtered PID setpoin and the time constant given	t after PID-RFG. in P2261.	r2262 is the	result of the v	alue in r226	50, filtere	d with F	PT1-Filter
Note:	r2262 = 100 % corresponds	to 4000 hex.						
P2263	PID controller type	0 - 1	0	Т	-	-	U16	3
	Sets the PID controller type.							
	0	D component	on feedback	signal				
	1	D component	on error sigr	nal				
P2264[02]	CI: PID feedback	0 - 4294967295	0	U, T	4000H	CDS	U32	2
	Selects the source of the PID	feedback signa	ıl.	·	•	•		
Setting:	See P2254							
Note:	When analog input is selecter scaling).	ed, offset and ga	ain can be in	plemented us	ing P0756	to P0760	(analog	input
P2265	PID feedback filter time constant [s]	0.00 - 60.00	0.00	U, T	-	-	Float	2
	Defines time constant for PI	D feedback filte	r.					
r2266	CO: PID filtered feedback [%]	-	-	-	-	-	Float	2
	Displays PID feedback signal							
Note:	r2266 = 100 % corresponds	to 4000 hex.						
P2267	Maximum value for PID feedback [%]	-200.00 - 200.00	100.00	U, T	-	-	Float	3
	Sets the upper limit for the	alue of the feed	dback signal.				_	
Notice:	When PID is enabled (P2200	= 1) and the sig	gnal rises abo	ove this value,	the conver	ter will tr	ip with I	F222.
Note:	P2267 = 100 % corresponds	to 4000 hex.						

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P2268	Minimum value for PID feedback [%]	-200.00 - 200.00	0.00	U, T	-	-	Float					
	Sets lower limit for value of	feedback signal.	•	•	•	•	•					
Notice:	When PID is enabled (P2200	0	nal drops bel	ow this value	e, the conve	rter will t	rip with	F221.				
Note:	P2268 = 100 % corresponds						1					
P2269	Gain applied to PID feedback	0.00 - 500.00	100.00	U, T	-	-	Float	3				
	Allows the user to scale the signal has not changed from			value. A gair	n of 100.0 %	means t	hat feed	lback				
P2270	PID feedback function selector	0 - 3	0	U, T	-	-	U16	3				
	Applies mathematical functions to the PID feedback signal, allowing multiplication of the result by P2269.											
	0	Disabled										
	1	Square root (ro	oot(x))									
	2 Square (x*x)											
	3	Cube (x*x*x)										
Notice:	PID transducer type	0 - 1	0	U, T	-	-	U16	2				
	21	PID transducer type     0 - 1     0     U, I     -     -     U16     2       Allows the user to select the transducer type for the PID feedback signal.										
	0											
	1 Inversion of PID feedback signal											
	<ol> <li>Disable the PID function (P2200 = 0).</li> <li>Increase the motor frequency while measuring the feedback signal.</li> <li>If the feedback signal increases with an increase in motor frequency, the PID transducer type should b 0.</li> <li>If the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not the feedback signal decreases with an increase in motor frequency the PID transducer type should be not type should</li></ol>											
	<ol> <li>Increase the motor frequies</li> <li>If the feedback signal inconstruction</li> <li>0.</li> </ol>	ency while mea reases with an i	ncrease in mo	otor frequenc	cy, the PID t		•					
r2272	<ol> <li>Increase the motor frequing</li> <li>If the feedback signal inconstruction</li> <li>If the feedback signal de</li> </ol>	ency while mea reases with an i	ncrease in mo	otor frequenc	cy, the PID t		•	ould be				
r2272	<ol> <li>Increase the motor frequing</li> <li>If the feedback signal incomposition</li> <li>If the feedback signal de set to 1.</li> <li>CO: PID scaled feedback</li> </ol>	ency while mea creases with an i creases with an	ncrease in mo	otor frequenc	cy, the PID t		r type sh	ould be				
	<ol> <li>Increase the motor frequing</li> <li>If the feedback signal incomposition on the feedback signal description of the feedback signal description of the feedback [%]</li> </ol>	ency while mea creases with an i creases with an - signal.	ncrease in mo	otor frequenc	cy, the PID t		r type sh	ould be				
Note:	<ol> <li>Increase the motor frequence</li> <li>If the feedback signal inconstruction</li> <li>If the feedback signal destruction</li> </ol>	ency while mea creases with an i creases with an - signal.	ncrease in mo	otor frequenc	cy, the PID t		r type sh	2				
Note:	<ol> <li>Increase the motor frequence</li> <li>If the feedback signal incomposition</li> <li>If the feedback signal destrict to 1.</li> <li>CO: PID scaled feedback</li> <li>[%]</li> <li>Displays PID scaled feedback</li> <li>r2272 = 100 % corresponds</li> </ol>	reases with an increases with an increase with an increases with a	increase in mo	otor frequend	cy, the PID t cy the PID t -		r type sh	2				
<b>Note:</b> r2273	<ul> <li>2. Increase the motor frequence of the feedback signal incomposition of the feedback signal description of the feedback signal description of the feedback signal description of the feedback [%]</li> <li>Displays PID scaled feedback r2272 = 100 % corresponds</li> <li>CO: PID error [%]</li> </ul>	ency while mea creases with an i creases with an creases with an crease with an crease with an creases with an crease with an cre	increase in mo	otor frequend	cy, the PID t cy the PID t -		r type sh	2				
Note: r2273 Note:	<ul> <li>2. Increase the motor frequence of the feedback signal incomposition of the feedback signal designal d</li></ul>	ency while mea creases with an i creases with an creases with an crease with an crease with an creases with an crease with an cre	increase in mo	otor frequend	cy, the PID t cy the PID t -		r type sh	2 2 2				
Note: r2273 Note:	<ul> <li>2. Increase the motor frequence of the feedback signal incomposition of the feedback signal destination of the feedback sis sis signal destination</li></ul>	ency while mea creases with an in creases with an creases with an - - c signal. to 4000 hex. - e) signal betwee to 4000 hex. 0.000 -	ncrease in mo increase in m - - n setpoint an	otor frequend otor frequen - - d feedback s	cy, the PID t cy the PID t -		r type sh Float	2 2 2				
Note: r2273 Note:	<ol> <li>Increase the motor frequence</li> <li>If the feedback signal incomposition on the feedback signal destination on the feedback sis sincluste</li></ol>	ency while mea creases with an in creases with an in creases with an - - to 4000 hex. - e) signal betwee to 4000 hex. 0.000 - 60.000	ncrease in me increase in m - - n setpoint an 0.000	otor frequend otor frequend - d feedback s	cy the PID t cy the PID t - ignals.		r type sh Float	2 2 2				
r2272 Note: r2273 Note: P2274 P2280	<ul> <li>2. Increase the motor frequence.</li> <li>3. If the feedback signal incomposition on the feedback signal destination on the feedback signal destination.</li> <li>4. If the feedback signal destination on the feedback signal destination on the feedback set to 1.</li> <li>CO: PID scaled feedback [%]</li> <li>Displays PID scaled feedback r2272 = 100 % corresponds</li> <li>CO: PID error [%]</li> <li>Displays PID error (difference r2273 = 100 % corresponds</li> <li>PID derivative time [s]</li> <li>Sets PID derivative time.</li> </ul>	ency while mea creases with an in creases with an in creases with an - - to 4000 hex. - e) signal betwee to 4000 hex. 0.000 - 60.000	ncrease in me increase in m - - n setpoint an 0.000	otor frequend otor frequend - d feedback s	cy the PID t cy the PID t - ignals.		r type sh Float	2 2 2 2				
Note: r2273 Note: P2274	<ul> <li>2. Increase the motor frequence.</li> <li>3. If the feedback signal incomposition on the feedback signal destination on the feedback sis sinclustes</li></ul>	reacy while mea creases with an in creases with an in creases with an - - - - - - - - - - - - - - - - - - -	ncrease in me increase in m - - n setpoint an 0.000 e any effect ( 3.000 ontroller. The	otor frequence otor frequence - d feedback s U, T it applies a g U, T e PID controll	cy, the PID t cy the PID t - ignals. - ain of 1). -	ransducei	Float Float Float	2 2 2 2				
Note: r2273 Note: P2274	<ul> <li>2. Increase the motor frequence.</li> <li>3. If the feedback signal incomposition on the feedback signal destination of the feedback sis sinclusted</li></ul>	rency while mea creases with an in creases with an in crease with an	ncrease in me increase in m - - n setpoint an 0.000 e any effect ( 3.000 ontroller. The h P and I tern	otor frequence otor frequence - d feedback s U, T U, T it applies a g U, T e PID controll 15.	cy, the PID t cy the PID t - ignals. - ain of 1). - er is implen	ransducei	Float Float Float	2 2 2 2				
Note: r2273 Note: P2274 P2280	<ul> <li>2. Increase the motor frequence.</li> <li>3. If the feedback signal incomposition on the feedback signal destination on the feedback signal destination.</li> <li>4. If the feedback signal destination on the feedback signal destination of the feedback s</li></ul>	reases with an increases with an increase with an increases with an increase with an increases with an increases with an increases with an increase with an incr	ncrease in me increase in me - - - - 0.000 e any effect ( 3.000 ontroller. The h P and I term s on the squa	otor frequend otor frequend - - d feedback s U, T U, T it applies a g U, T e PID controll ns. re of the error	cy, the PID t cy the PID t - ignals. - ain of 1). - er is implen or signal.	ransducer	Float Float Float	2 2 2 2				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2285	PID integral time [s]	0.000 - 60.000	0.000	U, T	-	-	Float	2
	Sets integral time constant for	or PID controller						
Note:	See P2280							
P2291	PID output upper limit [%]	-200.00 - 200.00	100.00	U, T	-	-	Float	2
	Sets upper limit for PID contr	oller output						
Dependency:	If f_max (P1082) is greater the limit) must be changed to ac		rence frequer	ncy), either P	2000 or P22	291 (PID o	output u	ipper
Note:	P2291 = 100 % corresponds	to 4000 hex (as	defined by P	2000 (referer	nce frequen	cy)).		
P2292	PID output lower limit [%]	-200.00 - 200.00	0.00	U, T	-	-	Float	2
	Sets lower limit for the PID c	ontroller output						
Dependency:	A negative value allows bipo	lar operation of	PID controlle	r.				
Note:	P2292 = 100 % corresponds	to 4000 hex.						
P2293	Ramp-up/-down time of PID limit [s]	0.00 - 100.00	1.00	U, T	-	-	Float	3
							output u	
Note:	limit) and P2292 (PID output PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp-	lower limit). Lir arted. Once the imes are used w d, the converter	nits prevent l limits have be henever a RL	arge step cha een reached, IN command	inges appea the PID con is issued.	aring on t troller ou	he outp tput is	ut of the
<b>Note:</b> r2294	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue	lower limit). Lir arted. Once the imes are used w d, the converter	nits prevent l limits have be henever a RL	arge step cha een reached, IN command	inges appea the PID con is issued.	aring on t troller ou	he outp tput is	ut of the down
	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp-	lower limit). Lir arted. Once the imes are used w d, the converter	nits prevent l limits have be henever a RL	arge step cha een reached, IN command iency ramps	anges appea the PID con is issued. down as set	aring on t troller ou	he outp tput is I (ramp-	ut of the down
	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b>	lower limit). Lir arted. Once the imes are used w d, the converter down time).	nits prevent l limits have be henever a RL	arge step cha een reached, IN command iency ramps	anges appea the PID con is issued. down as set	aring on t troller ou	he outp tput is I (ramp-	ut of the down
r2294	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output.	lower limit). Lir arted. Once the imes are used w d, the converter down time). - -	nits prevent l limits have be henever a RL	arge step cha een reached, IN command iency ramps	anges appea the PID con is issued. down as set	aring on t troller ou	he outp tput is I (ramp-	down
r2294 Note:	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output. r2294 = 100 % corresponds	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent l limits have be henever a RL output frequ -	arge step cha een reached, JN command Jency ramps - U, T	anges appea the PID con is issued. down as set	in P1121	he outp tput is I (ramp- Float Float	down 2 3
r2294 Note:	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output. r2294 = 100 % corresponds t <b>Gain applied to PID output</b> Allows the user to scale the P	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent l limits have be henever a RL output frequ - 100.00 percentage va	arge step cha een reached, JN command Jency ramps - - U, T Jue. A gain o	anges appea the PID con is issued. down as set - - f 100.0 % n	in P1121	he outp tput is I (ramp- Float Float t outpu	down 2 3 t signal
r2294 Note: P2295	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output. r2294 = 100 % corresponds t <b>Gain applied to PID output</b> Allows the user to scale the P has not changed from its def	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent l limits have be henever a RL output frequ - 100.00 percentage va	arge step cha een reached, JN command Jency ramps - - U, T Jue. A gain o	anges appea the PID con is issued. down as set - - f 100.0 % n	in P1121	he outp tput is I (ramp- Float Float t outpu	down 2 3 t signal
r2294 Note: P2295 Note:	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output. r2294 = 100 % corresponds t <b>Gain applied to PID output</b> Allows the user to scale the P has not changed from its def The ramp rate applied by the	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent I limits have be henever a RL output frequ - 100.00 percentage va	arge step cha een reached, JN command Jency ramps - - U, T Jue. A gain o	anges appea the PID con is issued. down as set - - f 100.0 % n	in P1121	he outp tput is I (ramp- Float Float t outpur conver	down 2 3 t signal ter.
r2294 Note: P2295 Note:	PID when the converter is sta instantaneous. These ramp t If an OFF1 or OFF 3 are issue time) or P1135 (OFF3 ramp- <b>CO: Actual PID output [%]</b> Displays PID output. r2294 = 100 % corresponds <b>Gain applied to PID output</b> Allows the user to scale the P has not changed from its def The ramp rate applied by the <b>CO/BO: PID status word</b>	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent I limits have be henever a RL output frequ - 100.00 percentage va	arge step cha een reached, JN command Jency ramps - - U, T Jue. A gain o	anges appea the PID con is issued. down as set - - f 100.0 % n	in P1121	he outp tput is I (ramp- Float Float t outpur conver	down 2 3 t signal ter. 3
r2294 Note: P2295 Note:	<ul> <li>PID when the converter is stainstantaneous. These ramp to instantaneous. These ramp to instantaneous. These ramp to instantaneous. These ramp to iterate the instantaneous of the correspondent of the ramp rate applied by the co/BO: PID status word.</li> </ul>	lower limit). Lir arted. Once the imes are used w d, the converter down time). - - - - - - - - - - - - - - - - - - -	nits prevent I limits have be henever a RL output frequ - 100.00 percentage va	arge step cha een reached, JN command Jency ramps - - U, T Jue. A gain o	anges appea the PID con is issued. down as set - - f 100.0 % n - /100% to pr -	in P1121	he outp tput is I (ramp- Float Float t output conver U16	down 2 3 t signal ter. 3

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2350	PID autotune enable	0 - 4	0	U, T	-	-	U16	2
	Enables autotune function o	f PID controller.						
	0	PID autotuning	g disabled					
	1	PID autotuning	g via Ziegler N	lichols (ZN) s	tandard			
	2	PID autotuning	g as 1 plus sor	ne overshoot	t (O/S)			
	3	PID autotuning	g as 2 little or	no overshoo	t (O/S)			
	4	PID autotuning	g PI only, quar	rter damped i	response			
Dependency:	Active when PID loop is enab	led (see P2200)	•					
Note:	<ul> <li>P2350 = 1 This is the standard Ziegl</li> </ul>	er Nichols (ZN)	tuning which	should be a d	quarter dam	ped resp	onse to	a step.
	<ul> <li>P2350 = 2         This tuning will give som     </li> <li>P2350 = 3         This tuning should give lively and the selected degrees and the selected degrees and the selected degrees and the selected.     </li> <li>The tuning procedure is the selected.</li> </ul>	ttle or no oversl values of P and pends on the ap response is des en option 3 is th same for all opti	noot but will r I and should plication but ired option 2 e choice. For ons. It is just f	not be as fast be a quarter broadly spea should be se cases where the calculatic	as option 2 damped res king option lected. no D term is	ponse. 1 will giv s wanted	then op	otion 4
P2354	After autotune this paramete		autotune con 240	npleted). U, T	-		1116	3
r2004	PID tuning timeout length [s]	60 - 65000	240	υ, ι	-	-	U16	3
	This parameter determines the oscillation has been obtained		autotuning c	ode will wait	before abo	rting a tu	ning ru	n if no
P2355	PID tuning offset [%]	0.00 - 20.00	5.00	U, T	-	-	Float	3
	Sets applied offset and devia	tion for PID auto	otuning.					
Note:	This can be varied depending larger value.	g on plant condi	tions e.g. a ve	ery long syste	em time con	stant mig	ght requ	iire a

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level					
P2360[02]	Enable cavitation protection	0 - 2	0	U, T	-	DDS	U16	2					
	Cavitation protection enable	ed.											
	Will generate a fault/warning		ation conditions	are deemed t	o be preser	nt.							
		Scaled			·								
	Feedback flow / feedb pressure sensor	Dack [%]	•										
		1 Threshold 200.00 [%]	<										
					Cavitatio	n protectio	on delay						
	P2361	(40.00)											
	Statusword 2 bit 10 PID minimum limit reached         0 65000 [s]           P2362 (30)												
	R53.10												
	Statusword 2 bit 11 PID maximum limit												
	reached ≥1 → ∝												
	Statusword1 bit 2 PID converter running												
	R52.02	R52.02											
	PID enable / d	lisable		>									
		-											
	P2200.CDS ≥ (0)	j											
	Cavitation	n protection en	<sup>able</sup>										
		02 P2360 (0)											
			Cavita	ation protection	disabled	• 00 <b>、</b>							
				r cavitation faul									
				r cavitation war									
	Not used												
	Cavitation Protection Logic Diagram												
	0	Disable											
	1	Fault											
	2	Warn											
2361[02]	Cavitation threshold [%]	0.00 - 200.	00 40.00	U, T	_	DDS	Float	2					
	Feedback threshold over wh				ntage (%)	1000	ilout	-					
2362[02]	Cavitation protection time		30	U, T		DDS	U16	2					
2302[02]	[s]							2					
	The time for which cavitatio	n conditions	have to be pres		ault/warning	g is trigge	ered.	1					
2365[02]	Hibernation enable/disable	0 - 2	0	U, T	-	DDS	U16	2					
	Select or disable the hiberna	tion function	nality.										
	0	Disabled											
	1	Frequency wakeup tric	hibernation (Th gger. You can u	e converter us se P2366 and	ses the frequences the frequencies of the second seco	uency set	point as his fund	the tion.)					
	wakeup trigger. You can use P2366 and P2367 to configure this function.)           2         PID hibernation (The converter uses the PID error as the wakeup trigger. You can use P2390, P2391, and P2392 to configure this function.)												

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level					
P2366[02]	Delay before stopping motor [s]	0 - 254	5	U, T	-	DDS	U16	3					
	With hibernation enabled. If seconds before the converte	the frequence r is stopped.	y demand drop	s below the th	nreshold the	ere is a de	elay of P	2366					
P2367[02]	Delay before starting motor [s]	0 - 254	2	U, T	-	DDS	U16	3					
	With hibernation enabled. If frequency demand has incre seconds before the converte	ased to above	een disabled b the hibernatio	by the unit goi on threshold, t	ng into hibe there will be	ernation, e a delay	and the of P236	7					
P2370[02]	Motor staging stop mode	0-1 0 T - DDS U16 3											
	Selects stop mode for extern	al motors when motor staging is in use.											
	0	Normal stop	)	-									
	1	Sequence st											
P2371[02]	Motor staging configuration	0 - 3	0	Т	-	DDS	U16	3					
	Selects configuration of external motors (M1, M2) used for motor staging feature.												
	O         Motor staging disabled												
	1	Motor staging disabled M1 = 1 x MV, M2 = Not fitted											
	2	$M1 = 1 \times M$	/, M2 = 1 x MV										
	3	$M1 = 1 \times MV, M2 = 2 \times MV$											
Caution:	For this kind of motor applic			ble negative fr	reauencv se	tpoint!							
	Motor staging allows the consystem. The complete system consists controlled from contactors of The contactors or motor state The diagram below shows a A similar system could be seen Mains Converter	ts of one pum or motor starte ter are contro typical pump t up using fan	p controlled by ers. Illed by outputs ing system.	the converte	r with up to overter. umps and pi	2 furthe							
		starters			nput								

Parameter	Function		Ran	-	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level					
	D		- +			3		set	type	Level					
	By default th				0	•									
	In the text b		-												
	MV - Variabl	•			otor)										
	M1 - Motor		-	•											
	M2 - Motor	switched w	ith digital o	output 2											
	Staging: The	e process o	f starting o	ne of the fix	ed speed m	otors.									
	De-staging:	The proces	s of stoppi	ng one of th	e fixed spee	d motors.									
	When the co is required,	onverter is the conver	running at ter switche	maximum f s on (stages	requency, ar ;) one of the	nd the PID fe digital outp	edback ind ut controlle	icates that d motors	t a highe M1 and	er speed M2.					
		At the same time, to keep the controlled variable as constant as possible, the converter must ramp down minimum frequency.													
	Therefore, during the staging process, PID control must be suspended (see P2378 and diagram below)														
	Staging of external motors (M1, M2) Switch-on														
	Staying of e	1	2.	<b>2)</b> 3.	Λ	5.	6. 5v								
			<u> </u>		7.	<u>ч</u> .	<u>Ч</u> .	<del>7.</del> ►t							
	P2371 = 0		-	-	-	-	-	-							
	1	- M' - M'		M1 M1+M2	M1 M1+M2	M1 M1+M2	M1 M1+M2	M1 M1+M2							
	3	- M		M1+M2	M1+M2	M1+M2	M1+M2	M1+M2							
	When the co required, th In this case, control (see	e converter the conver P2378 and	switches o ter must ra I diagram b	off (de-stage imp from m eelow).	es) one of th	e digital out	aximum free	quency ou							
	required, th In this case,	e converter the conver P2378 and	switches o ter must ra I diagram b	off (de-stage imp from m eelow).	es) one of th	e digital out	aximum free	quency ou vitch-off							
	required, th In this case, control (see	e converter the conver P2378 and	switches o ter must ra I diagram b	off (de-stage imp from m eelow).	es) one of th inimum freq	e digital out uency to ma	aximum free Sv	quency ou							
	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1	e converter the conver P2378 and of external r 	switches c ter must ra l diagram b notors (M1, <u>1</u> . - -	off (de-stage imp from m eelow).	es) one of th inimum freq	e digital out uency to ma	aximum free Sv	quency ou vitch-off							
	required, th In this case, control (see <b>Destaging o</b> P2371 = 0	e converter the conver P2378 and of external r	switches o ter must ra I diagram b	off (de-stage imp from m eelow).	es) one of th inimum freq	e digital out uency to ma	aximum free Sv	quency ou vitch-off							
·2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2	e converter the conver P2378 and of external r - M1 M1+M2 M1+M2	r switches of ter must ra l diagram b notors (M1, 1. - - - - M1 M2	off (de-stage imp from m ielow). <b>M2)</b> 2. - - - - M1	es) one of th inimum freq	e digital out uency to ma	aximum free Sv	quency ou vitch-off							
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stag</b>	e converter the conver P2378 and of external r - M1 M1+M2 M1+M2 ing cycling	switches of ter must ra diagram b notors (M1, 1. - - - - M1 M2 0	off (de-stage imp from m ielow). <b>M2)</b> 2. - - - M1	as) one of th inimum freq 3. 4.   0	e digital out juency to ma 5. - - - - -	aximum free Sv	quency ou /itch-off 7.→t - - -	tside of	PID					
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot	e converter the converter P2378 and of external r 	switches of ter must ra l diagram b notors (M1, 1. 1. 2 3 4 1 1. 2 4 5 7 6 7 7 7 7 7 7 8 7 8 7 8 7 8 7 8 7 8 7	off (de-stage imp from m ielow). <b>M2)</b> 2. - - - - - - - - - - - - - - - - - -	<ul> <li>a) one of th</li> <li>inimum freq</li> <li>a</li> <li>4.</li> <li>a</li> <li>a</li></ul>	e digital out uency to ma <u>5.</u> - - - - - - - - - - - - - - - - - - -	Aximum free Sv 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS n counter	U16	PID 3 When					
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the	e converter the converter P2378 and of external r - M1 M1+M2 M1+M2 ing cycling ed, the mo motor with f. ptors are di	r switches of ter must ra l diagram b notors (M1, 1. - - - - - M1 M2 for the mot tor selected n the least	off (de-stage imp from m velow). <b>M2)</b> 2. - - - - - - - - - - - - - - - - - -	3. 4. 3. 4. 3. 4. 4. 5. 6. 6. 7. 6. 7. 6. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	6. - - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS in counter or with m	U16 V2380. ost hour	PID 3 When s is					
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot	e converter the converter P2378 and of external r - M1 M1+M2 M1+M2 ing cycling ed, the mo motor with f. ptors are di	switches of ter must ra l diagram b notors (M1, 1. - - - - M1 M2 0 - 7 for the mot tor selected n the least fferent size n hours rur	off (de-stage imp from m velow). <b>M2)</b> 2. - - - - - - - - - - - - - - - - - -	3. 4. 3. 4. 3. 4. 4. 5. 6. 6. 7. 6. 7. 6. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	6. - - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS in counter or with m	U16 V2380. ost hour	PID 3 When s is					
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still	e converter the converter P2378 and of external r - M1 M1+M2 M1+M2 ing cycling ed, the mo motor with f. ptors are di	r switches of ter must rai l diagram b notors (M1, 1. - - - M1 M2 0 for the mot tor selected n the least fferent size n hours run Disa	off (de-stage imp from m ielow). <b>M2)</b> 2. - - - M1 tor staging f d for staging f d for staging f s the choice n.	3. 4. 3. 4. 3. 4. 4. 5. 6. 6. 7. 6. 7. 6. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	6. - - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS in counter or with m	U16 V2380. ost hour	PID 3 When s is					
	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still	e converter the conver P2378 and of external r M1 M1+M2 M1+M2 tor cycling tor cycling ed, the mo motor with f. ptors are dir a choice, o	switches of ter must rail diagram b notors (M1, 1. - - - - - - - - - - - - - - - - - -	off (de-stage imp from m ielow). <b>M2)</b> 2. - - - - - - - - - - - - - - - - - -	3. 4. 3. 4. 3. 4. 4. 5. 6. 6. 7. 6. 7. 6. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	6. - - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - DDS In counter or with m motor size	U16 V2380. ost hour	9D When s is en if					
P2372[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still 0 1 <b>Motor stagi</b>	e converter the converter P2378 and of external r - M1 M1+M2 M1+M2 ing cycling led, the mo motor with f. otors are dir a choice, o ing hystere	r switches of ter must rai l diagram b notors (M1, 1. - - - - M1 M2 0 - 7 for the mot tor selected n the least fferent size n hours rur Disa Ena esis 0.0	off (de-stage imp from m below). <b>M2)</b> 2. - - M1 1 cor staging f d for staging f d for staging f cor staging f bled bled - - - - - - - - - - - - -	<ul> <li>a) one of the inimum frequencies of the inimum frequencies of the inimum frequencies of the initial structure of</li></ul>	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	Aximum free Sv 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS or with m motor size	U16 P2380. ost hour e, and th Float	PID 3 When s is en if 3					
2373[02]	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot Staging, the switched off If staged mot there is still 0 1 <b>Motor stagi</b> [%]	e converter the converter P2378 and of external r 	switches of ter must rai diagram b notors (M1, 1. - - - M1 M2 for the mot tor selected n the least fferent size n hours run Disa esis 0.0 of PID setp	off (de-stage imp from m relow). <b>M2)</b> 2. - - M1 1 cor staging f d for staging f d for staging f d for staging f bled bled - 200.0 point that Pl	<ul> <li>a) one of the inimum frequencies of the inimum frequencies of the inimum frequencies of the initial of</li></ul>	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	Aximum free Sv 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - - DDS or with m motor size - DDS fore stagin	U16 P2380. ost hour e, and th Float	PID 3 When s is en if 3					
22373[02] Note:	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still 0 1 <b>Motor stagi</b> [%] P2373 as a p The value of	e converter the conver P2378 and of external r M1 M1+M2 M1+M2 ing cycling tor cycling ed, the mo motor with f. otors are dir a choice, o ing hystere percentage f this paran	switches of ter must ra l diagram b notors (M1, 1. - - - M1 M2 for the mot tor selected n the least fferent size n hours run Disa Ena esis 0.0 of PID setp	off (de-stage imp from m relow). <b>M2)</b> 2. - M1 - - - - - - - - - - - - -	<ul> <li>a) one of the inimum frequencies of the inimum frequencies of the inimum frequencies of the inimum frequencies of the initial of</li></ul>	e digital out juency to ma 5. - - - - - - - - - - - - - - - - - -	Aximum free Sv 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - DDS or with m motor size - DDS fore stagir imer P237	U16 • P2380. ost hour e, and th Float ng delay 77.	PID 3 When s is len if 3 starts.					
	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still 0 1 <b>Motor stagi</b> [%] P2373 as a p The value of <b>Motor stagi</b>	e converter the conver P2378 and of external r M1 M1+M2 M1+M2 ing cycling tor cycling ed, the mo motor with f. otors are dir a choice, o ing hyster percentage f this paran ing delay [	switches of ter must ra l diagram b notors (M1, 1. - - - - - - - - - - - - - - - - - -	off (de-stage imp from m ielow). <b>M2)</b> 2. - M1 - - - - - - - - - - - - -	<ul> <li>a) one of the inimum frequencies of the inimum frequencies of the inimum frequencies of the inimum frequencies of the initial of the</li></ul>	e digital out uency to ma 5. - - - - - - - - - - - - - - - - - -	Aximum free Sw 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - DDS or with m motor size fore stagin imer P237 DDS	U16 • P2380. ost hour e, and th Float ng delay 7. U16	PID 3 When s is en if 3					
22373[02] Note:	required, th In this case, control (see <b>Destaging o</b> P2371 = 0 1 2 3 <b>Motor stagi</b> Enables mot When enabl staging, the switched off If staged mot there is still 0 1 <b>Motor stagi</b> [%] P2373 as a p The value of <b>Motor stagi</b>	e converter the converter P2378 and of external r - M1 M1+M2 M1+M2 ing cycling tor cycling ed, the mo of motor with f. otors are dir a choice, o ing hyster percentage f this paran ing delay [ D error r22	r switches of ter must rai diagram b notors (M1, 1. - - - - - - - - - - - - - - - - - -	off (de-stage imp from m below). <b>M2)</b> 2. - - M1 1 cor staging f d for staging f d for staging f d for staging f d for staging f bled bled - 200.0 point that Pl always be s 550 sceed motor	<ul> <li>a) one of the inimum frequencies of the inimum frequencies of the inimum frequencies of the inimum frequencies of the initial of</li></ul>	e digital out uency to ma 5. - - - - - - - - - - - - - - - - - -	Aximum free Sw 6. - - - - - - - - - - - - - - - - - -	quency ou vitch-off 7.→t - DDS or with m motor size fore stagin imer P237 DDS	U16 • P2380. ost hour e, and th Float ng delay 7. U16	PID 3 When s is len if 3 starts.					

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P2376[02]	Motor staging delay override [%]	0.0 - 200.0	25.0	U, T	PERCENT	DDS	Float	3				
	P2376 as a percentage of PII staged/destaged irrespective	e of the delay ti	mers.			ie, a mot	or is					
Note:	The value of this parameter	Į.	larger than s	taging hyster	esis P2373.	1	- 1					
P2377[02]	Motor staging lockout timer [s]	0 - 650	30	U, T	-	DDS	U16	3				
	Time for which delay override is prevented after a motor has been staged or destaged. This prevents a second staging event immediately after a first, being caused by the transient conditions after the first staging event.											
P2378[02]	CO: Motor staging frequency f_st [%]	0.0 - 120.0	50.0	U, T	PERCENT	DDS	Float	3				
	This is illustrated by the follo Staging: P1082 f set P1082 P1082 P2378 DP1082 P2373 APID	a agrams		← P1121 -								

Parameter list

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
	P10 -P23 r23 Bit 01 Bit 00 Condition fo	f 78 6 6 78 6 78 6 78 6 78 6 78 78 78 78 78 78 78 79 77 77 77 77 77 77 77 77 77			Changed Changed Changed Control (Control (Contro) (Contro)		set	type	Level
	(b) A	act ≤ P1080 APID ≤ -P2373 a(b) > P2375		( 10	0 P1082)				
r2379 0 1	© t	00	-	-	-	-	-	U16	3
r2379.01	© t CO/BO: Mot status word	tor staging d	-	-	-	-	-	U16	3
r2379.01	© t CO/BO: Mor status word Output wor	t <b>or staging</b> d d from the moto	- r staging feature	- that allows	- external conn		- De made.		
r2379.01	© to	tor staging d from the moto Signal name		- that allows	- external conn	1 signal	- be made.	0 sigr	
r2379.01	© to	t <b>or staging</b> d d from the moto		- that allows	- external conn	<b>1 signal</b> Yes	- be made.		
r2379.01	© to	tor staging d from the moto Signal name		- that allows	external conn	1 signal	- be made.	0 sigr	al
r2379.01	© to	tor staging d from the moto Signal name Start motor 1		- that allows 0.0	- external conn	<b>1 signal</b> Yes	e made.	0 sigr	
	© to CO/BO: Mot status word Output word Bit 00 01 01 Motor stag [h]	tor staging d from the moto Signal name Start motor 1 Start motor 2 ing hours run	r staging feature	0.0	U, T	1 signal Yes Yes -	-	0 sigr No No Float	al 3
P2380[02]	© to	tor staging d from the moto Signal name Start motor 1 Start motor 2 ing hours run	0.0 - 429496720.0	0.0	U, T	1 signal Yes Yes -	-	0 sigr No No Float	al 3
P2380[02]	© to the status word status word Output word Bit 00 01 01 00 01 01 00 01 00 01 00 01 00 01 00 01 00 00	tor staging d from the moto Signal name Start motor 1 Start motor 2 ing hours run urs run for extern ==> 6 min	0.0 - 429496720.0	0.0	U, T	1 signal Yes Yes -	-	0 sigr No No Float	al 3
P2380[02] Example:	© to CO/BO: Moti- status word Output word Bit 00 01 Motor stag [h] Displays hour ignored. P2380 = 0.1 60 min = 1	tor staging d from the moto Signal name Start motor 1 Start motor 2 ing hours run urs run for extern ==> 6 min	0.0 - 429496720.0 nal motors. To re	0.0 set the runn	U, T	1 signal Yes Yes -	-	0 sigr No No Float	al 3
P2380[02]	© to the status word status word Output word Bit 00 01 01 00 01 01 00 01 00 01 00 01 00 01 00 01 00 00	tor staging d from the moto Signal name Start motor 1 Start motor 2 ing hours run urs run for extern ==> 6 min	0.0 - 429496720.0	0.0 set the runn	U, T	1 signal Yes Yes -	-	0 sigr No No Float	al 3

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level	
P2390	PID hiberna [%]	ition setpoint	-200.00 - 200.00	0	U, T	-	-	Float	3	
	The PID hibe	ernation setpoint	P2390 is a per	centage of the	rated motor	frequency I	P0310.			
	setpoint P23	alue of P2365 is s 390, the PID hibe er is ramped dow	ernation timer P	2391 is started	d. When the F	יD hibernat				
Notice:	converter is	tion is an added t running at low s together with st	etpoint. Note th							
Note:	should be g	PID hibernation setpoint is 0, the PID hibernation function is disabled. The PID hibernation setpoint nould be greater than the minimum frequency (P1080). Reverse operation is not allowed with the PID ibernation mode.								
P2391	PID hiberna	ition timer [s]	0 - 254	0	Т	-	-	U16	3	
	When the Pl PID hibernat	D hibernation tir tion mode.	mer P2391 has	expired, the co	onverter is rai	mped down	to stop a	nd ente	ers the	
P2392	PID hiberna setpoint [%	ition restart ]	-200.00 - 200.00	0	Т	-	-	Float	3	
		hibernation mo oint P2392, the								
r2399	CO/BO: PID status word	hibernation I	-	0	-	-	-	U16	3	
	Displays PID	hibernation stat	us word.							
	Bit	Signal name				1 signal		0 signal		
	Bit 00	Not used				Yes		No		
	Bit 01		n enabled (PID h s not in PID hibe		enabled and	Yes		No		
	Bit 02		tive (PID hibern PID hibernation		ed and the	d the Yes		No		
P2800	Enable FFB	S	0 - 1	0	U, T	-	-	U16	3	
	Free functio	n blocks (FFB) ar	re enabled in tw	o steps:						
	1. P2800 e	nables all free fu	nction blocks (F	2800 = 1).						
	<ol> <li>P2801 and P2802 respectively, enable each free function block individually. Additionally fast free function blocks can be enabled via P2803 = 1.</li> </ol>								ee	
	0		Disable							
	1		Enable							
Dependency:	All active fu	nction blocks wil	l be calculated	n every 128 m	ns, fast free fi	unction bloo	ks in eve	ry 8 ms		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2801[016]	Activate FFBs	0 - 6	0	U, T	-	-	U16	3
	P2801 and P2802 respective addition, P2801 and P2802 which the free function bloc The following table shows t	determine the chi k will work.	ronological orde	er of each fun	ction block b	y setting	02[x] > the leve	0). In l in
					low	y 2 hig	h	
	Fas	FFBs			Leve		<del></del>	
		03 = 1			Leve	1 5	Priority 1	
					Leve	4	92	
					Leve	a 3 ▼		
					Leve	<u> </u>		
						tive 0		
		<u> </u>	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		mac			
	NF NF NF NF	1231	0 T D 0 T 0	7 10	7 5 3			
	CMP 2 CMP 1 DIV 2 DIV 1 MUL 2 MUL 1 SUB 2 SUB 2 SUB 1	Timer 3 Timer 2 Timer 1 RS-FF 3 RS-FF 2 RS-FF 1	D-FF 2 D-FF 1 NOT 3 NOT 2 NOT 1 XOR 3	XOR 2 XOR 1 OR 3 OR 2 OR 1	AND			
					AA			
	[13] [13] [13] [13] [13] [13] [13] [13]	[1] [16] [16] [17] [16] [17]	[11] [110 [9] [8]	[7] [6] [4] [3]	[2] [2] [2] [2]			
	P2802 [13] P2802 [12] P2802 [11] P2802 [1] P2802 [9] P2802 [9] P2802 [6] P2802 [6] P2802 [6] P2802 [4]	P2802 [2] P2802 [2] P2802 [1] P2801 [16] P2801 [15] P2801 [14]	P2801 [13] P2801 [12] P2801 [11] P2801 [10] P2801 [9] P2801 [9]	P2801   P2801   P2801   P2801   P2801	P2801 P2801 P2801			
	0	Not Active						
	1	Level 1						
	2	Level 2						
	6	Level 6						
Example:	P2801[3] = 2, P2801[4] = 2 FFBs will be calculated in fo			8], P2801[4],	P2802[4]			
Index:	[0]	Enable AND 1						
	[1]	Enable AND 2						
	[2]	Enable AND 3						
	[3]	Enable OR 1						
	[4]	Enable OR 2						
	[5]	Enable OR 3						
	[6]	Enable XOR 1						
	[7]	Enable XOR 2						
	[8]	Enable XOR 3						
	[9]	Enable NOT 1						
	[10]	Enable NOT 2						
	[11]	Enable NOT 3						
	[12]	Enable D-FF 1						
	[13]		Enable D-FF 2					
	[14]	Enable RS-FF						
	[15]	Enable RS-FF 2						
	[16]	Enable RS-FF	3					
Dependency:	Set P2800 to 1 to enable fur All active function blocks wi to 6) will be calculated in ev	ll be calculated in	every 128 ms,	if set to level ´	l to 3. Fast fi	ree functi	on block	s (level

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level						
P2802[013]	Activate FFBs	0 - 3	0	U, T	-	-	U16	3						
	Enables free function blocks P2801.		mines the ch		rder of each	function		-						
	0	Not Active												
	1	Level 1												
	2	Level 2												
	3 Level 3													
ndex:	[0] Enable timer 1													
	[1]													
	[2] Enable timer 3													
	[3] Enable timer 4													
	[4]	Enable ADD 1												
	[5]	Enable ADD 2												
	[6]	Enable ADD 2 Enable SUB 1												
	[7]	Enable SUB 2												
	[8]	Enable MUL 1												
	[9]	Enable MUL 2												
	[10]	Enable DIV 1												
	[11]	Enable DIV 2												
	[12]	Enable CMP 1												
	[13]	Enable CMP 2												
Dependency:	Set P2800 to 1 to enable fun	ction blocks.												
	All active function blocks, en	abled with P28	02, will be cal	culated in ev	ery 128 ms.									
P2803[02]	Enable Fast FFBs	0 - 1	0	U, T	-	CDS	U16	3						
	Fast free function blocks (FF	B) are enabled i	n two steps:											
	1. P2803 enables the use of	f fast free funct	ion blocks (P2	803 = 1).										
	2. P2801 enables each fast (P2801[x] = 4 to 6).	free function bl	ock individual	lly and deterr	mines the cl	nronologi	cal orde	er						
	0	Disable												
	1	Enable												
Dependency:	All active fast function block		ted in every 8	ms.										
Note:	Attention: P2200 and P2803 cannot be active at same tim	are locked para			PID and FFE	B of the s	ame dat	a set						
P2810[01]	BI: AND 1	0 - 4294967295	0	U, T	-	-	U32	3						
	P2810[0], P2810[1] define in	nputs of AND 1	element, outp	P2810[0], P2810[1] define inputs of AND 1 element, output is r2811.										
			element, outp	out is r2811.										
	P2810[0], P2810[1] define in P2800 P2801[0 P2810 P2810 A B C		A         B           0         0           0         1           1         0           1         1	<b>C</b> 0 0 1										
Index:	P2800 P2801[0 P2810 A Index 0 B Index 1 C	2811	A         B           0         0           0         1           1         0           1         1	C 0 0 0										
Index:	P2810 P2810 Index 0 A R C	ı 	A         B           0         0           0         1           1         0           1         1	C 0 0 0										

Parameter	Function			Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r2811.0	BO: AND 1			-	-	-	-	-	U16	3
	Output of A	ND 1 e	lement. D	isplays and logi	c of bits defin	ed in P2810[(	), P2810[1	].		
	Bit	Signa	al name				1 signal	-	0 sigr	nal
	00	Outp	ut of BO				Yes		No	
Dependency:	See P2810	<u> </u>								
P2812[01]	BI: AND 2			0 - 4294967295	0	U, T	-	-	U32	3
	P2812[0], 2	812[1]	define in	puts of AND 2 e	lement, outpi	ut is r2813.				
Index:	See P2810									
Dependency:	P2801[1] as	signs t	he AND el	ement to the p	rocessing sequ	uence.				
r2813.0	BO: AND 2			-	-	-	-	-	U16	3
	Output of A field descrip		lement. D	isplays and logi	c of bits defin	ed in P2812[(	D], P2812[1	]. See r28	311 for	the bit
Dependency:	See P2812									
P2814[01]	BI: AND 3	C 2		0 - 4294967295	0	υ, τ	-	-	U32	3
	P2814[0], P	2814[1	] define i	nputs of AND 3	element, outp	out is r2815.				
Index:	See P2810									
Dependency:	P2801[2] as	signs t	he AND el	ement to the p	ocessing sequ	uence.				
r2815.0	BO: AND 3			-	-	-	-	-	U16	3
	Output of A field descrip		lement. D	isplays and logi	c of bits defin	ed in P2814[(	D], P2814[1	]. See r28	311 for	the bit
Dependency:	See P2814				1	-1	1	1	- <b>r</b>	1
P2816[01]	BI: OR 1			0 - 4294967295	0	U, T	-	-	U32	3
	P2816[0], P	_	define in 1  define in 1  define in 1  define in 2  define in 2  define in	r2817	ement, outpu <b>A B</b> 0 0 1 1 0 1 1 1	<b>C</b> 0 1 1 1				
Index:	See P2810									
Dependency:	P2801[3] as	signs t	he OR ele	ment to the pro	cessing seque	ence.				
r2817.0	BO: OR 1			-	-	-	-	-	U16	3
	Output of O description.		ment. Dis	plays or logic of	bits defined i	in P2816[0], I	P2816[1]. S	ee r2811	for the	bit field
Dependency:	See P2816				T	1		T		
P2818[01]	BI: OR 2			0 - 4294967295	0	U, T	-	-	U32	3
		2818[1	] define i	nputs of OR 2 el	ement, outpu	ıt is r2819.				
Index:	See P2810									
Dependency:	P2801[4] as	signs t	he OR ele	ment to the pro	cessing seque	ence.		1		1
r2819.0	BO: OR 2			-	-	-	-	-	U16	3
	Output of O description.		ment. Dis	plays or logic of	bits defined i	in P2818[0], I	P2818[1]. S	ee r2811	for the	bit field
Dependency:	See P2818									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2820[01]	BI: OR 3	0 - 4294967295	0	U, T	-	-	U32	3
	P2820[0], P2820[1] define i	nputs of OR 3 el	ement, outpu	t is r2821.				
Index:	See P2810							
Dependency:	P2801[5] assigns the OR ele	ment to the prod	cessing seque	nce.				
r2821.0	BO: OR 3	-	-	-	-	-	U16	3
	Output of OR 3 element. Dis description.	plays or logic of	bits defined i	n P2820[0], I	P2820[1]. S	ee r2811	for the	bit field
Dependency:	See P2820							
P2822[01]	BI: XOR 1	0 - 4294967295	0	U, T	-	-	U32	3
	P2822[0], P2822[1] define i	nputs of XOR 1 e	element, outp	out is r2823.				
	P2800 P2801[6] P2822 Index 0 B = 1 C	r2823	A         B           0         0           0         1           1         0           1         1	<b>C</b> 0 1 1 0				
Index:	See P2810							
Dependency:	P2801[6] assigns the XOR e	ement to the pro	ocessing sequ	ience.				
r2823.0	BO: XOR 1	-	-	-	-	-	U16	3
		icolove ovelucivo		ts dofined in	ו נסוכבסכם	22822[1]		
	Output of XOR 1 element. D the bit field description.	ispidys exclusive	or logic of bi	ts defined in	FZ0ZZ[U], I	2022[1].	See r28	811 for
Dependency:	Output of XOR 1 element. D the bit field description. See P2822		-or logic of bi		F2822[U], I		See r28	811 for
<b>Dependency:</b> P2824[01]	the bit field description.	0 - 4294967295		U, T	-	-	U32	311 for
· · ·	the bit field description. See P2822 BI: XOR 2 P2824[0], P2824[1] define i	0 - 4294967295	0	U, T	-	-		I
· · ·	the bit field description. See P2822 BI: XOR 2	0 - 4294967295	0	U, T	-	-		I
P2824[01]	the bit field description. See P2822 BI: XOR 2 P2824[0], P2824[1] define i	0 - 4294967295 nputs of XOR 2 6	0 element, outp	U, T out is r2825.	-	- -		I
P2824[01]	the bit field description. See P2822 BI: XOR 2 P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el BO: XOR 2	0 - 4294967295 nputs of XOR 2 e ement to the pro	0 element, outp ocessing sequ	U, T but is r2825. lence.	-	-	U32 U16	3
P2824[01] Index: Dependency:	the bit field description. See P2822 BI: XOR 2 P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el	0 - 4294967295 nputs of XOR 2 e ement to the pro	0 element, outp ocessing sequ	U, T but is r2825. lence.	-	-	U32 U16	3
P2824[01] Index: Dependency: r2825.0 Dependency:	the bit field description. See P2822 <b>BI: XOR 2</b> P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el <b>BO: XOR 2</b> Output of XOR 2 element. D	0 - 4294967295 nputs of XOR 2 e ement to the pro	0 element, outp ocessing sequ	U, T but is r2825. lence.	-	-	U32 U16	3
P2824[01] Index: Dependency: r2825.0	the bit field description. See P2822 <b>BI: XOR 2</b> P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el <b>BO: XOR 2</b> Output of XOR 2 element. D the bit field description.	0 - 4294967295 nputs of XOR 2 e ement to the pro	0 element, outp ocessing sequ	U, T but is r2825. lence.	-	-	U32 U16	3
P2824[01] Index: Dependency: r2825.0 Dependency:	the bit field description. See P2822 <b>BI: XOR 2</b> P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el <b>BO: XOR 2</b> Output of XOR 2 element. D the bit field description. See P2824	0 - 4294967295 nputs of XOR 2 e ement to the pro - isplays exclusive 0 - 4294967295	0 element, outp ocessing sequ - -or logic of bi	U, T but is r2825. lence. - ts defined in U, T	-  -  P2824[0], F	- - - 2824[1].	U32 U16 See r25	3 3 311 for
P2824[01] Index: Dependency: r2825.0 Dependency:	the bit field description. See P2822 BI: XOR 2 P2824[0], P2824[1] define i See P2810 P2801[7] assigns the XOR el BO: XOR 2 Output of XOR 2 element. D the bit field description. See P2824 BI: XOR 3	0 - 4294967295 nputs of XOR 2 e ement to the pro - isplays exclusive 0 - 4294967295	0 element, outp ocessing sequ - -or logic of bi	U, T but is r2825. lence. - ts defined in U, T	-  -  P2824[0], F	- - - 2824[1].	U32 U16 See r25	3 3 311 for

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r2827.0	BO: XOR 3	-	-	-	-	-	U16	3
	Output of XOR 3 eler the bit field descripti		ys exclusive-o	r logic of bits defir	ied in P2826[0]	, P2826[	1]. See ı	r2811 for
Dependency:	See P2826	-						-
P2828	BI: NOT 1	0 - 4294967 295	0	U, T	-	-	U32	3
	P2828 defines input	of NOT 1 ele	ement, output	is r2829.				
	P2828 A		r2829	A         C           0         1           1         0				
Dependency:	P2801[9] assigns the	NOT eleme	ent to the proc	essing sequence.				
r2829.0	BO: NOT 1	-	-	-	-	-	U16	3
	Output of NOT 1 eler description.	nent. Displa	iys not logic of	bit defined in P28	28. See r2811 1	or the b	it field	
Dependency:	See P2828							
P2830	BI: NOT 2	0 - 4294967 295	0	U, T	-	-	U32	3
	P2830 defines input	of NOT 2 ele	ement, output	is r2831.	<u>.</u>		-	
Dependency:	P2801[10] assigns th	ne NOT elem	nent to the pro	cessing sequence.				
r2831.0	BO: NOT 2	-	-	-	-	-	U16	3
	Output of NOT 2 eler description.	nent. Displa	iys not logic of	bit defined in P28	30. See r2811 1	or the b	it field	
Dependency:	See P2830							
P2832	BI: NOT 3	0 - 4294967 295	0	U, T	-	-	U32	3
	P2832 defines input	of NOT 3 ele	ement, output	is r2833.	-	•		
Dependency:	P2801[11] assigns th	ne NOT elem	nent to the pro	cessing sequence.				
r2833.0	BO: NOT 3	-	-	-	-	-	U16	3
	Output of NOT 3 eler description.	ment. Displa	iys not logic of	bit defined in P28	32. See r2811 1	or the b	it field	
Dependency:	See P2832							

Parameter	Function	Range	Factory default	Can char	be 1ged	Scali	ng	Data set	Data type	Acc. Level									
P2834[03]	BI: D-FF 1	0 - 4294967 295	0	U, T		-		-	U32	3									
	P2834[0], P2834[1],		P2800 P2801		35 <b>RESET</b> 0 1 1 0 0 0	D x x x 1 0	STORE X X X J	Q 1 0 Q <sub>n</sub> 1 0	-1 C	2 0 1 1 0 1									
	POWER-ON 0 1																		
Index:	[0] Binector input: Set																		
	[1] Binector input: D input																		
	[2] Binector input: Store pulse																		
	[3]     Binector input: Reset       P2801[12] assigns the D-FlipFlop to the processing sequence.																		
Dependency:		ie D-FlipFlop	to the proce	ssing se	quence.														
r2835.0	BO: Q D-FF 1 Displays output of D- for the bit field descr	<u> </u> - FlipFlop 1, i iption.	- nputs are def	ined in F	2834[0],	- P2834[1]	], P2834[2	- 2], P28	U16 34[3]. S	3 Gee r281									
Dependency:	See P2834	*																	
r2836.0	BO: NOT-Q D-FF 1	-	-	-		-		-	U16	3									
	Displays Not-output	Displays Not-output of D-FlipFlop 1, inputs are defined in P2834[0], P2834[1], P2834[2], P2834[3]. See r2811 for the bit field description.																	
Dependency:	See P2834																		
P2837[03]	BI: D-FF 2	0 - 4294967 295	0	U, T		-		-	U32	3									
	P2837[0], P2837[1],	P2837[2], F	2837[3] defi	ne input	s of D-Flip	Flop 2, o	utputs are	e r2838	3, r2839										
Index:	See P2834																		
Dependency:	P2801[13] assigns th	e D-FlipFlop	to the proce	ssing se	quence.														
r2838.0	<b>BO: Q D-FF 2</b> U16 3																		
	Displays output of D-	FlipFlop 2, i iption.	nputs are def	ined in F	2837[0],	P2837[1]	], P2837[2	2], P28	Displays output of D-FlipFlop 2, inputs are defined in P2837[0], P2837[1], P2837[2], P2837[3]. See r281 for the bit field description.										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
r2839.0	BO: NOT-Q D-FF 2	-	-	-	-	-	U16	3			
	Displays Not-output o for the bit field descri		2, inputs are de	fined in P2837	0], P2837[1], P2837	[2], P28	37[3]. Se	e r2811			
Dependency:	See P2837										
P2840[01]	BI: RS-FF 1	0 - 42949672 95	0	U, T	-	-	U32	3			
	P2840[0], P2840[1] d	efine inputs	of RS-FlipFlop P2800 P2801[14]	- · ·	2841, r2842.		10				
			TT		SET RESET Q	Q					
	P2840		SET		0 0 Q <sub>n-1</sub>	Qn-1					
	lndex 0		► (Q=1) Q	► <u>12841</u>	0 1 0	1	]				
	) Index 1		DEGET		1 0 1	0	]				
		∟≥1⊦		r2842	1 1 Q <sub>n-1</sub>	Qn-1	1				
	POWER ON				POWER-ON 0	1	]				
Index:	[0]	Binector in	put: Set				-				
	[1] Binector input: Reset										
Dependency:	P2801[14] assigns the	e RS-FlipFlop	to the process	ing sequence.							
r2841.0	BO: Q RS-FF 1	-	-	-	-	-	U16	3			
	Displays output of RS- description.	FlipFlop 1, in	puts are define	ed in P2840[0],	P2840[1]. See r2811	for the	bit field				
Dependency:	See P2840						_				
r2842.0	BO: NOT-Q RS-FF 1	-	-	-	-	-	U16	3			
	Displays Not-output o description.	f RS-FlipFlop	1, inputs are d	efined in P2840	[0], P2840[1]. See r2	811 for	the bit fi	ield			
Dependency:	See P2840										
P2843[01]	BI: RS-FF 2	0 - 42949672 95	0	υ, τ	-	-	U32	3			
	P2843[0], P2843[1] define inputs of RS-FlipFlop 2, outputs are r2844, r2845.										
Index:	See P2840										
Dependency:	P2801[15] assigns the	e RS-FlipFlop	to the process	ing sequence.							
r2844.0	BO: Q RS-FF 2	-	-	-	-	-	U16	3			
	Displays output of RS- description.	FlipFlop 2, in	puts are define	ed in P2843[0],	P2843[1]. See r2811	for the	bit field				
Dependency:	See P2843										
r2845.0	BO: NOT-Q RS-FF 2	-	-	-	-	-	U16	3			
	Displays Not-output o description.	f RS-FlipFlop	2, inputs are d	efined in P2843	[0], P2843[1]. See r2	811 for	the bit fi	ield			
Dependency:	See P2843										
P2846[01]	BI: RS-FF 3	0 - 42949672 95	0	U, T	-	-	U32	3			
			I of DS ElinElon		 2847_r2848	1	1	<u> </u>			
	P2846[0] P2846[1] d	efine innuts	O   K - F   O F   O O								
Index.	P2846[0], P2846[1] d	efine inputs	ог кз-гиргюр.	5, outputs are r.							
	See P2840	·	• •	•							
Dependency:	See P2840 P2801[16] assigns the	·	• •	•	-	-	U16	3			
Index: Dependency: r2847.0	See P2840	e RS-FlipFlop	to the process	ing sequence.	-	- for the	U16 bit field	3			

Parameter	Function	Range	Factory	Can be	Scaling	Data		Acc.				
			default	changed		set	type	Level				
r2848.0	BO: NOT-Q RS-FF 3	-	-	-	-	-	U16	3				
	Displays Not-output of description.	of RS-FlipFlop	3, inputs are o	defined in P2846[(	)], P2846[1]. See	r2811 for	the bit fi	eld				
Dependency:	See P2846											
P2849	BI: Timer 1	0 -	0	U, T	-	-	U32	3				
		42949672 95										
	Define input signal of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r285											
	P2850 (0.000) P2851(0) P2800 P2802 0 Delay Time Mode											
	P2851 = 0 (ON Del P2851 = 1 (OFF Del	P2850										
				< <u>₽2</u>	±850 ► t							
	P2851 = 2 (ON-OF	F Delay)										
		P2850		P2	.850 ► t							
	P2851 = 3 (Pulse			•								
	In F				►t							
	Out	P2850		~	►t							
	In				►t							
	Out	P2850			►t							
	-	P2850										
Dependency:	P2802[0] assigns th	e timer to th	e processing s	sequence.								

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P2850	Delay time of	0.0 - 9999.9	0.0	U, T	-	-	Float	3			
	timer 1 [s]			29E1 are the imp	.ta of the times						
Denendeneu	Defines delay time o		2849, 22850, 2	2851 are the hip	uts of the timer,	outputs	are 1285	2,12803			
Dependency:	See P2849	0 12					1110	2			
P2851	Mode timer 1	0 - 13	0	U, T		-	U16	3			
	Selects mode of time	-	-	are the inputs of	the timer, outpl	its are r <sub>2</sub>	2852, rz	553.			
	0	ON delay									
	- ·	OFF delay	elay (seconds)								
	2		, ,	)							
	3     Pulse generator (seconds)       10     ON delay (minutes)										
	11 OFF delay (minutes)										
	12 ON/OFF delay (minutes)										
	13		erator (minutes)	)							
Dependency:	See P2849	Tuise gene		·)							
r2852.0		_	1_	_	_	-	1116	3			
12052.0	BO: Timer 1U163Displays output of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, r2853. See r2811 for the bit field descriptionU163										
Dependency:	See P2849										
r2853.0	BO: Nout timer 1	-	-	-	-	-	U16	3			
	Displays Not-output r2853. See r2811 fo	put of timer 1. P2849, P2850, P2851 are the inputs of the timer, outputs are r2852, I for the bit field description.									
Dependency:	See P2849		•								
P2854	BI: Timer 2	0 - 4294967 295	0	U, T	-	-	U32	3			
	Define input signal of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r285										
Dependency:	P2802[1] assigns the timer to the processing sequence.										
P2855	Delay time of timer 2 [s]	0.0 - 99999.9	0.0	U, T	-	-	Float	3			
	Defines delay time o	f timer 2. P2	2854, P2855, P	2856 are the inp	uts of the timer,	outputs	are r285	7, r285			
Dependency:	See P2854										
P2856	Mode timer 2	0 - 13	0	U, T	-	-	U16	3			
	Selects mode of time				the timer, outpu	uts are r2	2857, r2	858.			
	See P2851 for value	description.									
Dependency:	See P2854										
r2857.0	BO: Timer 2	-	-	-	-	-	U16	3			
	Displays output of timer 2. P2854, P2855, P2856 are the inputs of the timer, outputs are r2857, r2858. See r2811 for the bit field description.										
Dependency:	See P2854										
r2858.0	BO: Nout timer 2	-	-	-	-	-	U16	3			
	Displays Not-output r2858. See r2811 fo			2856 are the inp	uts of the timer,	outputs	are r28	57,			
Dependency:	See P2854										

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P2859	BI: Timer 3	0 - 4294967 295	0	U, T	-	-	U32	3				
	Define input signal o	Define input signal of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r286										
Dependency:	P2802[2] assigns the	timer to th	e processing s	equence.								
P2860	Delay time of timer 3 [s]	0.0 - 9999.9	0.0	υ, τ	-	-	Float	3				
	Defines delay time of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r286											
Dependency:	See P2859											
P2861	Mode timer 3	0 - 13	0	U, T	-	-	U16	3				
	Selects mode of timer 3. P2859, P2860, P2861 are the inputs of the timer, outputs are r2862, r2863. S P2851 for value description.											
Dependency:	See P2859											
r2862.0	BO: Timer 3	-	-	-	-	-	U16	3				
	Displays output of tir See r2811 for the bit			61 are the input	s of the timer, ou	itputs are	r2862,	r2863.				
Dependency:	See P2859											
r2863.0	BO: Nout timer 3	-	-	-	-	-	U16	3				
	Displays Not-output r2863. See r2811 for			P2861 are the ir	puts of the time	r, outputs	s are r28	62,				
Dependency:	See P2859											
P2864	Bl: Timer 4	0 - 4294967 295	0	U, T	-	-	U32	3				
	Define input signal o P2868.	f timer 4. P2	2864, P2865, I	2866 are the in	puts of the timer	, outputs	are P28	67,				
Dependency:	P2802[3] assigns the	timer to th	e processing s	equence.								
P2865	Delay time of timer 4 [s]	0.0 - 9999.9	0.0	U, T	-	-	Float	3				
	Defines delay time of	timer 4. P2	864, P2865, F	2866 are the inp	outs of the timer,	outputs	are r286	7, r2868				
Dependency:	See P2864											
P2866	Mode timer 4	0 - 13	0	U, T	-	-	U16	3				
	Selects mode of time P2851 for value desc		P2865, P2866	are the inputs o	f the timer, outp	uts are r2	2867, r2	868. See				
Dependency:	See P2864											
r2867.0	BO: Timer 4	-	-	-	-	-	U16	3				
	Displays output of tir See r2811 for the bit			66 are the input	s of the timer, ou	itputs are	r2867,	r2868.				
Dependency:	See P2864											
r2868.0	BO: Nout timer 4	-	-	-	-	-	U16	3				
	Displays Not-output or r2868. See r2811 for			P2866 are the ir	puts of the time	r, output						
Dependency:	See P2864											


Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P2869[01]	CI: ADD 1	0 - 4294967 295	0	U, T	4000H	-	U32	3
	Define inputs of Adde	er 1, result i	s in r2870.		L			
	P2869 Index 0 Index 1	0 P2802[4]	Result r2870	Result = x1+ If: x1 + x2 > 21 x1 + x2 < -2	<b>x2</b> $00\% \rightarrow \text{Result}$ $00\% \rightarrow \text{Result}$	= 200% =- 200%	, 0	
Index:	[0]	Connector	input 0 (Cl 0)					
	[1]	Connector	input 1 (Cl 1)					
Dependency:	P2802[4] assigns the	Adder to th	e processing se	quence.				
r2870	CO: ADD 1	-	-	-	-	-	Float	3
	Result of Adder 1.							
Dependency:	See P2869		1	1	1	•		
P2871[01]	CI: ADD 2	0 - 4294967 295	0	U, T	4000H	-	U32	3
	Define inputs of Adde	er 2, result i	s in r2872.					
Index:	See P2869							
Dependency:	P2802[5] assigns the	Adder to th	e processing se	quence.			-	-
r2872	CO: ADD 2	-	-	-	-	-	Float	3
	Result of Adder 2.							
Dependency:	See P2871		1	1	1	•		
P2873[01]	CI: SUB 1	0 - 4294967 295	0	U, T	4000H	-	U32	3
	Define inputs of Subt	P2802[6]	Result r2874.	Result = x1 - :	<b>x2</b> 00% → Result	= 200%		
		(1-x2		x1 - x2 < -2	00%→ Result	=-200%	, D	
Index:	See P2869							
Dependency:	P2802[6] assigns the	Subtractor	•		Γ	1		-
r2874	CO: SUB 1	-	-	-	-	-	Float	3
Demonstration	Result of Subtractor 1	l <b>.</b>						
Dependency:	See P2873	0	2		400011	1		2
P2875[01]	CI: SUB 2	0 - 4294967 295	0	υ, τ	4000H	-	U32	3
	Define inputs of Subt	ractor 2, res	ult is in r2876.					
Index:	See P2869							
Dependency:	P2802[7] assigns the	Subtractor	to the processin	ig sequence.				

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Leve				
r2876	CO: SUB 2	-	-	-	-	-	Float	3				
12070	Result of Subtractor 2.		I				riout	3				
Dependency:	See P2875											
P2877[01]	CI: MUL 1	0 -	0	U, T	4000H	Τ_	U32	3				
12077[01]		42949672 95		0,1	400011		052	5				
		Define inputs of Multiplier 1, result is in r2878. P2800 P2802[8]										
	$P2877 \qquad $											
	Index 0 Result r2878 If: $\frac{x1*x2}{100\%} > 200\% \rightarrow \text{Result} = 200\%$											
	$\frac{x1*x2}{100\%} - 200\% \to \text{Result} = -200\%$											
Index:	See P2869											
Dependency:	P2802[8] assigns the N	lultiplier to th	e processing seg	uence.								
r2878	CO: MUL 1			_	_	-	Float	3				
12070	Result of Multiplier 1.						Tioat	5				
Dependency:	See P2877											
P2879[01]	CI: MUL 2	0 -	0	U, T	4000H		U32	3				
F2079[01]		42949672	0	0, 1	400011	-	032	2				
		95										
	Define inputs of Multip	lier 2, result i	s in r2880.									
Index:	See P2869											
Dependency:	P2802[9] assigns the M	lultiplier to th	e processing seq	uence.								
r2880	CO: MUL 2	-	-	-	-	-	Float	3				
	Result of Multiplier 2.											
Dependency:	See P2879											
P2881[01]	CI: DIV 1	0 - 42949672	0	U, T	4000H	-	U32	3				
	95 Define inputs of Divider 1, result is in r2882.											
	P2800 P2802[10]											
	X1*100%											
	200%											
	$\begin{array}{c c c c c c c c c c c c c c c c c c c $											
	x1+1	-200%										
	$\frac{\frac{x1*100\%}{x2}}{x2} \qquad \qquad \frac{x1*100\%}{x2} < -200\% \rightarrow \text{Result} = -200\%$											
Index:	See P2869											
Dependency:	P2802[10] assigns the	Divider to the	processing seau	ence.								
r2882	CO: DIV 1	-	-	-	-	-	Float	3				
	Result of Divider 1.		1	•	1							
Dependency:	See P2881											
P2883[01]	CI: DIV 2	0 -	0	U, T	4000H	-	U32	3				
		42949672										
		95	2004									
	Define inputs of Divide	r 2, result is ir	n r2884.									
Index:	See P2869											
Dependency:	P2802[11] assigns the		processing sequ	ence.	1		1					
r2884	CO: DIV 2	-	-	-	-	-	Float	3				
	Result of Divider 2.											
	See P2883											

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level			
P2885[01]	CI: CMP 1	0 - 4294967 295	0	υ, τ	4000H	-	U32	3			
	Defines inputs of Cor	nparator 1,	output is r2886	j.							
	P2885 Index 0 x1 x2	0 P2802[12]		$\begin{array}{l} x1 \geq x2 \ \rightarrow \ Out = 1 \\ x1 < x2 \ \rightarrow \ Out = 0 \end{array}$							
Index:	See P2869										
Dependency:	P2802[12] assigns th	e Comparat	or to the proce	ssing sequence.							
r2886.0	BO: CMP 1	-	-	-	-	-	Float	3			
	Displays result bit of Comparator 1. See r2811 for the bit field description.										
Dependency:	See P2885										
P2887[01]	CI: CMP 2	0 - 4294967 295	0	υ, τ	4000H	-	U32	3			
	Defines inputs of Comparator 2, output is r2888.										
Index:	See P2869										
Dependency:	P2802[13] assigns the Comparator to the processing sequence.										
r2888.0	BO: CMP 2	-	-	-	-	-	U16	3			
	Displays result bit of Comparator 2. See r2811 for the bit field description.										
Dependency:	See P2887			T	1						
P2889	CO: Fixed setpoint 1 in [%]	-200.00 - 200.00	0.00	U, T	-	-	Float	3			
	Fixed percent setting Connector Se P2889 P2890 Range: -200%	tting in %									
P2890	CO: Fixed setpoint 2 in [%]	-200.00 - 200.00	0.00	U, T	-	-	Float	3			
	Fixed percent setting	2.									
P2940	BI: Release wobble function	0 - 4294967 295	0.0	Т	-	-	U32	2			
	Defines the source to release the wobble function.										
P2945	Wobble signal frequency [Hz]	0.001 - 10.000	1.000	Т	-	-	Float	2			
	Sets the frequency of	the wobble	e signal.	•		·	•				

Parameter	Function		Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
P2946	Wobble signa amplitude [%		0.000 - 0.200	0.000	Т	-	-	Float	2		
	Sets the value generator (RF output. For example,	e for the am G) output. T if the RFG o	The value of I utput is 10 H	P2946 is mu	nal as a proport Itiplied by the o 6 has a value of	utput value of 0.100, the w	the RFG	then ac	lded to Ri blitude wi		
P2947	be 0.100 * 10 Wobble signa decrement st	al	s means that 0.000 - 1.000	the RFG ou 0.000	tput will therefo	re wobble be	ween 9	Hz and <sup>•</sup> Float	11 Hz. 2		
	Sets the value for decrement step at the end of the positive signal period. The amplitude of the step is dependent upon the signal amplitude as follows: Amplitude of signal decrement step = P2947 * P2946										
P2948	Wobble signation	al	0.000 - 1.000	0.000	T	-	-	Float	2		
	Sets the value increment ste Amplitude of	p is depend	ent upon the	e signal amp	f the negative si litude as follows	gnal period. T	he ampli	tude of	the		
P2949	Wobble signa width [%]	-	0 - 100	50	Т	-	-	U16	2		
	Sets the relative widths of the rising and falling pulses. The value in P2949 sets the proportion of the wobble period (determined by P2945) allocated to the rising pulse, the remainder of the time is allocation to the falling pulse. A value of 60% in P2949 means that 60% of the wobble period the wobble output will be rising. For the										
		% in P2949	means that 6	0% of the w	obble period th	e wohhle outr	ut will b	e risina	For the		
	remaining 40 <sup>0</sup>	% of the wo	means that 6 bble period t	0% of the w	obble period th output will be fa	e wobble outp lling.	out will b	-	1		
r2955	remaining 40 <sup>o</sup> CO: Wobble s output [%]	% of the wo signal	bble period t -	he wobble o	vobble period th putput will be fa -	e wobble outp lling.  -	out will b	e rising. Float	For the		
	remaining 40 <sup>d</sup> CO: Wobble s output [%] Displays the o	% of the wo signal output of the	bble period t -	he wobble o	robble period th putput will be fa -	e wobble outp lling.  -	out will b	-	1		
	remaining 40°         CO: Wobble s         output [%]         Displays the o         CO/BO: Fault	% of the wo signal output of the bit array	bble period t - e wobble fun -	he wobble o	obble period th putput will be fa - -	e wobble out lling. - -	out will b	-	1		
	remaining 40 <sup>c</sup> CO: Wobble s output [%] Displays the o CO/BO: Fault Gives informa	% of the wo signal output of the bit array tion about a	bble period t - e wobble fun - actual fault.	he wobble o	vobble period th putput will be fa -	lling.	out will b	Float U16	2		
	remaining 40 <sup>c</sup> CO: Wobble s       output [%]       Displays the o       CO/BO: Fault       Gives informa       Bit	% of the wo signal output of the bit array ition about a Signal nam	bble period t - e wobble fun - actual fault. ne	he wobble o	vobble period th putput will be fa -	lling. - - 1 signal	-	Float U16 <b>0 sign</b>	2		
	remaining 40 <sup>c</sup> CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00	% of the wo signal butput of the bit array ition about a Signal nam Converter e	bble period t - e wobble fun - actual fault. ne rror	he wobble o	obble period th putput will be fa -	lling. - - 1 signal Yes	-	Float U16 <b>0 sign</b> No	2		
	remaining 40°       CO: Wobble s       output [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01	% of the wo signal output of the bit array ition about of Signal nam Converter e Power line f	bble period t - wobble fun - actual fault. ne rror failure	he wobble of the	vobble period th putput will be fa -	lling. - - <b>1 signal</b> Yes Yes	-	Float U16 <b>0 sign</b> No No	2		
	remaining 40°       CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat	bble period t - e wobble fun - actual fault. ne rror failure e circuit pow	he wobble of the	vobble period th putput will be fa -	lling. - <b>1 signal</b> Yes Yes Yes	- -	Float U16 <b>0 sign</b> No No	2		
	remaining 40°       CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02       03	% of the wo signal butput of the bit array tion about a Signal nam Converter e Power line f Intermediat Error power	bble period t - e wobble fun - actual fault. ne rror failure e circuit pow r electronics	he wobble of the	vobble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes	-	Float U16 <b>0 sign</b> No No No	2		
	remaining 40 <sup>o</sup> CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02       03       04	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o	bble period t - e wobble fun - actual fault. ne rror failure te circuit pow r electronics vertemperati	he wobble of the	robble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes	- -	Float U16 No No No No No	2		
	remaining 40°       CO: Wobble s       output [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02       03       04       05	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag	bble period t - e wobble fun - actual fault. rror failure e circuit pow r electronics vertemperation ge	he wobble of the	vobble period th putput will be fa -	lling. - <b>1 signal</b> Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No	2		
	remaining 40°         CO: Wobble soutput [%]         Displays the o         CO/BO: Fault         Gives informa         Bit       9         00       9         01       9         02       9         03       9         04       9         05       96	% of the wo signal butput of the bit array tion about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl	bble period t - e wobble fun - actual fault. rror failure e circuit pow r electronics vertemperation ge	he wobble of the	robble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No	2		
	remaining 40°         CO: Wobble soutput [%]         Displays the o         CO/BO: Fault         Gives informa         Bit       1         00       1         01       1         02       1         03       1         04       0         05       0         07       1	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault	bble period t - e wobble fun - actual fault. rror failure e circuit pow r electronics vertemperation ge	he wobble of the	robble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No	2		
	remaining 400       CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02       03       04       05       06       07       09	% of the wo signal output of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault Reserved	bble period t e wobble fun - actual fault. e rror failure fe circuit pow felectronics vertemperation ge oad	he wobble of the	vobble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No No	2		
	remaining 40 <sup>o</sup> CO: Wobble s output [%]       Displays the o       CO/BO: Fault       Gives informa       Bit     9       00     9       01     02       03     9       04     9       05     06       07     9       10     10	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault Reserved Fault intern	bble period t bble period t bble period t bble fun bble fun bcl complete circuit fault. bcl complete circuit pow celectronics vertemperate bcl celectronics vertemperate bcl celectronics bcl cel	he wobble of the	robble period th putput will be fa - -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No No No No	2		
	remaining 40 <sup>o</sup> CO: Wobble s output [%]       Displays the o       CO/BO: Fault       Gives informa       Bit     9       00     9       01     9       02     9       03     9       04     9       05     9       06     9       07     9       10     11	% of the wo signal butput of the bit array tion about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault Reserved Fault intern Motor curre	bble period t bble period t - e wobble fun - e wobble fun - actual fault. ne rror failure c circuit pow r electronics vertemperati ge oad al communic ent limit	he wobble of the	robble period th putput will be fa -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No No No No No No	2		
r2955	remaining 400       CO: Wobble soutput [%]       Displays the o       CO/BO: Fault       Gives informa       Bit       00       01       02       03       04       05       06       07       09       10       11       12	% of the wo signal butput of the bit array ition about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault Reserved Fault intern Motor curre Supply failu	bble period t bble period t - e wobble fun - e wobble fun - actual fault. ne rror failure c circuit pow r electronics vertemperati ge oad al communic ent limit	he wobble of the	robble period th putput will be fa -	lling. - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No No No No No No	2		
	remaining 40°         CO: Wobble soutput [%]         Displays the o         CO/BO: Fault         Gives informa         Bit       9         00       01         02       03         04       05         06       07         09       10         11       12         13       13	% of the wo signal butput of the bit array tion about a Signal nam Converter e Power line f Intermediat Error power Converter o Earth leakag Motor overl Bus fault Reserved Fault intern Motor curre	bble period t bble period t - e wobble fun - e wobble fun - actual fault. ne rror failure c circuit pow r electronics vertemperati ge oad al communic ent limit	he wobble of the	vobble period th putput will be fa - -	lling. - - 1 signal Yes Yes Yes Yes Yes Yes Yes Yes		Float U16 No No No No No No No No No No No No No	2		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r3237[01]	CO: Calculated rms DC ripple voltage [V]	-	0	-	-	-	Float	4
	Displays calculated rms d	c-link ripple v	oltage.					
Index:	[0]	<b>Ripple Volts</b>	-					
	[1]	Unfiltered V	'olts					
P3350[02]	Super torque modes	0 - 3	0	Т	-	-	U16	2
P3350[02]	Selects the super torque f Super Torque - applies Hammer Start - applie Blockage Clearing - pe Super Torque Operation Boost (%) P3355	s a pulse of to es a sequence erforms a reve	orque for a g of torque p	given time to h oulses to help s	elp start the m tart the motor	otor		
	Output frequency (Hz) P3354 P3354 Super torque ramp P3353	P3356	-		Ramp-u P112	â	tim	*



Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level		
	Blockage Clearir	ng Operation:						•		
	Output frequence	y (Hz)	o, of blockage	clearing cycles						
	↑	i.	E.g. P33	2002 - 52						
	Setpoint	4	g		<b>&gt;</b>			·····		
		Blockage clearing	reverse time				/			
	P3361	P3362	2		·····	/				
	P3361 Super when r	P3353 torque ramp time, acti apid ramp (P3363) is	ve only disabled		P1120 Ramp-up ti	- ``. me	× • • • • • • • • • • • • • • • • • • •	t t		
	Setpoint							``		
		Currenter						2		
	0		ue modes dis	abled						
	2		ue enabled tart enabled							
	3		learing enabled	ed						
ndex:	[0]		set 0 (DDS0)							
	[1]		set 1 (DDS1)							
	[2]		set 2 (DDS2)							
Note:		of P3350 is changed,		P3353 is change	ed as follows:					
	• P3350 = 2: P3	353 = 0.0s								
	• P3350 ≠ 2: P3	353 = default								
		Os gives an addition	nal 'kicking' e	fect when ham	mer start is in	use.				
	This setting can b	e overridden by the	operator.							
	If blockage clearing mode is enabled (P3350 = 3), make sure that reverse direction is not inhibited, i.e. $P1032 = P1110 = 0$ .									
P3351[02]	Bl: Super torque enable	0 - 42949672 5	9 0	Т	-	CDS	U32	2		
	Defines source of	the super torque er	nable when P	3352 = 2.			1			
Dependency:	Applies only whe									

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level				
P3352[02]	Super torque startup mode	0 - 2	1	T	-	-	U16	2				
	Defines when the super tor	que function l	becomes act	ive.								
	0	Enabled on fi	irst run after	power-up								
	1	Enabled on e	very run									
	2 Enabled by digital input											
Index:	See P3350											
Dependency:	If P3352 = 2, enable source	If P3352 = 2, enable source is defined by P3351										
P3353[02]	Super torque ramp time [s]	0.0 - 650.0	5.0	Т	-	-	Float	2				
	Defines the ramp time to be used for all super torque functions. Overrides the P1120/P1060 when converter is amping to super torque/hammer start frequency (P3354) or the blockage clearing frequency (P3361).											
Index:	See P3350											
Dependency:	The value of this parameter is changed by the setting of P3350.											
	See the description of P335			1			1					
P3354[02]	Super torque frequency [Hz]	0.0 - 550.0	5.0	Т	-	-	Float	2				
	Defines the frequency at which the additional boost is applied for super torque and hammer start modes.											
ndex:	See P3350		1	1		-		-				
23355[02]	Super torque boost level [%]	0.0 - 200.0	150.0	Т	PERCENT	-	Float	2				
	V_ST = P0305 * Rsadj * (P3 Note: Rsadj = stator resistance ad Rsadj = (r0395/100) * (P03	justed for tem	•	305 * cart(3)								
Index:	See P3350	04/(3411(3) 1	(0303)) FC	505 sqrt(5)								
Dependency:	Up to 200% of rated motor	current (PO30	15) or limit o	f.converter								
Note:	The Super Torque boost is used, the calculated voltag	calculated in th	ne same way	/ as Continuous E								
	Setting in P0640 (motor ov	erload factor [	[%]) limits th	e boost.	-	2						
P3356[02]	Super torque boost time [s]	0.0 - 20.0	5.0	Т	-	-	Float	2				
	Sets the time for which the	additional bo	ost will be a	pplied, when the	output freque	ncy is he	ld at P33	354 Hz.				
Index:	See P3350		_		_							
P3357[02]	Hammer start boost level [%]	0.0 - 200.0	150.0	Т	PERCENT	-	Float	2				
	Ievel [%]       Image: Constraint of the Hammer Start boost is calculated as follows:         V_HS = P0305 * Rsadj * (P3357/100)         Note:         Rsadj = stator resistance adjusted for temperature         Rsadj = (r0395/100) * (P0304/(sqrt(3) * P0305)) * P0305 * sqrt(3)											
Index:	See P3350											
Dependency:	Up to 200% of rated motor	current (P030	5) or limit o	f converter.								
Note:	The Hammer Start boost is calculated in the same way as Continuous Boost (P1310). As the stator resistan used, the calculated voltage is only accurate at 0Hz. Thereafter, it will vary in the same way as Continuous Setting in P0640 (motor overload factor [%]) limits the boost.											

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P3358[02]	Number of hammer cycles	1 - 10	5	С, Т	-	-	U16	2
	The number of times the	e hammer star	t boost leve	l (P3357) is appl	ied.	1		
Index:	See P3350			<u>, , , , , , , , , , , , , , , , , , , </u>				
P3359[02]	Hammer on time [ms]	0 - 1000	300	Т	-	-	U16	2
	Time for which the addi	tional boost is	applied for	each repetition.	1	1		
Index:	See P3350			•				
Dependency:	The time must be at leas	st 3 x motor ma	agnetizatio	n time (P0346).				
P3360[02]	Hammer off Time [ms]	0 - 1000	100	Т	-	-	U16	2
	Time for which the addi	tional boost is	removed fo	r each repetition	1.	•		•
Index:	See P3350			•				
Note:	During this time, the bo	ost level drops	to the leve	l defined by P13	10 (continuou	s boost)		
P3361[02]	Blockage clearing frequency [Hz]	0.0 - 550.0	5.0	Т	-	-	Float	2
	Defines the frequency a blockage clearing revers		nverter runs	s in the opposite	direction to th	ne setpo	int duri	ng the
Index:	See P3350							
P3362[02]	Blockage clearing reverse time [s]	0.0 - 20.0	5.0	Т	-	-	Float	2
	Sets the time for which sequence.	the converter r	runs in the o	opposite directio	n to the setpo	int durii	ng the re	everse
Index:	See P3350			-	-		•	•
P3363[02]	Enable rapid ramp	0 - 1	0	Т	-	-	U16	2
	Selects whether the con	verter ramps t	o, or starts (	directly from, the	e blockage clea	aring fre	equency	(P3361).
	0	Disable rapi	d ramp for l	blockage clearing	g			
	1	Enable rapid ramp for blockage clearing						
Index:	See P3350							
Note:	If P3363 = 1, the output clear the blockage.	jumps to the r	reverse freq	uency - this intro	oduces a "kicki	ng" effe	ct whicł	n helps to
P3364[02]	Number of blockage clearing cycles	1 - 10	1	Т	-	-	U16	2
	The number of times the	e blockage clea	aring revers	ing cycle is repea	ated.			
Index:	See P3350							
r3365	CO/BO: Status word: super torque	-	-	-	-	-	U16	2
	Shows the operational s	tatus of the Su	iper Torque	function, while	active.			
	Bit Signal nar	ne			1 signal		0 sign	al
	00 Super Torc	ue Active			Yes		No	
	01 Super Torc	ue Ramping			Yes No		No	
	02 Super Torc	ue Boost On			Yes		No	
	03 Super Torc	ue Boost Off			Yes	_	No	
	04 Blockage C	learing Revers	e On		Yes		No	
		learing Revers			Yes		No	

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P3852[02]	Bl: Enable frost protection	0 - 429496729 5	0	U, T	-	CDS	U32	2
	Defines command source initiated. If converter is sto	of protection e	nable comm ection signa	and. If binary inp l becomes active,	ut is equal to c protection me	one, ther asure is	n protect applied	ion will be as follows:
	• If P3853 ≠ 0, frost prot	ection is applie	d by applyir	ng the given frequ	uency to the m	otor		
	• If P3853 = 0, and P385	$4 \neq 0$ , condens	ation proted	ction is applied by	/ applying the o	given cu	rrent to t	he motor
Note:	The protection function m	ay be overridde	en under the	e following circun	nstances:	-		
Note.	If converter is running	-		-				
	If converter is turning	notor due to a	ctive protect	tion signal and a	RUN command	is receiv	ved, RUN	command
	overrides frost signal			-				
	Issuing an OFF comma	nd while prote	ction is activ	ve will stop the m	otor			
P3853[02]	Frost protection frequency [Hz]	0.00 - 550.00	5.00	U, T	-	DDS	Float	2
	The frequency applied to t	he motor wher	n frost prote	ction is active.				
Dependency:	See also P3852.							
P3854[02]	Condensation protection current [%]	0 - 250	100	U, T	-	DDS	U16	2
	The DC current (as a perce is active.	ntage of nomir	nal current)	which is applied t	to the motor w	hen con	densatio	n protecti
Dependency:	See also P3852.	1	1		1		1	1
P3900	End of quick commissioning	0 - 3	0	C(1)	-	-	U16	1
	Performs calculations nece P0010 (parameter groups							0 and
	0	No quick commissioning						
	1	End quick cor	nmissioning	g with factory res	et			
	2	End quick cor	nmissioning	]				
	3	End quick cor	nmissioning	g and initiate mot	or data calcula	tion		
Dependency:	Changeable only when PO	010 = 1 (quick	commission	ing).				
Note:	P3900 = 1: When setting 1 is selected commissioning" are retain are also performed. P3900 = 2:	, only the parar ed; all other pa	neter settin rameter cha	gs carried out via nges, including t	the commissic he I/O settings,	oning me are lost	enu "Quio . Motor o	k alculatior
	When setting 2 is selected "Quick commissioning" (PC calculations performed.							
	P3900 = 3:							
	When setting 3 is selected commissioning with this s	, only the moto etting saves tin	r and contro ne (for exam	oller calculations ople, if only moto	are performed. r rating plate d	Exiting ata have	quick been ch	anged).
	Calculates a variety of mot P0350 (stator resistance),	P2000 (referen	ce frequenc	y), P2002 (refere	nce current).		motor w	eight),
	When transferring P3900, the converter uses its processor to carry out internal calculations.							
	5		· · · · · · · ·	dhus - aro intorru	inted for the tir	ne that i	t takes to	maka
	Communications - both via these calculations. This can (communications via Field	n result in the f						
	Communications - both via these calculations. This ca	n result in the f						
	Communications - both via these calculations. This can (communications via Field	n result in the f						

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
r3930[04]	Converter data version	-	-	-	-	-	U16	3
	Displays the A5E number a	nd the convert	ter data vers	ions.	1			
Index:	[0]	A5E 1st 4 dig	its					
	[1]	A5E 2nd 4 di						
	[2]	Logistic Versi	-					
	[3] Fixed Data Version							
	[4]	Calib Data Ve						
P3950	Access of hidden parameters	0 - 255	0	U, T	-	-	U16	4
	Accesses special paramete	rs for developn	nent (exper	t only) and facto	ry functionality	y (calibrat	ion para	meter).
r3954[012]					U16	4		
	Used to classify firmware (	only for SIEME	NS internal	purposes).	1			
Index:	[0]	CM label (inc		· · ·				
	[1]	CM label (cou		,				
	[2]	CM label						
	[310] GUI ID							
	[11] GUI ID major release							
	[12] GUI ID minor release							
r3978	BICO counter	-	-	_	_	_	U32	4
15570	Counts the number of chai	l aged BICO links					052	7
P3981	Reset active fault		0	Т	_	_	U16	4
15501			•	1			010	7
	Resets active faults when changed from 0 to 1.       0     No fault reset							
	1 Reset fault							
Note:	See P0947 (last fault code)							
Note.	Automatically reset to 0.							
P3984	Client telegram off time [ms]	100 - 10000	1000	Т	-	-	U16	3
	Defines time after which a	fault will be ge	enerated (F7	'3) if no telegrar	n is received fr	om the cl	ient.	
Dependency:	Setting 0 = watchdog disal	-						
r3986[01]	Number of parameters	-	-	-	_	-	U16	4
13366[01]	Number of parameters on	the converter					010	
Index:	[0]	Read only						
macx.	[1]	Read & write						
r4000 - r4064	Reserved	Read & write						
P7844	Acceptance test, confirmation	0 - 2	0	Т	-	-	U16	3
	After an automatic download from the SD card at startup, this parameter will be automatically set to 1. Also a fault F395 will be set.							
	With setting to P7844 = 0 y possible if an automatic do the previously stored parar	wnload has be	en perform	the parameter s ed at startup. In	ettings. Setting this case the d	g this para ownload	ameter t will be u	o 2 is only ndone an
	0	Acceptance to		ation OK				
	1			ation is pending				
	2	Undo clone						
Note:	If no automatic download If the clone file contains us the user defaults in the clo	from the SD ca er defaults and	d the cloning	g at startup is re	jected with P78	-		

Parameter	Function	Range	Factory default	Can be changed	Scaling	Data set	Data type	Acc. Level
P8458	Clone control	0 - 4	2	С, Т	-	-	U16	3
	This parameter specifies If no SD card is inserted t	whether a clor here will be a	ning at start normal star	up will be perfor tup.	med. The File	clone0	0.bin wi	ll be used.
	0	No startup cl	oning					
	1	Clone at star	tup once					
	2	Clone at startup always						
	3	Clone at startup once, except the motor data						
	4	Clone at startup always, except the motor data						
Note:	Default value is 2. After first cloning the parameter is set to 0. If an SD card is inserted without a valid file the converter will set a fault F61/F63/F64 which can only be cleared by a power-cycle. The fault is signale by a flashing RUN LED (Commissioning). The SF LED is not activated. P8458 will not be changed by performing a factory reset.			is signaled				
P8553	Menu type	0 - 1	0	U, T	-	-	U16	1
	Selects whether to have	menus with no	text or me	nus with some to	ext on the BO	P.		
	0	Menus with no text						
	1	Menus with	some text					

# Faults and alarms

#### Note

If there are multiple active faults and alarms, the BOP first displays all faults one after another. Once all faults are displayed, it displays all alarms in succession.

## 9.1 Faults

Immediately when a fault occurs the fault icon  $\otimes$  shows and the display transitions to the faults screen. The faults screen displays the fault number proceeded by "F".

#### Acknowledging/clearing faults

- To navigate through the current list of faults, press  $\blacksquare$  or  $\blacksquare$ .
- To view the converter status at fault, press (> 2 s); to return to the fault code display, press (< 2 s).</li>
- To clear/acknowledge the fault, press or acknowledge externally if the converter has been set up so; to ignore the fault, press .

After you acknowledge or ignore the fault, the screen returns to the previous display. The fault icon remains active until the fault is cleared/acknowledged.


#### Note

Under the following circumstances, the faults screen displays again:

- If the fault has not been cleared and the **I** button is pressed, the faults screen displays again.
- If there is no key press for 60 seconds.

If a fault is active and there has been no key press for 60 seconds, the backlight (P0070) flashes.

## Viewing converter status at fault



#### Customizing converter stop reaction for faults

You can use P2100 to select up to 3 faults for non-default stop reaction and use P2101 to specify the reaction. For more information, see the description of P2100 and P2101 in Section "Parameter list (Page 201)".

#### Fault code list

Fault	Cause	Remedy
F1 Overcurrent	<ul> <li>Motor power (P0307) does not correspond to the converter power (r0206).</li> <li>Motor lead short circuit</li> <li>Earth faults r0949 = 0: Hardware reported r0949 = 1: Software reported r0949 = 22: Hardware reported</li> </ul>	<ul> <li>Check the following:</li> <li>Motor power (P0307) must correspond to converter power (r0206).</li> <li>Cable length limits must not be exceeded.</li> <li>Motor cable and motor must have no shortcircuits or earth faults.</li> <li>Motor parameters must match the motor in use.</li> <li>Value of stator resistance (P0350) must be correct.</li> <li>Motor must not be obstructed or overloaded.</li> <li>Increase ramp-up time (P1120)</li> <li>Reduce starting boost level (P1312)</li> </ul>

Fault	Cause	Remedy
F2	Main supply voltage too high	Check the following:
Overvoltage	• Motor is in regenerative mode r0949 = 0: Hardware reported	• Supply voltage (P0210) must lie within limits indicated on rating plate.
	r0949 = 1 or 2: Software reported	• Ramp-down time (P1121) must match inertia of load.
		Required braking power must lie within specified limits.
		• Vdc controller must be enabled (P1240) and parameterized properly.
		Note:
		Regenerative mode can be caused by fast ramp downs or if the motor is driven by an active load.
		Higher inertia requires longer ramp times; otherwise, apply braking resistor.
F3	• Main supply failed.	Check supply voltage.
Undervoltage	• Shock load outside specified limits.	
	r0949 = 0: Hardware reported	
	r0949 = 1 or 2: Software reported	
F4	Converter overloaded	Check the following:
Converter overtemperature	Ventilation inadequate	Load or load cycle too high?
	Pulse frequency too high	Motor power (P0307) must match converter
	Surrounding temperature too high	power (r0206)
	Fan inoperative	Pulse frequency must be set to default value
		Surrounding temperature too high?
		Fan must turn when converter is running
F5	Converter overloaded.	Check the following:
Converter I <sup>2</sup> t	• Load cycle too demanding.	Load cycle must lie within specified limits.
	• Motor power (P0307) exceeds	Motor power (P0307) must match converter
	converter power capability (r0206).	power (r0206)
		<b>Note:</b> F5 cannot be cleared until the converter overload utilization (r0036) is lower than the converter I <sup>2</sup> t warning (P0294).
F6	Load at start-up is too high	Check the following:
Chip temperature rise	Load step is too high	Load or load step too high?
exceeds critical levels	Ramp-up rate is too fast	Increase ramp-up time (P1120).
		<ul> <li>Motor power (P0307) must match converter power (r0206).</li> </ul>
		• Use setting P0290 = 0 or 2 for preventing F6.

Fault	Cause	Remedy
F11	Motor overloaded	Check the following:
Motor overtemperature		Load or load step too high?
		<ul> <li>Motor nominal overtemperatures (P0626 - P0628) must be correct</li> </ul>
		Motor temperature warning level (P0604) must match
	This fault may occur if small motors	Check the following:
	are used and run at a frequency below 15 Hz, even though the motor temperature is within limits.	• Motor current is not in excess of the motor nominal current as indicated by the motor rating plate
		Physical temperature of the motor lies within limits
		If these two conditions are satisfied, then set parameter P0335 = 1.
F12 Converter temperature signal lost	Wire breakage of converter temperature (heat sink) sensor.	
<b>F20</b> DC ripple too high	The calculated DC ripple level has exceeded the safe threshold. This is commonly caused by loss of one of the mains input phases.	Check the mains supply wiring.
F23	The calculated output ripple level has exceeded the safe threshold. Common causes are as follows:	Check the output wiring.
Output current ripple too high		• Check the mechanical vibration of the motor.
ingi	<ul> <li>Output phase missing</li> <li>High motor vibration</li> </ul>	• Check whether the setting of converter response to high output current ripple (P0296) is correct.
	High motor vibration	
F35 Maximum number of auto restart attempts exceeded	Auto restart attempts exceed value of P1211.	
F41	Motor data identification failed.	Check the following:
Motor data identification failure	• r0949 = 0: No load applied	• r0949 = 0: is the motor connected to the
Idilure	• r0949 = 1: Current limit level	converter?
	reached during identification.	• r0949 = 1 - 49: are the motor data in P0304 -
	<ul> <li>r0949 = 2: Identified stator resistance less than 0.1% or greater than 100%.</li> </ul>	<ul> <li>P0311 correct?</li> <li>Check what type of motor wiring is required (star, delta).</li> </ul>
	<ul> <li>r0949 = 30: Current controller at voltage limit</li> </ul>	
	<ul> <li>r0949 = 40: Inconsistency of identified dataset, at least one identification failed</li> </ul>	
	Percentage values based on the impedance Zb = Vmot,nom/sqrt(3)/Imot,nom	

Fault	Cause	Remedy
<b>F51</b> Parameter EEPROM fault	Read or write failure while access to EEPROM. This can also be caused by the EEPROM being full, too many	• Must be power-cycled to cancel this bug as some parameters may not be read correctly.
	parameters have been changed.	<ul> <li>Factory reset (P0970 = 31) and new parameterization, if power-cycle does not remove fault.</li> </ul>
		• Change some parameters back to default values if the EEPROM is full, then power-cycle.
		Change converter. Note:
		• r0949 = 1: EEPROM full
		• r0949 = 1000 + block No: reading data block failed
		• r0949 = 2000 + block No: reading data block timeout
		• r0949 = 3000 + block No: reading data block CRC failed
		• r0949 = 4000 + block No: writing data block failed
		• r0949 = 5000 + block No: writing data block timeout
		• r0949 = 6000 + block No: writing data block verify failed
		• r0949 = 7000 + block No: reading data block at wrong time
		<ul> <li>r0949 = 8000 + block No: writing data block at wrong time</li> </ul>
		• r0949 = 9000 + block No: factory reset did not work because restart or power failure

Fault	Cause	Remedy
F52	Read failure for converter information or	Note:
Converter software fault	invalid data.	• r0949 = 1: Failed reading converter identity
		<ul> <li>r0949 = 2: Converter identity wrong</li> </ul>
		• r0949 = 3: Failed reading converter version
		<ul> <li>r0949 = 4: Converter version wrong</li> </ul>
		• r0949 = 5: Start of Part 1 converter data wrong
		<ul> <li>r0949 = 6: Converter number of temperature sensor wrong</li> </ul>
		<ul> <li>r0949 = 7: Converter number of application wrong</li> </ul>
		• r0949 = 8: Start of Part 3 converter data wrong
		• r0949 = 9: Reading converter data string wrong
		• r0949 = 10: Converter CRC failed
		• r0949 = 11: Converter is blank
		• r0949 = 15: Failed CRC of converter block 0
		• r0949 = 16: Failed CRC of converter block 1
		• r0949 = 17: Failed CRC of converter block 2
		• r0949 = 20: Converter invalid
		• r0949 = 30: Directory size wrong
		• r0949 = 31: Directory ID wrong
		• r0949 = 32: Invalid block
		• r0949 = 33: File size wrong
		• r0949 = 34: Data section size wrong

Fault	Cause	Remedy
F52 (continued)		• r0949 = 35: Block section size wrong
		• r0949 = 36: RAM size exceeded
		• r0949 = 37: Parameter size wrong
		• r0949 = 38: Device header wrong
		• r0949 = 39: Invalid file pointer
		• r0949 = 40: Scaling block version wrong
		• r0949 = 41: Calibration block version wrong
		• r0949 = 50: Wrong serial number format
		• r0949 = 51: Wrong serial number format start
		• r0949 = 52: Wrong serial number format end
		• r0949 = 53: Wrong serial number format month
		• r0949 = 54: Wrong serial number format day
		• r0949 = 1000 + addr: Converter read data failed
		• r0949 = 2000 + addr: Converter write data failed
		• r0949 = 3000 + addr: Converter read data wrong time
		<ul> <li>r0949 = 4000 + addr: Converter write data wrong time</li> </ul>
		<ul> <li>r0949 = 5000 + addr: Converter read data invalid</li> </ul>
		<ul> <li>r0949 = 6000 + addr: Converter write data invalid</li> </ul>
		Power-cycle converter
		Contact service department or change converter
<b>F60</b> Asic timeout	Internal communications failure.	Check converter. Fault appears sporadically: <b>Note:</b>
		• r0949 = 0: Hardware reported link fail
		• r0949 = 1: Software reported link fail
		• r0949 = 6: Feedback is not disabled for reading converter data
		<ul> <li>r0949 = 7: During converter download, message didn't transmit to disable feedback</li> </ul>
		Communication failure due to EMC problems
		Check - and if necessary - improve EMC
		Use EMC filter

Fault	Cause	Remedy
F61 SD card parameter cloning failed	<ul> <li>Parameter cloning failed.</li> <li>r0949 = 0: The SD card is not connected or the card type is incorrect or the card failed to initialize for automatic cloning.</li> <li>r0949 = 1: Converter data cannot be written to the card.</li> <li>r0949 = 2: Parameter cloning file is unavailable.</li> <li>r0949 = 3: The SD card cannot read the file.</li> <li>r0949 = 4: Reading data from the clone file failed (e.g., reading failed, data or checksum wrong).</li> </ul>	<ul> <li>r0949 = 0: Use an SD card with FAT16 or FAT32 format , or fit an SD card to the converter.</li> <li>r0949 = 1: Check the SD card (for example, is the card memory full?) - format the card again to FAT16 or FAT32.</li> <li>r0949 = 2: Put the correct named file in the correct directory /USER/SINAMICS/DATA.</li> <li>r0949 = 3: Make sure file is accessible - recreate file if possible.</li> <li>r0949 = 4: File has been changed - recreate file.</li> </ul>
F62 Parameter cloning contents invalid	File exists but the contents are not valid control word corruption.	Recopy and ensure operation completes.
F63 Parameter cloning contents incompatible	File exists but was not the correct converter type.	Ensure clone from compatible converter type.
F64 Converter attempted to do an automatic clone during startup	No Clone00.bin file in the correct directory /USER/SINAMICS/DATA.	<ul> <li>If an automatic clone is required:</li> <li>Insert the SD card with correct file and power-cycle.</li> <li>If no automatic clone is required:</li> <li>Remove the card if not needed and power-cycle.</li> <li>Reset P8458 = 0 and power-cycle.</li> <li>Note:</li> <li>Fault can only be cleared by a power-cycle.</li> </ul>
F70 I/O Extension Module communication fault	Communication is no longer established with the I/O Extension Module.	Reconnect the module and check whether it is operating correctly. Acknowledge the fault. If the fault persists, replace the module.
<b>F71</b> USS setpoint fault (on RS232)	No setpoint values from USS (on RS232) during telegram off time.	Check USS master on RS232.
F72 USS/MODBUS setpoint fault (on RS485) F80	No setpoint values from USS/MODBUS (on RS485) during telegram off time.	Check USS/MODBUS master on RS485.
Signal lost on analog input	<ul><li>Broken wire</li><li>Signal out of limits</li></ul>	
F85 External fault	External fault triggered via command input via control word 2, bit 13.	<ul> <li>Check P2106.</li> <li>Disable control word 2 bit 13 as command source.</li> <li>Disable terminal input for fault trigger.</li> </ul>
<b>F100</b> Watchdog reset	Software error	Contact service department or change converter.

Fault	Cause	Remedy
F101 Stack overflow	Software error or processor failure.	Contact service department or change converter.
<b>F200</b> Script error	Script of the internal converter program has stopped running due to script errors except for forced exit.	Check the script and make necessary corrections.
F221 PID feedback below minimum value	PID feedback below minimum value P2268.	<ul><li>Change value of P2268.</li><li>Adjust feedback gain.</li></ul>
F222 PID feedback above maximum value	PID feedback above maximum value P2267.	<ul><li>Change value of P2267.</li><li>Adjust feedback gain.</li></ul>
<b>F350</b> Configuration vector for the converter failed	During startup the converter checks if the configuration vector (SZL vector) has been programmed correctly and if hardware matches the programmed vector. If not the converter will trip.	Internal failures cannot be fixed. r0949 = 13 - Make sure the right power module is fitted. <b>Note:</b>
	<ul> <li>r0949 = 1: Internal failure - no hardware configuration vector available.</li> </ul>	Fault needs power-cycle to be acknowledged.
	<ul> <li>r0949 = 2: Internal failure - no software configuration vector available.</li> </ul>	
	• r0949 = 11: Internal failure - converter code not supported.	
	• r0949 = 12: Internal failure - software vector not possible.	
	• r0949 = 13: Wrong power module fitted.	
	<ul> <li>r0949 &gt; 1000: Internal failure - wrong I/O board fitted.</li> </ul>	
F395 Acceptance test/confirmation pending	This fault occurs after a startup clone. It can also be caused by a faulty read from the EEPROM, see F51 for more details.	The current parameter set needs to be checked and confirmed by clearing the fault.
	A startup clone could have changed and might not match the application.	
	This parameter set needs to be checked before the converter can start a motor.	
	<ul> <li>r0949 = 3/4: Converter data change</li> <li>r0949 = 5: Startup clone via an SD card has been performed</li> </ul>	
	<ul> <li>r0949 = 10: Previous startup clone was aborted</li> </ul>	

#### Faults and alarms

#### 9.2 Alarms

Fault	Cause	Remedy
<b>F410</b> Cavitation protection failure	Conditions exist for cavitation damage. Cavitation damage is damage caused to a pump in pumping systems when the fluid is not flowing sufficiently. This can lead to heat build up and subsequent damage to the pump.	If cavitation is not occurring, reduce the cavitation threshold P2361, or increase the cavitation protection delay. Ensure sensor feedback is working.
F452 Load monitoring trip	Load conditions on motor indicate belt failure or mechanical fault. • r0949 = 0: trip low torque/speed • r0949 = 1: trip high torque/speed	<ul> <li>Check the following:</li> <li>No breakage, seizure or obstruction of converter train.</li> <li>Apply lubrication if required.</li> <li>If using an external speed sensor, check the following parameters for correct function: <ul> <li>P2192 (delay time for permitted deviation)</li> <li>P2182 (threshold frequency f1)</li> <li>P2183 (threshold frequency f2)</li> <li>P2184 (threshold frequency f3)</li> <li>If using a specific torque/speed range, check parameters:</li> <li>P2182 (threshold frequency 1)</li> <li>P2183 (threshold frequency 2)</li> <li>P2184 (threshold frequency 3)</li> <li>P2185 (upper torque threshold 1)</li> <li>P2186 (lower torque threshold 2)</li> <li>P2188 (lower torque threshold 3)</li> <li>P2190 (lower torque threshold 3)</li> <li>P2192 (delay time for permitted deviation)</li> </ul> </li> </ul>

# 9.2 Alarms

If an alarm is activated the alarm icon  $\blacktriangle$  shows immediately and then the display shows the alarm code proceeded by "A".

#### Note

Note that alarms cannot be acknowledged. They are cleared automatically once the warning has been rectified.

#### Disabling converter stop reaction for alarms

You can disable stop reaction for three selected alarms or all alarms:

- Use P2100 to select up to 3 alarms and use P2101 to disable stop reaction for the selected alarms.
- Use P2113 to disable stop reaction for all alarms.

For more information, see the description of P2100, P2101, and P2113 in Section "Parameter list (Page 206)".

# Alarm code list

Alarm	Cause	Remedy
<b>A501</b> Current limit	<ul> <li>Motor power does not correspond to the converter power</li> <li>Motor leads are too long</li> <li>Earth faults</li> </ul>	See F1.
	• Small motors (120 W) under FCC and light load may cause a high current	Use V/f operation for very small motors
<b>A502</b> Overvoltage limit	Overvoltage limit is reached. This warning can occur during ramp down, if the Vdc controller is disabled (P1240 = 0).	If this warning is displayed permanently, check converter input voltage.
<b>A503</b> Undervoltage limit	<ul> <li>Main supply failed.</li> <li>Main supply and consequently DC-link voltage (r0026) below specified limit.</li> </ul>	Check main supply voltage.
A504 Converter overtemperature	Warning level of converter heat sink temperature, warning level of chip junction temperature, or allowed change in temperature on chip junction is exceeded, resulting in pulse frequency reduction and / or output frequency reduction (depending on parameterization in P0290).	<ul> <li>Note: r0037[0]: Heat sink temperature r0037[1]: Chip junction temperature (includes heat sink)</li> <li>Check the following:</li> <li>Surrounding temperature must lie within specified limits</li> <li>Load conditions and load steps must be appropriate</li> </ul>
A505	Warning level exceeded, current will be reduced if parameterized (P0610 = 1).	• Fan must turn when converter is running Check that load cycle lies within specified limits.
Converter I <sup>2</sup> t A506 IGBT junction temperature rise warning	Overload warning. Difference between heat sink and IGBT junction temperature exceeds warning limits.	Check that load steps and shock loads lie within specified limits.
A507 Converter temperature signal lost	Converter heat sink temperature signal loss. Possible sensor fallen off.	Contact service department or change converter.
A511 Motor overtemperature I <sup>2</sup> t	<ul> <li>Motor overloaded.</li> <li>Load cycles or load steps too high.</li> </ul>	<ul> <li>Independently of the kind of temperature determination check:</li> <li>P0604 motor temperature warning threshold</li> <li>P0625 motor surrounding temperature</li> <li>Check if name plate data is correct. If not, perform quick commissioning. Accurate equivalent circuit data can be found by performing motor identification (P1900 = 2).</li> <li>Check if motor weight (P0344) is reasonable. Change if necessary.</li> <li>With P0626, P0627, and P0628 the standard overtemperature can be changed, If the motor is not a SIEMENS standard motor.</li> </ul>

# 9.2 Alarms

Alarm	Cause	Remedy					
<b>A523</b> Output current ripple too high	<ul> <li>The calculated output ripple level has exceeded the safe threshold. Common causes are as follows:</li> <li>Loss of one of the output phases</li> <li>High motor vibration</li> </ul>	<ul><li>Check the output wiring.</li><li>Check the mechanical vibration of the motor.</li></ul>					
A535 Braking resistor overload A541 Motor data identification active	The braking energy is too large. The braking resistor is not suited for the application. Motor data identification (P1900) selected or running.	Reduce the braking energy. Use a braking resistor with a higher rating.					
A600 RTOS overrun warning	Internal time slice overrun	Contact service department.					
A910 Vdc_max controller de- activated	<ul> <li>Occurs</li> <li>if main supply voltage (P0210) is permanently too high.</li> <li>if motor is driven by an active load, causing motor to go into regenerative mode.</li> <li>at very high load inertias, when ramping down.</li> <li>If warning A910 occurs while the converter is in standby (output pulses disabled) and an ON command is subsequently given, the Vdc_max controller (A911) will not be activated unless warning A910 is rectified.</li> <li>The Vdc_max controller works to keep the</li> </ul>	<ul> <li>Check the following:</li> <li>Input voltage must lie within range.</li> <li>Load must be match.</li> <li>In certain cases apply braking resistor.</li> </ul>					
Vdc_max controller active	DC-link voltage (r0026) below the level specified in r1242.	<ul> <li>Supply voltage must lie within limits indicated on rating plate.</li> <li>Ramp-down time (P1121) must match inertia of load.</li> <li>Note: Higher inertia requires longer ramp times; otherwise, apply braking resistor.</li> </ul>					
A912 Vdc_min controller active	The Vdc_min controller will be activated if the DC-link voltage (r0026) falls below the level specified in r1246. The kinetic energy of the motor is used to buffer the DC-link voltage, thus causing deceleration of the converter! So short mains failures do not necessarily lead to an undervoltage trip. Note that this warning may also occur on fast ramp-ups.						

9.2 Alarms

Alarm	Cause	Remedy
A921 Analog output parameters not set properly	Analog output parameters (P0777 and P0779) should not be set to identical values, since this would produce illogical results.	<ul> <li>Check the following:</li> <li>Parameter settings for output identical</li> <li>Parameter settings for input identical</li> <li>Parameter settings for output do not correspond to analog output type</li> <li>Set P0777 and P0779 to different values.</li> </ul>
A922 No load applied to converter	No Load is applied to the converter. As a result, some functions may not work as under normal load conditions.	Check that motor is connected to converter.
<b>A923</b> Both JOG left and JOG right are requested	Both JOG right and JOG left (P1055/P1056) have been requested. This freezes the RFG output frequency at its current value.	Do not press JOG right and left simultaneously.
A930 Cavitation protection warn	Conditions exist for possible cavitation damage.	See F410.
A936 PID autotuning active	PID autotuning (P2350) selected or running	Warning disappears when PID autotuning has finished.
A952 Load monitoring warning	Load conditions on motor indicate belt failure or mechanical fault.	See F452.

Faults and alarms

9.2 Alarms

# **Technical specifications**

# Line supply characteristics

	Three phase AC 400 V converters	Single phase AC 230 V converters							
Voltage range	380 V AC to 480 V AC <sup>1)</sup> (tolerance: -15% to +10%) 47 Hz to 63 Hz Current derating at high input voltages: Output current [%] 120 120 100 80 40 120 100	200 V AC to 240 V AC <sup>1)</sup> (tolerance: -15% to +10%) 47 Hz to 63 Hz Current derating at high input voltages: Output current [%] 120 100 80 120 100 80 120 100 80 120 100 100 80 100 100 100 100 100 100 100							
	surrounding air temperature, refer to the table in Section "Converter variants (Page 21)".	frequency and 40 °C surrounding air temperature.							
Overvoltage category	EN 60664-1 Category III	EN 60664-1 Category III							
Permissible supply configuration	TN, TT, IT: FSA to FSE (unfiltered); FSE (filtered) <sup>2)</sup> TN, TT with grounded neutral: FSA to FSE	TN, TT: FSAA to FSAD (unfiltered); FSAD (filtered) TN, TT with grounded neutral: FSAA to FSAD							
		IT: FSAA to FSAD (unfiltered)							
Supply environment	Second environment (industrial power network)	First environment (residential power network)							
Inrush current	< maximum rated input current V20 can withstand 100,000 power cycles with a	n interval of 30 s.							
Short-circuit current (SCCR or lcc) and branch protection	Maximum permissible short-circuit current: 100 kA (When using fuses) Minimum required short-circuit current: 5 kA You can find the data for further overcurrent protection devices on the Internet: Branch protection and short-circuit strength according to UL and IEC (https://support.industry.siemens.com/cs/ww/en/ps/13208/man)								

<sup>1)</sup> When the input voltage is below the rated value, current deratings are permissible and therefore the voltage-dependent speed and/or torque may be reduced.

<sup>2)</sup> To operate FSE (filtered) on IT power supply, make sure you remove the screw for the EMC filter.

# **Overload capability**

Power rating (kW)	Average output current	Overload current	Maximum overload cycle
0.12 to 15	100% rated	150% rated for 60	150% rated for 60 seconds followed by 94.5% rated for
18.5 (HO)/22 (HO)		seconds <sup>1)</sup>	240 seconds <sup>1)</sup>
22 (LO)/30 (LO)		110% rated for 60 seconds	110% rated for 60 seconds followed by more than 98% rated for 240 seconds

<sup>1)</sup> For 230 V converters with 0.75 kW power rating, make sure that you set P1800 to a value between 2 k and 10 k to fulfil the specified overload capabilities.

## **EMC requirements**

#### Note

Install all converters in accordance with the manufacturer's guidelines and in accordance with good EMC practices.

Use copper screened cable. For the maximum motor cable lengths, refer to Section "Terminal description (Page 45)".

Do not exceed the default switching frequency.

	Three phase AC 400 V converters	Single phase AC 230 V converters
ESD	EN 61800-3	EN 61800-3
Radiated immunity		
Burst		
Surge		
Conducted immunity		
Voltage distortion immunity		
Conducted emissions	Three phase AC 400 V filtered converters:	Single phase AC 230 V filtered converters:
Radiated emissions	EN 61800-3 Category C2/C3	EN 61800-3 Category C1/C2

#### Maximum power losses

Three ph	Three phase AC 400 V converters																
Frame siz	e	FSA						FSB	FSB FSC FSD				FSE				
Power	(kW)	0.37	0.55	0.7	1.1	1.5	2.2	3	4	5.5	7.5	11	15	18.5	22	22	30
rating				5										HO	LO	HO	LO
	(hp)	0.75	0.75	1	1.5	2	3	5	5	7.5	10	15	20	25	30	30	40
														HO	LO	HO	LO
Maximun loss (w) <sup>1</sup>	n power	25	28	33	43	54	68	82	100	145	180	276	338	387	475	457	626

<sup>1)</sup> With I/O fully loaded

Single phase AC 230 V converters											
Frame size FSAA/FSAB						FSAC		FSAD			
Power	(kW)	0.12	0.25	0.37	0.55	0.75	1.1	1.5	2.2	3.0	
rating	(hp)	0.17	0.33	0.5	0.75	1	1.5	2	3	4	
Maximum power loss (w) <sup>1)</sup>		14	22	29	39	48	57	87	138	177	

1) With I/O fully loaded

#### Note

Power losses are given for nominal supply voltage, default switching frequency, and rated output current. Changing these factors may result in increased power losses.

#### Note

Data regarding the power loss in accordance with EcoDesign Regulation (EU) 2019/1781 and IEC 61800-9-2

You can find data regarding power loss on the Internet:

Partial load operation (https://support.industry.siemens.com/cs/ww/en/view/94059311)

#### Harmonic currents

In order that you may operate a V20 230 V converter in the first environment, Category C2, you must observe the limit values for harmonic currents. V20 converters are not designed for general use in residential areas. They are professional equipment for use in trades, professions or industries and are not intended for sale to the general public. Please also observe and adhere to the following notes and instructions when operating a V20 230 V converter.

#### Note

#### Observing the limit values for harmonic currents

With respect to the compliance with limits for harmonic currents, the EMC product standard EN 61800-3 for V20 230 V converters refers to compliance with standards EN 61000-3-2 and EN 61000-3-12.

#### Note

For unrestricted operation on public low-voltage grids, further EMC measures may be necessary. Compliance with harmonic emission limits (IEC 61000-3-12 and IEC 61000-3-2) cannot be guaranteed.

• V20 230 V converters with the rated output power  $\leq 1$  kW and rated input current  $\leq 16$  A:

It cannot be guaranteed that the limit values comply with EN 61000-3-2. The installation person/company or company operating the professionally used device must obtain authorization from the grid operator to connect the device regarding the harmonic currents. For more information about typical harmonic currents of V20 230 V converters, see the following table.

• V20 230 V converters with the rated output power > 1 kW and rated input current  $\leq$  16 A:

These devices are not subject to any limit values, and as a consequence can be connected to the public low-voltage grid without any prior consultation.

• V20 230 V converters with the rated input current > 16 A and  $\leq$  75 A:

It cannot be guaranteed that the limit values comply with EN 61000-3-12. The installation person/company or company operating the professionally used device must obtain authorization from the grid operator to connect the device regarding the harmonic currents. For more information about typical harmonic currents of V20 230 V converters, see the following table.

Single phase AC 230	Typical harmonic current (% of rated input current) at U $\kappa$ 4%											
V converters	3rd	5th	7th	9th	11th	13th	17th	19th	23rd	25th	29th	
Frame size AA/AB	42	40	37	33	29	24	15	11	4	2	1	
Frame size AC	53	42	31	23	16	11	2	3	2	1	1	
Frame size AD	57	38	20	7	2	2	2	1	1	2	1	

#### Typical harmonic currents of V20 230 V converters

#### Output current deratings at different PWM frequencies and surrounding air temperatures

Three ph	Three phase AC 400 V converters												
Frame size	Power rating [kW]		Current rating [A] at PWM frequency PWM frequency range: 2 kHz to 16 kHz (default: 4 kHz)										
		2 kHz			4 kHz			6 kHz			8 kHz		
		40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C
А	0.37	1.3	1.0	0.7	1.3	1.0	0.7	1.1	0.8	0.5	0.9	0.7	0.5
А	0.55	1.7	1.3	0.9	1.7	1.3	0.9	1.4	1.0	0.7	1.2	0.9	0.6
А	0.75	2.2	1.8	1.1	2.2	1.8	1.1	1.9	1.3	0.9	1.5	1.1	0.8
А	1.1	3.1	2.6	1.6	3.1	2.6	1.6	2.6	1.9	1.3	2.2	1.6	1.1
А	1.5	4.1	3.4	2.1	4.1	3.4	2.1	3.5	2.5	1.7	2.9	2.1	1.4
А	2.2	5.6	4.6	2.8	5.6	4.6	2.8	4.8	3.4	2.4	3.9	2.8	2.0
В	3.0	7.3	6.3	3.7	7.3	6.3	3.7	6.2	4.4	3.1	5.1	3.7	2.6
В	4.0	8.8	8.2	4.4	8.8	8.2	4.4	7.5	5.3	3.7	6.2	4.4	3.1
С	5.5	12.5	10.8	6.3	12.5	10.8	6.3	10.6	7.5	5.3	8.8	6.3	4.4
D	7.5	16.5	14.5	8.3	16.5	14.5	8.3	14.0	9.9	6.9	11.6	8.3	5.8
D	11	25.0	21.0	12.5	25.0	21.0	12.5	21.3	15.0	10.5	17.5	12.5	8.8
D	15	31.0	28.0	15.5	31.0	28.0	15.5	26.4	18.6	13.0	21.7	15.5	10.9
E	18.5 (HO)	38.0	34.5	19.0	38.0	34.5	19.0	32.3	22.8	16.0	26.6	19.0	13.3
E	22 (LO)	45.0	40.5	22.5	45.0	40.5	22.5	38.3	27.0	18.9	31.5	22.5	15.8

Three pha	se AC 400 V co	onverter	s										
Frame size	Power rating [kW]		-	[A] at P			z (defau	I+• 4 60-	•)				
E	22 (HO)	45.0	40.5	22.5	45.0	40.5	22.5	38.3	27.0	18.9	31.5	22.5	15.8
E	30 (LO)	60.0	53.0	30.0	60.0	53.0	30.0	51.0	36.0	25.2	42.0	30.0	21.0
L.	50 (20)	10 kHz		50.0	12 kHz		50.0	14 kHz		23.2	16 kHz		21.0
		40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C
A	0.37	0.8	0.5	0.4	0.7	0.5	0.3	0.6	0.4	0.3	0.5	0.4	0.3
A	0.55	1.0	0.7	0.5	0.9	0.6	0.4	0.8	0.5	0.4	0.7	0.5	0.3
А	0.75	1.3	0.9	0.7	1.1	0.8	0.6	1.0	0.7	0.5	0.9	0.6	0.4
A	1.1	1.9	1.3	0.9	1.6	1.1	0.8	1.4	1.0	0.7	1.2	0.9	0.6
А	1.5	2.5	1.7	1.2	2.1	1.4	1.0	1.8	1.3	0.9	1.6	1.1	0.8
А	2.2	3.4	2.4	1.7	2.8	2.0	1.4	2.5	1.7	1.2	2.2	1.6	1.1
В	3.0	4.4	3.1	2.2	3.7	2.6	1.8	3.3	2.3	1.6	2.9	2.0	1.5
В	4.0	5.3	3.7	2.6	4.4	3.1	2.2	4.0	2.7	1.9	3.5	2.5	1.8
С	5.5	7.5	5.3	3.8	6.3	4.4	3.1	5.6	3.9	2.8	5.0	3.5	2.5
D	7.5	9.9	6.9	5.0	8.3	5.8	4.1	7.4	5.1	3.6	6.6	4.6	3.3
D	11	15.0	10.5	7.5	12.5	8.8	6.3	11.3	7.8	5.5	10.0	7.0	5.0
D	15	18.6	13.0	9.3	15.5	10.9	7.8	14.0	9.6	6.8	12.4	8.7	6.2
E	18.5 (HO)	22.8	16.0	11.4	19.0	13.3	9.5	17.1	11.8	8.4	15.2	10.6	7.6
E	22 (LO)	27.0	18.9	13.5	22.5	15.8	11.3	20.3	14.0	9.9	18.0	12.6	9.0
E	22 (HO)	27.0	18.9	13.5	22.5	15.8	11.3	20.3	14.0	9.9	18.0	12.6	9.0
E	30 (LO)	36.0	25.2	18.0	30.0	21.0	15.0	27.0	18.6	13.2	24.0	16.8	12.0

Single ph	Single phase AC 230 V converters												
Frame size	Power rating [kW]		urrent rating [A] at PWM frequency VM frequency range: 2 kHz to 16 kHz (default: 8 kHz)										
		2 kHz		<u> </u>	4 kHz			6 kHz	·		8 kHz		
		40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C
AA/AB	0.12	0.9	0.6	0.5	0.9	0.6	0.5	0.9	0.6	0.5	0.9	0.7	0.5
AA/AB	0.25	1.7	1.2	0.9	1.7	1.2	0.9	1.7	1.2	0.9	1.7	1.4	0.9
AA/AB	0.37	2.3	1.6	1.2	2.3	1.6	1.2	2.3	1.6	1.2	2.3	1.8	1.2
AA/AB	0.55	3.2	2.2	1.6	3.2	2.2	1.6	3.2	2.2	1.6	3.2	2.3	1.6
AA/AB	0.75	4.2	2.9	2.1	4.2	2.9	2.1	4.2	2.9	2.1	4.2	3.2	2.1
AC	1.1	6.0	4.2	3.0	6.0	4.2	3.0	6.0	4.2	3.0	6.0	4.2	3.0
AC	1.5	7.8	5.5	3.9	7.8	5.5	3.9	7.8	5.5	3.9	7.8	5.5	3.9
AD	2.2	11	7.7	5.5	11	7.7	5.5	11	7.7	5.5	11	7.7	5.5
AD	3.0	13.6	9.5	6.8	13.6	9.5	6.8	13.6	9.5	6.8	13.6	9.5	6.8
		10 kHz			12 kHz			14 kHz			16 kHz		
		40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C	40 °C	50 °C	60 °C
AA/AB	0.12	0.8	0.6	0.4	0.8	0.5	0.4	0.7	0.5	0.3	0.6	0.5	0.3
AA/AB	0.25	1.6	1.1	0.8	1.4	1.0	0.7	1.3	0.9	0.6	1.2	0.9	0.6
AA/AB	0.37	2.1	1.5	1.1	2.0	1.4	1.0	1.7	1.2	0.9	1.6	1.2	0.8
AA/AB	0.55	2.9	2.0	1.5	2.7	1.9	1.3	2.4	1.7	1.2	2.2	1.6	1.1

Single ph	Single phase AC 230 V converters												
Frame	Power	Curren	it rating	[A] at P	WM free	quency							
size	rating [kW]	PWM f	requend	y range	: 2 kHz t	to 16 kH	z (defau	lt: 8 kHz	<u>z)</u>				
AA/AB	0.75	3.9	2.7	1.9	3.6	2.5	1.8	3.2	2.2	1.6	2.9	2.1	1.5
AC	1.1	5.5	3.8	2.8	5.1	3.6	2.5	4.5	3.1	2.2	4.2	3.0	2.1
AC	1.5	7.2	5.0	3.6	6.6	4.7	3.3	5.9	4.1	2.9	5.5	3.9	2.7
AD	2.2	10.1	7.0	5.1	9.4	6.6	4.6	8.3	5.7	4.1	7.7	5.5	3.9
AD	3.0	12.5	8.7	6.3	11.6	8.2	5.7	10.2	7.1	5.0	9.5	6.8	4.8

## Motor control

Control methods	Linear V/F, quadratic V/F, mult	Linear V/F, quadratic V/F, multi-point V/F, V/F with FCC				
Output frequency range	Default range: 0 Hz to 550 Hz Resolution: 0.01 Hz					
Maximum overload cycle	Rated power 0.12 kW to 15 kW	150% rated for 60 seconds followed by 94.5% rated for 240 seconds $^{\mbox{\tiny 1)}}$				
	Rated power 18.5 kW (HO)/22 kW (HO)					
	Rated power 22 kW (LO)/30 kW (LO)	110% rated for 60 seconds followed by more than 98% rated for 240 seconds				

<sup>1)</sup> For 230 V converters with 0.75 kW power rating, make sure that you set P1800 to a value between 2 k and 10 k to fulfil the specified overload capabilities.

## **Mechanical specifications**

Frame size		FSAA	FSAB	FSAC	FSAD	FSA	FSA		FSC	FSD	FSE
						with fan	without fan				
Outline	W	68/2.7	68/2.7	90.8/	136.6/	90/3.5	90/3.5	140/5.5	184/7.24	240/9.4	245/
dimensions				3.6	5.4						9.6
(mm/inch)	Н	142/5.6	142/5.6	160.9/	176.5/	166/6.5	150/5.9	160/6.3	182/7.17	206.5/8.1	264.5/
				6.33	7.0						10.4
	D	107.8/4.2	127.8/5	147/	158.8/	145.5/5.7	145.5	164.5/6.5	169/6.7	172.5/6.8	209/
				5.8	6.3		(114.5 <sup>1)</sup> )/				8.2
							5.7(4.5 <sup>1)</sup> )				
Mounting methods			ng in a cor Irough moi			)					

<sup>1)</sup> Depth of Flat Plate converter (400 V 0.75 kW variant only).

Frame	size	Net weight (kg)		Gross weight (ke	g)
		unfiltered	filtered	unfiltered	filtered
Three p	hase AC 400 V cor	nverters			
FSA	with fan	1.0	1.1	1.4	1.4
	without fan	0.9	1.0 (0.9 <sup>1)</sup> )	1.3	1.4 (1.3 <sup>1)</sup> )
FSB		1.6	1.8	2.1	2.3
FSC		2.4	2.6	3.1	3.3
FSD	7.5 kW	3.7	4.0	4.3	4.6
	11 kW	3.7	4.1	4.5	4.8
	15 kW	3.9	4.3	4.6	4.9
FSE	18.5 kW	6.2	6.8	6.9	7.5
	22 kW	6.4	7.0	7.1	7.7
Single p	ohase AC 230 V co	nverters			
FSAA		0.6	0.7	1.0	1.1
FSAB		0.8	0.9	1.2	1.3
FSAC		1.2	1.4	1.3	1.5
FSAD		1.9	2.2	2.1	2.4

<sup>1)</sup> Weight of Flat Plate converter (400 V 0.75 kW variant only).

## Air flow requirement

Frame size	Air flow (cfm <sup>1)</sup> )	
Single phase AC 230 V converters		
FSAC	7.5	
FSAD	30	
Three phase AC 400 V converters		
FSA (with fan)	7.5	
FSB	20.2	
FSC	25	
FSD	73	
FSE	163	

<sup>1)</sup> Cubic feet per minute

## **Environmental conditions**

Surrounding	air temperature	- 10 °C to 40 °C: without derating					
		40 °C to 60 °C: with derating (UL/cUL-compliant: 40 °C to 50 °C, with derating)					
Storage temp		- 40 °C to + 70 °C					
Protection cla	ass	IP 20					
Maximum hu	umidity level	95% (non-condensing)					
Shock and vi							
Operation	Shock	Peak acceleration: 5 g, 30 ms and 15 g, 11 ms					
		Quantity of shocks: 3 per direction × 6 directions					
		Duration of shock: 1 s					
	Vibration	Vibration during operation according to EN 60721-3-3: 2002 Class 3M2					
		230 V converters: 9 Hz to 29 Hz: 0.3 mm deflection					
		29 Hz to 200 Hz: 1 g vibration					
		400 V converters: 10 Hz to 58 Hz: 0.075 mm deflection					
		58 Hz to 200 Hz: 1 g vibration					
Product	Vibration	Transport in the transport packaging according to EN 60721-3-2 Class 2M3					
packaging		Long-term storage in the transport packaging according to EN 60721-3-1 Class 1M2					
Installation a	ltitude	Up to 4000 m above sea level:					
		<ul> <li>For the installation altitude lower than or equal to 2000 m above sea level, it is permissible to connect a V20 converter to any of the mains supply systems that are specified for it.</li> <li>For the installation altitude higher than 2000 m and lower than or equal to 4000 m above sea level, you must connect a V20 converter to any of the specified mains supply systems either via an isolating transformer or with a grounded neutral point.</li> <li>1000 m to 4000 m: output current derating Permissible output current [%]</li> <li>         100         100         200         300         4000         Installation altitude above sea level [m]     </li> </ul>					
		2000 m to 4000 m: input voltage derating Permissible input voltage [%] 100 90 80 77 70 60 0 1000 2000 3000 4000 Installation altitude above sea level [m]					

Environmental classes	Pollution degree: 2
	Solid particles: class 3S2
	Chemical gases: class 3C2 (SO <sub>2</sub> , H <sub>2</sub> S)
	Climate class: 3K3
Minimum mounting clearance	Top: 100 mm
	Bottom: 100 mm (85 mm for fan-cooled frame size A)
	Side: 0 mm

#### **Directives and standards**

	European Low Voltage Directive
CE	The SINAMICS V20 product series and SINAMICS V20 Smart Access comply with the requirements of the Low Voltage Directive 2006/95/EC as amended by Directive 98/68/EEC. The units are certified for compliance with the following standards:
	EN 61800-5-1 — Semiconductor converters – General requirements and line commutated converters
	European EMC Directive
	When installed according to the recommendations described in this manual, the SINAMICS V20 and SINAMICS V20 Smart Access fulfill all requirements of the EMC Directive as defined by the EMC Product Standard for Power Drive Systems EN 61800-3.
	European RED Directive
	SINAMICS V20 Smart Access complies with the following requirements of Radio Equipment Directive (RED) 2014/53/EU:
	Article 3(1)(a) Health and Safety (EN 60950-1, EN 62479)
	• Article 3(1)(b) EMC (EN 301 489-1, EN 301 489-17)
	• Article 3(2) Spectrum (EN 300 328)
	Directive 2011/65/EU
	The converter fulfills the requirements of Directive 2011/65/EU relating to the restriction of the use of certain hazardous substances in electrical and electronic devices (RoHS).
	European Directive on Waste Electrical and Electronic Equipment (WEEE)
	The SINAMICS converter series complies with the 2012/19/EU directive on taking back and recycling waste electrical and electronic equipment.
	The CE Declaration of Conformity is held on file available to the competent authorities at the following address:
	Siemens AG
	Digital Industries
	Motion Control
	Frauenauracher Straße 80
	DE-91056 Erlangen
	Germany
	UK Declaration of Conformity
UK CA	The converters comply with the requirements for the market in Great Britain (England, Wales and Scotland).
	The SINAMICS V20 product series has been examined and certified by Underwriters Laboratories (UL) to
. (H) <b>1</b>	standards UL61800-5-1 and CSA C22.2 NO-14-10.
LISTED	UL file number: E355661
A	The SINAMICS V20 product series complies with the appropriate RCM standard.

	The SINAMICS V20 product series complies with the appropriate EAC standard.
EAL	
LIIL	
	The SINAMICS V20 product series and SINAMICS V20 Smart Access comply with the requirements of the Korean Certification (KC mark).
ß	The SINAMICS V20 series (FSAA, FSAB, FSAC, and FSAD excluded) has been defined as Class A equipment, which is intended for industrial applications and has not been considered for home use. The SINAMICS V20 FSAA, FSAB, FSAC, and FSAD products have been defined as Class B equipment, which are intended for both industrial applications and home use with additional EMC measures. <b>EMC limit values in South Korea</b>
	The EMC limit values to be complied with for South Korea correspond to the limit values of the EMC product standard for variable-speed electric drives EN 61800-3, Category C2 or limit value class A, Group 1 according to EN55011. By applying suitable supplementary measures, the limit values according to Category C2 or according to limit value class A, Group 1are maintained. Further, additional measures may be required, for instance, using an additional radio interference suppression filter (EMC filter). The measures for EMC-compliant design of the system are described in detail in this manual. Please note that the final statement on compliance with the standard is given by the respective label attached to the individual unit.
	Notice to users in South Korea:
	이 컴퓨터는 전자파 적합성평가(인증)를 받은 내장구성품을 사용하여 조립한것으로 완성품에 대한 전자파 적합성평가는 받지 않은 제품입니다.
ISO 9001	Siemens AG uses a quality management system that meets the requirements of ISO 9001.
FA	SINAMICS V20 Smart Access complies with the appropriate FCC standard.
	FCC compliance statement
	SINAMICS V20 Smart Access complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
	(1) This device may not cause harmful interference.
	(2) This device must accept any interference received, including interference that may cause undesired operation.
	Changes or modifications made to this device not expressly approved by SIEMENS may void the FCC authorization to operate this device.
	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
	Reorient or relocate the receiving antenna.
	Increase the separation between the equipment and receiver.
	Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
	<ul> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ul>
	RF exposure statement
	This equipment complies with radio frequency exposure limits set forth by the FCC for an uncontrolled environment.
	This equipment should be installed and operated with a minimum distance of 20 cm between the device and the user or bystanders.
	This device must not be co-located or operating in conjunction with any other antenna or transmitter.

WPC	SINAMICS V20 Smart Access complies with the appropriate WPC standard.
SRRC	SINAMICS V20 Smart Access complies with the appropriate SRRC standard.
ANATEL	SINAMICS V20 Smart Access complies with the appropriate ANATEL standard.
	ANATEL certificate number: 05956-18-00199
	This device must not be protected against harmful interference and it may not cause interference in authorized systems (see below for corresponding text in Portuguese):
	Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.
NCC	SINAMICS V20 Smart Access complies with the appropriate NCC standard.
	第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率  、加大功率或變更原設計之特性及功能。
	常十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即 停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定作業之無線電通信。低功 率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。
KVALITET	SINAMICS V20 Smart Access complies with the appropriate KVALITET standard.
А И 005 19	
MOT	SINAMICS V20 Smart Access complies with the appropriate MOT standard.
	Certificate number: 4667 / E&M / 2019
Type Approved No.: ESD-1918474C	SINAMICS V20 Smart Access complies with the appropriate NTC standard.
Approved by PTA (year)	SINAMICS V20 Smart Access complies with the appropriate PTA standard.
NBTC	SINAMICS V20 Smart Access conforms to the technical standards or requirements of NBTC (see below for corresponding text in Thai).
	เครื่องโทรคมนาคมและอุปกรณ์นี้มีความสอดคล้องตามมาตรฐานหรือข้อกำหนดทางเทคนิคของ กสทช.
TRA	SINAMICS V20 Smart Access complies with the appropriate TRA standard.
	TRA REGISTERED No.: ER62396/18
	DEALER No.: 0016335/08

IFETEL	SINAMICS V20 Smart Access complies with the appropriate IFETEL standard. Certificate number: RCPSI6S18-1816
UkrCEPRO	SINAMICS V20 Smart Access complies with the appropriate UkrCEPRO standard.
IMDA	SINAMICS V20 Smart Access complies with the appropriate IMDA standard. Complies with IMDA Standards [DA104037]
FAC + CU	SINAMICS V20 Smart Access complies with the appropriate FAC and CU standard.
SDPPI	SINAMICS V20 Smart Access complies with the appropriate SDPPI standard.

You can download the certificates from the following Internet link:

Website for certificates (http://support.automation.siemens.com/WW/view/en/60668840/134200)

# **Options and spare parts**

#### Note

#### Repair and replacement of equipment

Any defective parts or components must be replaced using parts contained in the relevant lists of spare parts or options.

Disconnect the power supply before opening the equipment for access.

## B.1 Options


For more information about recommended cable cross-sections and screw tightening torques, see the table "Recommended cable cross-sections and screw tightening torques" in Section "Terminal description (Page 45)".

#### Note


In order to gain access to the expansion port to fit the Parameter Loader or BOP Interface Module, remove the detachable transparent cover gently using just finger pressure. It is recommended to keep the cover in a safe place and refit it when the expansion port is not in use.

#### B.1.1 Parameter Loader

Article number: 6SL3255-0VE00-0UA1



## **Outline dimensions (mm)**



## Functionality

The Parameter Loader provides the ability to upload/download parameter sets between the converter and an SD card. It is only a commissioning tool and has to be removed during normal operation.

#### Note

To clone saved parameter settings from one converter to another, a Parameter Loader is required. For more information about clone steps, see the data transferring steps described in this section.

During parameter cloning, make sure you either connect the PE terminal to earth or observe ESD protective measures.

#### SD card socket

The Parameter Loader contains an SD card socket which is connected directly to the expansion port on the converter.

#### Battery power supply

In addition to the memory card interface, the Parameter Loader can hold two batteries (consumer grade, non-rechargeable carbon-zinc or alkaline AA size batteries only) which allow the converter to be powered directly from this option module to perform data transfer when the mains power is unavailable.

#### 

#### Risk of fire and explosion due to charging or short-circuiting of batteries

Battery charging or direct connection of plus (+) and minus (-) poles can cause leakage, heat generation, fire and even explosion.

- Do not charge the non-rechargeable batteries.
- Do not store and/or carry batteries with metallic products such as necklaces.

#### 

#### Risk of fire and explosion due to improper disposal of batteries

Direct contact with metallic products and/or other batteries can cause battery damage, liquid leakage, heat generation, fire and even explosion. Disposal of batteries in fire is extremely dangerous with a risk of explosion and violent flaring.



Do not discard batteries into trash cans. Place them in the designated public recycling area for waste batteries.

# 

#### Risk of environmental pollution


Casual disposal of batteries into water, trash cans, etc. can cause environmental pollution.

Collect and recycle the waste batteries in compliance with relevant environmental laws and regulations.

### Micro USB interface

As an alternative way to power the converter to perform data transfer when the mains power is unavailable, you can use a Micro USB cable to connect an external 5 V DC power supply to the Micro USB interface on the Parameter Loader. If the converter can be supplied from the mains power, it is not necessary to power the Parameter Loader either from the batteries or via a Micro USB cable.

## Fitting the Parameter Loader to the converter



#### Note

When the converters you desire to install include FSAA and/or FSAB converters and you want to install FSAA and/or FSAB converters side by side, to make sure that there is sufficient space to fit the parameter loader to the FSAA/FSAB converter, install all available FSAA converters to the farthest right, followed by all available FSAB converters and then all other frame sizes. There are no additional mounting sequence requirements for converters other than FSAA and FSAB.

#### **Recommended SD card**

Article number: 6SL3054-4AG00-2AA0

#### Using memory cards from other manufacturers

SD card requirement:

- Supported file format: FAT16 and FAT 32
- Maximum card capacity: 32 GB
- Minimum card space for parameter transfer: 8 KB

#### Note

You use memory cards from other manufacturers at your own risk. Depending on the card manufacturer, not all functions are supported (for example, download).

#### Methods to power on the converter

Use one of the following methods to power on the converter for downloading/uploading parameters:

- Power on from the mains supply.
- Power on from the built-in battery power supply. Press the power button on the Parameter Loader and the converter is powered on.
- Power on from an external 5 V DC power supply that is connected to the Parameter Loader. Press the power button on the Parameter Loader and the converter is powered on.

#### Transferring data from converter to SD card

- 1. Fit the option module to the converter.
- 2. Power on the converter.
- 3. Insert the card into the option module.
- 4. Set P0003 (user access level) = 3.
- 5. Set P0010 (commissioning parameter) = 30.

6. Set P0804 (select clone file). This step is necessary only when the card contains the data files that you do not desire to be overwritten.

P0804 = 0 (default): file name is clone00.bin

P0804 = 1: file name is clone01.bin

...

P0804 = 99: file name is clone99.bin

7. Set P0802 (transfer data from converter to card) = 2.

The converter displays "8 8 8 8 8" during transfer and the LED is lit up orange and flashes at 1 Hz. After a successful transfer, both P0010 and P0802 are automatically reset to 0. If any faults occur during the transfer, see Chapter "Faults and alarms (Page 341)" for possible reasons and remedies.

#### Transferring data from SD card to converter

There are two ways to perform a data transfer.

#### Method 1:

#### (Precondition: Converter is to be powered up after inserting the card)

- 1. Fit the option module to the converter.
- 2. Insert the card into the option module. Make sure the card contains the file "clone00.bin".
- 3. Power on the converter.

Data transfer starts automatically. Then the fault code F395 displays which means "Cloning has occurred. Do you want to keep the clone edits?".

4. To save the clone edits, press and the fault code is cleared. When the clone file is written to EEPROM, the LED is lit up orange and flashes at 1Hz.

If you do not wish to keep the clone edits, remove the card or the option module and restart the converter. The converter will power up with the fault code F395 (r0949 = 10) indicating that the previous cloning was aborted. To clear the fault code, press  $\square$ .

#### Method 2:

#### (Precondition: Converter is powered up before inserting the card)

- 1. Fit the option module to the powered converter.
- 2. Insert the card into the option module.
- 3. Set P0003 (user access level) = 3.
- 4. Set P0010 (commissioning parameter) = 30.
- 5. Set P0804 (select clone file). This step is necessary only when the card does not contain the file "clone00.bin". The converter copies by default the file "clone00.bin" from the card.
- 6. Set P0803 (transfer data from card to converter) = 2 or 3.

The converter displays "8 8 8 8 8" during transfer and the LED is lit up orange and flashes at 1 Hz. After a successful transfer, both P0010 and P0803 are automatically reset to 0.

Note that fault code F395 only occurs with power-up cloning.

## B.1.2 External BOP and BOP Interface Module

## **External BOP**

Article number: 6SL3255-0VA00-4BA1


The external BOP is used for remote control of the converter operation. When mounted on a suitable cabinet door, the external BOP can achieve a UL/cUL Type 1 enclosure rating. The permissible operating temperature range for the external BOP is from -10  $^{\circ}$ C to 50  $^{\circ}$ C.

#### Components

- External BOP unit
- 4 x M3 screws


### **Rating plate**

The rating plate for the external BOP is located on the back side of the BOP.



### Panel layout

The SINAMICS V20 supports an external BOP for remote control of converter operation. The external BOP connects to the converter through an optional BOP Interface Module.



#### **Button functions**

Button	Description
	Stops the converter
O	Button functions the same as the <b>O</b> button on the built-in BOP.
	Starts the converter
	Button functions the same as the 📕 button on the built-in BOP.
	Multi-function button
м	Button functions the same as the $\square$ button on the built-in BOP.
	Pressing the button:
OK	Button functions the same as the $\hfill \kappa$ button on the built-in BOP.
UN	Turning clockwise:
	Button functions the same as the 🔺 button on the built-in BOP. Fast turning
	functions the same as long press of the 🔺 button on the built-in BOP.
	Turning counter-clockwise:
	Button functions the same as the 💌 button on the built-in BOP. Fast turning
	functions the same as long press of the 🔽 button on the built-in BOP.
Z	Button functions the same as the $\mathbf{I} + \mathbf{M}$ buttons on the built-in BOP.

#### Converter status icons

8	These icons have the same meaning as the corresponding icons on the built-in BOP.
A	
•	
$\sim$	
2	
Ť	Commissioning icon. The converter is in commissioning mode (P0010 = 1).

#### Screen display

The display of the external BOP is identical to the built-in BOP, except that the external BOP has a commissioning icon **Y** which is used to indicate that the converter is in commissioning mode.

On converter power-up, the converter-connected external BOP first displays "BOP.20" (BOP for the SINAMICS V20) and then the firmware version of the BOP. After that it detects and displays the baudrate and the USS communication address of the converter automatically.


See the following table for settable baudrate and address values. To change the baudrate, set P2010[0]. To change the USS communication address, set P2011[0].

Baudrate	Communication address	Display example
(bps)		
9600	0 31	
19200	0 31	38.4.00
38400	0 31	
57600	0 31	Baudrate: 38400 Address: 0
76800	0 31	
93750	0 31	
115200	0 31	

In case of any communication errors, the screen displays "noCon" which means that no communication connection has been detected. The converter then automatically restarts baudrate and address detection. In this case, check that the cable is correctly connected.

### Mounting dimensions of the external BOP

The outline dimensions, drill pattern and cut-out dimensions of the external BOP are shown below:



Unit: mm Fixings: 4 x M3 screws (length: 8 mm to 12 mm) Tightening torque: 0.8 Nm ± 10%

### **BOP Interface Module**

Article number: 6SL3255-0VA00-2AA1

#### Functionality

This module can be used as an interface module for the external BOP, thus realizing the remote control over the converter by the external BOP.

The module contains a communication interface for connecting the external BOP to the converter and a plug connector for connection to the expansion port on the converter. The permissible operating temperature range for the BOP Interface Module is from -10 °C to 50 °C.



#### **Outline dimensions (mm)**




### Mounting (SINAMICS V20 + BOP Interface Module + external BOP)

#### Note

Connecting the BOP Interface Module to the external BOP is required only when you desire to control the converter operation remotely with the external BOP. The BOP Interface Module needs to be screwed to the converter with a tightening torque of 1.5 Nm (tolerance:  $\pm 10\%$ ).

#### Note

Make sure that you connect the cable shield to the shield connection kit. For more information about the shielding method, see Section "EMC-compliant installation (Page 52)".



## B.1.3 Dynamic braking module

Article number: 6SL3201-2AD20-8VA0

#### Note

This module is applicable for frame sizes AA to C only.

#### Functionality


The dynamic braking module is typically used in applications in which dynamic motor behavior is required at different speed or continuous direction changes, for example, for conveyor drives or hoisting gear.

Dynamic braking converts the regenerative energy, which is released when the motor brakes, into heat. Dynamic braking activity is limited by the duty cycle selected with the control knob.


For more information about the dynamic braking module, see Section "Setting the braking function (Page 100)".

#### **Mounting orientation**

The dynamic braking module must be installed in the orientation as shown in the following diagram. That is, the open slots must always point directly upwards to ensure adequate cooling.



## Drill pattern (mm)



#### **Recommended cable cross-sections**

Converter frame size	Rated output power	Cable cross-sections for DC terminals (DC-, DC+)
230 V		
FSAA/FSAB	0.12 0.75 kW	1.0 mm <sup>2</sup>
FSAC	1.1 1.5 kW	2.5 mm <sup>2</sup>
FSAD	2.2 3.0 kW	4.0 mm <sup>2</sup>
400 V		
FSA	0.37 0.75 kW	1.0 mm <sup>2</sup>
	1.1 2.2 kW	1.5 mm <sup>2</sup>
FSB	3.0 4.0 kW	2.5 mm <sup>2</sup>
FSC	5.5 kW	4.0 mm <sup>2</sup>

Note: Do not use the cables with cross-sections less than 0.3 mm<sup>2</sup> (for converter frame size AA/AB/A)/0.5 mm<sup>2</sup> (for converter frame sizes AC/AD/B/C). Use a screw tightening torque of 1.0 Nm/8.9 lbf.in (tolerance: ±10%).

#### NOTICE

#### **Destruction of device**

It is extremely important to ensure that the polarity of the DC link connections between the converter and the dynamic braking module is correct. If the polarity of the DC terminals' connections is reversed, it could result in the destruction of the converter and the module.

### **Status LEDs**

LED	Color	Description
POWER	Yellow	Module is powered up.
STATUS	Red	Module is in protection mode.
ACTIVE	Green	Module is releasing regenerative energy produced when the motor brakes into heat.

#### **Duty cycle selection**

#### NOTICE

#### Damage to the braking resistor

Incorrect setting for the duty cycle/voltage could damage the attached braking resistor. Use the control knob to select the rated duty cycle of the braking resistor.

Value labels on the module have the following meanings:

Label	Meaning
230 V	Duty cycle values labeled are for 230 V converters
400 V	Duty cycle values labeled are for 400 V converters
5	5% duty cycle
10	10% duty cycle
20	20% duty cycle
50	50% duty cycle
100	100% duty cycle

### **Technical specifications**

	One phase AC 230 V converters	Three phase AC 400 V converters			
Peak power rating	3.0 kW	5.5 kW			
RMS current at peak power	8.0 A	7.0 A			
Maximum continuous power rating	3.0 kW	4.0 kW			
Maximum continuous current rating	8.0 A	5.2 A			
Maximum continuous power rating (side-by-side mounted)	1.5 kW	2.75 kW			
Maximum continuous current rating (side-by- side mounted)	4.0 A	3.5 A			
Surrounding air temperature	- 10 °C to 50 °C: without derating	- 10 °C to 40 °C: without derating 40 °C to 50 °C: with derating			
Maximum continuous current rating at 50 °C surrounding air temperature	8.0 A	1.5 A			
Outline dimensions (L x W x D)	150 x 90 x 88 (mm)				
Mounting	Mounting in a control cabinet (4 x M	4 screws)			
Maximum duty cycle	100%				
Protection functions	Short-circuit protection, over-temper	ature protection			
Maximum cable length	Braking module to converter: 1 m				
	Braking module to braking resistor: 10 m				
UL file number	E355661				

#### Note

Mounting dynamic braking modules side-by-side causes derating of power and current to the modules. To avoid this, Siemens recommends that you observe the clearance requirements for V20 converters when mounting the dynamics braking modules. For more information, see Section "Mounting orientation and clearance (Page 27)".

## B.1.4 Braking resistor

## 

#### **Operating conditions**

Make sure that the resistor to be fitted to the SINAMICS V20 is adequately rated to handle the required level of power dissipation.

All applicable installation, usage and safety regulations regarding high voltage installations must be complied with.

If the converter is already in use, disconnect the prime power and wait at least five minutes for the capacitors to discharge before commencing installation.

This equipment must be earthed.



# 

#### Hot surface

Braking resistors get hot during operation. Do not touch the braking resistor during operation.

Using an incorrect braking resistor can cause severe damage to the associated converter and may result in fire.

A thermal cut-out circuit (see diagram below) must be incorporated to protect the equipment from overheating.

#### NOTICE

#### Device damage caused by improper minimum resistance values

A braking resistor with a resistance lower than the following minimum resistance values can damage the attached converter or braking module:

- 400 V converter frame sizes A to C: 56  $\Omega$
- 400 V converter frame size D/E: 27  $\Omega$
- 230 V converter frame sizes AA to AD: 37  $\Omega$

### Functionality

An external braking resistor can be used to "dump" the regenerative energy produced by the motor, thus giving greatly improved braking and deceleration capabilities.

A braking resistor which is required for dynamic braking can be used with all frame sizes of converters. Frame size D and E are designed with an internal braking module, allowing you to connect the braking resistor directly to the converter; however, for frame sizes AA to C, an additional dynamic braking module is required for connecting the braking resistor to the converter.

## Ordering data

Frame size	Converter power rating	Resistor article number	Continuous power	Peak power (5% duty cycle)	Resistance ± 10%	DC voltage rating	
Three phase	AC 400 V converters						
FSA	0.37 kW	6SL3201-0BE14-3AA0	75 W	1.5 kW	370 Ω	840 V +10%	
	0.55 kW						
	0.75 kW						
	1.1 kW						
	1.5 kW						
	2.2 kW	6SL3201-0BE21-0AA0	200 W	4.0 kW	140 Ω	840 V +10%	
FSB	3 kW						
	4 kW						
FSC	5.5 kW	6SL3201-0BE21-8AA0	375 W	7.5 kW	75 Ω	840 V +10%	
FSD	7.5 kW						
	11 kW	6SL3201-0BE23-8AA0	925 W	18.5 kW	30 Ω	840 V +10%	
	15 kW						
FSE	18.5 kW	6SE6400-4BD21-2DA0	1200 W	24 kW	27 Ω	900 V	
	22 kW						
Single phase	AC 230 V converter	5			•		
FSAA/FSAB	0.12 kW	6SE6400-4BC05-0AA0	50 W	1.0 kW	180 Ω	450 V	
	0.25 kW						
	0.37 kW						
	0.55 kW						
	0.75 kW						
FSAC	1.1 kW	JJY:023151720007 <sup>1)</sup>	110 W	2.2 kW	68 Ω	450 V	
	1.5 kW						
FSAD	2.2 kW	JJY:023163720018 <sup>1)</sup>	200 W	4 kW	37 Ω	450 V	
	3 kW						

Note that all the resistors below are rated for a maximum duty cycle of 5%.

<sup>1)</sup> Manufacturer: Heine Resistor GmbH


## **Technical data**


Surrounding operating temperature:	-10° C to +50° C
Storage/transport temperature:	-40° C to +70° C
Degree of protection:	IP20
Humidity:	0% to 95% (non-condensing)
cURus file number:	E221095 (Gino)
	E219022 (Block)

## Installation

# For three phase AC 400 V converters FSA to FSD and single phase AC 230 V converters FSAC to FSAD


The resistors can be installed in a vertical or horizontal position and secured to a heat resistant surface. The required minimum clearance distances are shown below:





# For single phase AC 230 V converters FSAA to FSAB and three phase AC 400 V converter FSE

The resistors must be installed in a vertical position and secured to a heat resistant surface. At least 100 mm must be left above, below and to the side of the resistor to allow an unimpeded airflow.




## **Mounting dimensions**

<b>Resistor article</b>	Dimensions (mm)									Wei	Fixin	g screw	Applicable V20
number	L	L1	L2	L3	D	D1	D2	w	W1	ght (kg)	Size	Tighte ning torque (Nm)	frame sizes
Three phase AC 400 V	onver	ters											
6SL3201-0BE14-3AA0	295	266	-	-	100	-	-	105	72	1.48	M4 (4)	3.0	FSA (0.37 to 1.5 kW)
6SL3201-0BE21-0AA0	345	316	-	-	100	-	-	105	72	1.80	M4 (4)	3.0	<ul> <li>FSA (2.2 kW)</li> <li>FSB (3 to 4 kW)</li> </ul>
6SL3201-0BE21-8AA0	345	316	-	-	100	-	-	175	142	2.73	M4 (4)	3.0	<ul> <li>FSC (5.5 kW)</li> <li>FSD (7.5 kW)</li> </ul>
6SL3201-0BE23-8AA0	490	460	-	-	140	-	-	250	217	6.20	M5 (4)	6.0	FSD (11 to 15 kW)
6SE6400-4BD21-2DA0	515	350	205	195	175	242	210	270	315	7.4	M4 (4)	3.0	FSE (18.5 to 22 kW)
Single phase AC 230 V	conver	ters											
6SE6400-4BC05-0AA0	230	217	-	-	43.5	-	-	72	56	1.0	M4 (4)	3.0	FSAA/FSAB (0.12 to 0.75 kW)
JJY:023151720007 <sup>1)</sup>	217	200	-	-	60	-	-	30	10	0.7	M4 (2)	3.0	FSAC (1.1 to 1.5 kW)
JJY:023163720018 <sup>1)</sup>	337	320	-	-	60	-	-	30	10	1.1	M4 (2)	3.0	FSAD (2.2 to 3 kW)

<sup>1)</sup> Manufacturer: Heine Resistor GmbH

### Connection

The mains supply to the converter can be provided through a contactor which disconnects the supply if the resistor overheats. Protection is provided by a thermal cut-out switch (supplied with each resistor). The cut-out switch can be wired in-series with the coil supply for the main contactor (see diagram below). The thermal switch contacts close again when the resistor temperature falls; after which the converter starts automatically (P1210 = 1). A fault message is generated with this parameter setting.



### Commissioning

The braking resistors are designed to operate on a 5% duty cycle. For converter frame size D and E, set P1237 = 1 to enable the braking resistor function. For other frame sizes, use the dynamic braking module to select the 5% duty cycle.

#### Note

#### **Additional PE terminal**

Some resistors have an additional PE connection available on the resistor housing.

## B.1.5 Line reactor



# 

#### Heat during operation

The line reactors get hot during operation. Do not touch. Provide adequate clearance and ventilation.

When operating the larger line reactors in an environment with a surrounding air temperature in excess of  $40^{\circ}$  C, the wiring of the terminal connections must be accomplished using  $75^{\circ}$  C copper wire only.



## 

### Risk of equipment damage and electric shocks

Some of the line reactors in the table below have pin crimps for the connection to the converter's mains terminals.

Use of these pin crimps can cause damage to the equipment and even electric shocks.

For safety reasons, replace the pin crimps using UL/cUL-certified fork crimps or stranded cables.

# 

### **Protection rating**

The line reactors have a protection rating of IP20 in accordance with EN 60529 and are designed to be mounted inside a cabinet.

## Functionality

The line reactors are used to smooth voltage peaks or to bridge commutating dips. They also can reduce the effects of harmonics on the converter and the line supply.


The larger line reactors for the 230 V variants of converters have side mounting brackets to allow side-by-side mounting (see diagram below).

# Ordering data


Frame size	Converter power rating	Line reactor							
		Article number	Voltage	Current					
Three phase A	C 400 V converters								
FSA	0.37 kW	6SL3203-0CE13-2AA0	380 V to 480 V	4.0 A					
	0.55 kW								
	0.75 kW								
	1.1 kW								
	1.5 kW	6SL3203-0CE21-0AA0	380 V to 480 V	11.3 A					
	2.2 kW								
FSB	3 kW								
	4 kW								
FSC	5.5 kW	6SL3203-0CE21-8AA0	380 V to 480 V	22.3 A					
FSD	7.5 kW								
	11 kW	6SL3203-0CE23-8AA0	380 V to 480 V	47.0 A					
	15 kW								
FSE	18.5 kW	6SL3203-0CJ24-5AA0	200 V to 480 V	53.6 A					
	22 kW	6SL3203-0CD25-3AA0	380 V to 600 V	86.9 A					
Single phase A	AC 230 V converters								
FSAA/FSAB	0.12 kW	6SE6400-3CC00-4AB3	200 V to 240 V	3.4 A					
	0.25 kW								
	0.37 kW	6SE6400-3CC01-0AB3	200 V to 240 V	8.1 A					
	0.55 kW								
	0.75 kW								
FSAC	1.1 kW	6SE6400-3CC02-6BB3	200 V to 240 V	22.8 A					
	1.5 kW	7							
FSAD	2.2 kW	6SE6400-3CC03-5CB3	200 V to 240 V	29.5 A					
	3 kW	7							

## Connecting the line reactor to the converter

The following illustration takes the line reactors for the 230 V variants of converters as an example.




## Mounting dimensions



## For three phase AC 400 V converters FSA to FSD


Article	Dimer	Dimensions (mm)							screw	Cable cross	Applicable V20
number 6SL3203	A	В	с	D	E	F	ht (kg)	Size	Tightening torque (Nm)	section (mm²)	frame sizes
0CE13-2AA0	120	125	71	-	55	100	1.10	M4 (4)	3.0	2.5	FSA (0.37 to 1.1 kW)
0CE21-0AA0	140	125	71	-	55	100	2.10	M4 (4)	3.0	2.5	<ul> <li>FSA (1.5 to 2.2 kW)</li> <li>FSB (3 to 4 kW)</li> </ul>
OCE21-8AA0	145	125	81	91	65	100	2.95	M5 (4)	5.0	6.0	<ul> <li>FSC (5.5 kW)</li> <li>FSD (7.5 kW)</li> </ul>
0CE23-8AA0	220	190	91	-	68	170	7.80	M5 (4)	5.0	16.0	FSD (11 to 15 kW)


## For three phase AC 400 V converter FSE




Article number 6SL3203-	Electrical characte		Overa dimer (mm)			Fixing	g dime	ension	s (mr	1)	Fixing screw	Weight (kg)
	Voltage (V)	Current (A)	А	В	C	D	E	F	G	H		
0CJ24- 5AA0	380 to 480	47	455	275	84	235	235	421	419	325	4 x M8 (13 Nm)	13
0CD25- 3AA0		63										

For single phase AC 230 V converters







Article number 6SE6400	Dimensions (mm)							Fixing screw		Cable cross section (mm <sup>2</sup> )		Applicable V20 frame sizes	
	A	В	с	D	E	F		Size	Tightening torque (Nm)	Min.	Max.		
3CC00-4AB3	200	75.5	50	56	56	187	0.5	M4 (2)	1.1	1.0	2.5	• FSAA (0.12 to 0.25 kW)	
3CC01-0AB3	200	75.5	50	56	56	187	0.5	M4 (2)				<ul> <li>FSAA (0.37 kW)</li> <li>FSAB (0.55 to 0.75 kW)</li> </ul>	
3CC02-6BB3	213 (233*)	150	50	138	120	200	1.2	M4 (4)	1.5	1.5	6.0	• FSAC (1.1 to 1.5 kW)	
3CC03-5CB3	245 (280*)	185	50 (50/80*)	174	156	230	1.0	M5 (4)	2.25	2.5	10	• FSAD (2.2 to 3 kW)	

\* Height with side-mounting bracket

## B.1.6 Output reactor

## 

#### **Pulse frequency restriction**

The output reactor works only at 4 kHz switching frequency. Before the output reactor is used, parameters P1800 and P0290 must be modified as follows: P1800 = 4 and P0290 = 0 or 1.

## Functionality

The output reactor reduces the voltage stress on the motor windings. At the same time, the capacitive charging/discharging currents, which place an additional load on the converter output when long motor cables are used, are reduced.

For safety reasons, it is recommended to use a shielded cable (maximum length: 200 m) to connect the output reactor. When the output reactor is used, the output frequency of the converter must be no more than 150 Hz.

Note that the output reactors comply with degree of protection of IP20.

## **Ordering data**

Frame size	Converter power rating	Output reactor							
		Article number	Voltage	Current					
Three phase A	C 400 V converters								
FSA	0.37 kW	6SL3202-0AE16-1CA0	380 V to 480 V	6.1 A					
	0.55 kW								
	0.75 kW								
	1.1 kW								
	1.5 kW								
	2.2 kW	6SL3202-0AE18-8CA0	380 V to 480 V	9.0 A					
FSB	3 kW								
	4 kW	6SL3202-0AE21-8CA0	380 V to 480 V	18.5 A					
FSC	5.5 kW								
FSD	7.5 kW	6SL3202-0AE23-8CA0	380 V to 480 V	39.0 A					
	11 kW								
	15 kW								
FSE	18.5 kW	6SE6400-3TC03-8DD0	380 V to 480 V	45.0 A					
	22 kW	6SE6400-3TC05-4DD0	380 V to 480 V	68.0 A					
Single phase A	C 230 V converters			·					
FSAA/FSAB	0.12 kW	6SL3202-0AE16-1CA0	200 V to 480 V	6.1 A					
	0.25 kW								
	0.37 kW								
	0.55 kW								
	0.75 kW								
	1.1 kW								
FSAC	1.5 kW	6SL3202-0AE18-8CA0	200 V to 480 V	9.0 A					
FSAD	2.2 kW	6SL3202-0AE21-8CA0	200 V to 480 V	18.5 A					
	3 kW								


## Connecting the output reactor to the converter

 Image: Constraint of the motor


 Image: Constraint of the motor

The following illustration takes the output reactor for the single phase 230 V FSAC as an example.

## **Mounting dimensions**



#### For three phase AC 400 V converters FSA to FSD and single phase AC 230 V converters




## Options and spare parts

B.1 Options

Article number	Dime	nsions	(mm)				Weig	Fixing screw	Cable	Applicable V20 frame sizes
6SL3202	A	В	с	D	E	F	ht (kg)	Size (Tightening torque)	cross section (mm²)	
0AE16-1CA0	175	178	72.5	166	56.5	207	3.4	M4 * 4	4.0	Three phase AC 400 V converters:
								(3.0 Nm)		• FSA (0.37 to 1.5 kW) Single phase AC 230 V converters:
										• FSAA/FSAB (0.12 to 0.75 kW)
										• FSAC (1.1 kW)
0AE18-8CA0	180	178	72.5	166	56.5	207	3.9	M4 * 4	4.0	Three phase AC 400 V converters:
								(3.0 Nm)		• FSA (2.2 kW)
										• FSB (3 kW)
										Single phase AC 230 V converters:
										• FSAC (1.5 kW)
0AE21-8CA0	215	243	100	225	80.5	247	10.1	M5 * 4	10.0	Three phase AC 400 V converters:
								(5.0 Nm)		• FSB (4 kW)
				• FSC (5.5 kW)						
										Single phase AC 230 V converters:
										• FSAD (2.2 to 3 kW)
0AE23-8CA0	235	243	114.7	225	84.7	257	11.2	M5 * 4	16.0	Three phase AC 400 V converters:
								(5.0 Nm)		• FSD (7.5 to 15 kW)

## For three phase AC 400 V converter FSE



Article number					Overall dimensions (mm)			Fixing dim (mm)	iensions	Fixing screw	Weight (kg)
6SE6400 -	Voltage (V)	Current (A)	Torque (Nm)	bolt	Н	w	D	n1	n2		
3TC05- 4DD0	200 to 480	54	3.5 to 4.0	M5	210	225	150	70	176	M6	10.7
3TC03- 8DD0	380 to 480	38	3.5 to 4.0	M5	210	225	179	94	176	M6	16.1

### B.1.7 External line filter



### WARNING

#### Risk of equipment damage and electric shocks

Some of the line filters in the table below have pin crimps for the connection to the converter's PE and mains terminals.

Use of these pin crimps can cause damage to the equipment and even electric shocks.

For safety reasons, replace the pin crimps using appropriately sized UL/cUL-certified fork or ring crimps for PE terminal connection, and using UL/cUL-certified fork crimps or stranded cables for mains terminal connection.

#### Note

The line filter with an article number of 6SE6400-2FL02-6BB0 in the following table has two DC terminals (DC+, DC-) that are not used and should not be connected. The cables of these terminals need to be cut back and suitably insulated (for example, with heat shrink shroud).

#### Functionality

In order to achieve EN61800-3 radiated and conducted emission category C1/C2 (level equivalent to EN55011, Class B/A1) for 230 V unfiltered converters and achieve C2 for 400 V unfiltered converters, the external line filters shown below are required. In this case, only a screened output cable can be used. For more information about the maximum cable length, see Section "Terminal description (Page 45)".

# Ordering data


Frame size	Converter power	Line filter				
	rating	Article number	Voltage	Current		
Three phase A	C 400 V converters					
FSA	0.37 kW	6SL3203-0BE17-7BA0	380 V to 480 V	11.4 A		
	0.55 kW					
	0.75 kW					
	1.1 kW					
	1.5 kW					
	2.2 kW					
FSB	3 kW	6SL3203-0BE21-8BA0	380 V to 480 V	23.5 A		
	4 kW					
FSC	5.5 kW					
FSD	7.5 kW	6SL3203-0BE23-8BA0	380 V to 480 V	49.4 A		
	11 kW					
	15 kW					
FSE	18.5 kW	6SL3203-0BE27-5BA0	380 V to 480 V	72 A		
	22 kW					
Single phase A	C 230 V converters					
FSAA/FSAB	0.12 kW	6SL3203-0BB21-8VA0	200 V to 240 V	20 A		
	0.25 kW					
	0.37 kW					
	0.55 kW					
	0.75 kW					
FSAC	1.1 kW					
	1.5 kW					
FSAD	2.2 kW	Siemens recommends	200 V to 240 V	30 A		
	3 kW	that you use the line filter of Type "Schaffner FS41095-30-44" or equivalent.				

#### Installation

For the EMC-compliant installation of the external line filters, refer to Section "EMC-compliant installation (Page 52)".


### Connecting the line filter to FSAA ... FSAC

The figure below is an example that shows how to connect the line filter to the converter.




#### Connecting the line filter to FSAD

The figure below is an example that shows how to connect the line filter to the converter.





#### Connecting the line filter to FSA ... FSE

The figure below is an example that shows how to connect the line filter to the converter.




### Mounting dimensions





E

′C



Article number	Dimensions (mm)			Wei Fixing screw ght (kg)		Cable cross section (mm <sup>2</sup> )		Applicable V20 frame sizes			
	A	В	С	D	E	9	Size	Tightening torque (Nm)	Min.	Max	
Three phase AC 400 V	conver	ters									
6SL3203-0BE17-7BA0	202	73	65	36.5	186	1.75	M4 (4)	0.6 to 0.8	1.0	2.5	FSA (0.37 to 2.2 kW)
6SL3203-0BE21-8BA0	297	100	85	80	281	4.0	M4 (4)	1.5 to 1.8	1.5	6.0	<ul><li>FSB (3 to 4 kW)</li><li>FSC (5.5 kW)</li></ul>
6SL3203-0BE23-8BA0	359	140	95	120	343	7.3	M4 (4)	2.0 to 2.3	6.0	16.0	FSD (7.5 to 15 kW)
6SL3203-0BE27-5BA0	400	100	140	75	385	7.6	M6 (4)	3.0	16.0	50.0	FSE (18.5 to 22 kW)
Single phase AC 230 V	conve	rters									
6SL3203-0BB21-8VA0	168	59	53	-	143	0.9	M4 (2)	1.5	2.5	4	• FSAA/FSAB (0.12 to 0.75 kW)
											<ul> <li>FSAC (1.1 to 1.5 kW)</li> </ul>
FS41095-30-44*	244	80	50	60	215	1.0	M5 (4)	1.0 to 1.2	0.5	6.0	FSAD (2.2 to 3 kW)

Siemens recommends that you use the line filter of Type "Schaffner FS41095-30-44" or equivalent. For more information about this filter, contact the manufacturer.

### B.1.8 Shield connection kits

### Functionality

The shield connection kit is supplied as an option for each frame size. It allows easy and efficient connection of the necessary shield to achieve EMC-compliant installation of the converter (see Section "EMC-compliant installation (Page 52)" for details).

#### Components


Converter	Shield connection kit						
variant	Illustration	Components					
FSAA/FSAB	Article number: 6SL3266-1AR00-0VA0	<ol> <li>Shielding plate</li> <li>3 × cable shield clamps</li> <li>4 × M4 screws (tightening torque: 1.8 Nm ± 10%)</li> </ol>					
FSAC	Article number: 6SL3266-1AU00-0VA0	<ol> <li>Shielding plate</li> <li>3 × cable shield clamps</li> <li>4 × M4 screws (tightening torque: 1.8 Nm ± 10%)</li> </ol>					
FSAD	Article number: 6SL3266-1AV00-0VA0	<ul> <li>(1) Shielding plate</li> <li>(2) 3 × cable shield clamps</li> <li>(3) 4 × M4 screws (tightening torque: 1.8 Nm ± 10%)</li> </ul>					

Converter	Shield connection kit					
FSA	Article number: 6SL3266-1AA00-0VA0	<ol> <li>Shielding plate</li> <li>3 × cable shield clamps</li> <li>4 × M4 screws (tightening torque: 1.8 Nm ± 10%)</li> </ol>				
FSB	Article number: 6SL3266-1AB00-0VA0	<ul> <li>(1) Shielding plate</li> <li>(2) 2 × clips<sup>1</sup>)</li> <li>(3) 3 × cable shield clamps</li> <li>(4) 7 × M4 screws (tightening torque: 1.8 Nm ± 10%)</li> </ul>				
FSC	Article number: 6SL3266-1AC00-0VA0	<ul> <li>(1) Shielding plate</li> <li>(2) 2 × clips<sup>1</sup>)</li> <li>(3) 3 × cable shield clamps</li> <li>(4) 7 × M4 screws (tightening torque: 1.8 Nm ± 10%)<sup>2</sup>)</li> </ul>				

Converter	Shield connection kit	
FSD/FSE	Article number: 6SL3266-1AD00-0VA0 (FSD) Article number: 6SL3266-1AE00-0VA0 (FSE)	<ul> <li>(1) Shielding plate</li> <li>(2) 2 × clips<sup>1</sup>)</li> <li>(3) 4 × cable shield clamps</li> <li>(4) 8 × M4 screws (tightening torque: 1.8 Nm ± 10%)<sup>2</sup>)</li> </ul>


- <sup>1)</sup> The clips are required only when fixing the shielding plate to a converter mounted in a control cabinet.
- <sup>2)</sup> For "push-through" applications, you must use two M5 screws and nuts (tightening torque: 2.5 Nm ± 10%) rather than two M4 screws ("<sup>1</sup> in the illustration) to fix the shielding plate to the converter.

### **Outline dimensions (mm)**



# Fixing the shield connection kit to the converter

If the converter is mounted in a contro	l cabinet:	
Fixing to FSAA/FSAB		<ol> <li>Loosen the PE screw and slide the shielding plate from below, then retighten the screw to 1.8 Nm (tolerance: ± 10%).</li> <li>Fold the cable shield clamp to suit the cable diameter during converter installation.</li> </ol>
Fixing to FSA/FSAC/FSAD		<ol> <li>Loosen the PE screw and slide the shielding plate from below, then retighten the screw to 1.8 Nm (tolerance: ± 10%).</li> <li>Clamp the heatsink between the shielding plate and the cabinet panel and tighten the screws and nuts to 1.8 Nm (tolerance: ± 10%).</li> <li>Fold the cable shield clamp to suit the cable diameter during converter installation.</li> </ol>
FSA	FSAC/FSAD	



### B.1.9 Memory card

#### Functionality

A memory card can be used on the Parameter Loader and allows you to upload/download parameter sets to/from the converter. For detailed use of the memory card, refer to Appendix "Parameter Loader (Page 367)".

#### Article number

Recommended SD card: 6SL3054-4AG00-2AA0

#### B.1.10 RS485 termination resistor

An RS485 termination resistor is used to terminate the bus for the RS485 communication between the SINAMICS V20 and SIEMENS PLCs. For detailed use of the termination resistor, refer to Section "Communicating with the PLC (Page 183)".

Article number: 6SL3255-0VC00-0HA0

### B.1.11 Residual current circuit breaker (RCCB)

#### Note

The SINAMICS V20 converter has been designed to be protected by fuses; however, as the converter can cause a DC current in the protective earthing conductor, if a Residual Current Circuit Breaker (RCCB) is to be used upstream in the supply, observe the following:

- SINAMICS V20 single phase AC 230 V converters (filtered) FSAC and FSAD can be operated only on a type A<sup>1)</sup> 100 mA or type B(k) 300 mA RCCB.
- All SINAMICS V20 three phase AC 400 V converters (filtered or unfiltered) can be operated on a type B(k) 300 mA RCCB.
- SINAMICS V20 three phase AC 400 V converters (unfiltered) FSA to FSD and FSA (filtered) can be operated on a type B(k) 30 mA RCCB.
- When multiple converters are in use, one converter must be operated on one RCCB of the corresponding type; otherwise, overcurrent trips will occur.

<sup>1)</sup> To use a type A RCCB, the regulations in this FAQ must be followed: Siemens Web site (http://support.automation.siemens.com/WW/view/en/49232264)

### Ordering data

Unless otherwise specified in the footnotes, the RCCBs given in the table below apply to both filtered and unfiltered V20 converters.

Frame size	Converter power rating	Recommended R	CCB article num	iber <sup>1)</sup>		
		RCCB Type A 30 mA	RCCB Type A 100 mA <sup>2)</sup>	RCCB Type A(k) 30 mA <sup>3)</sup>	RCCB Type B(k) 30 mA <sup>4)</sup>	RCCB Type B(k) 300 mA <sup>2)</sup>
Three phase	e AC 400 V conve	erters				
FSA	0.37 kW to 2.2 kW	-	-	-	5SV3342-4	5SV3642-4
FSB	3 kW to 4 kW					
FSC	5.5 kW					
FSD	7.5 kW	-	-	-	5SV3344-4	5SV3644-4
	11 kW	-	-	-	5SV3346-4	5SV3646-4
	15 kW					
FSE	18.5 kW	-	-	-	-	5SV3646-4
	22 kW	-	-	-	-	5SV3647-4
Single phas	e AC 230 V conve	erters				
FSAA/FSAB	0.12 kW to 0.75 kW	5SV3311-6	-	5SV3312-6KK01	5SV3321-4	5SV3621-4
FSAC	1.1 kW	5SV3312-6	5SV3412-6	1	5SV3322-4	5SV3622-4
	1.5 kW	5SV3314-6	5SV3414-6	5SV3314-6KK01	5SV3324-4	5SV3624-4
FSAD	2.2 kW	]				
	3 kW	5SV3316-6	5SV3416-6	5SV3316-6KK01	5SV3326-4	5SV3626-4


<sup>1)</sup> You can select commercially available 5SV3 series RCCBs (as given in the table) or equivalent.

<sup>2)</sup> SINAMICS V20 single phase AC 230 V filtered converters FSAC and FSAD can be operated only on a type A 100 mA or type B(k) 300 mA RCCB.

 $^{3)}$  Letter "k" in the RCCB type names indicates RCCB types with time delay.

<sup>4)</sup> SINAMICS V20 three phase AC 400 V filtered converters FSB to FSD cannot be operated on a type B(k) 30 mA RCCB.

### B.1.12 DIN rail mounting kits (only for FSAA, AB, AC, A, and B)



Article numbers:

- 6SL3261-1BA00-0AA0 (for frame size AA/AB/AC/A)
- 6SL3261-1BB00-0AA0 (for frame size B)

### B.1.13 Migration mounting kit for FSAA ... FSAD

Article numbers:

- 6SL3266-1ER00-0VA0 (for frame size AA/AB)
- 6SL3266-1EB00-0VA0 (for frame size AC)
- 6SL3266-1EV00-0VA0 (for frame size AD)


### Functionality

As frame size FSAA/FSAB has smaller outline dimensions, this migration mounting kit is supplied for easy installation of frame size AA/AB converters to the G110 control cabinet or DIN rail. If the holes on your control cabinet were drilled to match the frame size A, you can drill additional holes according to the outline dimensions of FSAA/FSAB, or use this option for installation.

Frame size FSAC can be directly installed to an FSA DIN rail mounting kit. You can also use the migration mounting kit for FSAC to install the FSAC to an FSB DIN rail mounting kit. If the holes on your control cabinet were drilled to match the frame size B, you can drill additional holes according to the outline dimensions of FSAC, or use this option for an FSAC converter.

If the holes on your control cabinet were drilled to match the frame size C, you can drill additional holes according to the outline dimensions of FSAD, or use this option for installation.

### Outline dimensions (mm)





### Fixing the migration mounting kit to the converter

• Converter mounted in a control cabinet:

FSAA/FSAB

FSAC/FSAD







• DIN rail mounting mode:

### B.1.14 SINAMICS V20 Smart Access

#### Article number: 6SL3255-0VA00-5AA0



#### **Outline dimensions (mm)**



#### Functionality

SINAMICS V20 Smart Access is a Web server module with integrated Wi-Fi connectivity. It allows Web-based access to the converter from a connected device (conventional PC with wireless network adapter installed, tablet or smart phone) to realize converter operations including quick commissioning, converter parameterization, JOG, monitoring, diagnostics, backup and restore, etc. This module is only for commissioning and thus cannot be used with the converter permanently. For more information, see Chapter "Commissioning via the SINAMICS V20 Smart Access (Page 147)".

#### **Button description**

The reset button on SINAMICS V20 Smart Access enables you to perform the following functions:

- Basic upgrading (Page 178)
- Wi-Fi configuration resetting

For more information, see the description later in this section.

#### **Technical specifications**


Firmware version	≥ V01.04.02
Rated voltage	24 V DC
Wireless technology and working frequency	Wi-Fi 2400 MHz to 2483.5 MHz
Maximum radio frequency power	17.5 dBm (EIRP*)
Wireless modulation type	802.11 b/g
Modulation technology	• 802.11b: CCK, DSSS
	• 802.11g: OFDM
Antenna gain	1.9 dBi
Extreme temperature range	-10 °C to 60 °C

\* EIRP means effective isotropic radiated power.

#### Note

Depending on environmental conditions, the maximum wireless communication distance (without barrier) can reach 140 m.

### Fitting SINAMICS V20 Smart Access to the converter



Recommended tightening torque: 0.8 Nm ± 10%

For more safety instructions during the fitting process, see Section "Fitting SINAMICS V20 Smart Access to the converter (Page 149)".

#### **Resetting Wi-Fi configuration**

When the converter is in power-on state, pressing the reset button on the module resets the Wi-Fi configuration to defaults:

- Wi-Fi SSID: V20 smart acess\_xxxxx ("xxxxxx" stands for the last six characters of the MAC address of SINAMICS V20 Smart Access)
- Wi-Fi password: 12345678
- Frequency channel: 1

#### Note

Check and make sure the status LED lights up solid green/solid yellow or flashes green before pressing the reset button to reset the Wi-Fi configuration. After you press the reset button, make sure you keep the button pressed until the status LED flashes yellow. Only then can the Wi-Fi configuration be reset successfully with the reset button.


#### **Status LED**

LED color		Meaning	
Solid red		One client is connected to the module and USS communication between the module and the converter fails.	
Solid green		The module is running and one client is connected to it.	
Solid yellow		The module is running and no client is connected to it.	
Flashing red	Flashing at 1 Hz	No client is connected to the module and USS communication between the module and the converter fails. *	
	Flashing at 0.5 Hz	The module is starting.	
Flashing greer	1	The module is running and one WebSocket channel is connected to it.	
Flashing yellow		Reminder of restarting the module.	
Flashing red and yellow alternatively		The Web application, firmware, or service package is upgrading.	

\* In case of USS communication failure between the module and the converter, you must power off the module by sliding its power switch to "OFF" first, keep the reset button pressed and power on the module by sliding its power switch to "ON", and then update the firmware version of the module. For more information about firmware update, see Section "Upgrading (Page 178)".

### B.1.15 I/O Extension Module

#### Article number: 6SL3256-0VE00-6AA0




#### Functionality

The SINAMICS V20 I/O Extension Module supports the SINAMICS V20 400 V variants with firmware version 3.94 and later versions. It expands the number of V20 I/O terminals, enabling more converter control functions. You can use the expansion port on the SINAMICS V20 converter to connect the module. This module provides an expansion port to connect the SINAMICS V20 Smart Access or the BOP Interface Module.

#### **Status LED**

LED color	Description
Solid yellow	The module is powered on and is initializing.
Solid green	The module works properly and the communication between the module and the converter is successfully established.
Flashing red at 2 Hz	The communication between the module and the converter fails.

#### Connecting the device



#### NOTICE

#### Equipment malfunctions due to improper installing or removing

Installing or removing the SINAMICS V20 I/O Extension Module when the V20 converter is in power-on state can cause malfunctions of the SINAMICS V20 I/O Extension Module.

• Make sure that the V20 converter is powered off before installing or removing the SINAMICS V20 I/O Extension Module.

#### Note

Remove the I/O Extension Module before fitting the Parameter Loader to upload and download V20 parameters.

#### Wiring diagram and terminal description

For more information about the wiring diagram and terminal description, see Sections "Typical system connections (Page 41)" and "Terminal description (Page 45)".

#### B.1.16 User documentation

#### **Operating Instructions (Chinese version)**

Article number: 6SL3298-0AV02-0FP0

### B.2 Spare parts - replacement fans


#### **Article numbers**


- 6SL3200-0UF06-0AA0 (for frame size AC)
- 6SL3200-0UF07-0AA0 (for frame size AD)
- 6SL3200-0UF01-0AA0 (for frame size A)
- 6SL3200-0UF02-0AA0 (for frame size B)
- 6SL3200-0UF03-0AA0 (for frame size C)
- 6SL3200-0UF04-0AA0 (for frame size D)
- 6SL3200-0UF05-0AA0 (for frame size E)

#### **Replacing fans**


Proceed through the steps as illustrated below to remove the fan from the converter. To reassemble the fan, proceed in reverse order. When re-assembling the fan, make sure that the arrow symbol ("A" in the illustration) on the fan points to the converter rather than the fan housing, the position for the fan cable exit point ("B") as well as the mounting orientation and position of the cable connector ("C") are sufficient for connecting the fan cable to the converter.


Replacing the fan from FSAC







### Replacing the fan from FSAD










Replacing the fans from FSE



# **General license conditions**

For Resellers: In order to avoid infringements of the license conditions by the reseller or the buyer these instructions and license conditions and accompanying CD – if applicable - have to be forwarded to the buyers.

#### 1) Siemens License Conditions

#### General License Conditions for Software Products for Automation and Drives

(2011-08-01)

#### 1 Supply of Software to Licensee and Granting of Rights to use the Software

1.1 These General License Conditions shall exclusively apply to the delivery of Software for Automation and Drives to the Licensee. General terms and conditions of the Licensee shall apply only where expressly accepted in writing by us. The scope of delivery of the Software shall be determined by the congruent mutual written declarations of both parties. We shall grant the Licensee rights to use the software specified in the Confirmation of Order or, if the Licensee does not receive a Confirmation of Order, the software specified in the Certificate of License or that specified in the Software Product Sheet, if the Licensee is instead submitted a Software Product Sheet (hereinafter referred to as "SW"). The Certificate of License and the Software Product Sheet shall be collectively referred to as "CoL" hereinafter. The Licensee shall be submitted the CoL when the SW is supplied or in conjunction with the delivery bill. The way in which the SW is supplied is also derived directly from the Confirmation of Order or from the SW purchase order number contained in the Confirmation of Order, in conjunction with the associated order data of our catalog valid at the time of the Confirmation of Order (hereinafter collectively referred to as "Order Data"), or from the CoL. If the Licensee does not receive a data medium, it shall be authorized to copy the SW already available to it to the extent necessary to exercise the rights to use the SW granted to it. The aforesaid shall apply, mutatis mutandis, to electronic supply of the software (downloading). Where reference is made to the Order Data or the CoL in these General License Conditions, the reference to the CoL is of significance if the Licensee has not received a Confirmation of Order. In any case, the data contained in the Order Data is also contained in the CoL.

1.2 The Documentation relating to the SW (hereinafter referred to as "Documentation") shall be purchased separately, unless either the Order Data or CoL contains a stipulation stating that it belongs to the scope of delivery. If the Licensee is authorized to copy the SW in accordance with Clause 1.1, this shall also apply to the Documentation provided that it is included in the scope of delivery.

1.3 In the event that we submit a License Key to the Licensee, which unlocks the SW (hereinafter referred to as "License Key"), this License Key must also be installed.

1.4 The rights granted to the Licensee with respect to the SW are based on the License Type (see Section 2) and the Software Type (see Section 3). The license and Software Types are detailed in the Order Data or CoL. If the SW is supplied electronically or if copying rights are granted for it, the rights and duties specified in these General License Conditions shall apply to the legitimately generated copies.

1.5 If the Licensee is legitimately in possession of a previous SW version/release (hereinafter referred to as "Previous Version"), the Licensee shall be authorized to exercise the rights to use the SW granted to it either with respect to the SW or - if this is intended from a technical point of view - to the Previous Version, at its own discretion (downgrading). If the SW is an Upgrade or PowerPack in accordance with Section 4, Section 4 shall apply additionally.

1.6 If Previous Versions are listed in the Readme file of the SW under the category "parallel use", the Licensee has the right to exercise, alternatively to the user rights granted to him for the SW, the user rights for the listed Previous Versions in one (1) Instance. If the "Type of use" named in the Order Data or the CoL is: "Installation" or "User", the Licensee is entitled to the previously described right additionally to and at the same time as the Previous Versions listed in one Instance. An "Instance" in the context of these General License Conditions is either an instance in a physical operating system environment or an instance in a virtual operating system environment. The transferability of the user rights onto Previous Versions is only permissible in conjunction with the user rights for the SW in accordance with Clause 5.3.

1.7 In case the Licensee obtains only the data media but no license as per the Order Data or the CoL, any use of the SW by the Licensee is subject to the acquisition of a license according to Section 2. Up to the acquisition of the license, the Licensee is not entitled to supply the SW to third parties.

1.8 In case the SW contains Open Source Software or any similar software of a third party (hereinafter referred to as "OSS") the OSS is listed in the Readme\_OSS-file of the SW. The Licensee is entitled to use the OSS in accordance with the respective license conditions of the OSS. The license conditions are provided on the same data carrier as the SW. The license conditions of the respective OSS shall prevail over these General License Conditions with respect to the OSS. If the license conditions of the OSS require the distribution of the source code of such OSS we shall provide such source code on request against payment of the shipping and handling charges.

1.9 The SW may be or contain licensed software other than OSS, i.e. software which has not been developed by us itself but which has been licensed to us by a third party (hereinafter referred to as the "Licensor"), e.g. Microsoft Licensing Inc. If the Licensee receives the terms and conditions stipulated by the relevant Licensor together with the SW in the Readme\_OSS file in this case, such terms and conditions shall apply with respect to the Licensor's liability vis-à-vis the Licensee. Our own liability vis-à-vis the Licensee shall be governed in any case by these General License Conditions.

#### 2 License Type

Depending on the License Type, the Licensee shall be granted the following rights to the SW:

2.1 Single License (One Off License, Copy License) The term "One Off License" or "Copy License" which may be used in the Software Product Sheet corresponds to the term "Single License". The following regulation shall apply to the full scope of the One Off License / Copy License. The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and valid for an unlimited period of time, to install the SW in one (1) Instance and to utilize the SW thus installed in the manner specified in the Order Data or CoL (see "Type of Use").

2.2 Floating License The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and valid for an unlimited period of time, to install the SW on any desired number of the Licensee's hardware devices. The number of objects (for example, users or devices) permitted to utilize the SW at the same time can be derived from the Order Data or CoL (see "Type of Use).

2.3 Rental License The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and limited in time as stipulated in the Order Data or CoL (see "Type of Use"), to install and use the SW in one (1) Instance. If the period of use is specified in hours, the usage decisive for the calculation of the time limit commences with the software start-up and finishes with its shut-down. If the period of usage is specified in days, weeks or months, the specified period, which commences in conjunction with the first SW start-up, shall apply independently of the actual time of usage. If the period of use is specified with a date, the right of use ends on this date – regardless of the actual period of use.

2.4 Rental Floating License The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and limited in time as stipulated in the Order Data or the CoL (s. "Type of use"), to install the SW on any desired number of the Licensee's hardware devices. The number of objects (for example, users or devices) permitted to utilize the SW at the same time can be derived from the Order Data or CoL (see "Type of Use) as well. If the period of use is specified in hours, the usage decisive for the calculation of the time limit commences with the software start-up and finishes with its shut-down. If the period of usage is specified in days, weeks or months, the specified period, which commences in conjunction with the first SW start-up, shall apply independently of the actual time of usage. If the period of use is specified with a date, the right of use ends on this date – regardless of the actual period of use.

2.5 Demo License The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and limited in time as stipulated in the Order Data or the CoL (s. "Type of use"), to install the SW in one (1) Instance and to use it for validation purposes. If the period of usage is specified in days, weeks or months, the specified period, which commences in conjunction with the first SW start-up, shall apply independently of the actual time of usage. If the period of use is specified with a date, the right of use ends on this date – regardless of the actual period of use.

2.6 Demo Floating License The Licensee shall be granted the non-exclusive right, transferable in accordance with Clause 5.3 and limited in time as stipulated in the Order Data or the CoL (s. "Type of use"), to install the SW on any desired number of the Licensee's hardware devices. The number of objects (for example, users or devices) permitted to utilize the SW at the same time can be derived from the Order Data or CoL (see "Type of Use) as well. If the period of usage is specified in days, weeks or months, the specified period, which commences in conjunction with the first SW start-up, shall apply independently of the actual time of usage. If the period of use is specified with a date, the right of use ends on this date – regardless of the actual period of use.

2.7 Trial License The Licensee shall be granted the non-exclusive and non-transferable right to install the SW in one (1) Instance and to use it for validation purposes in the manner specified in the Order Data or CoL (see "Type of Use"). The period of usage is limited to 14 days and commences with the SW start-up, unless a different period of usage is specified in the Order Data or CoL.

#### 3 Software Type

If the Software Type is not specified in the Order Data or CoL, the rights specified in Clause 3.2 (Runtime Software) shall apply to the SW.

3.1 Engineering Software (hereinafter referred to as "E-SW") In the event that the Licensee uses E-SW to generate its own programs or data containing parts of the E-SW, the Licensee shall have the right, without having to pay any license fee, to copy and to use these parts of the E-SW as a part of its own programs or data, or to supply them to third parties for use. In the event that such parts are supplied to third parties for use, these parties shall be bound in

writing to comply with stipulations corresponding to those in Clauses 5.1 and 5.2 with respect to the above parts of the E-SW.

3.2 Runtime Software (hereinafter referred to as "R-SW") If the Licensee incorporates R-SW or any parts thereof into its own programs or data, it shall purchase a license with respect to the R-SW each time it installs or copies - depending on what is done first - its own programs or data containing RSW or parts thereof, in accordance with the relevant intended Type of Use and on the basis of the Siemens catalog valid at that time. In the event that the Licensee supplies the specified programs or data to third parties for their use, these parties shall be bound in writing to adhere to stipulations corresponding to those in Section 5, with respect to the R-SW parts contained therein. The aforesaid shall not affect the Licensee's obligation to purchase a license for the R-SW if the RSW original is copied. If the R-SW contains tools for parameterization/configuration and extended rights have been granted in this regard, this will be detailed in the readme file of the R-SW.

#### 4 Upgrade and PowerPack

If it is apparent from the Order Data or CoL, e.g. by the addition "Upgrade" or "PowerPack" after the SW product name, that the SW is an upgrade for another software item (hereinafter referred to as "Source License"), the rights originally granted to the Licensee to use the Source License end in conjunction with the upgrade measure. The rights of use in accordance with Clause 1.6 remain unaffected by this. However, the Licensee is entitled to undo the upgrading (downgrading) - if this is intended from a technical point of view - and to exercise the rights to use the SW granted to it with respect to the Source Version in accordance with Clause 1.5.

#### 5 Further Rights and Duties of the Licensee

5.1 Unless a stipulation to the contrary relating to a specific number of copies is contained on the data medium or in the readme file of the SW, the Licensee may generate an appropriate number of copies of every item of SW which it is authorized to use in accordance with these General License Conditions, where such copies shall be used exclusively for data backup purposes. Furthermore the Licensee may only copy the SW if and insofar as it has been granted copying rights by us in writing.

5.2 The Licensee shall not be entitled to modify, decompile or reverse engineer the SW. Nor may it extract any individual parts unless this is permitted by mandatory copyright law. Furthermore, the Licensee shall not be entitled to remove any alphanumeric identifiers, trademarks or copyright notices from the SW or the data medium and, insofar as it is entitled to make copies of the SW, shall copy them without alteration. The aforementioned regulation shall apply accordingly to the Documentation supplied in accordance with Section 1.

5.3 The Licensee shall be entitled to completely transfer the right to use the SW granted to it to a third party, provided that it concludes a written agreement with the third party in conformance with all of the conditions contained in this Section 5 and on the proviso that it does not retain any copies of the SW. If the Licensee has received a License Key for the SW, this key shall be supplied to the third party together with the SW. Furthermore, the third party shall be submitted the CoL together with these General License Conditions. The Licensee shall submit the CoL received for the SW to us at any time, if requested.

5.4 If the SW is a PowerPack or an Upgrade, the Licensee shall keep the CoL of the Source License and submit it to us at any time, if requested, together with the CoL for the SW. In the event that the Licensee transfers its right to use the PowerPack SW or Upgrade SW in accordance with Clause 5.3, it shall also submit the CoL of the Source License to the third party.

5.5 If the Licensee receives a data medium which, in addition to the SW, contains further software products which are released for use, then it shall have the right to use these released software products exclusively for validation purposes, for a limited period of time and free of charge. The period of use shall be limited to 14 days, commencing with the first start-up of the relevant software program unless a different period is specified e.g. in the readme file of the relevant software product. These software products supplied exclusively for validation purposes shall be governed, mutatis mutandis, by the stipulations contained in these General License Conditions. The Licensee shall not be authorized to pass on these software products separately, i.e. without the SW, to a third party.

The conditions of the purchase contract apply if not otherwise stipulated hereafter for the Open Source Software.

#### 2) License Conditions and Disclaimers for Open Source Software and other Licensed Software

In the product "SINAMICS V20", Copyright Siemens AG, 2015 (hereinafter "Product"), the following Open Source Software is used either unchanged or in a form that we have modified, and additionally the other License Software noted below:

#### Liability for Open Source Software

Open Source Software is provided free of charge. We are liable for the Product including Open Source Software contained in accordance with the license conditions applicable to the Product. Any liability for use of Open Source Software beyond the program flow intended for the Product is explicitly excluded. Furthermore, any liability for defects resulting from modifications to the Open Source Software by you or third parties is excluded.

We do not provide any technical support for the Product if it has been modified.

#### Availability of Source Code

Certain license conditions of third-party software components used in this product may require Siemens to provide you with the source code and additional information for such components. In most cases, Siemens provides this information on or with the device. In case Siemens is technically unable to do so, you may request a copy of this information against payment of shipping and handling charges. Please send your request to the address provided at the end of this section.

Siemens AG Digital Industries Customer Services DI DI CS SD CSS TS Gleiwitzer Str. 555 90475 Nuernberg, Deutschland Internet: http://www.siemens.com/automation/support-request Tel.: +49 911 958 1231

# Please note the following license conditions and copyright notices applicable to Open Source Software and other License Software:

Component	Open Source Software ("OSS") [Yes/No]	Copyright Information / File
FatFS R0.08a	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT FATFS R0.08A
FatFS R0.10c <sup>1)</sup>	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT FATFS R0.10c
Jquery.touchSwipe.js 1.6.15 <sup>2)</sup>	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT jquery.touchSwipe.js 1.6.15
TI CC3200 HTTPServer 1.2.0 <sup>3)</sup>	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT TI CC3200 HTTPServer 1.2.0
GNU GCC libgcc 4.8.3	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT GNU GCC LIBGCC 4.8.3
Lua 5.2.1	YES	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT LUA 5.2.1
STM32F4xx Standard Peripherals Library V1.3.0	NO	LICENSE AND COPYRIGHT INFORMATION FOR COMPONENT STM32F4XX STANDARD PERIPHERALS LIBRARY V1.3.0

1), 2), 3) Apply to SINAMICS V20 Smart Access only

#### LICENSE CONDITIONS AND COPYRIGHT NOTICES

For detailed information about license conditions and copyright notices of the individual software mentioned in the above table, visit Siemens Service and Support Web site at https://support.industry.siemens.com/cs/ww/en/ps/13208.

# Index

#### 8

87 Hz, 48

### Α

Advanced functions Automatic restart, 128 Blockage clearing, 120 Cavitation protection, 138 Condensation protection, 130 Dual ramp function, 140 Economy mode, 122 Flying start, 127 Free functions blocks (FFBs), 126 Frost protection, 129 Hammer start, 118 Hibernation, 131 High/low overload (HO/LO) mode, 144 Motor protection with PTC sensor, 124 Motor staging, 135 Super torque, 116 UL61800-5-1-compliant motor overheat protection, 123 User default parameter set, 139 Wobble function, 134 Alarm code list, 351 Article numbers of converters, 22

### В

Basic functions Boost functions, 96 Braking functions, 100 Imax controller, 111 JOG function, 95 Load torque monitoring, 114 OFF functions, 92 PID controller, 98 Ramp time, 109 Vdc controller, 113 BI P0731[0...2], 237 P0732[0...2], 237

P0734[0...2], 237

P0806, 243 P0810, 244 P0811, 244 P0820, 244 P0821, 244 P0840[0...2], 244 P0842[0...2], 245 P0843[0...2], 245 P0844[0...2], 245 P0845[0...2], 245 P0848[0...2], 245 P0849[0...2], 245 P0852[0...2], 246 P0881[0...2], 246 P0882[0...2], 246 P0883[0...2], 246 P1020[0...2], 256 P1021[0...2], 256 P1022[0...2], 256 P1023[0...2], 256 P1035[0...2], 257 P1036[0...2], 257 P1041[0...2], 258 P1043[0...2], 258 P1055[0...2], 259 P1056[0...2], 259 P1074[0...2], 260 P1110[0...2], 263 P1113[0...2], 263 P1124[0...2], 264 P1140[0...2], 265 P1141[0...2], 265 P1142[0...2], 265 P1175[0...2], 266 P1218[0...2], 270 P1230[0...2], 271 P2103[0...2], 297 P2104[0...2], 297 P2106[0...2], 297 P2200[0...2], 303 P2220[0...2], 304 P2221[0...2], 304 P2222[0...2], 305 P2223[0...2], 305 P2235[0...2], 305 P2236[0...2], 305

P2241[0...2], 306 P2243[0...2], 306 P2810[0...1], 319 P2812[0...1], 320 P2814[0...1], 320 P2816[0...1], 320 P2818[0...1], 320 P2820[0...1], 321 P2822[0...1], 321 P2824[0...1], 321 P2826[0...1], 321 P2828, 322 P2830, 322 P2832, 322 P2834[0...3], 323 P2837[0...3], 323 P2840[0...1], 324 P2843[0...1], 324 P2846[0...1], 324 P2849, 325 P2854, 326 P2859, 327 P2864, 327 P2940, 330 P3351[0...2], 334 P3852[0...2], 337 BO r0807.0, 243 r1025.0, 257 r2036.0...15, 295 r2037.0...15, 295 r2225.0, 305 r2811.0, 320 r2813.0, 320 r2815.0, 320 r2817.0, 320 r2819.0, 320 r2821.0, 321 r2823.0, 321 r2825.0, 321 r2827.0, 322 r2829.0, 322 r2831.0, 322 r2833.0, 322 r2835.0, 323 r2836.0, 323 r2838.0, 323 r2839.0, 324 r2841.0, 324 r2842.0, 324 r2844.0, 324 r2845.0, 324

r2847.0, 324 r2848.0, 325 r2852.0, 326 r2853.0, 326 r2857.0, 326 r2858.0, 326 r2862.0, 327 r2863.0, 327 r2867.0, 327 r2868.0, 327 r2886.0, 330 r2888.0, 330 **Built-in BOP** button functions, 58 operating modes Hand/Jog/Auto, 58 screen displays, 64 status icons, 59 status LEDs, 66

### С

CDS	
P0700[02],	231
P0701[02],	
P0702[02],	232
P0703[02],	232
P0704[02],	
P0705[02],	233
P0706[02],	
P0712[02],	233
P0713[02],	233
P0719[02],	
P0727[02],	
P0731[02],	
P0732[02],	
P0733[02],	
P0734[02],	
P0840[02],	
P0842[02],	
P0843[02],	
P0844[02],	
P0845[02],	
P0848[02],	
P0849[02],	
P0852[02],	
P0881[02],	
P0882[02],	
P0883[02],	
P0886[02],	246
P1000[02],	
P1020[02],	
P1021[02],	256

P1022[02]	
P1022[02]	
	. 256
P1023[02]	, 256
P1035[02]	, 257
P1036[02]	, 257
P1041[02]	, 258
P1042[02]	, 258
P1043[02]	, 258
P1044[02]	, 258
P1055[02]	, 259
P1056[02]	, 259
P1070[02]	, 260
P1071[02]	,200
P1074[02]	, 260
P1075[02]	260
P1076[02]	260
P1110[02]	. 263
P1113[02]	, 263
P1124[02]	, 264
P1140[02]	, 265
D11/1[0 2]	, 265
P1141[02]	
P1142[02]	, 265
P1175[02]	, 266
P1218[02]	, 270
	, _, .
P1230[02]	, 271
P1330[02]	, 279
P2103[02]	
P2104[02]	, 297
	207
	<i>J</i> <b>4</b> <i>7</i>
P2106[02]	
P2200[02]	, 303
P2200[02]	, 303
P2200[02] P2220[02]	, 303 , 304
P2200[02] P2220[02]	, 303 , 304
P2200[02] P2220[02] P2221[02]	, 303 , 304 , 304
P2200[02] P2220[02]	, 303 , 304 , 304
P2200[02] P2220[02] P2221[02] P2222[02]	, 303 , 304 , 304 , 305
P2200[02] P2220[02] P2221[02]	, 303 , 304 , 304 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02]	, 303 , 304 , 304 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02]	, 303 , 304 , 304 , 305 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02]	, 303 , 304 , 304 , 305 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 305 , 306
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 305 , 306
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02] P2253[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02] P2253[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02]	, 303 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02]	, 303 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307
P2200[02] P2220[02] P2221[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02] P2264[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 308
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 308
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2253[02] P2254[02] P2264[02] P2803[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 308 , 319
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2253[02] P2254[02] P2264[02] P2803[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 308 , 319
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02] P2254[02] P2264[02] P3351[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 307 , 308 , 319 , 334
P2200[02] P2220[02] P2222[02] P2222[02] P2235[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2253[02] P2254[02] P2264[02] P2803[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 307 , 308 , 319 , 334
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2243[02] P2244[02] P2254[02] P2264[02] P3351[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 307 , 308 , 319 , 334
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2264[02] P2803[02] P3351[02] P3852[02]	, 303 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 308 , 319 , 334 , 337
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2264[02] P2803[02] P3351[02] P3852[02]	, 303 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 308 , 319 , 334 , 337
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2264[02] P2264[02] P3351[02] P3852[02] P0095[09]	, 303 , 304 , 305 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 308 , 319 , 334 , 337 , 216
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2264[02] P2264[02] P3351[02] P3852[02] P0095[09]	, 303 , 304 , 305 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 308 , 319 , 334 , 337 , 216
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02] P2264[02] P3351[02] P3852[02] P0095[09] P0771[0], 24	, 303 , 304 , 305 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 307 , 308 , 319 , 334 , 337 , 216
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2264[02] P2264[02] P3351[02] P3852[02] P0095[09]	, 303 , 304 , 305 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 307 , 307 , 307 , 308 , 319 , 334 , 337 , 216
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2243[02] P2253[02] P2254[02] P2264[02] P3351[02] P3852[02] P0095[09] P0771[0], 24 P1042[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 308 , 307 , 308 , 319 , 334 , 337 , 216 H1 , 258
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2244[02] P2253[02] P2254[02] P2264[02] P3351[02] P3852[02] P0095[09] P0771[0], 24	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 307 , 308 , 307 , 308 , 319 , 334 , 337 , 216 H1 , 258
P2200[02] P2220[02] P2222[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2243[02] P2254[02] P2254[02] P2264[02] P2264[02] P3351[02] P3852[02] P3852[02] P0095[09] P0771[0], 24 P1042[02] P1044[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 306 , 307 , 305 , 305
P2200[02] P2220[02] P2221[02] P2222[02] P2223[02] P2235[02] P2236[02] P2241[02] P2242[02] P2242[02] P2243[02] P2253[02] P2254[02] P2264[02] P3351[02] P3852[02] P0095[09] P0771[0], 24 P1042[02]	, 303 , 304 , 304 , 305 , 305 , 305 , 305 , 306 , 306 , 306 , 306 , 306 , 307 , 305 , 305

CI

P1075[0...2], 260 P1076[0...2], 260 P1330[0...2], 279 P2019[0...7], 292 P2151[0...2], 299 P2242[0...2], 306 P2244[0...2], 306 P2253[0...2], 307 P2254[0...2], 307 P2264[0...2], 308 P2869[0...1], 328 P2871[0...1], 328 P2873[0...1], 328 P2875[0...1], 328 P2877[0...1], 329 P2879[0...1], 329 P2881[0...1], 329 P2883[0...1], 329 P2885[0...1], 330 P2887[0...1], 330 Clone saved parameter settings, 368 CO P2378, 315 P2889, 330 P2890, 330 r0020, 209 r0021, 209 r0024, 210 r0025, 210 r0026[0], 210 r0027, 210 r0028, 210 r0031, 210 r0032, 210 r0035[0...2], 210 r0036, 210 r0037[0...1], 211 r0038, 211 r0039, 211 r0051[0...1], 211 r0066, 214 r0067, 214 r0068, 214 r0069[0...5], 215 r0070, 215 r0071, 215 r0072, 215 r0074, 215 r0078, 215 r0080, 215

r0084, 215

r0085, 215

P1071[0...2], 260

r0086, 215 r0087, 215 r0395, 228 r0512, 229 r0623[0...2], 230 r0630[0...2], 231 r0631[0...2], 231 r0632[0...2], 231 r0633[0...2], 231 r0755[0...1], 239 r0947[0...63], 247 r0949[0...63], 248 r0954[0...2], 248 r0956[0...2], 249 r0957[0...2], 249 r0958[0...2], 249 r1024, 257 r1045, 259 r1050, 259 r1078, 260 r1079, 261 r1114, 263 r1119, 263 r1170, 265 r1242, 273 r1246[0...2], 274 r1315, 278 r1337, 280 r1343, 281 r1344, 281 r1801[0...1], 282 r2018[0...7], 290 r2110[0...3], 297 r2224, 305 r2245, 306 r2250, 307 r2260, 307 r2262, 308 r2266, 308 r2272, 309 r2273, 309 r2294, 310 r2870, 328 r2872, 328 r2874, 328 r2876, 329 r2878, 329 r2880, 329 r2882, 329 r2884, 329 r2955, 331 r3237.0...1, 332

CO/BO, 209 r0019.0...14, 209 r0050, 211 r0052.0...15, 212 r0053.0...15, 212 r0054.0...15, 213 r0055.0...15, 213 r0056.0...15, 214 r0722.0...12, 234 r0747.0...1, 237 r0751.0...9, 238 r0785.0, 242 r0955[0...2], 249 r1199.7...12, 266 r2067.0...12, 296 r2197.0...12, 302 r2198.0...12, 302 r2349, 310 r2379.0...2, 316 r2399, 317 r3113.0...15, 331 r3365, 336 Communication MODBUS communication, 188 USS communication, 183 Connecting EMC-compliant cabinet design, 55 EMC-compliant installation, 52 terminal layout, 45 typical system connections, 41 wiring diagram, 43 Converter functions, 90 Converter menu structure 50/60 Hz selection menu, 67 Display menu, 61 Main menu, 59 Parameter menu, 59, 87 Setup menu, 69 Setup menu: application macros sub-menu, 82 Setup menu: common parameters sub-menu, 84 Setup menu: connection macros sub-menu, 71 Setup menu: motor data sub-menu, 69 Converter status at fault, 342

#### D

DDS P0291[0...2], 221 P0301[0...2], 221 P0304[0...2], 222 P0305[0...2], 223 P0307[0...2], 223

0000010	~ 1	222
P0308[0	.2]	, 223
P0309[0		
P0310[0	.2]	, 223
P0311[0		
P0314[0	.21	, 224
P0320[0		
P0335[0	.21	. 224
P0340[0		
P0341[0	.21	. 226
P0342[0	.2]	, 226
P0344[0	21	226
P0346[0	.2]	, 226
P0347[0	21	226
P0350[0	.2]	, 227
P0352[0	21	227
P0354[0	.2]	, 227
P0356[0	21	227
P0358[0	.2]	, 227
P0360[0		
P0604[0	.2]	, 229
P0610[0		
P0622[0	.2]	, 230
P0625[0		
P0626[0	.2]	, 231
P0627[0		
P0628[0	.2]	, 231
P0640[0		
P1001[0	.2]	, 254
P1002[0	21	254
P1003[0	.2]	, 254
P1004[0	21	254
P1005[0	.2]	, 255
P1006[0	21	255
P1007[0	.2]	, 255
P1008[0	21	255
P1009[0	.2]	, 255
P1010[0	.21	. 256
-	-	
P1011[0	.2]	, 250
P1012[0	.21	. 256
P1013[0		
P1014[0	.21	. 256
P1015[0		
P1016[0	.21	, 256
P1031[0		
P1040[0	.21	, 258
		,
P1046, 25	99	
P1047[0	.21	, 259
P1048[0		
P1058[0	.21	, 259
P1060[0		
P1061[0	.21	, 260
P1080[0	.2]	, 201

P1082[02], 261	
P1001[0 2] 201	
P1091[02], 262	
P1092[02], 262	
P1093[02], 262	
P1094[02], 263	
F1094[02], 203	
P1101[02], 263	
P1120[02], 263	
P1121[02], 264	
D1120[0 2], 201	
P1130[02], 264	
P1131[02], 264	
P1132[02], 264	
P1133[02], 264	
P1134[02], 265	
P1135[02], 265	
P1138[02], 265	
P1139[02], 265	
P1222[02], 203	
P1202[02], 267	
P1219[02], 270	
P1227[02], 270	
P1232[02], 271	
P1233[02], 271	
P1234[02], 271	
P1236[02], 272	
P1240[02], 273	
P1243[02], 273	
P1245[02], 274	
P1247[02], 274	
P1250[02], 274	
P1251[02], 274	
P1252[02], 274	
P1253[02], 274	
N255[02], 274	
P1256[02], 275	
P1257[02], 275	
P1300[02], 275	
P1310[02], 277	
P1311[02], 277	
P1312[02], 278	
P1316[02], 278	
P1320[02], 278	
P1321[02], 278	
P1322[02], 278	
P1323[02], 278	
P1324[02], 278	
P1325[02], 279	
P1333[02], 279	
P1334[02], 279	
P1335[02], 279	
P1336[02], 279	
P1338[02], 280	
P1340[02], 280	
P1341[02], 280	
P1345[02], 281	

P1346[02], 281 P1350[02], 281 P1780[02], 282 P1800[02], 282 P1803[02], 282 P1803[02], 282	
P1820[02, 283	
P1909[02], 283	
P2000[02], 285	
P2001[02], 286	
P2002[02], 286	
P2003[02], 286 P2004[02], 287	
P2150[02], 287	
P2151[02], 298	
P2155[02], 299	
P2156[02], 299	
P2157[02], 299	
P2158[02], 299	
P2159[02], 299	
P2160[02], 299	
P2162[02], 299	
P2164[02], 299	
P2166[02], 299	
P2167[02], 299	
P2168[02], 300 P2170[02], 300	
P2170[02], 300 P2171[02], 300	
P2172[02], 300	
P2173[02], 300	
P2177[02], 300	
P2181[02], 300	
P2182[02], 301	
P2183[02], 301	
P2184[02], 301	
P2185[02], 301	
P2186[02], 301	
P2187[02], 301	
P2188[02], 301	
P2189[02], 301	
P2190[02], 302 P2192[02], 302	
P2192[02], 302 P2201[02], 303	
P2202[02], 303	
P2203[02], 303	
P2204[02], 303	
P2205[02], 303	
P2206[02], 303	
P2207[02], 304	
P2208[02], 304	
P2209[02], 304	
P2210[02], 304	

P2211[02], 304
P2212[02], 304
P2213[02], 304
P2214[02], 304
P2215[02], 304
P2216[02], 304
P2231[02], 305
P2240[02], 306
P2247[02], 306
P2248[02], 307
P2360[02], 312
P2361[02], 312
P2362[02], 312
P2365[02], 312
P2366[02], 313
P2367[02], 313
P2370[02], 313
P2371[02], 313
P2372[02], 314
P2373[02], 314
P2374[02], 314
P2375[02], 314
P2376[02], 315
P2377[02], 315
P2378[02], 315
P3853[02], 337
P3854[02], 337
r0035[02], 210
r0313[02], 224
r0330[02], 224
r0331[02], 224
r0332[02], 224
r0333[02], 224
r0345[02], 226
r0370[02], 227
r0372[02], 227
r0373[02], 227
r0374[02], 227
r0376[02], 228
r0377[02], 228
r0382[02], 228
r0384[02], 228
r0386[02], 228
r0623[02], 230
r0630[02], 230
r0631[02], 231
r0632[02], 231
r0633[02], 231
r1246[02], 274
Directives and standards, 363

### F

Fault code list, 342

### G

General license conditions, 423

### L

List of modified parameters, 91

### Μ

Macros application macros, 82 connection macros, 71 Mounting Mounting in a control cabinet, 28 push-through mounting, 34 Mounting orientation and clearance, 27

### 0

Options BOP Interface Module, 374 braking resistor, 380 DIN rail mounting kit, 409 dynamic braking module, 377 external BOP, 372 external line filter, 395 I/O Extension Module, 415 line reactor, 385 memory card, 406 migration mounting kit, 409 output choke, 391 Parameter Loader, 368 residual current circuit breaker (RCCB), 408 RS485 termination resistor, 407 shield connection kit, 402 SINAMICS V20 Smart Access, 412 user documentation, 416

### Ρ

Parameter resets, 145 Parameters access levels, 204 BICO parameters, 202 C, C(1), C(30),U, T, 205 data set, 201 Digit-by-digit editing, 63 Normal editing of parameters, 62 Parameter types, 62 scaling, 205 Permissible line systems, 355 Product maintenance, 4

### Q

Quick commissioning through the parameter menu, 86 through the setup menu, 68

### R

Replacement fans, 416

### Т

Technical support, 4 Text menu for common parameters, 85 for motor parameters, 70

### U

Use of third-party products, 4 User documentation components, 3

# **Further information**

SINAMICS converters: www.siemens.com/sinamics

Siemens AG Digital Industries Motion Control Postfach 31 80 91050 ERLANGEN Germany

Scan the QR code for additional information about SINAMICS V20.

